



This is a digital copy of a book that was preserved for generations on library shelves before it was carefully scanned by Google as part of a project to make the world's books discoverable online.

It has survived long enough for the copyright to expire and the book to enter the public domain. A public domain book is one that was never subject to copyright or whose legal copyright term has expired. Whether a book is in the public domain may vary country to country. Public domain books are our gateways to the past, representing a wealth of history, culture and knowledge that's often difficult to discover.

Marks, notations and other marginalia present in the original volume will appear in this file - a reminder of this book's long journey from the publisher to a library and finally to you.

Usage guidelines

Google is proud to partner with libraries to digitize public domain materials and make them widely accessible. Public domain books belong to the public and we are merely their custodians. Nevertheless, this work is expensive, so in order to keep providing this resource, we have taken steps to prevent abuse by commercial parties, including placing technical restrictions on automated querying.

We also ask that you:


- + *Make non-commercial use of the files* We designed Google Book Search for use by individuals, and we request that you use these files for personal, non-commercial purposes.
- + *Refrain from automated querying* Do not send automated queries of any sort to Google's system: If you are conducting research on machine translation, optical character recognition or other areas where access to a large amount of text is helpful, please contact us. We encourage the use of public domain materials for these purposes and may be able to help.
- + *Maintain attribution* The Google "watermark" you see on each file is essential for informing people about this project and helping them find additional materials through Google Book Search. Please do not remove it.
- + *Keep it legal* Whatever your use, remember that you are responsible for ensuring that what you are doing is legal. Do not assume that just because we believe a book is in the public domain for users in the United States, that the work is also in the public domain for users in other countries. Whether a book is still in copyright varies from country to country, and we can't offer guidance on whether any specific use of any specific book is allowed. Please do not assume that a book's appearance in Google Book Search means it can be used in any manner anywhere in the world. Copyright infringement liability can be quite severe.

About Google Book Search

Google's mission is to organize the world's information and to make it universally accessible and useful. Google Book Search helps readers discover the world's books while helping authors and publishers reach new audiences. You can search through the full text of this book on the web at <http://books.google.com/>

Library
of the
University of Wisconsin





A HANDBOOK
ON THE
GAS ENGINE

COMPRISING A PRACTICAL TREATISE ON
INTERNAL COMBUSTION ENGINES

FOR THE USE OF ENGINE BUILDERS, ENGINEERS, MECHANICAL DRAUGHTSMEN
ENGINEERING STUDENTS, USERS OF INTERNAL COMBUSTION
ENGINES, AND OTHERS

BY
HERMAN HAEDER
CIVIL ENGINEER, WIESBADEN

TRANSLATED FROM THE GERMAN AND EDITED BY

W. M. HUSKISSON, A.M.I.E.E.
(9½ YEARS WITH MESSRS. CROSSLEY BROTHERS, OPENSHAW)

*WITH THE ADDITION OF NUMEROUS USEFUL TABLES
AND OTHER MATTER*



NEW YORK
McGRAW-HILL BOOK COMPANY
239 WEST 39TH STREET
LONDON
CROSBY LOCKWOOD AND SON
1911

161560
JAN 22 1912

TK
HII
EH9

6966568

AUTHOR'S PREFACE TO THE FIRST EDITION.

THE question whether, for industrial purposes, steam or power gas* (internal combustion) engines are the most economical, has been much discussed of late years in technical periodicals, but unfortunately mostly from a partisan point of view. Those interested in the construction both of gas and of steam engines commit themselves to exaggerated statements, which darken rather than throw light upon the real subject.

In estimating the size of a gas engine plant, the following points must be kept in view:—

THE OUTPUT.

GAS ENGINES.

It is not possible to increase the output, because the effect of the explosion stroke cannot be enhanced. With the output corresponding to the most favourable, that is the most economical, fuel consumption, the power developed by every explosion engine is therefore exhausted, and if a greater output be demanded, the engine simply comes to a stand. If, for instance, a so-called 10 HP gas or other internal combustion engine is run on the brake and develops 12 HP, erroneous conclusions may be drawn from the trial. Since at 10 HP no explosion strokes are supposed to be missed,† it naturally follows that the engine has intentionally been made larger than is needed to develop that power. It would be as reasonable to rate it at 8 HP and to specify among its advantages that it would give a maximum of 12 HP, that is a "reserve of power" of 50 per cent.

As a rule, the normal output has hitherto been taken as corresponding to 85 to 90 per cent. of the maximum, thus giving from 10 to 15 per cent. "reserve of power."

It will be seen from the above that it is necessary to take the so-called normal output of a gas engine relatively higher than that of a steam engine doing the same work. In other words, the

Maximum output of a gas engine should be $= 1.4 \times$ normal output of a steam engine.

The gas engine will then be of the same value in regard to the output or work done, as the steam engine.

If, for instance, a 30 HP engine is sufficient to supply the power required to drive a work-

* Suction and pressure gas plants are generally classed as power gas producers.

† In quality and quantity governing, less work is done during the explosion strokes, with a smaller load, and results in a larger consumption of fuel.

STEAM ENGINES.

In steam engines a larger output can be obtained by a later cut-off. This is effected automatically by the governor. If, for instance, a 10 HP engine is required to run under a load of 14 HP, the governor adjusts the valve gear to give a later cut-off, and the engine will then develop virtually 14 HP, the maximum output being 40 per cent. more than the so-called normal output. For this increased output the consumption of steam is about 10 per cent. more than at normal load.

shop or mill, and a gas engine has been selected for the purpose, it will be necessary to have an engine developing $1.25 \times 30 = 37$ HP and giving a maximum of $1.4 \times 30 = 42$ HP.

To denote the size and power of a gas engine, therefore, and to make a correct comparison with a steam engine, the maximum HP on the brake should also always be stated. For gas engines it is best to rate the power developed at

Normal output = $0.7 \times$ maximum output,

because this method of computation has become the rule for steam engine work, and 40 per cent. reserve of power is desirable in nearly all power plants. The consumption of coal should at the same time be calculated for this normal output. At the present time it is the almost invariable rule to state the power in gas engines at

Normal output = $0.85 \times$ maximum output.

AUTHOR'S PREFACE TO THE SECOND EDITION.

THE matter in this book, and especially the Tables, have been thoroughly revised and checked, in accordance with the latest information obtainable.

The endeavour to build much lighter gas engines for export, and thus effect a saving in weight and freight charges, is laudable, but should not be carried too far, because the dimensions exercise considerable influence on the smooth running, freedom from accidents, and life of an engine. The cast-iron parts (the frame, cylinder, and piston) can be kept relatively light, if they are very carefully constructed, and of the best material, judiciously distributed. On the other hand, if the flywheel is too light, it has always a disadvantageous effect on the steadiness of the engine. This is especially noticeable in engines supplying electric light, and in installations where the power required varies considerably, as fully explained at p. 176.

My book on "Die Kranke Gasmotor" (Defects in Gas Engines) was collated with this book during its revision, and data taken from it were used in the parts relating to gas engine construction. Thus previous omissions were as far as possible made good.

I shall be glad to have my attention drawn to any errors, or suggestions for fuller details in later editions.

TRANSLATOR'S PREFACE.

THE English Edition of this work has been prepared with a view to assist those engaged in the application of scientific principles to internal combustion engine design, and especially for those who cannot read the German text with ease, and have neither the time nor the desire to convert the German units into English. If the English edition proves as useful to the reader as "Die Gasmotoren" has been to me, the book will have fulfilled its object.

The tabulated dimensions of the various engines are expressed in millimetres as they relate to continental engines, but tables of the nearest equivalent in inches are also given, to save time and labour to those who are not accustomed to work in millimetres.

In order to render the book as complete as possible, and to save the reader the time and trouble of referring to other works, a full set of tables has been added; for granting me permission to use these tables, etc., I take the opportunity of thanking the publishers, and the authors of the works from which these tables, etc., have been taken, viz. Mackrow's "Naval Architect's Pocket-book," Kempe's "Engineer's Year Book," Hutton's "Practical Engineer's Handbook," Clark's "Mechanical Engineer's Pocket-book," and "The Mechanical World Pocket Diary"; my thanks are also due to Mr. H. A. Humphrey, and Mr. Edwin Kenyon, for their papers.

In conclusion, I have to acknowledge my indebtedness to Mrs. E. M. Donkin in helping me with the translation, and to Mr. Guy E. Lloyd, Assoc.M.I.C.E., in checking all the formulas and calculations throughout the book.

WILLIAM M. HUSKISSON.

45, CAMBRIDGE GARDENS,
NORTH KENSINGTON,
LONDON,
July, 1911.

TABLE OF CONTENTS.

CHAPTER I.

Methods of Working, Type, Description, and Diagrams.

	PAGE		PAGE
Method of Working	1	Working Method of Four-cycle Engines	7
Single- and Double-acting Engines	1	Single-cylinder Four-cycle Engine	8
Short Description of Various Types of Engines	2	Double-acting " "	9
Table I. Type and Description of the Thirteen best-known Engines	3	Vis-à-Vis " "	10
Combustion Chamber	4	Twin " "	11
Rise of the Explosion Line in the Diagram	4	Tandem " "	12
Gas Engine Indicator Diagram	5	Twin Double-acting " "	14
Indicator Diagram of a Four-cycle Gas Engine	7	Tandem " "	15
		Remarks on the Developed Diagrams	16
		Classification of Types yielding the same Developed Diagrams	16

CHAPTER II.

Output of the Engine.

Indicated and Effective (Brake) Horse-power	18	Approximate Determination of the Mean Pressure on Piston, p_m	19
The Mechanical Efficiency η	18	Table II. Approximate Values for Calculating the Output	20
Table I. Approximate Values of η	18	Calculation of IHP and BHP	21
The Effective Piston Area, A	18	Table III. Values of Constant C	22
Mean Pressure on the Piston, p_m	18		
The Ratio ϵ	19		

CHAPTER III.

Main Dimensions of the Engine.

Table I. Types of Engines. Four-cycle up to 28-inch Stroke and 115 BHP per Cylinder	24
---	----

CHAPTER IV.

Effect of the Inertia of the Reciprocating Parts.

Inertia of the Reciprocating Parts	25	Table IV. Approximate Values for Motor-car Engines	28
Table I. Value of a_0 , x_1 , and x_2	27	Table V. Acceleration for Engines of Different Powers	29
Table II. Weights of Reciprocating Parts	28	A Combination of the Inertia and Indicator Diagrams	30
Table III. Approximate Values for large Gas Engines	28		

CHAPTER V.

Tangential Pressure or Turning Movement Diagram for Calculating the Flywheel.

	PAGE		PAGE
Tangential Pressure or Turning Moment Diagram	34	VII. Twin Double-acting Four-cycle Engine, Z D 4	48
Determination of the Tangential Pressure and of the Radial Component	34	VIII. Tandem Double-acting Four-cycle Engine, R D 4	49
I. Single-acting Four-cycle Engine, E 4	35	Appendix to Chapter. Turning Moment Diagrams, etc., etc.	51
II. Double-acting " " D 4	40	Table A. Weight of Reciprocating Parts of Large Gas Engines and Acceleration Pressures	52
III. Vis-à-vis " " G Z 4	42		
IV. Twin Four-cycle Engine, Z 4	42		
V. Tandem " " R 4	44		
VI. Double Vis-à-vis " " Z G Z 4	45		

CHAPTER VI.

Forces acting on the Cross Head, Piston, Connecting Rod, and Main Bearings.

(a) Forces acting on the Cross Head	53	Variation and Magnitude of Forces acting on the Crank Pin	60
1. Forces acting on the Piston Rod, Connecting Rod, Crank Pin, and Crank Journals	53	Table II. Single-cylinder Four-cycle Engine, E 4	60
2. Pressure on the Crank-shaft Bearings	54	Table III. Double-acting Four-cycle Engine, D 4	61
Effect of Flywheel on the Pressure on the Bearings	55	Table IV. Double-acting Two-cycle Engine, D 2	62
I. Bearing on Outer Side (Side-shaft Side), A ₁	55	Table V. Single-cylinder Condensing Steam Engine	62
II. Main Bearing (Flywheel Side), A ₂	56	Table VI. Comparison of the Load on the Piston of a Gas Engine and of a Steam Engine	63
Table I. Pressure on the Bearings	57	Table VII. Comparison of the Load on the Piston (less Inertia) of a Four-cycle Gas Engine and a Steam Engine	64
I. Outer Bearing (Side-shaft Side), A ₁	57	Table VIII. Maximum Horse-Power at Normal Load	65
Determination of the Resultant Thrust, R ₁	57		
II. Main Bearing (Flywheel Side), A ₂	58		
(b) Forces acting on the Cross Head, Crank Pin, etc.	59		

CHAPTER VII.

The Parts of the Engine and Working Costs.

Names of the Various Parts of an Engine	66
Calculation and Construction of the Parts of an Engine	68
Table I. Pressures and Temperatures	68

Section I. The Crank Shaft.

1. Numbers of Bearings and Flywheels	70	Standard Dimensions of the Centrifugal Oiling Ring	77
2. Dimensions of the Crank Shaft	70	Tables IV. and IVa. Centrifugal Lubricator for Crank Pin	78, 79
Tables II. and IIa. Crank Shaft	73, 74	6. Working of Valve Gear	79
3. Dimensions of Shoulder between Crank Web and Main Bearings	75	7. Balancing the Reciprocating and Rotating Parts	79
4. Oil Fender Ring	75	Rules for Constructing the Balance Weights	80
Table III. Dimensions of Oil Fender Ring	75	Parts of the Balance Weights	81
5. Crank Pin Lubrication	75	Table V. Balance Weights	81
Construction of the Centrifugal Ring Lubricator	76	8. Material of the Crank Shaft	82
Parts of a Centrifugal Oiling for the Crank Pin	77	9. Calculating the Strength of the Crank Shaft	82

TABLE OF CONTENTS.

ix

	PAGE		PAGE
(a) Crank on Dead Point at Explosion	88	Table VII. Summary of Stresses on the Crank Shaft	94
(b) Crank in Position where Greatest Turning Moment is Developed	84	Overheating the Bearings	95
Bending and Twisting Moments and Stresses	86	Strength and Overheating of the Bearings	97
(a) Ignition with Crank on Dead Centre	86	Table VIII. Values of p_r , calculated for a Single Crank-pin Bearing	97
(b) Crank in Position where Greatest Turning Moment occurs	87	Table IX. Values of q and $q \times v$	98
Table VI. Data for Calculating the Crank Shaft	90	Table X. Values of q and $F^{\frac{1}{2}}$	99

Section II. The Main Bearings of a Gas Engine.

The Main Bearings	100	Tables XIII. and XIIIa. Oil-box Lids	104
Rules for constructing Crank-shaft Bearings	101	Tables XIV. and XIVa. Dimensions of Main Bearing with Oiling Ring	105, 106
Tables XI. and XIa. Oil Grooves and Check Screws	102	Parts of Crank-shaft Bearing with Two Oiling Rings	108
Table XII. Oil Guard for Crank-shaft Bearing	108		

Section III. Frame and Cylinder.

Frame	109	Tables XIX. and XIXa. Frame and Cylinder for Engines E 4 up to 27½" Stroke	119, 120
Rules for Constructing the Frame	110	Calculation of the Strength of a Frame	121
Tables XV. and XVa. Holding down Bolts	110	1. Simplest Type of Frame	121
Table XVI. Crank Splasher Guard	112	2. Where the Neutral Axis lies below the Crank Shaft	121
The Cylinder	112	3. Where the Side Frames are connected by a Bottom Plate	121
Table XVII. Liner Joint Ring, and Stuffing Box, for packing Joint between Liner and Jacket	114	4. Hollow Cast-iron Box Frame	122
Joint between Breech End and Liner	114	Calculation of the Thickness of the Cylinder Wall	123
Tables XVIII. and XVIIIa. Frame and Cylinder for Engines E 4 up to 16" Stroke	117, 118	Tables XX. and XXa. Values of x and δ in Centimetres and Inches	123

Section IV. The Pistons of the Engine.

1. Open-ended or Trunk Pistons	124	Standard Types of Piston and Piston Pin for E 4 Engines	139
2. Box Pistons	125	Tables I. and Ia. Dimensions of Pistons and Piston Pins	140
Open-ended or Trunk Piston for Single-acting Four-cycle Engines	125	Tables II. and IIa. Lubrication of the Piston Pin	141
Pressure on the Guide	126	Cooling the Cylinder	142
Position of the Piston Pin in the Piston	127	(a) Heat developed in the Cylinder	142
Rules for Constructing the Piston	128	Table I. Temperatures in the Working Cylinder	142
Lubricating the Cylinder	129	Table II. Determination of the Mean Temperature T_m	144
Piston and Piston Pins should be separately lubricated	129	(b) Cooling the Cylinder with Water	145
Lubricating the Piston and Piston Pin from an Oil Pump	129	(c) The Actual Temperatures	146
Calculation of the Piston End	131	(d) Calculation of Quantity of Cooling Water required	147
Body or Trunk of Piston	131	Table III. B.T.U. transmitted per HP hour	147
Bore of the Cylinder	131	(e) Consumption of Cooling Water	148
Piston Rings	132	Table IV. Consumption of Water per HP hour	148
Table I. Piston Rings—Values of q	132	Cooling the Piston	148
Thickness of Self-adjusting Piston Rings	132	(f) Dimensions of Inlet and Outlet Water Pipes	149
Calculation of the Piston Rings	133	Table V. Diameter of Cooling Water Pipes	149
Table II. Ramsbottom or Self-adjusting Piston Rings	133		
Number of Rings	135		
Drawing the Rings over the Piston Body	135		
The Piston Pin	137		
(a) Fitting the Piston Pin in the Boss	137		
(b) Calculation of the Piston Pin or Cross Head	138		

Section V. The Connecting Rod.

	PAGE		PAGE
Rules for Constructing the Connecting Rod	150	(1) Marine Type Big End, with Cap . . .	159
Table I. Dimensions of Recessed Nuts and Check Screws for Cap Bolts . . .	153	(c) Small End, or Piston Pin End . . .	160
Tables II. and IIa. Dimensions of Connecting Rod . . .	154, 155	(1) Small End of Connecting Rod (solid forged-eye) . . .	160
Table III. Maximum Stresses on the Connecting Rod . . .	157	(2) Connecting Rod Small End, with Adjustable Cap . . .	161
(a) Shaft or Body of the Connecting Rod . . .	157	(a) Marine Type End . . .	161
Conversion of Round into Rectangular Cross Section . . .	157	(b) Small End (Piston End) with Cap . . .	162
Table IV. Constant m . . .	158	Explanation of Table IV. . .	162
(b) Big End (or Crank-pin End) of the Connecting Rod . . .	159	Table IV. Connecting Rod, Crank-shaft Bearings, Crank Pin, Piston Pin (Cross Head) and Piston . . .	163

Section VI. The Flywheel.

1. Degree of Irregularity in running at Full Load, the Load remaining Constant . . .	164	Width of the Flywheel . . .	184
Table I. Diagram showing Fluctuations in the Power developed . . .	164	Calculation of the Tensile Strength of the Flywheel . . .	185
Table Ia. Degree of Irregularity, δ_0 . . .	165	(a) Shape and Dimensions of Rim Cross Section . . .	185
Table II. Values of i for calculating the Flywheel . . .	166	(b) Centrifugal Force and Tensile Stress in the Flywheel Rim . . .	186
Table III. Comparative Weights of the Flywheel in Gas and Steam Engines . . .	167	Table I. Approximate Values for Factor x . . .	187
2. Degree of Irregularity at Light Loads, the Load remaining Constant . . .	167	Table II. Combined Stress . . .	187
(a) Hit-and-Miss Governing . . .	167	(c) Rim Joints . . .	188
Table IV. Values of δ_0 at less than Full Load . . .	169	1. Joints and Bolts . . .	188
(b) Quantity or Quality Governing . . .	170	2. Fastening with Cotters . . .	189
3. Fluctuations in the Speed with Variations of Load . . .	170	3. Calculation of the Shrunk Rings . . .	192
Table V. Work done by the Flywheel . . .	171	Dimensions of the Shoulder . . .	192
Degree of Uniformity $\frac{1}{\delta_0}$, and Energy of the Flywheel . . .	172	(a) Round Shrunk Rings . . .	192
Moment of Rotation of the Flywheel . . .	173	Table III. Examples worked out from Equations 36 and 41 . . .	193
Table VI. Energy of the Flywheel, and Degree of Irregularity in Rolling Mills . . .	173	(b) Elliptical Shrunk Rings (Shrunk Hoops) . . .	193
Determination of the Weight of the Flywheel . . .	174	Table IV. Examples worked out from Equations 36 and 45 . . .	193
(a) Engines for driving Dynamos . . .	174	(c) Usual Forms of Rim Fastenings . . .	194
Engines run in Parallel . . .	174	Calculation of Rim Fastenings with Screwed Bolts and Dowels . . .	194
Table VII. Lowest allowable Values of δ_0 . . .	175	(d) Flywheel Arms . . .	195
(b) Engines for Various Purposes . . .	176	1. Tensile Stress on the Arms, due to Centrifugal Force of the Rim . . .	196
Table VIII. Variations in the Load occurring in Various Industrial Purposes . . .	176	2. Stress due to Tension and Bending at the Nave . . .	196
Table IX. Approximate Values for determining the Weight of the Flywheel . . .	177	(e) Nave Fastenings . . .	197
Rules for constructing the Flywheel . . .	178	Bursting of Flywheels . . .	197
Method of transmitting the Power . . .	178	(f) Defects in the Lugs cast on the Rim for coupling the Wheel together . . .	197
Diameter of the Flywheel and of the Driving Pulley respectively . . .	179	1. Determination of the Output . . .	198
Width of Flywheels and Pulleys . . .	180	2. Determination of the Weight of the Rim . . .	198
Table X. Approximate Thickness of Belts . . .	180	3. Width of Flywheel Rim . . .	198
Tables XI. and XIa. Dimensions of Flywheel . . .	182	4. Calculation of the Flywheel . . .	199
	183	5. Flywheel Arms . . .	199
		(a) Tensile Stress on the Rim . . .	199
		(b) Stresses on the Nave, due to Tension and Bending . . .	199
		6. Width of the Belt . . .	200

TABLE OF CONTENTS.

xī

	PAGE		PAGE
Rules for fitting together the Parts of the Flywheel	200	Table IV. R D 4, Z D 4 Two-cylinder Engine	204
1. Boring out the Nave	200	Table V. R Z D 4 Four-cylinder Engine	204
2. Securing the Flywheel to the Shaft	200	Table VI. Double-acting, Two-cycle, Single-cylinder Engine (D 2, 1 Cyl.)	205
3. Nave secured by Shrunk Rings	200	Table VII. Single-cylinder Condensing Steam Engine	206
4. Keys for securing the Flywheel	201	Table VIII. Tandem Condensing Steam Engine	206
Tables IV. and IVa. Keys	201, 202	Table IX. Compound Condensing Steam Engine	207
Main Dimensions of a Gas Engine	203	Speed in Gas and Steam Engines	208
Table I. E 4 Single-cylinder Engine	203		
Table II. R 4, Z 4 Two-cylinder Engines	203		
Table III. D 4 Single-cylinder Engine	204		

Section VII. Costs of Working Gas and Steam Engines.

Working Costs	209	Table V. Comparative Values of the Cost of Fuel	212
(a) Cost of the Plant	209	(e) Consumption of Fuel	213
Table I. Cost of Installation, including Buildings, etc., per HP at Normal Load	209	Table VII. Comparative Values of the Cost of Fuel in proportion to Maximum Power developed	214
(b) Depreciation	209	Table VIII. Consumption of Anthracite in a Gas Engine Plant	214
Table II. Stresses on Crank Shafts	210	Table IX. Consumption of Steam in a Modern Steam Engine Plant	214
(c) Subsidiary Costs	210	Table X. Working Costs and Costs of Fuel in Pence per BHP hour	215
Table III. Subsidiary Costs per HP hour, for Gas and Steam Engines, exclusive of Fuel	211	Heating Value of Exhaust Steam in Steam Engines	216
(d) Prices of Coal and Steam	211	Degree of Irregularity in Running, etc.	216
Table IV. Residual Products, Heating Value, Evaporative Power, etc., in Various Colliery Districts	212	EXERCISES	217-222

APPENDIX I.

Description of the Humphrey Pump.

APPENDIX II.

Useful Tables.

TABLE	PAGE
I. Strength and Weight of Metals	244
II. Bolts and Nuts	245
III. Bolts and Nuts, Whitworth	246
IIIa. Bolts and Nuts, Whitworth	247
IV. Safe Loads on Studs and Bolts	248
V. Pipe Threads (Gas Threads)	248
VI. Fuels: Chemical Composition of Combustibles	249
VII. Quantity of Gas in Cubic Feet obtained from Coal	249
VIII. Composition and Calorific Power of Dowson Water-Gas, and of ordinary 16 Candle-power Coal-Gas	250
IX. Conversion of Degrees on the Centigrade Thermometer into those on the Fahrenheit Scale	251
X. Conversion of Degrees on the Fahrenheit Thermometer to those on the Centigrade Scale	252
XI. Conversion of Kilogrammes per Square Centimetre to Pounds per Square Inch	253

TABLE	PAGE
XII. Moments of Inertia, Moduli of Sections, Beams, and Bending Moments . . .	254-256
XIII. Moments of Inertia and Moduli Z, for Circular Sections . . .	256
XIV. Moments of Inertia and Constants for Moments of Resistance for Hollow Tubular Sections . . .	257
XV. Graphical Bending Moments and Shearing Forces of Beams . . .	258-260
XVI. Beams of Equal Strength throughout their Length . . .	261
XVII. French Liquid Measure . . .	262
XVIII. French Measures of Length . . .	262
XIX. French Measures of Surface . . .	262
XX. French Measures of Weight . . .	262
XXI. Millimetres to Inches . . .	263-266
XXII. Equivalents of Metres in Inches . . .	266
XXIII. Fractions of an Inch to Millimetres . . .	267
XXIV. Equivalents in Millimetres of the Divisions of a Foot . . .	267
XXV. Lineal Feet in Metres . . .	268
XXVI.-VII. Metres in Lineal Feet . . .	268
XXVIII. Avoirdupois Ounces in French Kilograms . . .	269
XXIX. Avoirdupois Pounds in French Kilograms . . .	269
XXX. Quarters in French Kilograms . . .	269
XXXI. Cwts. in French Kilograms . . .	269
XXXII. Tons in French Kilograms . . .	269
XXXIII. Kilograms in Avoirdupois Pounds and Tons . . .	270
XXXIV. Belt Velocity or Circumferential Speed of Pulleys . . .	271
XXXV. Horse-power of Leather Belts . . .	272
Rope Driving . . .	273
XXXVI. Horse-power of Ropes (Four Cylinder Double-acting Engines) . . .	274
XXXVII. Horse-power of Ropes (Two Cylinder Double-acting Engines, etc.) . . .	275
XXXVIII. Horse-power of Ropes (Single Cylinder Single-acting Engines, etc.) . . .	276
XXXIX. Circumferences and Areas of Circles, advancing by 8ths . . .	277-279
XL. Circumferences of Circles, advancing by 10ths . . .	279-281
XLI. Areas of Circles, advancing by 10ths . . .	282-284
XLII. Circumferences of Circles, advancing by 12ths . . .	284-285
XLIII. Areas of Circles, advancing by 12ths . . .	285-286
XLIV. Areas of Segments of a Circle . . .	286-287
XLV. Squares, Cubes, Square Roots, Cube Roots, and Reciprocals of all Integer Numbers from 1 to 2200 . . .	288-310
XLVI. Squares, Cubes, and Fourth Powers of Fractions . . .	311
INDEX . . .	312

GAS ENGINES

CHAPTER I.

Method of Working, Type, Description, and Diagrams.

ENGINES driven with gas, petroleum, alcohol, benzine, etc., are usually termed "*Internal Combustion Engines*," because the power generated in them is produced by the combustion of a mixture of gas, oil, etc., and air in the cylinder. The customary term, "*Explosion or Ignition Engines*," is derived from the sudden, almost instantaneous, combustion of the gases.

Method of Working.

If a mixture of gas and air is enclosed in a chamber and ignited, it explodes with violence; this explosion is a result of the rapid combustion of the gas. The speed and violence of the explosion depend upon the proportions in which the gas and air are combined, and upon the pressure of the mixture. When ignition takes place, there is a rise of both temperature and pressure in the combustion chamber, and this pressure and the subsequent expansion of the products of combustion drive the piston of the cylinder forward, and useful work is done.

There are two main working systems or cycles, *i.e.*—

1. The *Four-cycle* (Otto).
2. The *Two-cycle*.


The word *cycle* here means a single stroke to and fro of the piston, and the expressions *four-cycle* and *two-cycle* denote respectively the number of single strokes required to complete one cycle of operations.

(Steam engines work on the *two-cycle* principle, that is to say, two strokes are required on one face of the piston to complete one working cycle, as shown in the accompanying diagram. The beginner is usually inclined to consider the steam engine as a *one-cycle* engine.)


Single- and Double-acting Engines.

The term *single-acting* denotes an engine in which work is done at one end of the cylinder only, whereas in a "*double-acting*" engine work is done at both ends.

In a single-acting engine the piston usually serves as the cross-head; in double-acting engines a separate crosshead and stuffing box for the piston rod



Steam Engine.



Single acting.



Double acting.

Gas Engine.

are necessary. The difference will be readily understood from the outline drawings. Care must be taken not to confuse the expressions "two-cycle" and "four-cycle," and "single-acting" and "double-acting," with each other.

Thus we have—

Single-acting and double-acting *Four-cycle* engines, and
 " " " " " *Two-cycle* engines.

A careful study of Table I., p. 3, will make this clear.

Short Description of Various Types of Engines.

From the classification on p. 3 it will be seen that a lengthy description is required to explain the distinctive features of each type. The construction and method of working



FIG. 1.—Single-acting Four-cycle.



FIG. 2.—Double-acting Four-cycle.

differ so much in the various engines that shortened forms and lettering have been adopted




FIG. 3.—Double-acting Two-cycle (Koerting).




FIG. 4.—Oechelhäuser Engine (Two-cycle).

to describe them, as shown in the first column of Table I. In the outline drawings of four-cycle engines, Fig. 1 will be used to denote single-acting, and Fig. 2 double-acting engines.

Two-cycle double-acting engines (Fig. 3), Koerting type, require special charging pumps.*

The Oechelhäuser engine (Fig. 4), has two pistons in one cylinder working in opposite directions; its distinguishing features are the triple crank, and charging pumps.

Two-cycle engines will be fully described in the chapter on "Large Gas Engines."

The usual types of gas engines are tabulated in Table I., and should be carefully studied by beginners, as we shall often have occasion to refer to them.

* Single-acting two-cycle engines are seldom used, and will not be considered in this book.

Table I.—Type and Description of the Thirteen best-known Engines.

The thick capital letters of the right-hand column correspond to the first letters of the (German) descriptions in the left-hand column (to avoid confusion the German lettering has been retained, but it does not correspond to the first letters of the English terms).

	Symbol.	Type.	Description.
Single-acting four-cycle.	E 4, 1 Z		Single-acting Four-cycle engine (One Cylinder).
	G Z 4, 2 Z		Vis-à-vis Four-cycle engine (Two Cylinders).
	Z 4, 2 Z		Twin Four-cycle engine (Two Cylinders).
	R 4, 2 Z		Tandem Four-cycle engine (Two Cylinders).
	Z G Z 4, 4 Z		Double Vis-à-vis Four-cycle engine (Four Cylinders).
Double-acting four-cycle.	D 4, 1 Z		Double-acting Four-cycle engine (One Cylinder).
	Z D 4, 2 Z		Twin Double-acting Four-cycle engine (Two Cylinders).
	R D 4, 2 Z		Tandem Double-acting Four-cycle engine (Two Cylinders).
	R Z D 4, 4 Z		Twin Tandem Double-acting Four-cycle engine (Four Cylinders).
Double-acting two-cycle.	Kör. D 2, 1 Z		Koerting Double-acting Two-cycle engine (One Cylinder). (Necessitating separate charging pumps for gas and air.)
	Oech. D 2, 1 Z		Oechelhäuser Double-acting Two-cycle engine (One Cylinder). (Charging pump for gas and air is shown to the left of the drawing.)
	Kör. Z D 2, 2 Z		Koerting Twin Double-acting Two-cycle engine (Two Cylinders). (Each motor cylinder requires separate gas and air pumps as shown.)
	Oech. ZD 2, 2 Z		(Oechelhäuser Twin Double-acting Two-cycle engine (Two Cylinders). (Each motor cylinder requires a separate charging pump as shown to the left.)

Thus the symbol **D4** always denotes double-acting four-cycle engines.

Engines without the symbol **D** (the first group in Table I.) are all single-acting.

Four-cycle engines are by far the most extensively used. By combining several single-cylinder four-cycle engines, a number of other types have been evolved (compare Table I.), and it seems desirable first to examine and describe the working method of these various systems. This plan will also enable us to understand the action of the combustible mixture in every position of the crank, and thus to obtain a clear idea of the processes taking place inside the engine.

Combustion Chamber.

This part of a gas engine is best compared with the clearance of a steam engine. In the latter (Figs. 6, 6A) the clearance space, the effect of which is wholly injurious, is kept




FIG. 5.

Gas Engine. Combustion Chamber indicated by Dots.




FIG. 6.

Steam Engine. Clearance indicated by Dots.




FIG. 6A.

as small as possible, while in a gas engine (Fig. 5) this space must be of a certain size, since to work without it is impossible.

The size of the combustion chamber depends on the degree of compression (*i.e.* on the compression pressure, C , Fig. 7).

We shall in a subsequent chapter return to the determination of the cubic capacity required in this chamber.

Rise of the Explosion Line in the Diagram (Fig. 7).

Shortly before explosion the gaseous mixture is at the final compression pressure, C (Fig. 7). Ignition raises the pressure to p atmospheres.

The question of the speed of explosion of a gas in a closed chamber, in other words, the length of time which elapses between ignition and complete combustion, cannot be mathematically determined without further study.

In Fig. 7 the travel of the piston corresponding to the time of combustion is denoted by k , and varies from 0.02 to 0.05 of the stroke.* For present purposes we will take $k = 0.03$ in the diagram.




FIG. 7.—Diagram.

The degree of *final compression* giving the best results, from which, as already mentioned, the size of the combustion chamber is determined,

* The effects of pre-ignition and after-combustion are here neglected.

depends on the composition of the gas, and of the explosive gaseous charge. Too high a compression gives rise to pre-ignition, whilst too low a compression is uneconomical. We may take—

With lighting gas $C = 6$ atm. (= 85 lbs. per sq. in.). Suction gas $C = 9$ atm. (= 130 lbs. per sq. in.). Blast furnace gas $C = 13$ atm. (= 185 lbs. per sq. in.) above atmospheric pressure. These compressions correspond to an ignition pressure for lighting gas $p = 20$ atm. (= 285 lbs. per sq. in.). Suction gas $p = 23$ atm. (= 328 lbs. per sq. in.). Blast furnace gas $p = 20$ atm. (= 285 lbs. per sq. in.) above atmosphere.*

Gas Engine Indicator Diagram.

A thorough knowledge of the theory of the steam engine, and especially of indicator diagrams, is taken for granted, and is essential to any useful study of our subject. Before, however, proceeding to a closer examination of the working method, we must obtain some idea of the behaviour of the mixture of gas and air in the engine cylinder, and it will be advisable to make a comparison between steam and gas. For this purpose we will take a steam engine with an initial pressure of 6 atmospheres (absolute) (= 88 lbs. per sq. in.) and a gas engine with an initial pressure of 27 atmospheres (absolute) (= 397 lbs. per sq. in.), and we get the following diagrams:—




FIG. 10.—Steam Engine. At *a* is shown the cut-off, including the clearance.






FIG. 13.—Gas Engine. At *a* is shown the combustion and compression chamber.

Assume that, behind the piston as shown, at the distance *a* from the cylinder cover there is—

In Fig. 9, Steam at 6 atmospheres (abs.) pressure,

In Fig. 12, Gas at 27 atmospheres (abs.) pressure,

both cylinders being steam- and air-tight. Assume further that the piston moves out

* [TRANSLATOR'S NOTE.—Gas-engine makers have recently increased the compression pressures; and now make $C = 120$ lbs. per sq. inch for lighting gas, and $C = 150$ lbs. per sq. inch for producer or suction gas.]

the distance a ; then, as indicated in Figs. 8 and 11, the pressure in the steam cylinder will fall to 3 atmospheres, and in the gas cylinder to 10.6 atmospheres. The further the pistons move out, the lower will the pressures fall, as shown in Figs. 10 and 13.

The curve in Figs. 10 and 13 is called the *expansion curve*. This is obtained by plotting the pressures corresponding to given positions of the piston vertically on a horizontal line (the so-called atmospheric line). Any given scale is chosen for this purpose, and any given height to represent one atmosphere; in Fig. 10, for instance, 5 mm. ($\frac{3}{16}$ inch) = 1 atmosphere for steam; and in Fig. 13, 1.1 mm. ($\frac{1}{20}$ inch) = 1 atmosphere for gas.

As shown in these figures, the pressure falls more rapidly during expansion in gas than in steam engines; in Fig. 14 the two diagrams are super-imposed.



FIG. 14.

— Gas Engine Indicator Diagram.
 ...Steam Engine Indicator Diagram.

The same thing is expressed in equations 1 to 3.

Let p be initial pressure in atmospheres (absolute),

„ v be volume of steam at pressure p ,

„ p_1 be pressure at any given point of the stroke (or position of piston),

„ v_1 be volume of steam at pressure p_1 .

The fall in pressure will therefore follow the law—

$$p \cdot v = p_1 \cdot v_1 = \text{constant (for steam)} \quad (1)$$

$$p \cdot v^\chi = p_1 \cdot v_1^\chi = \text{constant (for gas)} \quad (2)$$

χ varies from 1.2 to 1.5, and may

$$\text{be taken at a mean of } = 1.35 \quad (3)$$

Although a knowledge of the meaning of the different curves in the steam engine diagram, Fig. 15, is taken for granted, it is necessary clearly to understand the curves of the gas-engine diagram, Fig. 16. That part of the travel of the piston marked “cut-off”




FIG. 15.—Steam Engine Diagram.




FIG. 16.—Gas Engine Diagram.

in the steam diagram is in a gas engine = zero, and the part marked “compression” is in the latter = one whole stroke.

This point will be considered more in detail in a subsequent chapter.

Indicator Diagram of a Four-cycle Gas Engine.

This diagram forms a closed figure, in which the various phases of work in the cylinder are shown. The numbers I. to IV. in Fig. 17 mark the different strokes, each corresponding to half a revolution of the crank shaft.




FIG. 17.

(The admission and exhaust lines in the diagram (Fig. 16) lie closely one over the other. This is explained in the purposely distorted diagram at the side.) The sequence of working strokes, represented by the different lines of the indicator diagram, is as follows:—

1st Stroke.—Drawing in the mixture of gas and air, combined in definite proportions. In the diagram this line lies rather below the atmospheric line, as a fall in pressure is produced by the frictional resistance of the mixture in the passages and valves.*



2nd Stroke.—Compression of the mixture drawn in, therefore increase of pressure due to reduction of the cylinder volume as the piston moves in.



3rd Stroke.—Increase of pressure through ignition of the compressed mixture. Expansion follows, with fall in pressure of the burnt charge, since the piston moves out, and the volume of the cylinder is enlarged. As a result of the opening in advance of the exhaust, the expanded gases are discharged, till the piston reaches the dead point.



4th Stroke.—Discharge of remaining gases, as a result of the reduction of the cylinder volume by the piston moving in. As there is a rise in pressure, due to frictional resistance of the gases in the exhaust valve, this line in the diagram lies somewhat higher than the atmospheric.*



The above explanation will suffice for a cursory study of the indicator diagram. In a later chapter the actual plotting of the diagram will be considered; meanwhile the standard diagram (p. 23) should be consulted.

Working Method of Four-cycle Engines.



In studying these, the lines of the indicator diagram plotted between the drawings of cylinders must not be overlooked. The line to which a given stroke of the piston marked above it corresponds, is drawn full, the lines corresponding to the rest of the cycle are dotted. Thus the evolution of the diagram can be followed.

* See the developed diagrams (pp. 8-17). This line, for the sake of simplicity, is shown as = the atmospheric.

Single-cylinder Four-cycle E 4, One Cylinder (Usual Type).

The term "four-cycle" denotes, as already explained on p. 1, the number of single strokes of the piston required to complete one cycle of operations. The four positions of the piston in the illustrations below show this graphically and clearly.

The Roman numerals I. to IV. give the different piston strokes for one cycle.



STROKE I.

Outstroke of piston towards bearings. Drawing in a charge of combustible mixture during the whole stroke.

STROKE II.

Instroke.—Compression of the mixture, ignition taking place at end of stroke (left-hand position of piston).

STROKE III.

Outstroke.—Explosion and expansion of the burning gases. Shortly before piston reaches end of cylinder (right-hand) discharge of exhaust begins.

STROKE IV.

Instroke.—Exhausting the products of combustion. At the end of this stroke (left-hand position of piston) all gases are exhausted, and the cycle of operations is completed.

Fresh charge drawn in, as in Stroke I.

The term "outstroke" signifies the moving of the piston towards the crank bearings. At full load, work is done by the piston once in every two revolutions of the crank




FIG. 24.—Developed Diagram, E 4, One Cylinder.

shaft, as against four working strokes per two revolutions in a steam engine. At half load, or when there is a miss-fire, ignition only takes place once in


every four revolutions, and the piston and connecting rod must be carried along during seven piston strokes by the energy stored up in the flywheel.

The developed diagram (Fig. 24) is a so-called "continuous" diagram of the cycle of operations, the numbers give in degrees the path described by the crank pin.

180° is equivalent to one piston stroke.

Double-acting Four-cycle Engine, D 4, One Cylinder.

The working method of this engine is the same as that of two single-cylinder four-cycle engines, the ignitions in which take place first at 180° then at 540° apart, in the circle described by the crank.



The output of such an engine is thus double that of a single-acting four-cycle engine of the same cylinder dimensions.

Here again the Roman numerals show the sequence of piston strokes for one cycle, v denoting the front, and h the back end of the piston.





FIG. 30.—Developed Diagram for D 4, One-cylinder Engine.

The developed diagram for a double-acting four-cycle engine is shown at Fig. 30. The work done at the back end of the cylinder is marked —, that at the front Each developed diagram represents the work done during four strokes, or two revolutions of the crank shaft.

Vis-à-Vis Four-cycle Engine, G Z 4, Two Cylinders (Deutz).




FIGS. 81-89.

The working method is the same, as regards the sequence of operations, as that of the double-acting four-cycle engine (p. 9). Both pistons act upon the *same* crank. The pistons pass successively over the dead points, front and back. The sequence of the working strokes is as follows:—

	Left-hand Cylinder.	Right-hand Cylinder.
One revolution {	1st stroke Admission.	2nd stroke Compression.
	2nd " Compression.	3rd " Explosion and expansion.
One revolution {	3rd " Explosion and expansion.	4th " Exhaust.
	4th " Exhaust.	1st " Admission.

The developed diagram (Fig. 40) is given, as before, to explain the working operations. The work done in each cylinder is shown, and comprises four strokes, or two revolutions of the crank shaft.







Besides this engine there are also *vis-à-vis* engines with cranks set at an angle of 180° to each other. With this arrangement the two pistons pass at the same time over the dead point, back or front. The developed diagram is the same as that of engine Z 4 (p. 11).

Twin Four-cycle Engine, Z 4, Two Cylinders.

The cranks are at the same angle, and the two pistons are always in the same positions (with reference to the dead point) at the same moment.

Ignition and the working operations in both cylinders succeed each other at an angle of 360° , that is, ignition is obtained, in one or other cylinder, at each revolution of the crank shaft.

Cylinder A.	Cylinder B.
INSTROKE.	
2nd Stroke. Compression of charge. Ignition at dead point.	4th Stroke. Discharge of exhaust gases.
OUTSTROKE.	
3rd Stroke. Explosion and expansion of the burning gases.	1st Stroke. Drawing in the combustible charge.
INSTROKE.	
4th Stroke. Discharge of exhaust gases.	2nd Stroke. Compression of charge. Ignition at dead point.
OUTSTROKE.	
1st Stroke. Drawing in the combustible charge.	3rd Stroke. Explosion and expansion of the burning gases.



The developed diagram for this type is shown at Fig. 45; the work done in cylinder A is marked ———, and that in cylinder B ———.





FIG. 45.—Developed Diagram for Z 4, Two-cylinder Engine.

Tandem Four-cycle Engine, R 4, Two Cylinders (Nürnberg).

The cylinders are arranged one behind the other, and both pistons work upon the same crank. The sequence of operations in the two cylinders takes place at an angle of 860° apart; thus there is one ignition for each revolution of the crank shaft. The working method is the same as that of the last engine.

The sequence of the different working strokes is as follows :—

	<i>First Cylinder.</i>	<i>Second Cylinder.</i>
One revolution {	3rd stroke Explosion and expansion.	1st stroke Admission.
	4th " Exhaust.	2nd " Compression.
One revolution {	1st " Admission.	3rd " Explosion and expansion.
	2nd " Compression.	4th " Exhaust.



The developed diagram for both cylinders is shown at Fig. 51; the work done in cylinder 2 is marked ———, that in cylinder 1




FIG. 51.—Developed Diagram for R 4, Two-cylinder Engine.

Double Vis-à-Vis Four-cycle Engine, Z G Z 4, Four Cylinders (Deutz).

Type especially intended for engines driven with blast furnace gas (now little made, as it has several disadvantages). As all four pistons move in the same direction, the working strokes in each cylinder succeed each other at an angle of 180° apart, that is to say, an ignition is obtained in one or other cylinder at every half revolution of the crank shaft.





Fig. 56 shows the developed diagram of the sequence of work. The diagrams of the different cylinders cover two revolutions of the crank shaft, and are marked

Twin Double-acting Four-cycle Engine, Z D 4, Two Cylinders.

Type for large engines, especially when driven with blast furnace gas.

The working strokes at either end of the cylinders succeed each other at an angle of 180° apart, both pistons moving in the same direction, that is, ignition takes place at every half revolution of the crank shaft. The cranks may also be set 180° apart, the strokes will then follow each other at the same interval as before.






FIG. 61.—Developed Diagram for Z D 4, Two-cylinder Engine.

The developed diagram is exactly the same as that of Z G Z 4, four cylinders (p. 13). The diagrams of work at either end of the cylinders are marked —, — . . . —, ..., — — — — .

Tandem Double-acting Four-cycle Engine, R D 4, Two Cylinders.

Type for large engines, especially for work with blast furnace gas.

The working strokes at either ends of the cylinders follow each at 180° distance, that is, an ignition is obtained at every half revolution.



FIGS. 63-66.

The developed diagram is the same as that of Z G Z 4, one cylinder, p. 13. The diagrams for the two ends of both




Fig. 67.—Developed Diagram for R D 4, Two-cylinder Engine.

cylinders are marked —, — — —, each representing two revolutions of the crank shaft. The strokes are so arranged that the working (or motor) stroke cannot take place in both cylinders at the same time.

Remarks on the Developed Diagrams.

To explain the developed diagrams given at pp. 8 to 17, let us suppose the four single strokes of the piston required for one complete cycle of operations to be set out side by side, thus :—

Outstroke.	Instroke.	Outstroke.	Instroke.
I	II	III	IV

If the corresponding curves of the indicator diagram are plotted vertically, a graphic representation of the sequence of operations in the engine is obtained. The pressure in the cylinder during admission and exhaust is in these diagrams taken as the same as the line of atmospheric pressure.

Classification of Types yielding the same Developed Diagrams.

The numbers below the diagrams give the angle described by the crank pin, in degrees, thus—
 0° to 180° corresponds to a single stroke, or half a revolution of the crank shaft.

0° to 360° " " " a double stroke (to and fro), or one complete revolution of the crank shaft.

0° to 540° " " " three single strokes, or three half-revolutions of the crank shaft.

0° to 720° " " " two double strokes (to and fro), or two complete revolutions of the crank shaft.




FIG. 68.—Diagram for E 4, One-cylinder Engine.





FIG. 69.—Diagram for G Z 4, Two-cylinder, and D 4, One-cylinder Engine.



E 4, 1 Cylinder.

G Z 4, 2 Cylinders.



D 4, 1 Cylinder





Fig. 70.—Diagram for Z 4, Two-cylinder, and R 4, Two-cylinder Engines.





Fig. 71.—Diagram for Z G Z 4, Four-cylinder, Z D 4, Two-cylinder, and R D 4, Two-cylinder Engines.

Remarks on diagram, Fig. 71.

The working operations in the different cylinders (in double-acting engines at both ends of the cylinder) are marked —, - - - - -, ..., ...

The cycle requires four strokes, or two revolutions of the crank shaft. The words on the developed diagrams denote—

- | | | |
|------------|---------------|--|
| 1st Stroke | Admission : | Drawing in the charge of gas and air. |
| 2nd " | Compression : | Of the charge drawn in. |
| 3rd " | Explosion : | Ignition of the compressed mixture which burns with rapid increase of pressure. |
| | Expansion : | Of the exploded charge as a consequence of the increase of cylinder volume due to the piston moving out. |
| | Release : | Escape of gases and products of combustion before the end of the stroke. |
| 4th " | Exhaust : | Discharge of gases still remaining in cylinder (the volume of the cylinder being reduced by the piston moving in). |

c Thus for a complete cycle of work at either end of the cylinder, a four-cycle engine requires two revolutions or four piston strokes, but in the last three types, described above, these are so arranged that work is done at each stroke of the piston (compare Fig. 71).

Remarks on the Developed Diagrams.

To explain the developed diagrams given at pp. 8 to 17, let us suppose the four single strokes of the piston required for one complete cycle of operations to be set out side by side, thus :—

Outstroke.	Instroke.	Outstroke.	Instroke.
I	II	III	IV

If the corresponding curves of the indicator diagram are plotted vertically, a graphic representation of the sequence of operations in the engine is obtained. The pressure in the cylinder during admission and exhaust is in these diagrams taken as the same as the line of atmospheric pressure.

Classification of Types yielding the same Developed Diagrams.

The numbers below the diagrams give the angle described by the crank pin, in degrees, thus—

- 0° to 180° corresponds to a single stroke, or half a revolution of the crank shaft.
- 0° to 360° " a double stroke (to and fro), or one complete revolution of the crank shaft.
- 0° to 540° " three single strokes, or three half-revolutions of the crank shaft.
- 0° to 720° " two double strokes (to and fro), or two complete revolutions of the crank shaft.





FIG. 68.—Diagram for E 4, One-cylinder Engine.



G Z 4, 2 Cylinders.

D 4, 1 Cylinder

FIG. 69.—Diagram for G Z 4, Two-cylinder, and D 4, One-cylinder Engine.





Fig. 70.—Diagram for Z 4, Two-cylinder, and R 4, 2 Cylinders.




Fig. 71.—Diagram for Z G Z 4, Four-cylinder, Z D 4, Two-cylinder, and R D 4, Two-cylinder Engines.

Remarks on diagram, Fig. 71.

The working operations in the different cylinders (in double-acting engines at both ends of the cylinder) are marked —, - - - -, ... The cycle requires four strokes, or two revolutions of the crank shaft. The words on the developed diagrams denote—

- | | | |
|------------|---------------|--|
| 1st Stroke | Admission : | Drawing in the charge of gas and air. |
| 2nd " | Compression : | Of the charge drawn in. |
| 3rd " | Explosion : | Ignition of the compressed mixture which burns with rapid increase of pressure. |
| | Expansion : | Of the exploded charge as a consequence of the increase of cylinder volume due to the piston moving out. |
| | Release : | Escape of gases and products of combustion before the end of the stroke. |
| 4th " | Exhaust : | Discharge of gases still remaining in cylinder (the volume of the cylinder being reduced by the piston moving in). |

Thus for a complete cycle of work at either end of the cylinder, a four-cycle engine requires two revolutions or four piston strokes, but in the last three types, described above, these are so arranged that work is done at each stroke of the piston (compare Fig. 71).

CHAPTER II.

Output of the Engine.

Indicated and Effective (or Brake) Horse-power.

Let (IHP) be the whole of the work done in the motor cylinder; IHP the available indicated work; (IHP) - IHP the energy absorbed by the engine, namely, in four-cycle engines the energy absorbed in drawing in the charge; in two-cycle engines the energy absorbed by the resistance of the pumps (as shown by the indicator); RHP frictional resistance of the engine; BHP actual output, or work given off at the end of the crank shaft. Then—

$$\text{IHP} = \text{RHP} + \text{BHP}; (\text{IHP}) = \text{IHP} + \text{the indicated work required for the pumps or for drawing in the charge} \quad (1)$$

The Mechanical Efficiency η

is the ratio the Brake Horse-power bears to the Indicated Horse-power, therefore—

$$\eta = \frac{\text{BHP}}{\text{IHP}}; \text{BHP} = \text{IHP} \eta; \text{IHP} = \frac{\text{BHP}}{\eta} \quad (2)$$

The mechanical efficiency varies with differences in the load on the same engine, and is greatest at maximum and lowest at minimum load.

Table I.—Approximate Values of η (Mechanical Efficiency).

Load.	Maximum.	Rated $\epsilon^* = 85$.	$\frac{3}{4}$	$\frac{1}{2}$	$\frac{1}{4}$
Single-acting Four-cycle, 1 cylinder $\eta =$	0.84	0.78	0.70	0.60	0.48
" " " " 2 " $\eta =$	0.86	0.80	0.74	0.62	0.49
" " " " 4 " $\eta =$	0.88	0.82	0.79	0.68	0.52
Double-acting Four-cycle, 1 cylinder $\eta =$	0.86	0.78	0.75	0.65	0.50
" " " " 2 " $\eta =$	0.88	0.80	0.78	0.68	0.54
" " " " 4 " $\eta =$	0.90	0.82	0.80	0.70	0.58
Two-cycle (with separate charging pump) $\eta =$	0.90	0.82	0.80	0.70	0.58
Steam Engine $\eta =$	0.90	0.89	0.88	0.82	0.70

The Effective Piston Area, A,

is equal to the sectional area of the motor cylinder, less the area of the piston rod, therefore—



FIG. 1.

$$\text{For a single-acting engine, } A = \frac{\pi}{4} D^2 \quad (3)$$




FIG. 2.

$$\text{,, double-acting engine, } A = \frac{\pi}{4} \left(D^2 - \frac{d^2}{2} \right) \quad (4)$$

$$\text{For engines with a piston rod passing through both covers } A = \frac{\pi}{4} (D^2 - d^2) \quad (4A)$$

Mean Pressure on the Piston p_m .

This pressure varies with the different positions of the piston during a cycle of work, that is, in a four-cycle engine, during two revolutions of the crank shaft).

* For ratio ϵ , see next page.

The mean or average pressure, p_m , for one cycle therefore represents the mean pressure exerted on the piston during the motor stroke, less the mean pressure during the three other strokes, when the piston receives its motion (or impulse) from the flywheel.*

The Ratio ϵ .

In a single-cylinder *four-cycle* engine, as already explained, there is one impulse or motor stroke for every two revolutions of the crank shaft. Therefore if n = the number of revolutions per minute, $\frac{n}{2}$ will be the maximum number of impulses obtained with this type of engine, that is, the maximum power developed. It is customary with engine builders to rate their engines at a lower or *nominal horse-power*, and to assume that they will be run with a lesser number of ignitions or impulses per minute than the maximum $\frac{n}{2}$.

We will denote the ratio $\frac{\text{actual number of impulses per minute}}{\text{maximum number of impulses per minute}}$ by ϵ . . . (5)

The maximum theoretical number of impulses depends upon the type of engine. For this, Table II., p. 20, may be consulted, which gives—

For *four-cycle engines*, maximum number of impulses = $\frac{z}{4} 2n$ (6)

For *two- " " " " " "* = $\frac{z}{2} 2n$ (6A)

z being the number of working ends of the cylinder (in a single-acting engine, $z = 1$; in a double-acting engine, $z = 2$, for each cylinder).

The ratio ϵ can also be applied to engines which are governed by varying the *proportions* of the charge; in these, as in other types, the mean pressure on the piston may be taken as $= \epsilon p_m$.

Three systems of governing are chiefly employed in gas engines, namely, the "*hit-and-miss*," the "*qualitative*," and the "*quantitative*," and also a combination of the two latter. In the first, the gas valve is closed from time to time during the suction stroke, if the governor runs at too high a speed, but when the valve is opened, the quantity of gas reaching the cylinder is *always the same*. Governing by "*cut-off*," or varying the quantity or quality of the charge, may be effected in various ways; we shall recur to it later.

Approximate Determination of the Mean Pressure on the Piston p_m .

As various kinds of combustible (rich and poor gases) are used in internal combustion engines, naturally the curves obtained in the indicator diagrams also vary † (see Fig. 9). It is necessary, however, to have a standard, or *normal diagram*, as a basis for rough *approximate* calculations, and this is shown at Fig. 10, p. 21.

* In four-cycle engines, if the diagram of work be planimetered, it will give p_m direct for the IHP, because when this is done the lower area */////* (work of drawing in the charge (IHP)—IHP is already deducted from the positive work *|||||* (Fig. 8).

† The theoretical explanation of these diagrams will be found in a later chapter.




FIG. 3.

In two-cycle engines we may write—

Instead of p_m	.	.	.	.	.	.	$0.9 p_m$	} approx.
" "	p_i	.	.	.	.	.	$0.9 p_i$	

This value may be more accurately determined by subtracting the mean resistance of the air-pumps from the work done in the motor cylinder (compare Part B., "Larger Gas Engines").

The mean pressure p_m calculated from the standard diagram (Fig. 10) is available for determining the IHP of the engine.

In most cases the diagram (Fig. 10) corresponds to the work done by an engine with lighting or coal gas.




FIG. 9.—Various Diagrams.




FIG. 10.—Standard Diagram.

Calculation of Indicated Horse-power, IHP, and the Brake Horse-power, BHP.

(See Table I., p. 18, and Table II., p. 20.)

Example 1 (Table II., p. 20).—Taking the rated horse-power of an engine at 80 per cent. or the maximum, then $e = 0.8$, that is to say, out of every possible 100 impulses or ignitions there are twenty miss-fires, or the governor must so regulate the admission of gas that the indicator diagram shows that only 80 per cent. of the total power has been developed.

Example 2 (Table II).—If a single-acting four-cycle engine has a cylinder diameter of $D = 16.5$ inches, $V = 472$ feet per minute piston speed, and mechanical efficiency $\eta = 0.78$ (Table I, p. 18), then by equation 8, and the last line of column a in Table II. ($\epsilon = 0.85$), the rated HP

$$= 0.78 \frac{\pi 16.5^3 \times 472}{4 \times 33,000} \times 17.5 = 42 \text{ BHP, working load.}$$

Example 3 (Table II.).—Let $A = 108.5$ sq. inches, $V = 550$ feet per minute piston speed, for a four-cylinder, double-acting four-cycle engine (for type, see column d , Table II.). According to Table I., the mechanical efficiency $\eta = 0.82$, and by equation 8 and Table II.,

$$\text{Maximum HP} = \eta \frac{\Delta V}{33,000} p_t = 0.85 \frac{108.5 \times 550}{33,000} \times 165 = \mathbf{254 \text{ HP.}}$$

$$\begin{aligned} \text{Rated or Brake HP at working load} &= \eta \frac{\Delta V}{33,000} \rho_i = 0.82 \frac{108.5 \times 550}{33,000} \times 140 \\ &= \mathbf{208 \text{ BHP at working load.}} \end{aligned}$$

We will take this engine as developing 200 HP.

Thus to calculate the work done by any engine it is necessary to know—

1. Whether the engine is of the *four-cycle* or *two-cycle* type.
2. Whether the engine is *single-* or *double-acting*.
3. *Number of motor cylinders.*
4. Nature of *combustible* to be used.

Rapid approximate calculation of the normal power developed by an engine. Taking $\epsilon = 0.85$ (p. 20), and η from Table I., p. 18, we get Table III., Values of Constant C.

D = diameter of cylinder in feet.

S = stroke of piston in feet.

n = revolutions per minute.

$$\text{Rated HP} = C \times D^2 \times S \times n; D^2 = \frac{\text{rated HP}}{CSn}; n = \frac{\text{rated HP}}{CD^2S} \quad \dots \quad (9)$$

Table III.

Combustible.	Mean calorific value in British thermal units per cubic foot, or per lb.	p_m lbs. per sq. in.	Single-acting four-cycle. $\eta = 0.78$ to 0.82 .			Double-acting four-cycle. $\eta = 0.78$ to 0.82 .			Double acting two-cycle. $\eta = 0.82$.	
			1 cylinder.	2 cyl.	4 cyl.	1 cyl.	2 cyl.	4 cyl.	1 cyl.	2 cyl.
Lighting or Coal Gas	563 B.T.U. per cub. ft.	82.5	C = 0.094	0.196	0.892	—	—	—	—	—
Pressure or Suction Gas	124 " " " "	65.5	" = 0.077	0.156	0.812	0.147	0.312	0.653	0.312	0.625
" rich	140 " " " "	71	" = 0.0825	0.170	0.841	0.162	0.341	0.710	0.341	0.682
Blast Furnace Gas	113 " " " "	57	" = 0.0655	0.136	0.278	0.130	0.270	0.568	0.278	0.540
Benzine	19,800 B.T.U. per lb.	74	" = 0.0825	0.176	—	—	—	—	—	—
Petroleum	18,000 " " " "	54	" = 0.0625	0.128	—	—	—	—	—	—
Alcohol	10,250 " " " "	54	" = 0.0625	0.128	—	—	—	—	—	—

The above values give the so-called *Rated HP* with 15 per cent. reserve. In exceptional cases, as when the engine is worked with rich gas, or has a high mechanical efficiency, insufficient cooling of the parts, etc., the *maximum HP* may be 25 per cent. higher.

Example 1 (Table III.).—*Blast Furnace Gas Engine.*

An R D 4, two-cylinder gas engine (double-acting, four-cycle). Diameter of cylinders D, 24 inches, stroke S = 28 inches, $n = 120$ revolutions per minute; taking the constant C = 0.27 from Table III. for blast furnace gas, we get—

$$\text{Rated HP} = 0.27 \times 2^2 \times \frac{28}{12} \times 120 = 300 \text{ HP}; \text{Maximum HP } 1.25 \times 300 = 375 \text{ HP.}$$

Example 2 (Table III.).—*Suction Gas Engine.*

An engine of the Z 4, type (two-cylinder, single-acting, four-cycle). Diameter of cylinder D = 18 inches = 1.5 foot, stroke S = 24 inches = 2 feet. It is required to develop 100 BHP, at what speed must the engine run? Taking from Table III. the value of the constant C for suction gas (for this type of engine), C = 0.156, we get—

$$n = \frac{100}{0.156 \times 1.5^2 \times 2} = 143 \text{ revolutions per minute.}$$

For lighting or coal gas, Table III. gives C = 0.196, therefore—

$$n = \frac{100}{0.196 \times 1.5^2 \times 2} = 114 \text{ revolutions per minute.}$$

The *thick figures* of values of C in Table III. can always be used for one motor cylinder, and the work of the engine calculated from it, and multiplied by the *number* of cylinders.

CHAPTER III.

Main Dimensions of the Engine.

To lengthen the stroke of the piston gives a better division of the pressure on the connecting rod, and therefore greater uniformity in running the engine; but theoretical determinations of the *ratio S : D* (stroke to diameter of cylinder), have led to no practical results, and it will be advisable to adhere to such dimensions as practical experience has shown to be best. In the diagram Fig. 1, this ratio is plotted for a number of different types of engine, and varies from 1.05 to 2.




FIG. 1.—Ratio S : D for Horizontal Engines.

Engines made by the same firm are denoted by the same symbol in the diagram, as, for instance—

Deutz, ○. Nuremberg, □. Swiderski, △. Körting (two-cycle), ○○.

The same ratio has not been adopted in the different types, as will be seen, nevertheless $S : D = 1.6$ for small engines (with 5-inch stroke), decreasing to 1.2 for larger engines (up to 28-inch stroke) appears to be the best, and we will take this as the *normal* ratio.

(The ratio $S : D$ of the standard types of Haeder steam engines is, for the sake of comparison, indicated in Fig. 1, by the dotted line)

The shaded area // represents the ratio $S : D$ for types of engines the dimensions of which are given in the table overleaf.

For gas engines, as for the standard types of Haeder steam engines, the following rule holds good :—

To build as many different types of engines, of uniformly increasing powers, with as few patterns as possible.

On referring to Table I., it will be noticed that two different diameters of cylinders are given for engines above 3 BHP. ; the larger cylinder gives a more powerful engine, with the same stroke. The alternative dimensions may be used in order to save the expense of patterns, etc.

Table I.--Types of Engines. Four-cycle up to 28-inch Stroke and 115 BHP per Cylinder.

Stroke (or travel) of piston S =	5"	6½"	7½"	8½"	10½"	12"	18¾"	16"	17¾"	20"	21½"	24"	28"	ins.									
Diameter of cylinder D =	3"	4"	5"	5¾"	6"	7½"	8"	8½"	9"	10¼"	10½"	12"	12½"	13"	13½"	14"	14½"	16"	17"	18¾"	21½"	24"	ins.
Ratio S:D =	1.67	1.62	1.5	1.48	1.75	1.4	1.5	1.4	1.53	1.84	1.52	1.88	1.45	1.97	1.51	1.43	1.48	1.84	1.41	1.28	1.32	1.17	ins.
Number of revolutions n =	240	240	285	280	280	230	225	220	220	210	195	185	175	165	150								per min.
Speed of piston V =	200	260	294	326	402	402	450	560	505	560	578	618	626	660	700								ft. per min.
Area of cyl. A =	7	12½	19½	26	28½	44	50½	56¾	63¾	82½	86½	113	118	132½	138	154	165	201	227	276	354¾	452½	sq. ins.
Rated HP* =	0.5	1	2	3	4	6	8	9	11½	15	17	22½	24	28	30	94	37	45	53	65	88	113	BHP.
Maximum HP (at 25%) . . .	0.625	1.25	2.5	3.75	5	7.5	10	11.25	14.3	18.7	21	28	30	35	37.5	42.5	46	56	66	81	110	140	HP.
Flywheel diameter 2'	7½"	8'	9"	9½"	10'	11'	12'	13'	14'	15'	16'	17'	18'	19'	20'	21'	22'	23'	24'	25'	26'	27'	ft. & ins.
" breadth 3"	3½"	3¾"	4"	4½"	4¾"	5"	5½"	5¾"	6"	6¾"	7"	7½"	7' 10½"	8'	8½"	9'	9¾"	9' 0¾"	9' 6½'	9' 6½'	10'	10"	ft. & ins.
Wgt. of flywheel —																							ins.
For power † . . .	485	585	870	1147	1047	1548	1675	2050	2205	2820	2780	3920	4040	5250	5740	6620	7600	9050	11550	14500	21500	29800	lbs.
For electric light ‡	773	999	1390	1830	1675	2470	2690	3310	3530	4410	4110	6290	7390	8390	9150	10600	12100	14900	18600	23200	34500	39400	lbs.

Number of Revolutions.—For the number of revolutions here taken as a standard, see Fig. 11, p. 180. The powers developed vary in direct ratio to the number of revolutions.

* The *Rated HP* are calculated for single-acting four-cycle engines, worked with *lighting gas*, $p_m = 82.5$ lbs. per sq. inch; $\epsilon = 0.85$; $\eta = 0.74$. Compare pp. 18, *et seq.*; with *suction gas* (see p. 22) 25 per cent. less power is developed.

† Mean values, calculated for a variation of $\delta_0 = \frac{1}{30} = 0.02$ } For further details, see chapter on "Flywheels."

$$\delta_0 = \frac{1}{80} = 0.0125$$

These dimensions form the basis of the standard types given in Chapter VII., "Parts of the Engine."

CHAPTER IV.

Effect of the Inertia of the Reciprocating Parts.

BEFORE we proceed to consider the diagram of tangential pressures for calculating the weight of the flywheel and the construction of the various parts of the engine, it is necessary to take into account the inertia of the moving parts. Although here as elsewhere it is assumed that the student has a knowledge of the effect of the inertia of the moving parts in a steam engine, we will briefly recapitulate the fundamental rules, and reduce the equations embodying them to their simplest expression. Let—

A be the sectional area of the working cylinder in sq. inches.

W = „ weight of the reciprocating parts (piston with piston pin, connecting rod, etc.) in lbs. according to Tables II., III.

D = „ diameter of the cylinder in inches.

S = „ stroke in feet.

r = „ radius (or throw) of the crank (*i.e.* half the stroke) in feet.

n = „ revolutions per minute.

ϕ = „ acceleration of the reciprocating parts in feet per second.²

(ϕ) = „ negative acceleration or retardation of the reciprocating parts in feet per sec.²

P = „ pressure in lbs. required to impart to the reciprocating parts having weight W, the exact degree of acceleration determined by a given speed and length of stroke.

$v = \frac{\pi n}{30}$ „ circumferential velocity in circle described by crank in feet per second.

L = „ length of connecting rod in feet.

$\alpha = \text{„ } 0^\circ \text{ to } 180^\circ \text{ angle of inclination of the crank in relation to the dead points, see Figs. 5-6.}$

Thus for any given angle α of the crank:

During the outstroke of the piston towards the crank shaft.

Outstroke.—Acceleration $\phi = \frac{v^2}{r} \left(\cos \alpha + \frac{r}{L} \cos 2\alpha \right)$ (1)

During the return stroke towards the back end of the cylinder.

Instroke.—Acceleration $\phi = \frac{v^2}{r} \left(\cos \alpha - \frac{r}{L} \cos 2\alpha \right)$ (2)

From these equations for the positions of the cranks at the dead points we get—

Outstroke.—Back dead point. Front dead point.

Acceleration $\phi_1 = \frac{v^2}{r} \left(1 + \frac{r}{L} \right)$; (ϕ_2) = $-\frac{v^2}{r} \left(1 - \frac{r}{L} \right)$ (3)

Instroke.—Front dead point. Back dead point.

Acceleration $\phi_2 = \frac{v^2}{r} \left(1 - \frac{r}{L} \right)$; (ϕ_1) = $-\frac{v^2}{r} \left(1 + \frac{r}{L} \right)$ (4)*

The degrees of acceleration can be plotted as ordinates along a straight line (Figs. 3 and 4), the + (plus) values (acceleration) below, and the - (minus) values (retardation) above.

* Acceleration with a minus sign - (equations 3 and 4) denotes the same as retardation.





FIG. 2.



FIGS. 3-6.

The direction in which the crank rotates has no effect on the values of ϕ (Figs. 3 to 6). If we take the usual ratio $\frac{r}{L} = \frac{1}{5.5}$ to $\frac{1}{6}$, or a mean value of $\frac{1}{5.8}$, we obtain for the crank positions at the dead points—

Outstroke.—Back dead point.

$$\text{Acceleration } \phi_1 = \frac{v^2}{r} \times \frac{6.8}{5.8} \sim \frac{n^2 \times r}{78}$$

Instroke.—Front dead point.

$$\text{Acceleration } \phi_2 = \frac{v^2}{r} \times \frac{4.8}{5.8} \sim \frac{n^2 \times r}{110}$$

Front dead point.

$$\text{Retardation } (\phi_2) = \frac{v^2}{r} \times \frac{4.8}{5.8} \sim \frac{n^2 \times r}{110} \quad (5)$$

Back dead point.

$$\text{Retardation } (\phi_1) = \frac{v^2}{r} \times \frac{6.8}{5.8} \sim \frac{n^2 \times r}{78} \quad (6)$$

and also—

Outstroke.—Back dead point.

$$\text{Pressure due to acceleration, } P_1 = \phi_1 \times \frac{W}{g}$$

Instroke.—Front dead point.

$$\text{Pressure due to acceleration, } P_2 = \phi_2 \times \frac{W}{g}$$

Front dead point.

$$\text{Pressure due to retardation, } P_2 = (\phi_2) \times \frac{W}{g} \quad (7)$$

Back dead point.

$$\text{Pressure due to retardation, } P_1 = (\phi_1) \times \frac{W}{g} \quad (8)$$

This pressure, due to acceleration or retardation, may be considered as distributed over the whole area of the piston, then the pressure, or inertia, per unit of area will be—

$$\text{At the back dead point } q_1 = P_1 \div A; \text{ and } (q_1) = (P_1) \div A \text{ respectively} \quad (9)$$

$$\text{„ front „ „ } q_2 = P_2 \div A; \text{ and } (q_2) = (P_2) \div A \text{ „} \quad (10)$$

The inertia diagram (per unit of piston area) can be plotted on ordinates along a straight line, in the same way as the acceleration itself in Figs. 3 and 4. See Fig. 7. Here the axis of the abscissa is cut at the point k , where the inertia is = zero.




FIG. 7.

wards the crank shaft. The distance x_1 of point k , from the dead point is dependent on the ratio $\frac{r}{L} = \frac{\text{radius of crank}}{\text{length of connecting rod}}$.

The angle α_0 of the crank (in which $\phi = 0$) corresponds to the distance x_1 (Fig. 7) traversed by the piston, and according to Radinger* is determined thus—

$$\cos \alpha_0 = \frac{-1 + \sqrt{1 + 8\left(\frac{r}{L}\right)}}{4\frac{r}{L}} \quad (11)$$

* Radinger, "Maschinen mit hoher Kolbengeschwindigkeit" ("Engines with High-Piston Speeds").

The travel of the piston x (Fig. 8) corresponding to any given angle of the crank α is calculated thus—

$$x = r(1 - \cos \alpha) + L(1 - \cos \beta) \quad (12)$$

The angle of the connecting rod β can be determined by the equation—

$$\sin \beta = \frac{r \sin \alpha}{L} \quad (13)$$

There is no necessity to work out equations 12 and 13, because q_1 and q_2 can be determined from equations 9 and 10, and x_1 from Table I. Given these three points, the general shape of the curve can be determined. The values in Table I. are calculated from equations 11 to 13.




FIG. 8.

Table I.—Values of α_0 , x_1 , and x_2 (Figs. 5 and 6).

Ratio $r : L =$	0	$\frac{1}{7}$	$\frac{1}{6}$	$\frac{1}{5.5}$	$\frac{1}{5}$	$\frac{1}{4}$
Angle $\alpha_0 =$	90°	82°	81°	80°	79°	77°
Travel of piston $x_1 = r$	0.94 . r	0.93 . r	0.92 . r	0.91 . r	0.9 . r	0.89 . r
„ „ $x_2 = r$	1.06 . r	1.07 . r	1.08 . r	1.09 . r	1.1 . r	1.11 . r

Fig. 9.

The inertia diagram, or diagram of acceleration (Fig. 7), also shows that where the piston begins to move out during its travel along the distance x_1 , part of the available effort is absorbed in starting or accelerating the motion of the reciprocating parts. Therefore the ordinates for this part of the diagram lie below the line of no pressure (= zero). During the travel of the piston along x_2 (Fig. 7) there is retardation in the motion of the moving parts, and therefore, instead of absorbing, they release energy. Therefore the ordinates of the diagram (Fig. 9) for this part of the stroke lie above the atmospheric line.

(It should be noted here that in single-cylinder four-cycle engines, the necessary acceleration can only be imparted to the moving parts of the piston during the third stroke (explosion and expansion). During the first stroke (admission), the second (compression), and the fourth (exhaust), this energy must be communicated by the flywheel, but it has no effect on the graphic representation of the pressure curves of the reciprocating parts.)

The effect of the reciprocating parts of the engine on the pressure diagram of the piston will be most clearly seen by developing the different parts of the diagram, or by drawing a *continuous* diagram. Fig. 9 shows, for instance, the sequence of the in- and out-strokes for one revolution. For a four-cycle engine, however, the diagram must be drawn for four strokes, as at Fig. 13.




Fig. 9.—Inertia Diagram.

When designing an engine, the weights of the reciprocating parts are not generally known. Table II. gives these weights approximately for the piston and connecting rod of the standard types of engine (see Table I., p. 24).

Table II.—Weights of Reciprocating Parts for Single-acting Four-cycle Engines.*

Stroke S =	{ 180 (5½")	160 (6¼")	190 (7½")	220 (8¾")	270 (10½")	310 (12¼")	350 (13¾")	400 (15½")	450 (17¾")	500 (19¾")	550 (22")	600 (23¾")	700 mm. (27½")
Diam. of cylinder D =	{ 80 (3¼")	100 (4")	125 (5")	145 (5¾")	185 (7¼")	220 (8¾")	260 (10½")	300 (12")	380 (18")	360 (14½")	400 (16")	480 (19")	600 mm. (24")
Piston including bolts =	12	20	29	37½	71	120	190	272	345	445	550	880	1320 lbs.
Connecting rod . . . =	10	15½	26½	35½	78	188	210	300	395	485	620	980	1500 "
Total weight W . . . =	22	85½	55½	73	149	258	400	572	740	980	1170	1760	2820 "
Weight per sq. in. of cyl. area = $W \div A$. . .	2.7	2.8	2.8	2.8	8.4	4.2	4.6	5	5.6	5.65	5.8	6.2	6.25 lbs. per sq. in.
Weight per HP = $W \div HP$	37.5	28.6	27.8	21	21	22	22	22	22	22	22	22	22 lbs.

We can also write—

Table III.—Approximate values for large gas engines (stroke more than 32-inch). W and HP apply to one cylinder only.

Single-acting four-cycle $W = 6.43 \times A$ or $W = 22.3 \times HP$
 Double- " " " $W = 8.55 \times A$ " $W = 15.6 \times HP$
 " " two- " $W = 8.55 \times A$ " $W = 7.8 \times HP$
 Large steam engine $W = 4.98 \times A$ " $W = 5.1 \times HP$

Engines for Motor Cars run at very high speeds, and therefore the moving parts must be kept extremely light, otherwise the forces due to inertia would be too great.

Table IV.—Approximate Values for Motor-car Engines.

Power developed per cylinder	3 4	4 5	6 8 HP
$D \times S =$	3½" × 4"	4" × 4½"	4½" × 4½"
$n =$	1000 1410	900 1200	800 1100 revs. per min.
Permissible values of W =	7.7 lbs.	11.2 lbs.	15.9 lbs.
$W \div A =$	0.75 lbs.	0.89 lbs.	1.06 lbs. per sq. in.
$q_1 =$	51 102	55.5 102	55.5 102 lbs. per sq. in.
$q_2 =$	34 68	37 68.3	37 68 " "

Example.—Assuming a large single-acting four-cycle engine to have a cylinder diameter of 40 inches, what should be the weight of the reciprocating parts?

According to Table III., for a cylinder diameter of 40 inches (or 1260 sq. inches area)—

$$W + A = 6.43 \text{ lbs. per sq. inch. ; therefore } W = \frac{\pi}{4} \times 40^2 \times 6.43 = 8100 \text{ lbs.}$$

Example.—The reciprocating parts of a single-acting four-cycle gas engine, having a cylinder diameter of 13 inches, and 18 inches stroke, weigh according to Table II., $W = 740$ lbs. Taking the speed at $n = 180$ revolutions per minute, what are the pressures exerted by the moving parts?

We have—

Outstroke.

From equation 5—

$$\text{Acceleration } \phi_1 = \frac{180^2 \times 0.75}{78} = 312 \text{ ft. per sec.}$$

From equation 7—

$$\text{Inertia } P_1 = 312 \times \frac{740}{32} = 7200 \text{ lbs.}$$

Instroke.

From equation 6—

$$\phi_2 = \frac{180^2 \times 0.75}{110} = 220 \text{ ft. per second.}$$

From equation 8—

$$\text{Inertia } P_2 = 220 \times \frac{740}{32} = 5100 \text{ lbs.}$$

or reduced to the area of the piston: (area of 13 inches = 133 sq. inches).

* If the engine be properly constructed, and good material used, the weights of the reciprocating parts may be somewhat less, say, 0.8 of the values given in this table. Special attention should be given to reducing the weight of the piston.

According to equation 9—

$$\text{At the dead point back end of cylinder, } q_1 = \frac{7200}{133} = 54 \text{ lbs. per sq. inch.}$$

According to equation 10—

$$\text{At the dead point, front end of cylinder, } q_2 = \frac{5100}{133} = 38.4 \text{ lbs. per sq. inch.}$$

The values are plotted to scale in Fig. 13, 1 inch = 180 lbs.

In order that the beginner may be able to detect errors in calculating q_1 and q_2 , the values for the three sizes of engines (viz. $\frac{1}{2}$ HP, 30 HP, and 500 HP) are calculated in Table V. The first half of each column gives the *normal speed* for these powers, the second shows how q increases with the number of revolutions. (The spaces left in Table V. are for the insertion of further examples.) The change of load on the rods takes place exactly at the dead point, if $q = C$ (Fig. 10), because the pressure of explosion p is only developed at the distance k from the dead point.





FIG. 10.

The diagrams at the bottom of Table V. show the difference in the pressures between the standard diagram and the acceleration q .

Table V.—Acceleration for Engines of Different Powers (Single-acting, Four-cycle).

Stroke =	5½"	20"	47½"			
Diameter D =	3½"	14½"	43½"			
W =	22	980	9500			lbs.
n =	240	480	185	370	110	220
φ ₁ =	158	680	862	1445	306	1280
φ ₂ =	112	447	256	1022	217	870
P ₁ =	108	481	10,420	41,800	90,900	368,000
P ₂ =	76.6	306	7,400	29,500	64,800	256,000
q ₁ =	18.1	52.2	68	254	55	244
q ₂ =	9.8	37.2	44.9	179	43	172
						lbs. per sq. in.
						" "

lbs.
 revs. per min.
 ft. per sec.²
 ft. per sec.²
 lbs.
 lbs.
 lbs. per sq. in.
 " "




This table shows that engines with 19 inches and 47 inches stroke cannot be run at double the usual speed, the rule being that—

$$\text{Radial acceleration } q < C. \quad (14)$$

(otherwise there would be two successive changes of pressure in the rods).

The inertia increases as the *square of the number of revolutions*, in other words, q increases with n^2 . It will be well, therefore, to compare the speeds of gas and of steam engines.

These are plotted in Fig. 11. As gas engines require much larger cylinder dimensions than steam engines, to develop the same power, it was necessary from the first to run them at much higher speeds. On the other hand, the speed of steam engines has of late years considerably increased.



Stroke in millimetres.

FIG. 11.

A Combination of the Inertia and Indicator Diagrams,

gives the energy diagram, which we shall use to plot the diagram of tangential pressures (Chapter V.). The method of combining these two diagrams is as follows:—




FIG. 12.

We will suppose the area of work shown in the diagram is obtained without compression, and therefore without counterpressure on the back end of the piston, and is shown to the right in Fig. 12, down to the atmospheric line aa ; the area of work lost (absorbed) by compression is plotted below this line, to the left; the difference of the two areas gives the actual diagram of work. In the same way admission (drawing in the charge, and exhaust, both at a pressure of $\frac{1}{10}$ inch of an atmosphere (= say, $1\frac{1}{2}$ lbs. per sq. inch) are plotted below this line (Fig. 14).

A numerical example will best explain the further development of the diagram.





FIG. 18.—Continuous Inertia Diagram.

Example.—We will take $p = 22$ atmospheres (323 lbs. per sq. inch) as the pressure of explosion, and for the inertia the figures given in the example on the previous page, in which $q_1 = 52$ lbs. per sq. inch, $q_2 = 37$ lbs. per sq. inch. Scale = 1 inch = 190 lbs.

The diagram of acceleration is then drawn, and developed for one cycle of work, or four strokes (Fig. 13), and the degrees of acceleration, or inertia, plotted as ordinates,



FIGS. 14, 15.—Illustration of the Continuous Diagram.

as in Fig. 9. The developed diagram of work is then plotted. Figs. 14, 15 show how this is done, and require no further explanation.




FIG. 16.—Inertia and Indicator Diagram Combined.

The two diagrams, Figs. 13 and 14, must then be combined, and drawn one over the other, as shown at Fig. 16, in order to plot the resulting diagram of pressures.

The pressures resulting from this combination have been determined in Fig. 16, for several positions of the piston. In the second stroke, for instance, (e) is drawn = e , and a_4' is the resulting pressure. Again, in the third stroke, (k) is plotted = k , and (m) = m , therefore the resulting pressures = a_3 and a_3 respectively.

The pressures for each position of the piston are determined in the same way; the diagram thus produced is shown at Fig. 17. The beginner should refer back from Fig. 17 to Fig. 16, in order to understand both diagrams clearly.

The pressure diagram thus evolved yields in the first place the corresponding pressure on the crank pin for every position of the piston, expressed in lbs. per sq. inch of piston




FIG. 17.—Diagram corrected for Inertia.

area. It also shows where the changes of pressure in the rods during the various strokes occur, namely, at the points marked O, where the energy curve cuts the neutral lines. Thus, according to Fig. 17, we have in this example two changes of pressure during one cycle of work, viz.—

During the *first* stroke (admission, or drawing in the charge); and
During the *fourth* stroke (exhaust).

In the second stroke (compression) and the third (explosion and expansion) there are no similar changes in pressure (*i.e.* the pressure is either wholly above, or wholly below, the neutral line).

The inertia diagram, as well as the resultant pressure diagrams, or diagram corrected for inertia, can be plotted for other engines in the same way; the method of drawing them should be clear, without further explanation, to the student.

The developed or continuous diagrams may be classified under four heads, as follows:—

The <i>Inertia</i> diagram shows the effect of the reciprocating parts (Fig. 13).	} In relation to the stroke.
The diagram of <i>work</i> is plotted from the indicator diagram (Fig. 14).	
The <i>pressure</i> diagram is a combination of the diagrams of work and inertia (Fig. 17).	
The diagram of <i>tangential</i> pressure, commonly called the turning moment diagram, or the pressure diagram reduced to the circle described by the crank forms the subject of the next chapter.	

CHAPTER V.

Tangential Pressure or Turning Moment Diagram for Calculating the Flywheel.

	PAGE
General Remarks	34-35
Single-acting Four-cycle Engine, E 4 , 1 cyl.	35-40
Double-acting Four-cycle Engine, D 4 , 1 cyl.	40-42
Vis-à-Vis Four-cycle Engine, G Z 4 , 2 cyl.	42
Twin Four-cycle Engine, Z 4 , 2 cyl.	42-43
Tandem Four-cycle Engine, R 4 , 2 cyl.	44-45
Double Vis-à-Vis Four-cycle Engine, Z G Z 4 , 4 cyl.	45-48
Twin Double-acting Four-cycle Engine, Z D 4 , 2 cyl.	48-49
Tandem Double-acting Four-cycle Engine, R D 4 , 2 cyl.	49-50

A shortened method for determining the weight of the Flywheel, with the necessary Tables, will be found in the chapter on "Flywheels." But it is desirable that the beginner should study the following chapter thoroughly, and work out a few examples for himself.

CHAPTER V.

Tangential Pressure or Turning Moment Diagram for Calculating the Flywheel.

THE energy of the engine fluctuates periodically, the work of the flywheel consists in acting as an accumulator or reservoir of energy, storing up the excess taken from and restoring the deficiency of energy to the engine, so as to secure as far as possible a uniform, angular velocity of the crank shaft. As already explained, there is, in single-cylinder four-cycle engines, only one working or motor stroke per two revolutions, or four strokes, and in these engines the flywheel must carry the engine forward during the three remaining strokes by the kinetic energy stored up in its rim. During the working stroke (Stroke III.) the motion is accelerated, and the flywheel absorbs energy; during the other strokes it is retarded, and energy is liberated.

If the engine had no flywheel it would come to a stop at the dead point, since the whole pressure of the piston is transferred to the head of the crank pin, and cannot act upon and drive round the crank.

To calculate the revolving masses, or determine approximate values for the necessary equations, the graphic method and the turning moment, or tangential pressure diagram, will be found of most use. With the help of this diagram, the complicated conditions arising during a cycle of work can easily be represented.

The resistance acts *tangentially* to the circumference of the flywheel, and also, if reduced, to the circle described by the crank. The force of the piston is therefore divided into two components—a *tangential* and a *radial*. The tangential component, at the points where it cannot overcome the whole resistance, and where it acts counter to it, is aided and sustained by the kinetic energy stored up in the flywheel.




FIG. 1.—Determination of the Tangential and Radial Pressure.

Determination of the Tangential Pressure and of the Radial Component.

$$\text{Let } P = \frac{\text{thrust on the connecting rod in lbs.}}{\text{area of the piston in sq. inches}} \text{ in lbs. per sq. inch (1)}$$

= the load on the connecting rod reduced to 1 sq. inch of piston for any given position of the crank.

α = the angle formed by the crank with the dead point, in any given position.

Draw the crank circle K (of any given diameter, Fig. 1).

Produce the centre line of the connecting rod beyond point 1, where it intersects the crank circle.

Mark off the load P on the connecting rod along this line, beyond point 1, to scale (for instance, 1 inch = 400 lbs., or 2 inches = 400 lbs.).

Draw a line 1-3 at right angles to the crank position 0-1.

Draw the parallelogram of forces 1-4-2-3. Then the line—

1-3 gives the tangential pressure }
1-4 „ „ radial pressure } to the same scale as P.

Example.—Determine the tangential pressure when the crank is at an angle $\alpha = 30^\circ$, $P = 100$ lbs. per sq. inch.

Taking 180 lbs. to the inch as the scale; we carry out (from Fig. 1) $P = 0.55$ inch. Draw the parallelogram of forces, and measure from the diagram $t = 0.33$ inch. Calculating this to the above scale, the tangential pressure works out at $t = 0.33$ inch = 60 lbs. per sq. inch. (This example is shown to scale in Fig. 1.)

(The *radial pressure* P_r , also measured from Fig. 1, is = 0.44 inch = 79.5 lbs. per sq. inch; for the line P_r is 0.44 inch long, and the scale is 1 inch = 180 lbs. per sq. inch. In the following chapters, however, we have only to deal with the tangential pressure (or turning moment); the radial pressure need not be taken into account, except when determining the stress upon the crank shaft (comp. p. 83).)

We will now calculate the flywheel for the different types of engines.

I. Single-acting Four-cycle Engine, E 4, One Cylinder (pp. 35-40).

A cursory representation of the working method in a four-cycle engine might be afforded by the continuous diagram, Fig. 2, in which the direction and amount of the




FIG. 2.—Continuous Diagram (not applicable).

pressures are plotted from the indicator diagram. But this simple method cannot be utilized, because a distinction must be made between—

Positive work, that is, the work done in the motor cylinder, and
Negative work „ „ „ given off by the flywheel.

To make this clearer, we will now proceed as follows :—

1. Divide the *indicator diagram* (Fig. 3) into ten or more equal parts.
2. Draw the continuous (developed) diagram of *work*, as at Figs. 14 and 15, p. 31.
3. Draw the *inertia diagram*, as at Fig. 13, p. 30.
4. Draw the last two diagrams one over the other, as at Fig. 3A, and combine them to form the *energy diagram* (Fig. 4).

In this *energy* diagram, from which the diagram of tangential pressure (or the turning moment diagram corrected for inertia) must be plotted, the *area above the atmospheric*




FIG. 3A.—Energy Diagram with Inertia Curves.

line represents the work done in the motor cylinder, and the *area below the atmospheric* line the work done by the flywheel.




FIG. 3.—Indicator Diagram.




FIG. 4.—Resultant Energy Diagram.

If we designate the first as plus and the second as minus work, then in a single-acting four-cycle engine there will be plus work during one stroke (Stroke III.) and minus work during the other strokes (Strokes I., II., and IV.).

We will now plot the turning moment or tangential pressure diagram by means of a *numerical example*. We take, to start with, a diagram showing an explosive pressure of 27 atmospheres or, say roughly, 400 lbs. per sq. inch (Fig. 3). The inertia of the reciprocating parts we take approximately from p. 29, at $q_1 = 64$ lbs. per sq. inch $q_2 = 50$ lbs. per sq. inch. Scale of energy, 1 inch = 180 lbs. The lines of the diagram (Fig. 3A) are combined, according to Figs. 16, 17 (pp. 31, 32), to form the resultant energy diagram corrected for inertia (Fig. 4).




FIG. 5.—Movements of the Crank.

To determine the tangential pressure we will not use the method given at p. 34 for plotting the diagram, but an *auxiliary process* taken from Radinger.*

Draw out the path described by the crank (Fig. 5). It will be best to make the travel of the piston 0 to 10 equal to the length of a stroke in the diagram (Fig. 4). Divide the stroke into the same number of equal parts, as the diagram, and from L (length of the connecting rod) describe radii cutting the crank circle (Fig. 5). Mean of $L : r = 5.8$.




FIG. 6.—Determination of z_1 and z_2 .

Next, produce the line of direction of the connecting rod; for instance, for 0.3 travel of the piston (three-tenths of the stroke) (Fig. 6) to cut the vertical axis of the crank at z_2 . This point is then connected to O (Fig. 6), the pressure on the piston corresponding

* Radinger, "Maschinen mit hoher Kolbengeschwindigkeit" ("Engines with High-Piston Speeds").

to this position of the crank, which, according to Fig. 4, is a_3 ; it is then laid off on a horizontal line from O to the right, and a vertical line is drawn at right angles to it, up to the connecting line z_3O (Fig. 7). This vertical t_3 gives the turning moment at the third position of the piston (three-tenths of the stroke).

In Fig. 7 the turning moment t_2' is also determined for position 2' of the piston. For the pressure exerted by the piston a_2' at this point, see Fig. 4.

The neutral line BB' is marked off into horizontal divisions 1 to 10; the sections measured on the circle described by the crank (x in Fig. 5) are then plotted for the different crank positions during the out- and in-strokes of a working




Fig. 7.—Turning Moment for Crank Positions 3 and 2' (the Turning Moments here plotted are of the same value as those from Fig. 1).

Fig. 8.—Development of the Crank Circle. Plotting the Turning Moment t .




Fig. 9.—Conversion of the Areas, m , projecting above line CC' and the Areas below it, o , into Rectangles.

cycle, and therefore for two revolutions. (As these sections are measured on the circumference, they vary in length.)

The tangential pressures, or turning moment, t , from Fig. 7, are plotted over the ordinates of the corresponding crank positions, and the points thus obtained are joined (Fig. 8).

The whole of the shaded area is converted into a rectangle having the same length (in which the areas m lying above the neutral line BB' are taken as plus, and the areas o lying below it are taken as minus areas), and line CC' is drawn parallel to BB' at the distance BC thus found. The height of the rectangles $BCC'B'$ thus obtained represents the mean tangential effort on the crank-pin, and hence the difference between the plus and minus areas. The same scale must be used as that taken for the diagram, Figs. 3 and 4. The resultant line CC' cuts the turning moment curve at several points. Thus the areas which lie above line CC' denote the energy absorbed by the flywheel, and the areas below it the energy given off by the flywheel, showing plainly that the larger the areas projecting above or below the line, the greater must the weight of the flywheel be.

The areas above and below the line CC' are then converted by the planimeter, the Simpson formula, or simply by measuring with the eye, into rectangles (Fig. 9), and their size determined in sq. inches. The largest must be taken as the basis of the following calculation. Let—

A = sectional area of motor cylinder in sq. inches.


g = gravity = 32 feet per second².

δ_0 = permissible degree of irregularity in speed.

R = radius of centre of gyration of rim section in feet.*

n = revolutions per minute.

$v = \frac{2 \times R \times \pi \times n}{60} = \frac{R \times \pi \times n}{30}$ = circumferential velocity around path described by centre of gravity of rim section in feet per second (2)



u = length of greatest area above the line of mean tangential effort, measured from the diagram, in feet.

b = height of this area in lbs. per sq. inch (therefore height in inches multiplied by the scale).

l = height of a double stroke, to and fro, measured from the diagram in feet.

$S \times \pi$ = length of greatest area reduced to the crank circle in feet.

$1.1 W$ = weight of rim section, plus effect of weight of arms at the centre of gravity of the rim.

Thus the value of the rotating parts will be †—

$$1.1 \frac{W}{g} = u \times \frac{S \times \pi}{6} \times b \times \frac{A}{v^2} \times \frac{1}{\delta_0} = \frac{u}{l} \times b \times \frac{A \times S \pi}{v^2} \times \frac{1}{\delta_0} \quad (3)$$

Hence weight of the rim section in lbs.—

$$W = 92 \times \frac{u}{l} \times b \times \frac{A \times S}{v^2} \times \frac{1}{\delta_0} \quad (4)$$

* Radius of centre of gyration of rim section is about $0.45 \times$ external diameter of flywheel D_0 (see small drawing at side) (5)

† Deduced from the original equation:—

$$u \times \frac{b}{l} \times S \times \pi \times A = 1.1 \frac{W}{2g} \times (v_{max}^2 - v_{min}^2) \quad (6)$$

Excess of energy shown in diagram. Energy absorbed by the flywheel.

If we write $\delta_0 = \frac{v_{max} - v_{min}}{v}$; $v = \frac{v_{max} + v_{min}}{2}$;

$$\delta_0 \times v = \frac{v_{max}^2 - v_{min}^2}{2v}; \quad \delta_0 \times v^2 = \frac{v_{max}^2 - v_{min}^2}{2}$$

$$\text{then } u \times \frac{b}{l} \times S \times \pi \times A = 1.1 \frac{W}{g} \times \delta_0 \times v^2 \quad (7)$$

In the above equation v_{max} and v_{min} denote the greatest and least circumferential velocity in the path of the circle described by the centre of gyration of the rim section.

Since in four-cycle engines the work done during one cycle or two revolutions of the crank is always the same, the equations and formulas given above may be used for all standard types of engine, because the tangential pressures, and therefore the turning moment diagram corrected for inertia, are practically the same in all.

Example.—We take a single-acting four-cycle engine with—

Cylinder diameter = 12 inches.

Stroke = 16 inches or 1.33 feet.

Number of revolutions = 210 per minute.

Diameter of flywheel D_0 = 7 feet 3 inches.

The engine is supposed to work with δ_0 degree of irregularity = $1/80$. It is required to determine the weight of the flywheel.

For calculating the turning moment diagram corrected for inertia, we will use the diagram at p. 38. (Explosion pressure 27 atmospheres = say, 400 lbs. per sq. inch, p = 90 lbs. per sq. inch.)

Measured from Fig. 9, we get—

Length of greatest area above mean TM line u = 0.131 foot.

Height h = 0.36 "inch $\times$ 180 lbs. = 65 lbs. per sq. inch.

(since in the diagram 1 inch = 180 lbs.).

Circumference of circle described by the crank, measured from Fig. 9, l = 0.29 foot.

$$\text{Then } u \times \frac{h}{l} = 0.131 \times \frac{65}{0.29} = 29.4$$

Next,

Area of motor cylinder $A = \frac{\pi}{4} \times 12^2 = 113$ sq. inches (according

to equation 4A, p. 18).

From equation 5, p. 39, radius of centre of gravity of rim section, $R = 0.45 \times 7$ feet 3 inches = 3.26 feet.

From equation 2, p. 39, $v = \frac{3.26 \times \pi \times 210}{30} = 71.6$, or say, 72 feet per second.

The weight of the rim, according to equation 4, will thus be—

$$W = 92 \times 29.4 \times \frac{113 \times 1.33}{72^2} \times \frac{1}{\delta_0} = 78.5 \times \frac{1}{\delta_0}$$

For $\delta_0 = \frac{1}{80}$, $W = 78.5 \times 80 = 6280$ lbs.

It should be noted that this degree of irregularity δ can only occur when the engine is running at maximum load (that is, with an ignition at every two revolutions). At less load the irregularity fluctuates, being greater or less, according to the method of governing. We shall return to this point later.

As regards the permissible amount of cyclic irregularity δ_0 , see chapter on "Flywheels."

II. Double-acting Four-cycle Engine, D 4, One Cylinder.

To obtain accurate tangential pressure or turning moment diagrams in *double-acting*, *multi-cylinder four-cycle* engines, special attention must be paid to the sequence of ignitions.

The moment of ignition with reference to the stroke should also be noted, and whether the ignitions take place during the out- or in-stroke, because the inertia of the moving parts is not the same at the front and the back end of the cylinder.

In double-acting four-cycle engines, as already explained at p. 9, the ignitions are shifted 180° and 540° respectively, occurring after the first and third stroke, and the diagrams of pressure must be made to correspond with this arrangement.

A *continuous diagram* is first drawn, as in single-acting engines, and allowance being made for the inertia of the moving parts, the resultant pressure curves are plotted over it (comp. Fig. 10).

With the help of Figs. 5 to 7, the tangential pressure or turning moment is then determined for different positions of the crank, and carried out for the whole circle described by the crank (Fig. 11).




Fig. 10.—Continuous Energy Diagram.

The turning moment curve is obtained by drawing a curve through the points thus found.

If the area enclosed by the neutral line BB' and the turning moment curve be converted into a rectangle, it gives the mean pressure reduced to the crank circle, represented in Fig. 11 by the area $BCC'B'$. The line CC' cuts the turning moment curve at several points. The areas above and below this line are converted in the same way into rectangles, and the largest is used as the basis of calculation.

The weight of the flywheel is calculated in the same way as in the single-acting engine (comp. p. 39), but the mean pressure is twice as great.




Fig. 11.—Plotting the Turning Moment, and Conversion of the Projecting Areas into Rectangles.

III. Vis-à-vis Four-cycle Engine, G Z 4, Two Cylinders.

As already explained at p. 10, the sequence of ignitions in this engine is the same as in double-acting four-cycle engines. In both types the weight of the flywheel can be taken as the same. Theoretically this is not quite accurate, but the approximation is sufficiently close for practical purposes.



Fig. 12.—Vis-à-vis Four-cycle Engine.

The turning moment diagram, corrected for inertia, Fig. 11, can therefore be used as a basis from which to calculate the flywheel.

IV. Twin Four-cycle Engine, Z 4, Two Cylinders.

From the explanation given at p. 11 of the working method of this engine, it will be seen that the ignitions succeed each other at 360° interval; that is, an ignition follows at each revolution of the crank, or double stroke to and fro of the piston. Hence the diagrams must be shifted, and follow each other in the same order.

A resultant pressure curve cannot be obtained by adding the pressure diagrams of the two cylinders together, because the motor strokes of the two pistons never take place at the same time. Separate turning moment diagrams must be drawn for each cylinder, and combined to form a resultant curve of tangential pressures.

Example.—To show the effect of the double action on the weight of the rotating parts, we will determine the weight of the flywheel rim section for a double-acting engine, having the same dimensions as in the example at p. 40, namely $D = 12$ inches, $S = 16$ inches (1.33 feet), $n = 210$, $\delta_0 = \frac{S}{D} = 0.0125$; diameter of flywheel 7 feet 3 inches.

From p. 18 we get—

Equation 4a : Area of motor cylinder—

$$A = \frac{\pi}{4} \times 12^2 = 113 \text{ sq. inches.}$$

Equation 5, p. 39 : Radius of centre of gravity of rim section—

$$R = 0.45 \times 7.3 = 3.26 \text{ feet.}$$

Equation 2, p. 39 : Circumferential velocity around path described by centre of gravity of rim section—

$$v = \frac{3.26 \times \pi \times 210}{30} = 72 \text{ feet per second.}$$

Length of greatest area above the mean TE line—

$$u = u_1 + u_2 = 0.156 \text{ feet} + 0.165 \text{ feet} = 0.321 \text{ feet.}$$

Height of greatest area above the mean tangential effort line—

$$b = 0.196 \text{ inch} \times 180 \text{ lbs.} = 35.3 \text{ lbs. per sq. inch (because the scale is 1 inch = 180 lbs.)}$$

Circle described by crank-pin measured on the diagram $l = 0.295$ feet—

$$\frac{b}{l} = 0.321 \frac{35.3}{0.295} = 38.4 \text{ lbs. per sq. inch.}$$

From equation 4, weight of flywheel rim—

$$W = 92 \times 38.4 \frac{113 \times 1.33}{72^2} \times \frac{1}{\delta_0} = 101.5 \times \frac{1}{\delta_0}$$

For $\delta_0 = \frac{S}{D}$ then $W = 101.5 \times 80 = 8120 \text{ lbs.}$

The turning moment diagram is first drawn for one cylinder, according to the method described at pp. 35 *et seq.* The shape of the diagram is the same as for the single-acting four-cycle engine, Fig. 8, p. 38. The starting-point of the second diagram is shifted 360° , or two single strokes beyond the first (Fig. 14). Both diagrams being plotted, the different




Fig. 13.—Twin Four-cycle Engine.

tangential pressures are added together by the graphic method, as shown at Fig. 14, and a third curve, the so-called *Resultant* is obtained.

If the area enclosed by the neutral line BB' and the resultant be planimetered, it gives the distance of the line CC' from the neutral line. This distance $BC = B'C'$, corresponds to the *mean tangential pressure* reduced to the crank circle.

The areas above the line of mean tangential pressure are then converted into rectangles, and the *largest* (Fig. 14) is taken as the basis of calculation.




Fig. 14.—Plotting the Resultant Turning Moment Curves, and Conversion of the Projecting Areas into Rectangles.

Example.—To facilitate comparison with a single-acting engine, we will as before take an engine having the same dimensions as the one at p. 40, and determine the weight of the rim section of the flywheel. Thus $D = 12$ inches; $S = 1.33$ feet; $n = 210$; $\delta_0 = 0.0125 = \frac{1}{80}$. Diameter of flywheel, 7 feet 3 inches.

From p. 18 we have—

Equation 4A: Area of each motor cylinder—

$$A = 113 \text{ sq. inches.}$$

Equation 5, p. 39: Circle described by centre of gravity of rim section—

$$R = 0.45 \times 7 \text{ feet } 3 \text{ inches} = 3.26 \text{ feet.}$$

Equation 2, p. 39: Circumferential velocity around path described by centre of gravity of rim section—

$$v = 72 \text{ feet per second.}$$

By measurement from Fig. 14—

Length of the greatest area above mean tangential pressure line—

$$u = 0.125 \text{ feet.}$$

Height of the greatest area above mean tangential pressure line—

$$b = 0.323 \times 180 \text{ lbs.} = 58 \text{ lbs. per sq. inch.}$$

Circle described by crank (measured from diagram) $l = 0.293$ feet.

$$\text{Therefore } \frac{b}{l} = \frac{58}{0.293} = 198 \text{ lbs. per sq. inch.}$$

Then by equation 4: Weight of flywheel rim section—

$$W = 92 \times 25 \times \frac{113 \times 1.33}{72^2} \times \frac{1}{\delta_0} = 66.7 \times 1$$

For $\delta_0 = \frac{1}{80}$; then $W = 66.7 \times 80 = 5340 \text{ lbs.}$

V. Tandem Four-cycle Engine, R 4, Two Cylinders.

In this type of engine (compare p. 12) the ignitions also occur at intervals of 360° . It should be noted that in these engines the inertia of the moving parts is greater than in single-cylinder engines, because there are two pistons to be allowed for.

In Fig. 15 the two diagrams are continuously developed. The dotted lines denote the back, and the punctuated lines - - - - - the front cylinder. The resultant pressure curves, taking into account the effect of the reciprocating parts, were then determined, and have been plotted as full lines in Fig. 15.

With the help of the diagrams in Figs. 5-7, and the explanation there given, the turning moment diagram corrected for inertia can be plotted for this type of engine (Fig. 16). The areas




FIG. 15.—Continuous Diagram of Energy.




FIG. 16.—Plotting the Turning Moment Curves, and Conversion of the Projecting Areas into Rectangles.

Circle described by crank measured from the diagram $l = 0.293$ feet

$$u_l = 0.125 \frac{58}{0.293} = 24.8 \text{ lbs. per sq. inch.}$$

Equation 4, p. 39: Weight of rim section of flywheel—

$$W = 92 \times 24.8 \times \frac{113 \times 1.33}{72^2} \times \frac{1}{\delta_0} = 66.3 \times \frac{1}{\delta_0}$$

For $\delta_0 = \frac{1}{30}$; then $W = 66.3 \times 80 = 5300$ lbs.

VI. Double Vis-à-vis Four-cycle Engine, Z G Z 4, Four Cylinders.

According to the explanation given at p. 13 of the working method in this engine, there is an ignition at full load at every 180° of the crank circle, in other words, at every stroke to and fro of the piston. Since during each stroke the sequence of operations is the same in one or other of the four cylinders, the weight of the flywheel can be calculated by drawing the turning moment diagram for a single stroke.

The diagram of tangential pressure, or turning moment corrected for inertia, may be plotted from two different points of view, namely—

1. As shown at pp. 35 *et seq.*, the turning moment diagram may be drawn for one cylinder, in other words, for a single-acting four-cycle engine, as at Fig. 17, which is a reproduction of the tangential pressure or turning moment diagram (Fig. 8) to a smaller scale.




Fig. 17.—Turning Moment Diagram for One Cylinder.

between the turning moment curve and the neutral line BB' being planimetered, the weight of the mean tangential pressure

is determined, and the line CC' (Fig. 16) drawn. The areas above the line are converted into rectangles, and their extent determined as before.

Example.—The weight of the rim of the flywheel to be determined for a tandem, single-acting, four-cycle engine of the same dimensions as the example at p. 40, namely, $D = 12$ inches; $S = 1.33$ feet (16 inches); $n = 210$, $\delta_0 = 0.0125$. Diameter of flywheel, 7 feet 3 inches.

From p. 39—

Equation 4A, p. 18: Sectional area of one motor cylinder—

$$A = \frac{\pi}{4} \times 12^2 = 113 \text{ sq. inches.}$$

Equation 5, p. 39: Radius of centre of gravity of rim section—

$$R = 0.45 \times 7 \text{ feet } 3 \text{ inches} = 3.26 \text{ feet.}$$

Equation 2, p. 39: Circumferential velocity around path described by centre of gravity of rim section—

$$v = \frac{3.26 \times \pi \times 210}{30} = 72 \text{ feet per second.}$$

Length of greatest area above the mean tangential pressure line—

$$u = 0.125 \text{ feet.}$$

Height of the greatest area above the mean tangential pressure—

$$b = 0.323 \text{ inch, therefore } = 0.323 \times 180 \text{ lbs.} = 58 \text{ lbs. per sq. inch (since the scale is 1 inch} = 180 \text{ lbs.)}$$

The turning moment curves for the four simultaneous strokes are next combined, and plotted one over the other,




Fig. 19.—Double Vis-à-vis Four-cycle Engine.




Fig. 18.—Resultant Pressure Curve.




Fig. 20.—Determination of the Mean Pressure, and Conversion of the Projecting Areas into Rectangles.

as for one piston stroke (Fig. 18). They are then added together, and combined into one resultant curve, which may be used as the basis of calculation. The diagram, Fig. 18, shows the simultaneous action taking place in each cylinder, and in Fig. 20 the curves are numbered, to correspond with the strokes. For the operations carried out during each stroke, see p. 7.

By planimetering the areas enclosed by the neutral line BB' and the resultant pressure curve, their mean height is determined, and thus the mean pressure which, when reduced to the crank circle, is represented in Fig. 20 by the area $BCC'B'$.




Fig. 21.—Energy Diagram for First and Third Cylinders.




FIG. 22.—Energy Diagram for Second and Fourth Cylinders.
(Line x is plotted from (x) , and h from (h) .)

The areas projecting above and below line OC' are converted into rectangles, and the largest taken as the basis of further calculation (compare p. 39).

2. Draw the pressure curves for each pair of cylinders (1 and 3, and 2 and 4) in Fig. 16, as given at p. 36, and determine the resultant pressure curves. Two diagrams must be plotted, because the movement of the crank and piston are not the same in the two *vis-à-vis* cylinders.

The turning moment curves, as given in Figs. 5 to 7, are next drawn for each pair of cylinders (Fig. 23) and added together to form the resultant pressure curve (Fig. 28).




FIG. 23.—Plotting the Turning Moment, Determination of the Resultant, and of the Mean Pressure, and Conversion of the Projecting Areas into Rectangles. (Line a is plotted from (a) , and e from (e) .)

$$W = 92 \times 5.87 \times \frac{113 \times 1.33}{72^3} \times \frac{1}{s_0} = 15.7 \times \frac{1}{s_0}$$

For $s_0 = s_0'$; then $W = 15.7 \times 80 = 1260$ lbs.

To determine the mean height = mean pressure reduced to the crank circle, the areas enclosed by the resultant and the neutral line BB' are planimetered. In Fig. 23 the line BC is equal to the mean effort.

The areas above and below line CC' are converted into rectangles, the largest is taken, and the calculation worked out in the same way as at p. 40 for a single-cylinder engine.

In Fig. 23 the rectangles u , b are equal, and are larger than the areas below line CC'.

Example.—For a double *vis-à-vis* four-cycle engine, each of the four cylinders of which is of the same dimensions as the example given at p. 40, viz. $D = 12$ inches; $S = 1.33$ feet (16 inches); $n = 210$; $s_0 = s_0' = 0.0125$. Diameter of fly-wheel 7 feet 3 inches. The weight of the rim section of the flywheel to be determined.

Here (compare example, p. 40) $A = 113$ sq. inches; $v = 72$ feet per second (area of one cylinder only to be taken).

From the turning moment diagram (Fig. 23)—

Length of greatest projecting area $u = 0.0566$ foot.

Height of greatest projecting area $b = 0.17$ inch.

Therefore $= 0.17 \times 180$ lbs. $= 30.6$ lbs. per sq. inch (since the scale is 1 inch = 180 lbs.).

Circumference of circle described by crank pin $l = 0.295$ foot.

$$\text{therefore } u \frac{b}{l} = 0.0566 \frac{30.6}{0.295} = 5.87 \text{ lbs. per sq. inch.}$$

Equation 4, p. 39: Weight of rim of flywheel—




Fig. 24.—Energy Diagram for a Twin Double-acting Four-cycle Engine.

VII. Twin Double-acting Four-cycle Engine, Z D 4, Two Cylinders.

For an explanation of the working method in this engine see p. 14. The sequence of working strokes is shifted 180°, i.e. there is an explosion for every half-revolution of the crank shaft. As there are two cylinders, the inertia of the reciprocating parts must be twice allowed for.

The method of drawing the diagram is shown at Fig. 24. The turning moment diagram (Fig. 25) is constructed as shown at pp. 35 *et seq.* The mean pressure reduced to the crank circle is determined by planimetry the areas enclosed by the neutral line BB' and the turning moment curve. The line BC = B'C' corresponds to the mean pressure. The areas projecting above and below the line CC' are converted as before into rectangles, and the largest (Fig. 25) is taken as the basis of calculation.

Example.—To make a comparison with the single-acting four-cycle engine, the same dimensions as those given at p. 40 are again taken for determining the weight of the rim of the flywheel, $D = 12$ inches, $S = 1.33$ feet (16 inches), $n = 210$, $\delta_0 = \frac{1}{8}$ in. Diameter of flywheel, 7 feet 3 inches.

Equation 4A, p. 18: Sectional area of one motor cylinder—

$$A = 113 \text{ sq. inches.}$$

Equation 5, p. 39: Radius of centre of gravity of rim section—

$$R = 3.26 \text{ feet.}$$

Equation 2, p. 39: Circumferential velocity around path described by centre of gravity of rim section—

$$v = 72 \text{ feet per second.}$$




Fig. 25.—Plotting the Turning Moment Curve, and Conversion of the Projecting Areas into Rectangles.

Measured from Fig. 25—

Length of the greatest projecting area $u = 0.086$ foot.

Height of the greatest projecting area $b = 0.176$ inch.

therefore $= 0.176 \times 180 \text{ lbs.} = 31.7 \text{ lbs.}$ per sq. inch.

Circumference of circle described by crank-pin measured on diagram (Fig. 25)—

$$l = 0.295 \text{ foot}$$

$$\text{therefore } u \cdot l = 0.086 \cdot \frac{31.7}{0.295} = 9.25 \text{ lbs. per sq. inch.}$$

Then by equation 4: Weight of flywheel rim—


$$W = 92 \times 9.25 \cdot \frac{113 \times 1.33}{72^2} \times \frac{1}{\delta_0} = 24.7 \times \frac{1}{\delta_0}$$

For $\delta_0 = \frac{1}{8}$ in; $W = 24.7 \times 80 = 1980 \text{ lbs.}$

VIII. Tandem Double-acting Four-cycle Engine, R D 4.

As already explained at p. 15, the ignitions in this type of engine occur at intervals of 180° ; in other words, there is an ignition (or explosion) at every half-revolution of the crank shaft.

A continuous diagram (as at Fig. 26) is first plotted. Here the lines of the diagrams representing the work done on each face of the piston are denoted by similarly dotted lines. Allowance being made for the inertia of the moving parts, the resultant pressure diagram is drawn in thick lines in the same diagram (Fig. 26).



The turning moment diagram (Fig. 27) is then constructed, in the way described at p. 34. The areas enclosed by the neutral line BB' and the pressure curve are converted by the planimeter into a rectangle of the same area, the height being equal to the mean pressure reduced to the circle described by the crank. In Fig. 27 BC = B'C' is equal to the mean effort.

The areas projecting above and below CC' are next converted into rectangles, and the largest of them is taken as the basis of calculation.

Example.—The same dimensions are taken as in the former examples, viz.—

Area of one motor cylinder, $A = 113$ sq. inches.

Circumferential velocity in circle described by centre of gravity of flywheel, $v = 72$ ft. per second.

From Fig. 27:

Length of greatest projecting area $u = 0.08$ foot.

Height of greatest projecting area $b = 0.2$ inch.

therefore $b = 0.2 \times 180$ lbs. = 36 lbs. per sq. inch.

FIG. 26.—Energy Diagram.

Circumference of circle described by the crank $l = 0.295$ foot, therefore $\frac{b}{l} = 0.08 \times \frac{36}{0.295} = 9.75$ lbs. per sq. inch.

By equation 4: Weight of flywheel rim—

$$W = 92 \times 9.75 \times \frac{113 \times 1.33}{7.2^2} \times \frac{1}{8} = 26 \times \frac{1}{8_0}$$

For $\delta_0 = \frac{1}{8_0}$; $W = 26 \times 80 = 2080$ lbs.




FIG. 27.—Plotting the Turning Moment Curve, and Conversion of the Projecting Areas into Rectangles.


APPENDIX TO CHAPTER V.

NOTE.—The tables and curves given in this Appendix were worked out by Mr. H. A. Humphrey, M.I.C.E., M.I.E.E., etc., and are reproduced by his kind permission. See his contribution to the discussion on Messrs. Allen and Porter's paper, entitled "Use of Gas Engines for Generating Electric Power," read before the Institution of Electrical Engineers, February 25, 1909. Minutes of the Proceeding of the Institution of Electrical Engineers, No. 196, Vol. 43.

TABLE A.

WEIGHT OF RECIPROCATING PARTS OF LARGE GAS ENGINES AND ACCELERATION PRESSURES DUE TO THE RECIPROCATING MASSES (THE ACCELERATION PRESSURES ARE THE MEAN OF THE VALUES AT THE TWO DEAD CENTRES), BASED ON PARTICULARS FURNISHED BY THE RESPECTIVE MAKERS.

Firm.	Size of engine.	Total weight of reciprocating parts.	Weight per unit of piston area. Kg. per cm. ²	Revolutions per minute.	$\frac{m}{r}$ Kg. per cm. ² of piston.
		Kilogrammes.			
Gasmotoren Fabrik Deutz (Otto cycle)	2,000 B.H.P. (1,100 mm. × 1,300 mm.) (double-acting tandem)	23,700	2.66	94	17.10
Erhardt & Sehmer (Otto cycle)	2,000 B.H.P. (1,150 mm. × 1,300 mm.) (double-acting tandem)	20,000	2.06	94	13.25
Nurnberg (Otto cycle)	1,000 B.H.P.	7,200	1.64	125	14.30
	1,200 B.H.P.	8,600	1.57	107	10.80
	500 B.H.P.	3,500	1.21	128	8.31
Premier (Otto cycle)	1,200 B.H.P.	7,220 (two single-acting tandem sets)	1.585	120	10.70
Mather & Platt (2-cycle)	1,000 B.H.P. (2-cycle Korting)	2,687	0.95	110	6.44
Richardsons, Westgarth & Co. (Otto cycle)	1,000 B.H.P. (double-acting tandem)	7,250	1.24	107	7.92
	500 B.H.P. (double-acting tandem)	3,600	1.40	125	9.80
Bechem & Keetman (Otto cycle)	1,000 B.H.P. (double-acting tandem)	3,940	0.78	107	5.00
Snow Steam Pump Works (Otto cycle)	5,400 B.H.P. (double-acting twin-tandem)	20,500 (total mass per line)	2.63	88	17.35



10.

g rod to crank, 5:1. Weight of reciprocating parts, 23,700 kg.

? piston area, $17.1 \text{ kg. } \left(= \frac{Mv^2}{r} \right)$.

REN FABRIK DEUTZ.

FOR QUANTITY GOVERNING.

n crank pin due to indicator diagram pressures per cm^2 .

5 kg. per cm^2 mean effective pressure of diagram.

am 2.7 kg. per cm^2 .

am 1.5 kg. per cm^2 .


kg. per cm^2 (actual value).

Quantity Governing.

on of curves d and } of Fig. A (M.E.P. = 5.5 kgs. per cm.²)

" " f " } " A { " = 2.7 " "


" " " " } " A { " = 1.5 " "



A4 is obtained by integrating curve A4.

A5 " " " " A5.


A6 " " " " A6.



B4 is obtained by integrating curve B4.

B5 " " " " B5.

B6 " " " " B6.



are not exactly the true means.


).

Diagram and the forces due to the inertia are algebraically added.


on the mean velocity.

motor with 32 poles. Weight of flywheel to give total angular deviation of


Curve A7 combines curves a and g of Fig. A.
 " A8 " " " a " h "



Curve B7 is obtained by integrating curve A7
 " B8 " " " " A8.



Curve C7 is obtained by integrating curve B7.
 " C8 " " " " B8.



For further particulars, diagrams and curves, see Figs. A and B and curves 1 to 8 of Fig. D.

FIG. C.—2000-B.H.P. Double-acting Tandem Gas Engine (Deutz).

Curves A7 and A8 in this Fig. are directly comparable with curve A1 in Fig. B, and show the effect of combining the full-load tangential pressure of curve A (quality governing) with the reduced inertia forces obtained from curves g and h in Fig. A.

(For further particulars and curves, see Figs. A to C.)

(For further particulars and curves, see Figs. A to C.)




FIG. D.—Turning Moment Curves for Large Gas Engines.


Curves from 1 to 8 are for 2000-B.H.P. double-acting tandem gas engine (Dents), and are taken from Figs. A to D, and Curves 1 and 2 show in each case the first 5 harmonics in Fourier series.

ON FIG. D.

Harmonics.			
	3rd.	4th.	5th.
	$655 \cos (3\theta + 93^\circ) +$ 0.473	$1.425 \cos (4\theta + 223^\circ) +$ 0.407	$0.370 \cos (5\theta + 233^\circ)$ 0.106
14	$\cos (3\theta + 94^\circ) +$ 1.26	$0.778 \cos (4\theta + 249^\circ) +$ 0.458	$0.180 \cos (5\theta + 291^\circ)$ 0.106
05	$\cos (3\theta + 176^\circ) +$ 2.28	$0.678 \cos (4\theta + 8^\circ) +$ 0.753	$0.303 \cos (5\theta + 17^\circ)$ 0.337
85	$\cos (3\theta + 175^\circ) +$ 0.529	$1.3 \cos (4\theta + 41^\circ) +$ 0.372	$0.315 \cos (5\theta + 7^\circ)$ 0.09
02	$\cos (3\theta + 175^\circ) +$ 1.19	$0.690 \cos (4\theta + 60^\circ) +$ 0.406	$0.089 \cos (5\theta + 40^\circ)$ 0.052
065	$\cos (3\theta + 180^\circ) +$ 2.29	$0.602 \cos (4\theta + 45^\circ) +$ 0.669	$0.19 \cos (5\theta + 27^\circ)$ 0.211
527	$\cos (3\theta + 168^\circ) +$ 0.151	$1.487 \cos (4\theta + 45^\circ) +$ 0.425	$0.342 \cos (5\theta + 42^\circ)$ 0.098
005	$\cos (3\theta + 138^\circ) +$ 0.288	$1.43 \cos (4\theta + 46^\circ) +$ 0.409	$0.276 \cos (5\theta + 52^\circ)$ 0.079
789	$\cos (3\theta + 126^\circ) +$ 0.147	$1.952 \cos (4\theta + 54^\circ) +$ 0.365	$0.239 \cos (5\theta + 54^\circ)$ 0.045
36	$\cos (3\theta + 135^\circ) +$ 0.313	$37.8 \cos (4\theta + 62^\circ) +$ 0.298	$6.4965 \cos (5\theta + 76^\circ)$ 0.051
01	$\cos (3\theta + 180^\circ) +$ 0.114	$30.51 \cos (4\theta + 41^\circ) +$ 0.504	$6.772 \cos (5\theta + 15^\circ)$ 0.112
2	$\cos (3\theta + 132^\circ) +$ 0.092	$59.85 \cos (4\theta + 41^\circ) +$ 0.494	$11.69 \cos (5\theta + 72^\circ)$ 0.096
4.5	$\cos (3\theta + 289^\circ) +$ 0.205	$354.35 \cos (4\theta + 227^\circ) +$ 0.0114	$3,378.0 \cos (5\theta + 86^\circ)$ 0.109

1 engine cranks

- obtaining crank pin tangential forces for pump parts.



pp from actual indicator diagrams.

ies in air & gas pump from actual indicator diagrams


pressures to ordinates of curves m_1 & m_2 .

loss due to inertia of reciprocating parts

- both indicated pressures & forces due to inertia

defined by combining curves p_1 & q_1 & p_2 & q_2 .

ivalent pressures per cm² of main piston area.




cted for actual positions of piston

pressure curves for pump cylinder.

pressure curves for pump cylinder.
 crank pin for one set of pumps due to indicator diagram pressures & inertia forces

frank pin for one set of
" " " both sets "



Curve plotted on developed crank circle

Location of curves see Fig. F and curve 9, Fig. D.

Engines with Cranks at 90°.

000 mm. Revs. 110 per minute. Air and gas pumps, 650 mm.

Weight of one line of pump parts, 623 kg. ($\frac{Mv^2}{r} = 1.27$ kg. per cm.²)




FIG. F.—1000-B.H.P. 2-cycle Körting Gas Engine.
(Messrs. Mather & Platt, Ltd., Engineers.)

DIMENSIONS OF ENGINE—

Twin double-acting cylinders. Cranks at 90°.
Main cylinders: Diameter, 600 mm. Stroke, 1000 mm.
Pump cylinders: Diameter, 650 mm. Stroke, 850 mm.
Revs. per minute, 110.

FLYWHEEL—

Alternator rotor equivalent to 28 tons at 11.9 ft. diameter.
G.D.² = weight × diameter² = 3957 ton-feet² = 374,000 kg.-metres².

CALCULATION OF DEGREE OF IRREGULARITY—

Notation—

M = Difference between turning moment on crank and mean resisting torque in kg.m.
I = Moment of inertia of flywheel (mass × rad. of gyration², in kg.-metre/sec.²).
g = Acceleration due to gravity = 9.81 metres/sec.².
G.D.² = Moment of flywheel in kg.-metre².
ω = Angular velocity in rad./sec.
t = Time in seconds.

$$\delta = \text{Degree of irregularity} = \frac{\omega_{\text{max}} - \omega_{\text{min}}}{\omega_0}$$

$$M dt = I d\omega = \frac{G.D.^2}{4g} d\omega \quad \omega - \omega_0 = \frac{4g}{G.D.^2} \int M dt.$$

$$\text{Angular Deviation} = \int (\omega - \omega_0) dt.$$

TABLE OF FLYWHEEL WEIGHTS.

Mean Rim Speed.	75 Feet/Sec.			90 Feet/Sec.		
δ	250	300	350	250	300	350
G.D. ² ft. ² tons ...	2,250.0	2,700.0	3,145.0	2,250.0	2,700.0	3,145.0
D ft.	13.0	13.0	13.0	15.6	15.6	15.6
D ²	169.0	169.0	169.0	244.0	244.0	244.0
Rim weight G, tons	13.3	16.0	18.6	9.2	11.9	12.9
Total weight ...	18.0	21.6	25.1	12.4	14.9	17.4

(For other Diagrams and Curves, see Fig. E.)




FIG. G.



Before proceeding to treat of the *different parts of the engine*, it is necessary clearly to understand the forces acting upon them, which have to be taken into account.

CHAPTER VI.

Forces acting on the Cross Head, Piston, Connecting Rod, and Main Bearings.

(a) Forces acting on the Cross Head.

THE pressures developed in gas engines are of many kinds. They depend not only on the dimensions of the engine and the explosion pressures, but also on the clearance or slack in the brasses, or any slackness of the flywheel on the shaft, or of the frame on the foundation, or to any sudden rise in pressure due to pre-ignition, and so forth.

It is impossible to estimate these *accidental pressures* accurately, and we are obliged, therefore, to determine the strength of the different parts of the engine by calculating the *theoretical pressures only*. Of these we have specially to consider—

1. *Forces acting on the cross head.*
2. *Pressure on the crank-shaft bearings.*

The strength of many parts of the engine—for instance, of the frame—can only be tested in a few places. Thus it is hardly possible to determine the shearing stress on the holding-down or foundation bolts, because the strains on them are of a very complex nature. In this case it is usual to adopt dimensions that have been arrived at by practical experience. Any calculations the results of which deviate considerably from those obtaining in practice should be rejected.

1. Forces acting on the Piston Rod, Connecting Rod, Crank Pin, and Crank Journals.

The maximum pressure developed in the neighbourhood of the dead point is—

$$P' = A \times p \text{ in lbs. per sq. inch} \quad \dots (1)$$

A being the area of the cylinder in sq. inches, and P being pressure of explosion in lbs. per sq. inch (Fig. 1).

We will take a value within working limits, making due allowance for the continually increasing pressures of compression and explosion. In order to have the working parts strong enough to bear powers above the normal rated horse power, let—

$$p = 26 \text{ atmospheres above atmospheric pressure}^* (= 370 \text{ lbs. per sq. inch}) \quad (2)$$

With hit-and-miss governing, the full pressure of explosion must be taken into account, even if, as at less than full load, it is not often developed. If the engine is governed by




FIG. 1.

* As much as 30 atmospheres (430 lbs. per sq. inch) are sometimes allowed for.

varying the proportions of the charge, that is, an ignition is obtained at each working stroke (and therefore, in four-cycle engines, for every two revolutions of the crank shaft), the pressure of explosion varies. We must, however, take the *maximum* pressure developed as a basis of calculation.

2. Pressure on the Crank-shaft Bearings.

These bearings form one of the most important parts of the engine, and it is necessary for the engineer clearly to understand the pressures acting on them.

This he can only do by working out an example for himself—

We take the case of a single-cylinder, four-cycle engine with two bearings, and therefore having the flywheel overhung at the end of the crank shaft. What are the pressures on the bearings at the different crank positions? in which position is the greatest pressure developed? and in what direction is it exerted?

Further, can the engine continue running if the caps are taken off the bearings?




FIG. 2.




FIG. 3.—Diagram of Forces.




FIG. 4.—Plotting the Thrust.

First draw the diagram of forces without taking the length of the crank shaft or weight of the flywheel into account (Fig. 3).

We are dealing here with a *cranked shaft* (with two crank arms), and therefore two bearings (Fig. 2), but for the sake of simplicity the diagram of effort is shown with one crank only (Figs. 3 and 4).

Let P' be the pressure on the *piston* in lbs.

P be the thrust on the connecting rod in lbs.

K be the *vertical* pressure exerted on the cylinder liner in lbs. (Fig. 3).

β be the angle of inclination of the connecting rod in degrees (Fig. 8, p. 27).

Then the—

$$\text{Thrust } P = \frac{P'}{\cos \beta} \quad \dots \dots \dots (3)$$

With ordinary lengths of the connecting rod the maximum is $\beta = 10^\circ$, corresponding to $\cos \beta = 0.985$, where—

$$P = \frac{P'}{0.985} = \text{about } 1.015 + P'.$$

This difference is so small that it may be neglected, and we may make—

$$P = P' \quad \dots \dots \dots (4)$$

The pressure P is resolved into T , tangential pressure or turning moment, and C radial pressure, Fig. 4 (compare p. 34).

The energy expended in these two directions can easily be calculated, if the pressure on the piston at the corresponding crank position is known. If we suppose the bearings to be in the same plane as the crank pin, then the pressure on the two bearings will be equal in extent and direction to that on the crank pin.

As both the main bearings are at the same distance from the crank pin, and are thus symmetrically arranged (Fig. 2), then the—


$$\text{Pressure on the bearings} = \frac{P}{2} \quad \dots \dots \dots (5)$$

P being the pressure exerted by the piston corresponding to the simultaneous pressure on the connecting rod.

The pressure on the crank-shaft bearings, and the direction in which it is developed, vary for each position of the piston. It is greatest during explosion, and decreases during the expansion stroke, and the following exhaust, admission, and compression strokes.

Effect of the Flywheel on the Pressure on the Bearings.

The weight W of the flywheel acts downwards at right angles, and endeavours on the flywheel side to hold the shaft down on the lower brass of the main bearing A_2 and against the cap of the bearing A_1 on the other side.



From Fig. 5 we get—

Bearing on outer side, A_1 —

$$\text{Left-hand turning moment: } M_l = A_1(g + a)$$

$$\text{Right-hand turning moment: } M_r = W \times l$$

$$\text{Hence pressure upward on the bearing } A_1 = \frac{W \times l}{g + a} = W \times \frac{l}{L} \quad \dots \dots \dots (6)$$

Main bearing at A_2 —

$$\text{Left-hand turning moment: } M_l = A_2 \times (g + a)$$

$$\text{Right-hand turning moment: } M_r = W \times (L + l)$$

$$\text{Therefore downward pressure on the bearing } A_2 = W \frac{L + l}{g + a} = W \times \frac{L + l}{L} \quad \dots \dots \dots (7)$$

As there are two bearings, and the weight of the flywheel has a different effect on each, they must be treated separately.

I. Bearing on Outer Side (commonly called the Side-shaft Side), A_1 .

After the above explanation, we can draw the diagram for this bearing, Fig. 6.




FIG. 6.—Without a Flywheel.

P is the magnitude and direction of the thrust on the connecting rod.

0.5 P " " " " this pressure on the main bearing (neglecting the flywheel, Fig. 6).

a would be the theoretical point of contact of the journal with the brass of the bearing (neglecting the flywheel).

R_1 is the direction and magnitude of the resultant pressure.

b is the theoretical point of contact of the journal and brass under this pressure (with a flywheel, Fig. 7).




FIG. 7.—With a Flywheel.

Thus the effect of the flywheel is always to shift the point of contact in this outer bearing slightly upwards.

II. Main Bearing (Flywheel Side), A_2 .

Here




FIG. 8.—Without a Flywheel.




FIG. 9.—With a Flywheel.

The letters have the same meaning as before, when dealing with the outer bearing A_1 , but Fig. 9 shows that the resultant pressure R_2 is directed downwards, because the weight of the flywheel is exerted downwards.

We will now calculate a numerical example for a single-acting four-cycle engine, having cylinder diameter $D = 16$ inches; effective cylinder area $A = 201$ sq. inches; stroke $S = 22$ inches; explosion pressure = 400 lbs. per sq. inch, weight of flywheel $W = 11,600$ lbs.




FIG. 10.

Outer Bearing.

Main Bearing.

The dimensions of that part of the crank shaft which must be taken into account are given at Fig. 10.

We will base our calculations on the diagram Fig. 3A (p. 36), showing

the inertia of the moving parts, but will confine ourselves to the third stroke (explosion and expansion). Compare Fig. 11.

If the actual pressures be calculated for crank positions 1, 5, and 10, they work out as follows :—

Table I.—Pressure on the Bearings.

For Crank Positions.	Measured from Fig. 11.	On the Crank Pin.	On the Bearings.
1	$p_1 = 1\frac{1}{2}$ in. = 230 lbs. per sq. in.	$P = A \times p_1 = 201 \times 230 = 46,230$ lbs.	$0.5 \times P = 23,115$ lbs.
5	$p_5 = .5$ " = 90 " " "	$P = A \times p_5 = 201 \times 90 = 18,090$ "	$0.5 \times P = 9,045$ "
10	$p_{10} = .85$ " = 64 " " "	$P = A \times p_{10} = 201 \times 64 = 12,864$ "	$0.5 \times P = 6,432$ "

A = area of the cylinder in sq. inches.

This result is the same for both bearings, but the influence of the flywheel is exerted in different directions.




FIG. 11.—Diagram of the Third Stroke.




FIG. 12.—Diagram of Actual Pressure on the Bearings.

To make the subject clearer, a diagram of pressures on the bearings should be drawn, the figures printed in black type in Table I. being plotted as in Fig. 12. The scale chosen is $\frac{1}{10}$ inch = 2750 lbs. (For instance, for position 2 of the piston, measure from Fig. 12 a height of = 0.54 inch, which gives a pressure on the bearings of $0.54 \times 2750 = 14,850$ lbs.)

I. Outer Bearing (Side-shaft Side), A_1 .

The effect of the weight of the flywheel is the same for every position of the crank. In this bearing A_1 , according to equation 6 and Fig. 13, the pressure against the cap of the bearing A_1 will be—

$$\frac{11,600 \times 20}{33} = 7000$$

If these numbers be transferred to the scale of Fig. 12, i.e. $\frac{1}{10}$ inch = 2750 lbs., the ordinate gives—

$$\frac{7000}{2750 \times 10} = \text{about } 0.25 \text{ inch.}$$

Determination of the Resultant Thrust, R_1 .

From the pressure on the bearing $0.5P$ (parallel to the direction of the connecting rod), and the vertical upward pressure A_1 upon the cap of the bearing, a resultant can be determined. The method adopted for position 5 of the piston is shown at Fig. 14. The pressure on the





FIG. 13.

FIG. 14.—Determination of the Resultant Thrust, R_1 .

bearing, 0.5 P (from Table I. or Fig. 12) is 8700 lbs. With the scale of $\frac{1}{10}$ inch = 2750 lbs., this gives a length of 0.316 inch, and these values are plotted parallel to the direction of the thrust. The pressure against the cap of the bearing A_1 amounts to 7000 lbs. = 0.25 inch for every position of the piston, and is carried out vertically. By plotting the parallelogram of forces, as at Fig. 14, the resultant R_1 is obtained.

The resultants in Fig. 15 are determined in the same way, and are plotted for positions 0, 5, and 10 of the piston. The curve is drawn by joining the different points of the resultants.




FIG. 15.—Resultant Pressure Curve for the Outer Bearing (side-shaft side, away from the flywheel), A_1 .

Thus, in ordinary gas engines under normal conditions, all the pressures are seen to be directed upwards, towards the upper half of the circle described by the crank.

There is therefore a *pressure* on the *cap* of the bearing, and the engine could not work if the cap were taken off.

II. Main Bearing (Flywheel Side), A_2 .

The effect of the weight of the flywheel is a constant, and for this bearing, according to equation 7, it amounts to—

$$A_2 = 11,600 \times \frac{33 + 20}{33} = 18,650 \text{ lbs.}$$

Taking as before the scale of $\frac{1}{10}$ inch = 2750 lbs., the ordinate given—

$$\frac{18,650}{2750 \times 10} = 0.68 \text{ inch.}$$




FIG. 16.—Determination of the Resultant Thrust, R_2 .

From the pressure on the bearing (0.5 P) in the direction of the connecting rod, and the share borne by the weight of the flywheel, A_2 , which acts downwards, the resultant R_2 is obtained for each position of the crank, after completing the parallelogram of forces (compare Fig. 16).

In Fig. 17 all the resultant pressures are plotted for one stroke, and show clearly that they are all exerted downwards, in the lower half of the circle described by the crank.

Hence there is *no pressure* on the *cap* of the bearing.

In *theory*, therefore, the engine would work if the cap of the main bearing on the flywheel side were taken off.




FIG. 17.—Resultant Pressure Curve for the Main Bearing, A_2 .

From the above calculations the pressures on the bearings can be determined for other types of engine.

(b) Forces acting on the Cross Head, Crank Pin, etc.

Under this heading we will deal with the loads on the piston transmitting tension or compression loads on the cross head, crank pin, etc., through the agency of the piston rod, connecting rod, etc. Since no engine has yet been built with a piston load exceeding 660,000 lbs.—

we will take a maximum piston load $\leq 660,000$ lbs. . . . (8)

We must again make use of the steam engine for the sake of comparison, because sufficiently numerous tests have been made upon it to enable us to determine the loads of the moving parts.

The numerical examples given in Tables II. to V. are based upon the following values :—

The friction of the piston is neglected.

Admission pressure $p_s = 0.9$ atm. absolute ($1 - p_s = 0.1$ atm. (= 1.5 lbs. per sq. inch)).

Exhaust „ $p_s = 1.1$ „ „ $(p_s + 1) = 0.1$ „ $(= 1.5 \text{ lbs. } \text{ „ } \text{ „ })$.

(1 - p_i) × A ~ 1.5 × A. Energy required in lbs. per sq. inch to draw in the charge of gas and air.

$(p_s - 1) \times A \sim 1.5 \times A$. Energy required in lbs. per sq. inch to expel the charge of gas and air.

1.5 x C x A. Energy required in lbs. to overcome the compression pressure, when the piston is halfway through its stroke.

$0.25 p \times A = 81 \times A$. Pressure on the piston when halfway through the stroke, in lbs. per sq. inch.

Compression pressure C = 120 lbs. per sq. inch *above atmosphere* (gas engines).

Back pressure $C = 2.9$ lbs. " " " (condensing steam engines).

Explosion pressure	$p \sim 330$ lbs.	"	"	"	(23 atms.).
--------------------	-------------------	---	---	---	-------------

w = exhaust pressure in lbs. per sq. inch above atmosphere.

r = radius of the crank in feet.

$$A = \frac{\pi}{4} D^2 = \text{sectional area of cylinder in sq. inches.}$$

p_e = back pressure of exhaust steam in lbs. per sq. inch (*absolute*) $(1 - p_e) = 10.3$ lbs. per sq. inch. Table V.

W = weight of reciprocating parts, in lbs.

$$\frac{W}{g} = \frac{W}{32} = \text{mass of the reciprocating parts.}$$

$\frac{n^2 \times r}{78}$ acceleration on *back* centre, $\frac{n^2 \times r}{110}$ acceleration on *front* centre in ft. per second².

⊙ = *change of pressure*; in this crank position the pressure always falls upon a different side of the brass.

○ = release of the rods (pressure taken off). Here the brass remains on the same side as before, but has no pressure on it, because there is no change in the tensile and compressive stress upon the rods.

By change of pressure in the rods we mean the reversal of the direction in which the pressure of the load is exerted in the bearings (compare p. 63).

In the *motor strokes* (explosion and expansion), the part of the cylinder in which expansion takes place is indicated by dots.

The formulas for calculating the forces acting on the crank pin in the last column but one of the tables is very simple. For instance, Table IV., line 1. Pressure on the piston at the dead point, in lbs. per sq. inch. The whole of this pressure is not transferred to the piston rod; part of it, viz. acceleration $\times$ weight of the moving parts, or $\frac{W}{32} \times \frac{n^3 \times r}{78}$ in lbs., commonly called the inertia of the reciprocating parts, is employed to set the mass of the piston and rod in motion. The actual pressure on the piston rod is only the difference between the two values, viz. $p \times A - \frac{W}{32} \times \frac{n^3 \times r}{78}$.

Variation and Magnitude of Forces acting on the Crank Pin.

Table II.—Single-cylinder Four-cycle Engine, E 4.

(For meaning of the signs and letters, see pp. 59 and 68.)

Strokes.	Successive positions of the piston during one working cycle, two revolutions.	Tension or compression in the rods.	Load (minus the inertia of the reciprocating parts) in lbs.	EXAMPLES.*	
				25 HP. D = 12 ins. S = 16 „ n = 210 „	600 HP. D = 47 ins. S = 51 „ n = 90 „
s = admission		Tension	$= \frac{W}{32} \times \frac{n^2 r}{78} + (1-p) \times A$	6,600 lbs. (58.8 lbs.)	78,500 lbs. (45 lbs.)
		⊙	If $\alpha \cong 90^\circ$. Change of pressure in the rods. See diagram, Table VI.		
		Compression	$= \frac{W}{32} \times \frac{n^2 r}{110} - (1-p) \times A$	4,420 lbs. (39 lbs.)	51,500 lbs. (30 lbs.)
h = compression		Compression	$= \frac{W}{32} \times \frac{n^2 r}{110} - (1-p) \times A$	4,420 lbs. (39 lbs.)	51,500 lbs. (30 lbs.)
		Compression	$0.1C \times A$	1,280 lbs. (10.9 lbs.)	19,900 lbs. (11.5 lbs.)
		Compression	$C \times A - \frac{W}{32} \times \frac{n^2 r}{78}$	5,900 lbs. (52.2 lbs.)	128,000 lbs. (71 lbs.)
p = explosion e = expansion		Compression	$p \times A - \frac{W}{32} \times \frac{n^2 r}{78}$	29,000 lbs. (256 lbs.)	495,000 lbs. (286 lbs.)
		Compression	$0.25p \times A$	8,800 lbs. (78 lbs.)	148,000 lbs. (82.5 lbs.)
		Compression	$w \times A - \frac{W}{32} \times \frac{n^2 r}{110}$	6,280 lbs. (55 lbs.)	79,000 lbs. (45.5 lbs.)
a = exhaust		Compression	$(p_a - 1) \times A + \frac{W}{32} \times \frac{n^2 r}{110}$	4,780 lbs. (42 lbs.)	56,800 lbs. (32.5 lbs.)
		⊙	If $\alpha \cong 100^\circ$. Change of pressure in the rods. See diagram, Table VI.		
		Tension	$\frac{W}{32} \times \frac{n^2 r}{78} - (p_a - 1) \times A$	6,800 lbs. (55.7 lbs.)	78,500 lbs. (42.4 lbs.)

* The figures within brackets give the pressure in lbs. per square inch of piston area.

Variation and Magnitude of Forces acting on the Crank Pin.

Table III.—Double-acting Four-cycle Engine, D 4.

(For meaning of the signs and letters, see pp. 59 and 63.)

Strokes.	Successive positions of the piston during one working cycle, two revolutions.	Tension or compression in the rods.	Load (minus the inertia of the reciprocating parts) exerted on both faces of the piston in lbs.	EXAMPLE.* 600 HP. D = 33½ inches S = 81 " n = 90 "
s = admission k = compression		Tension	$\frac{W}{32} \times \frac{n^2 r}{78}$	50,600 lbs. (57.5 lbs.)
		Tension	$0.1C \times A + (1 - p_s)A$	11,200 lbs. (12.7 lbs.)
		○	Release of pressure on rods. Table VI.	See diagram,
k = compression p = explosion e = expansion		Tension	$C \times A - \frac{W}{32} \times \frac{n^2 r}{110}$	63,800 lbs. (72.5 lbs.)
		Tension	$p \times A - \frac{W}{32} \times \frac{n^2 r}{110} + (1 - p_s)A$	254,000 lbs. (288 lbs.)
		Tension	$25p \times A - 0.1C \times A$	61,600 lbs. (70 lbs.)
p = explosion a = exhaust e = expansion		⊙	Change of pressure. See diagram, Table VI.	
		Compression	$C \times A - \frac{W}{32} \times \frac{n^2 r}{78} - w \times A$	36,000 lbs. (40.8 lbs.)
		Compression	$p \times A - \frac{W}{32} \times \frac{n^2 r}{79} - (p_a - 1) \times A$	236,000 lbs. (268 lbs.)
p = explosion a = exhaust e = expansion		Compression	$0.25p \times A - (p_a - 1) \times A$	70,500 lbs. (80 lbs.)
		Compression	$w \times A + \frac{W}{32} \times \frac{n^2 r}{110} - (p_a - 1) \times A$	47,000 lbs. (53.4 lbs.)
		Compression	$(p_a - 1) \times A + \frac{W}{32} \times \frac{n^2 r}{110} - (1 - p_s) \times A$	36,200 lbs. (41 lbs.)
a = exhaust s = admission		⊙	Change of pressure. See diagram, Table VI.	
		○		
		Tension	$\frac{W}{32} \times \frac{n^2 r}{78} - (p_a - p_s) \times A$	48,200 lbs. (54.7 lbs.)

* See footnote, p. 60.

Variation and Magnitude of Forces acting on the Crank Pin.

Table IV.—Double-acting Two-cycle Engine, D 2.

Strokes.	Successive positions of the piston during one working cycle, one revolution.	Tension or compression in the rods.	Load (minus the inertia of the reciprocating parts) exerted on both faces of the piston in lbs.	EXAMPLE.* 600 HP. D = 23½ ins. S = 51 „ n = 90 „
p = explosion e = expansion k = compression		Compression	$p \times A - \frac{W}{32} \times \frac{n^2 r}{78}$	118,000 lbs. (266 lbs.)
		Compression	$0.25p \times A - 0.1C \times A$	30,800 lbs. (69.6 lbs.)
		⊙	Change of pressure. See diagram, Table VI.	
		Tension	$C \times A - \left(w \times A + \frac{W}{32} \times \frac{n^2 r}{110} \right)$	22,040 lbs. (49.7 lbs.)
p = explosion e = expansion k = compression		Tension	$p \times A - \frac{W}{32} \times \frac{n^2 r}{110}$	125,000 lbs. (282 lbs.)
		Tension	$0.25p \times A - 0.1C \times A$	30,800 lbs. (69.6 lbs.)
		⊙	Change of pressure. See diagram, Table VI.	
		Compression	$C \times A - \left(w \times A + \frac{W}{32} \times \frac{n^2 r}{78} \right)$	13,200 lbs. (29.8 lbs.)

Table V.—Single-cylinder Condensing Steam Engine.

Strokes.	Successive positions of the piston during one working cycle, one revolution.	Tension or compression in the rods.	Load (minus the inertia of the reciprocating parts) exerted on both faces of the piston in lbs.	EXAMPLE.* 600 HP. D = 29½ ins. S = 51 „ n = 90 „
p = full steam pressure e = expansion a = exhaust k = compression		Compression	$p \times A + (1 - p_o) \times A - \frac{W}{32} \times \frac{n^2 r}{78}$	66,200 lbs. (96.8 lbs.)
		Compression	$0.3p \times A + (1 - p_o) \times A$	26,500 lbs. (38.7 lbs.)
		Compression	$(w \times A - C \times A) + \frac{W}{32} \times \frac{n^2 r}{110}$	16,700 lbs. (24.5 lbs.)
		⊙	Change of pressure. See diagram, Table VI.	
p = full steam pressure e = expansion a = exhaust k = compression		Tension	$p \times A + (1 - p_o) \times A - \frac{W}{32} \times \frac{n^2 r}{110}$	70,500 lbs. (103 lbs.)
		Tension	$0.3p \times A + (1 - p_o) \times A$	26,400 lbs. (38.6 lbs.)
		Tension	$(w \times A - C \times A) + \frac{W}{32} \times \frac{n^2 r}{78}$	23,200 lbs. (34 lbs.)
		⊙	Change of pressure. See diagram, Table VI.	

* During two single strokes there are two changes of pressure. The figures within brackets give the pressure in lbs. per sq. inch of piston area.

To explain the expression "change of pressure," the diagrams in Tables II. to V. must be studied, to see which side of the bearings comes under pressure. In these diagrams

when the pressure falls on the back



brass of the bearings, it is called compression in the rods;

when there is no pressure on either



side of the bearings, it is called change of pressure, or release of pressure on the rods;

when the pressure falls on the



front brass, it is called tension in the rods.

In Tables II. to V. the load on the piston (minus the inertia of the reciprocating parts) is calculated for given dimensions of engine. If these pressures are plotted vertically for the different types, we get the diagrams shown at Table VI.

All the engines are assumed to have the same length of stroke, to develop the same power, and to run at the same number of revolutions, and therefore at the same piston speeds.

The four engines, diagrams of which are given, are—

1. Single-acting four-cycle.
2. Double-acting
3. " " two-cycle.
4. Steam engine.


All with one cylinder only.

Table VI.—Comparison of the Load on the Piston (less Inertia) of a Gas Engine and a Steam Engine, each having one Motor Cylinder.

HP about 600. Stroke = 51 inches. $n = 90$. c = piston speed = 765 feet per minute.

W = weight of reciprocating parts in lbs.

$\frac{W}{HP}$ = weight of reciprocating parts per HP in lbs.




Single-acting Four-cycle Engine
(E 4, one cyl.)

$$D = 47\frac{1}{2} \text{ inches; } \frac{p_m}{4} = \frac{82.5}{4} = 20.6 \text{ lbs.}$$

$$W = 11,200 \text{ lbs.; } \frac{W}{HP} = \frac{11,200}{600} = 18.7 \text{ lbs.}$$

$$\text{inertia (out stroke)} q_2 = 30 \text{ "}$$

$$\text{" (in ") } q_1 = 43 \text{ "}$$




Double-acting Four-cycle Engine
(D 4, one cyl.)

$$D = 33\frac{1}{2} \text{ inches; } \frac{p_m}{2} = \frac{82.5}{2} = 41.2 \text{ lbs.}$$

$$W = 7500 \text{ lbs.; } \frac{W}{HP} = \frac{7500}{600} = 12.5 \text{ lbs.}$$

$$\text{inertia (out stroke)} q_2 = 41.2 \text{ "}$$

$$\text{" (in ") } q_1 = 58 \text{ "}$$




Double-acting Two-cycle Engine
(Koerting) (D 2, one cyl.)

$$D = 23\frac{3}{4} \text{ inches; } p_1 = p_m = 82.5 \text{ lbs.}$$

$$W = 3750 \text{ lbs.; } \frac{W}{HP} = \frac{3750}{600} = 6.25 \text{ lbs.}$$

$$\text{inertia (out stroke)} q_2 = 41.2 \text{ "}$$

$$\text{" (in ") } q_1 = 58 \text{ "}$$



Steam Engine (Condensing).

$$D = 29\frac{1}{2} \text{ inches; } p_1 = p_m = 47 \text{ lbs.}$$

$$W = 3300 \text{ lbs.; } \frac{W}{HP} = \frac{3300}{600} = 5.5 \text{ lbs.}$$

$$\text{inertia (out stroke)} q_2 = 23 \text{ lbs.}$$

$$\text{" (in ") } q_1 = 33 \text{ "}$$

Although the above values have been determined for an engine developing 600 HP in one cylinder, they may also be used for smaller powers, as the inertia of the reciprocating parts (with a piston of the usual dimensions per sectional area) does not vary much, whatever the power developed. The diagram in Table VI. for a 600 HP single-acting engine can also be plotted for the 25 HP engine in Table II. Table VII., giving the comparative values, will not, as we have said, reveal any marked difference between them.

Example from Table VI. In a double-acting four-cycle engine (Deutz), the load on the piston, minus the inertia of the reciprocating parts, is three times, and in a double-acting, two-cycle engine one and a half times as great as in a steam engine, although the latter and a two-cycle gas engine have more or less the same working cycle. The apparent superiority of engine D 2 over engine D 4 is lost, because of the necessity for separate charging pumps in the former.

Table VII.—Comparison of the Load on the Piston (minus the Inertia of the Reciprocating Parts) in a Four-cycle Gas Engine and a Steam Engine.

(The figures show how many times greater the piston loads (minus the inertia of the reciprocating parts) are in gas engines than in steam engines of the same power.)






Type.		STEAM ENGINE.			
		Single cylinder.	Tandem.	Compound.	Triple.
					
Four-cycle. Single-acting.	(a) 	6	6	12	24
	(b) 	3	3	6	12
	(c) 				
	(d) 				
	(e) 	1.5	1.5	3	6
Gas engine. Double-acting.	(f) 	3	3	6	12
	(g) 	1.5	1.5	3	6
	(h) 				
	(i) 	0.75	0.75	1.5	3
					

TABLE VII.—*Example 1.*—The first line in this table shows that, for the same power, the load on the piston (minus the inertia of the reciprocating parts) in a single-acting, four-cycle gas engine (type *a*) is *six times* greater than in a single-cylinder steam engine, and twenty-four times greater than in a triple engine.

Example 2.—In a four-cylinder, single-acting, four-cycle engine (type *e*) the piston load (minus the inertia of the reciprocating parts) is three times greater than in a compound two-cylinder steam engine.

Example 3.—In double-acting, four-cycle gas engines the pressure is rather better distributed, but even here the steam engine is superior. In the double-acting, four-cycle, four-cylinder engine (type *i*), the piston load is still three times greater than in the three-cylinder steam engine.

According to equation 8 (p. 59) the maximum allowable pressure on the rods is taken at 660,000 lbs., and according to the above table this pressure is developed much sooner in gas than in steam engines.

With a pressure on the rods (piston load minus inertia of reciprocating parts) of 600,000 lbs. we get (from Table VII.)—

Table VIII.—Maximum Horse-Power at Normal Load.

In a four-cylinder, single-acting, four-cycle gas engine (type <i>e</i>):			
	About 600 HP per cylinder.	Total	2,400 HP.
,, ,, double-acting, four-cycle gas engine (type <i>i</i>):			
	About 1000 HP per cylinder.	,,	4,000 HP.
,, three-cylinder steam engine (triple expansion):			
	About 3600 HP per cylinder.	,,	10,800 HP.

NOTE.—The various parts of a gas engine have to be designed strong enough to resist the ignition pressure, which of course influences the cost of the engine, but the power of the engine is determined by the mean pressure.

CHAPTER VII.


The Parts of the Engine.

THE beginner should make himself familiar with the various parts of a gas engine, and with their names. The following definitions will be found useful to begin with:—

Names of the Various Parts of an Ordinary Four-cycle Gas Engine.

Figs. 1, 2 (next page).

No.	<i>Frame.</i>	No.	<i>Valve Gear.</i>
1	Frame or bed.	24	Breech end.
2	Cylinder water jacket.	25	Breech-end cover.
3	Water space.	26	Water jacket to valves.
4	Cylinder liner.	27	Mixing chamber for gas and air.
5	Liner joint ring (to water jacket).	27a	Combustion chamber (dotted).
		28	Gas pipe.
		29	Air pipe.
		30	Exhaust pipe.
		31	Water jacket to exhaust.
	<i>Bearings.</i>		<i>Valves.</i>
6	Main bearing. Flywheel side.	32	Admission valve block.
7	" " Side-shaft (outer) side.	33	" valve.
8	Out-end bearing.	34	Exhaust valve.
	<i>Shaft.</i>		<i>Cooling Water Pipes.</i>
9	Crank shaft.	35	Cooling water inlet pipe to cylinder.
10	Balance weights.	36	" " breech end.
11	Crank pin.	37	" " outlet from cylinder.
		38	" " " breech end.
		39	" " " exhaust.
		40	Main outlet pipe for cooling water.
	<i>Connecting Rod.</i>		<i>Drain Cocks.</i>
12	Connecting rod.	41	Drain cock from cylinder water jacket.
13	Big end of connecting rod (crank end).	42	" " breech end jacket.
14	Small " " (piston end).		
	<i>Piston.</i>		<i>Lubrication.</i>
15	Piston.	43	Oiling rings for main bearings.
16	Piston ring.	44	Piston lubricator.
17	Piston pin (cross-head).	45	Piston-pin lubricator.
		46	Oil pump for above.
		47	" driving gear.
		48	Centrifugal lubricator for crank pin.
		49	Lubricator for side-shaft bearing.
		50	Crank splasher guard.
		51	Oil guard on main bearings.
	<i>Flywheel.</i>		
18	Flywheel.		
	<i>Gearing.</i>		
19	Crank worm (driving the valve gear).		
20	Side shaft.		
21	Side-shaft bearing.		
22	Guard for gearing.		
	<i>Governor.</i>		
28	Governor.		



FIGS. 1, 2.—Diameter of cylinder, 400 mm. (15 $\frac{1}{2}$ "); Stroke, 550 mm. (21 $\frac{1}{2}$ "); Scale, 1 : 30.
See Table I., p. 24.

Calculation and Construction of the Parts of an Engine.

In studying the construction of the different parts of a gas engine, we assume that the reader has an accurate knowledge of steam-engine construction. To retain, when constructing a large gas engine, the same design of the parts as that used for a small engine, and merely to increase the scale of dimensions, is a serious error. We must utilize the experience accumulated during two hundred years in building steam engines, especially with regard to the strength of the working parts, and the effects of variations in the temperatures. These are shown in Table I. for steam engines and for internal combustion engines.

Table I.—Pressures and Temperatures (Figs. 3-5).

	Pressures in lbs. per sq. inch above atmosphere.					Temperatures in degrees Centigrade.				
	Initial ignition or explosion pressure	Terminal pressure	Back pressure p_b for steam engines p_a for gas engines absolute.	Compression pressure	Mean pressure	At ignition or explosion	After expansion (terminal.)	At exhaust	At admission	During compression
	p	m		C	p_m	t_p	t_w	t_n	t_s	t_c
1. Steam engine, 1 cyl. condensing	100-200	8.5*-21.5	4.3-15.6	0-171	30-71.2	160-300	90-120	65-105	—	100-200
2. Lighting gas	175-320	21.5-42.7	11.1-15.6	42.7-114	50-98	1250-1750	500-800	300-500	50-100	300-500
3. Press and suction producer gas	242-480	"	"	114-214	43-78	"	"	"	"	"
4. Blast furnace gas	215-355	"	"	171-228	43-78	"	"	"	"	"
5. Benzine	170-285	"	"	48-71	57-85	"	"	"	"	"
6. Oil	142-256	"	"	43-71	43-57	"	"	250-400	"	"
7. Diesel (oil)	455-500	"	"	455-500	85-114	1200-1600	"	"	"	500-600
8. Banki benzine	570	"	"	171-228	100	"	"	100-200	"	200-300

* Lbs. per sq. inch absolute.




FIG. 3.—Steam Engine, exhausting to atmosphere.




FIG. 4.—Steam Engine, condensing.




FIG. 5.—Four-cycle Gas Engine.

Section I. The Crank Shaft.

It is the universal practice of engineers to build solid forged cranked shafts (not over hung crank pins).




FIG. 6. — Design for a Small Engine with Light Flywheel (2 Bearings, 1 Flywheel).




FIG. 7. — Crank Shaft (3 Bearings, 1 Flywheel).

- L₁ Journal for main bearing, flywheel side. L₂ Journal for main bearing, side-shaft side.
 L₃ " " out-end bearing.
 SS Crank webs or cheeks.
 R₁ to R₄ Oil fender rings, to prevent the oil splashing, when the bearings are lubricated by rings (see p. 75).
 O₁ Oil holes in crank pin K; gg, tapped holes for set screws, to screw the centrifugal lubricator ring to the crank web.
 M₁ Sunk or feather key for flywheel.
 M₂ " " crank worm.
 NN Keys for securing balance weights to crank webs (see p. 79).
 G₁, G₂ Balance weights (to balance the rotating parts) (see p. 79).

In designing the crank shaft the following points must be considered:—

1. Are there to be two or three bearings, one or two flywheels?
2. In choosing the dimensions, careful note must be taken of engines already built.
3. Provision must be made that the engine when built can be run with a cylinder of larger diameter.
4. Oil must not be thrown out from the main bearings.
5. Oil feed to the crank pin must be automatic and certain in action.
6. Driving the valve gear. If the valves are not worked from the side shaft, some arrangement for driving the governor will be necessary.
7. Balancing the reciprocating and rotating parts.
8. Choice of suitable materials for the crank shaft, etc.
9. The strength of the crank pin, journals, and crank webs should be tested. The pressure on the bearings, as well as the friction, and the factor of safety, should be determined. Occasions may arise when the dimensions of these parts have to be altered.
10. For hand-turning gear, or a pulley and belt for compressing air, see chapter on "Starting."

We will now consider these different points in detail.

1. Numbers of Bearings and Flywheels.

As a general rule, the following are the six most usual methods of arranging a given number of bearings, flywheels, and pulleys (Figs. 8 to 13).

FIG. 8.—2 Bearings, 1 Driving Pulley Flywheel.




FIG. 9.—2 Bearings, 2 Driving Pulley Flywheels.




FIG. 10.—3 Bearings, 1 Driving Pulley Flywheel.




FIG. 11.—2 Bearings, 1 Flywheel, 1 Driving Pulley.

FIG. 12.—2 Bearings, 2 Flywheels, 1 Driving Pulley.




FIG. 13.—3 Bearings, 1 Flywheel, 1 Driving Pulley.

From these we will select as *most suitable* for study:—

FIG. 14.—2 Bearings, 1 Flywheel, 1 Driving Pulley Flywheel.

FIG. 15.—2 Bearings, 1 Driving Pulley Flywheel.

FIG. 16.—3 Bearings, 1 Driving Pulley Flywheel.



Up to 20 P for power in factories and workshops, but with a heavy flywheel a third bearing is necessary.

Above 20 P for industrial purposes, and in general for electric lighting, and therefore a heavy flywheel is required.

Engines in factories, workshops, mines, etc., generally have a separate pulley, as shown at Figs. 11 and 13, otherwise the speed of the drive would be too great. In engines driving dynamos the flywheel always forms the driving pulley (compare "Flywheels," pp. 164 *et seq.*).

2. Dimensions of the Crank Shaft.


The most important of these, and first to be considered, are—

Diameter and length of the crank pin.

" " " of the main bearing journals.

Distance L between the crank-shaft bearings.


These dimensions are generally directly proportioned to the diameter of the cylinder. In the following diagrams the ratios for some engines are plotted.



DIAGRAM, FIG. 17.—Horizontal Engines.

$$\text{Ratio } \frac{\text{crank-pin diameter}}{\text{cylinder diameter}}$$


The thick line ——— corresponds to the dimensions of engines at p. 73.



DIAGRAM, FIG. 18.—Horizontal Engines.


$$\text{Ratio } \frac{\text{diameters of main bearings}}{\text{cylinder diameter}}$$

The thick line ——— corresponds to the dimensions of engines at p. 73.



DIAGRAM, FIG. 19.—Horizontal Engines.

$$\text{Ratio } \frac{\text{distance between the bearings}}{\text{cylinder diameter}}$$




The dimensions of engines in p. 73 lie within the shaded areas //

Engines by the same makers are, in the above diagrams, denoted by the same sign. Thus O signifies Deutz, □ Nürnberg E., △ Swiderski, Ö Koerting D₂ (two-cycle).


In engines of over 14 inches cylinder diameter the crank pin is made larger in diameter than the main bearing journals. In engines up to 20 inches the diameter of the crank pin may be = diameter of the main bearing journal.

The *standard types of crank shafts* given at pp. 72, 73, represent actual engines, and are based on the calculations at pp. 83–94.

FIGS. 20, 21.—Crank Shaft for Engine.
Diam. = 100 mm. (4"). Stroke = 160
mm. (6 1/4"). Scale 1 in 20.



FIGS. 22, 23.—Crank Shaft for Engine with
Light Flywheel. Diam. = 800 mm. (31 1/2").
Stroke = 400 mm. (15 3/4"). Scale 1 in 20.



FIGS. 24, 25.—Crank Shaft for Engine. Diam. = 480 mm. (18 7/8"). Stroke = 600 mm. (25 1/4").
Scale 1 in 20.

Table II.—Crank Shaft.

(Dimensions in millimetres.)

		Main		Main		Out-end		Extension for main		Extension for side-shaft wheels		Extension for main		Extension for side-shaft wheels		Extension for main		Extension for side-shaft wheels	
Ins.	Ins.	Ins.	Ins.	Ins.	Ins.	Ins.	Ins.	Ins.	Ins.	Ins.	Ins.	Ins.	Ins.	Ins.	Ins.	Ins.	Ins.	Ins.	Ins.
5	31	77	41	58	18	2	18	27	18	27	18	27	18	27	18	27	18	27	18
6	41	91	51	61	21	21	21	31	21	31	21	31	21	31	21	31	21	31	21
7	51	101	61	71	31	31	31	41	31	41	31	41	31	41	31	41	31	41	31
8	61	111	71	81	41	41	41	51	41	51	41	51	41	51	41	51	41	51	41
10	81	131	91	101	61	61	61	71	61	71	61	71	61	71	61	71	61	71	61
12	101	151	111	121	81	81	81	91	81	91	81	91	81	91	81	91	81	91	81
13	111	161	121	131	91	91	91	101	91	101	91	101	91	101	91	101	91	101	91
15	131	181	141	151	111	111	111	121	111	121	111	121	111	121	111	121	111	121	111
17	151	201	161	171	131	131	131	141	131	141	131	141	131	141	131	141	131	141	131
19	171	221	181	191	151	151	151	161	151	161	151	161	151	161	151	161	151	161	151
21	191	241	201	211	171	171	171	181	171	181	171	181	171	181	171	181	171	181	171
23	211	261	221	231	191	191	191	201	191	201	191	201	191	201	191	201	191	201	191
25	231	281	241	251	211	211	211	221	211	221	211	221	211	221	211	221	211	221	211
27	251	301	261	271	231	231	231	241	231	241	231	241	231	241	231	241	231	241	231


The dimensions of h , i , and m can be more accurately determined when we come to the side-shaft wheels.

The higher of the two values given for B and q in engines of more than 16 inches stroke developing power in factories, mines, etc., should be used, if a driving pulley can be fitted on the shaft next the flywheel (Fig. 13, p. 70). The lower values apply in engines in which the flywheel acts as the driving pulley, that is, the belt is on the rim of the flywheel.

* If there is a separate driving pulley (in power engines), o is either made correspondingly longer, or the driving pulley is bolted to the arms of the flywheel.

3. Dimensions of Shoulder between the Crank Web and Main Bearings.

In the standard types of engines given in the preceding table, the main brasses are not, as in Fig. 26, fitted close up to the crank web, but a shoulder is interposed, the diameter of which is not less than $1.2 d$, and should be somewhat smaller than the width of the crank web (see Fig. 27). The dangerous point is where movement is transmitted from the crank web to the journals. If the same pattern of frame is used for different diameters of cylinder, the dimensions of a must be correspondingly increased or diminished. In certain cases the shoulder may be made very narrow (compare Fig. 30).



4. Oil Fender Ring.


The oil escaping from the bearings at k is thrown outwards and upwards towards s (Fig. 28) by centrifugal force, and might then be flung out from the crank web. This is a defect common to many gas engines, and is avoided by having the oil fender ring turned on the shaft (Fig. 29). The oil cannot then creep along to the crank web, but only to the outer periphery of the ring. If the circumferential velocity is small, it drops from here into the oil-guard; if the speed is great, it is flung off.

When the shoulder is very narrow, the fender ring may be shaped as shown at Fig. 30.

The bottom of the groove z should have no sharp angles, as at Fig. 31, but should be rounded off, and be at least 10 per cent. larger in diameter than the crank shaft journal, as in Fig. 32. All sharp corners are liable to start a fracture.

Table III.—Dimensions of the Oil Fender Ring.
(Fig. 33.)

$d = 3\frac{1}{2}''$	$3\frac{1}{2}''-4\frac{3}{8}''$	$4\frac{3}{8}''-6''$	$6\frac{1}{4}''-7\frac{1}{2}''$	$8''-12''$
$a = \frac{1}{8}''$	$\frac{1}{4}''$	$\frac{1}{8}''$	$\frac{3}{8}''$	$\frac{1}{2}''$
$b = \frac{1}{8}''$	$\frac{1}{2}''$	$\frac{1}{8}''$	$\frac{3}{8}''$	$\frac{1}{2}''$



The oil which drips from the fender ring is caught in the guard shown at Fig. 29, and from thence escapes into the reservoir of the oil-ring bearing, as seen in the drawings at p. 105.

5. Crank Pin Lubrication.

For oiling the crank pin the so-called *centrifugal ring lubricator*, which has proved very satisfactory in high-speed steam engines with cranked shafts, is exclusively used.

The oiling ring R (Fig. 34) is secured to the crank web by set screws.

The action of the centrifugal-ring lubricator is as follows:—

The oil is fed from the sight-feed lubricator T through the small pipe *r* into the ring R, is driven by centrifugal force into the deep channel turned in the inside of this ring, and passes to the crank pin through the hole *z*.




FIG. 34.—Oiling Ring.





FIG. 35.—Wrong.



FIGS. 36, 37.—Right.

To allow the oil to pass freely out of the hole, the latter should not discharge parallel to the direction of the crank web, as at Fig. 35, because after compression and during explosion the big end brasses are pressed hard against the pin at this point. It is better to drill the oil hole at the side, towards the front when the crank is vertical, as shown in Figs. 36, 37, and preferably in an oblique direction.

Construction of the Centrifugal Ring Lubricator.



Smaller rings are made of gun metal, larger of cast iron. They may be either semicircular or *square* in section (Figs. 38, 39).

The lubricator ring is preferably made in two parts, as otherwise it is impossible to take it off after the engine has been erected.




FIG. 40.—Lubricator Ring.






FIG. 41.—Lubricator Ring for Engines above 32" Stroke.

To avoid too large a diameter of the lubricator ring R, making it liable to "wobble," a small pipe *v* with flange *f* is added; for engines above 10 inches throw it is cast on (Fig. 46), and above 16 inches throw screwed on to the ring R (Fig. 41). The ring must always, however, be large enough to allow ample clearance between the bearing, oil fender guard and oiling ring, that oil may be poured direct into the latter, if necessary (Fig. 41).

Parts of a Centrifugal Oiling for the Crank Pin.




Figs. 42-45.—For Engines up to 20" Stroke.



Figs. 46-51.—For Engines from 22" to 32" Stroke.

- a_1, a_2 Top and bottom halves of ring (gun metal or cast iron).
 b Bolts for holes B, to bolt the two halves of the ring together.
 c Leather packing washer for oil channel C.
 d Screws for holes D, to secure the oiling ring to the cheek of the crank.
 e " " " branch to the crank cheek.
 f Nipple to close the oiling hole F in the branch E.


Standard Dimensions of the Centrifugal Oiling Ring.



Figs. 52-57.—For Engines up to 20" Stroke (see Table IV.).

(The drawing shows a centrifugal oiling ring for an engine 14" stroke. Scale $\frac{1}{16}$.)

The following measurements are merely to serve as a guide in designing these parts. Deviations from them are naturally allowable.



FIGS. 58-62.—For Engines above 22" Stroke.

(This drawing shows a centrifugal lubricator for an engine of 24" stroke. Scale $\frac{1}{10}$.)Table IV.—Centrifugal Lubricator for Crank Pin.
(Figs. 52-57 and 58-62.)

Piston stroke.		a	b	c	d	e	f	g	h	i	k	l	o	p	q	s	s ₁	s ₂	t	
Fig. 52	{	180 to 190	4	14	3	$d = \text{stroke} + i$	17	6	9	9	6	10	3	20	—	—	8	8	—	—
		220 „ 310	5	18	4		21	8	12	11	6	14	4	24	—	—	10	10	—	—
		350 „ 400	6	22	5		25	10	16	13	8	18	4	30	—	—	12	13	—	—
		450 „ 500	8	28	6		27	12	20	14	8	24	4	33	—	—	13	16	—	—
Fig. 58	{	550	8	32	7	430	27	12	20	14	10	24	4	33	16	16	13	16	12	84
		600	9	35	7	460	27	13	20	14	10	26	5	33	18	17	13	16	12	86
		700	9	35	8	540	27	13	20	14	10	28	5	33	18	17	13	16	13	94

The dimension m , i.e. the distance between the centre of the screws fastening the ring to the crank web, must be determined when designing the parts.

To calculate the stress upon the *balance weight bolts* and *side keys*, centrifugal force exerted when the balance weight is revolving at the speed of the engine must be known, namely—

$$CF = \frac{W_1}{g} \times \frac{V^2}{R} = \frac{WRn^2}{2935} \dots \dots \dots (5)$$

in which

W_1 = weight of balance weight in lbs. (equations 1 and 2).

R = radius of centre of gravity of balance weight in feet (Fig. 63).

n = revolutions per minute.

$V = \frac{R \times 3.14 \times n}{30}$ = circumferential velocity of centre of gravity in feet per second . (6)

Equation 5 gives the centrifugal force exerted by the whole of the balance weight, which must be halved to get the weight on each crank web.

Rules for Constructing the Balance Weights.

"The weights should be placed *as nearly as possible in the same place* as the reciprocating parts. With forged cranked shafts in gas engines this arrangement is not difficult, as each crank web carries a balance weight equal to half the total weight.

Balance weights should not be placed on the flywheel, as dangerous lateral thrusts may be set up (compare "Steam Engines," 8th Edition).

In any case it is often difficult, if the frame is to be kept low, to place the balance weights in the crank pit and allow them sufficient room to slew round, without having the crank pit projecting below the frame. It should also be possible to withdraw the piston without taking off the balance weights (see "Kranker Gas Motor," par. 72b).

The balance weight should either be *forged* solid with the crank web, or cast in a separate piece, and firmly secured to it, as shown in various ways in Figs. 65 to 74.


Figs. 65, 66. Balance weight *forged* solid with the crank web. This method is rarely adopted, because it makes the crank shaft much more difficult to manufacture and erect.

Figs. 67, 68. Cast-iron balance weights *dove-tailed* on to the crank web, and locked with set screws.

Figs. 69, 70. Cast-iron balance weights secured with bolts. Side keys or bolts should be provided as an additional safeguard, as otherwise the centrifugal force falls only on the bolts.

Figs. 71, 72. Balance weights fixed on by studs, and secured by *side keys*. The hole for tightening up the nut or stud is closed by a plate, painted and varnished.

Figs. 73, 74. Balance weights secured by *long bolts* and side keys (Dentz 60 H.P.). The nuts on the bolts can be let into recesses in the balance weights, that they may not project beyond them.



FIGS. 65-74.

Parts of the Balance Weights.

In Figs. 75-77—


AA denote balance weight (cast iron).

K „ key for keyways N.

S „ studs to fit holes L.

O „ hole to tighten nut on stud S.

To improve the appearance of the balance weights the openings O are covered with a plate.



FIGS. 75-77.


Table V.—Balance Weights.

(Figs. 78, 79.)

(The drawings show the balance weights for an engine of 22" stroke. Scale 1:20.)

The studs are intended to facilitate the putting together of the balance weights, and the side keys to strengthen them.

It should be possible (after disconnecting the connecting rod) to withdraw the piston without removing the balance weights, and this must be allowed for when calculating the dimensions.



FIGS. 78, 79.

Dimensions in inches.

Diameter of cylinder	Stroke.	a	b	c	d	e	g	h	i	k	k ₁
ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.
8 $\frac{3}{4}$	12 $\frac{1}{2}$	9 $\frac{1}{2}$	14	4	$\frac{3}{4}$	$\frac{3}{4}$	1 $\frac{9}{16}$	1	$\frac{3}{8}$	$\frac{7}{8}$	—
10 $\frac{1}{2}$	13 $\frac{3}{4}$	10 $\frac{3}{4}$	15 $\frac{1}{2}$	4 $\frac{3}{4}$	1	$\frac{1}{2}$	2	1 $\frac{3}{8}$	$\frac{1}{2}$	$\frac{7}{8}$	—
11 $\frac{1}{2}$	15 $\frac{1}{2}$	12 $\frac{1}{2}$	13 $\frac{1}{2}$	4 $\frac{1}{2}$	1	$\frac{1}{2}$	2 $\frac{3}{8}$	1 $\frac{1}{2}$	$\frac{1}{2}$	1	—
13	17 $\frac{1}{2}$	13 $\frac{3}{4}$	20 $\frac{1}{2}$	5 $\frac{3}{8}$	1 $\frac{1}{2}$	1	2 $\frac{3}{8}$	1 $\frac{1}{2}$	$\frac{1}{2}$	1 $\frac{1}{2}$	—
14 $\frac{1}{2}$	19 $\frac{1}{2}$	15 $\frac{1}{2}$	22 $\frac{1}{2}$	5 $\frac{1}{2}$	1 $\frac{1}{2}$	1	2 $\frac{1}{2}$	1 $\frac{3}{8}$	$\frac{1}{2}$	1 $\frac{3}{8}$	—
15 $\frac{1}{2}$	21 $\frac{1}{2}$	16 $\frac{1}{2}$	25	6 $\frac{1}{2}$	1 $\frac{1}{2}$	1	2 $\frac{1}{2}$	2	$\frac{1}{2}$	1 $\frac{3}{8}$	1 $\frac{3}{8}$
19	23 $\frac{1}{2}$	18 $\frac{1}{2}$	27 $\frac{1}{2}$	6 $\frac{9}{16}$	1 $\frac{1}{2}$	1 $\frac{3}{8}$	2 $\frac{3}{8}$	2 $\frac{3}{8}$	$\frac{1}{2}$	1 $\frac{1}{2}$	1 $\frac{9}{16}$
23 $\frac{1}{2}$	27 $\frac{1}{2}$	21 $\frac{1}{2}$	31 $\frac{1}{2}$	7 $\frac{1}{2}$	1 $\frac{3}{4}$	1 $\frac{1}{2}$	3 $\frac{3}{8}$	2 $\frac{9}{16}$	1	1 $\frac{3}{8}$	1 $\frac{1}{4}$

Dimensions in millimetres.

Cylinder diameter.	Piston stroke.	a	b	c	d	e	g	h	i	k	k ₁
220	310	240	355	100	20	18	40	25	10	22.5	
260	350	270	400	110	23	21	50	30	12	22.5	
300	400	310	460	120	26	23	55	36	14	26	
380	450	350	520	132	29	24	60	40	16	27	
360	500	390	575	144	32	25	65	46	18	28	
400	550	425	635	155	35	26	68	50	20	30	35
480	600	465	690	167	39	28	72	56	22	32	40
600	700	545	800	190	45	30	80	65	24	35	45

These measurements amount to about 75 per cent. of the weight W_1 given by equation 1, and in most cases this approximation is sufficient.

8. Material of the Crank Shaft.

For this the best quality of forged steel is almost exclusively used.

9. Calculating the Strength of the Crank Shaft.*

It is desirable, as already stated, to determine approximately, *at the outset, the strength of the journals*, and other dimensions of the crank shaft. For these the diagrams (p. 71) and Table of Standard Measurements of the various parts of the crank shaft (p. 73) may be used, but other types of engine must also, as far as possible, be studied.

The *diameter of the crank shaft* should not be *worked out* from a given formula; the student is too much inclined to place reliance on results thus obtained. To calculate a crank shaft, the main dimensions must first be determined either graphically, or by analysing the stresses. The graphic method is preferable, but it can only be used to advantage by those who are specially practised in the art of graphic representation, and have thoroughly mastered the subject. We will therefore base our calculations on an *analysis* of the stresses, because it is more easily understood, and forms a check on the results graphically obtained.

The following calculations apply to *single* as well as *double* acting engines, because, in both, the sequence of explosion strokes is so arranged that there is no increase in the pressure of explosion (compare the developed diagrams, pp. 16, 17). Therefore the bending stresses upon the crank shaft are more often repeated in the same unit of time in double-acting and multi-cylinder than in single-acting engines, while the intensity of the stresses remains the same.




FIG. 80.




FIG. 81.




FIG. 82.

We will now proceed to consider the three methods of arranging the crank, crank-shaft bearings, and flywheel shown at Figs. 80–82, which according to p. 70 are those in most general use. For clearness' sake the calculations for the three types are tabulated side by side, although this has necessitated more elaborate equations than would otherwise have been required. In vertical engines, the maximum stresses in the flywheel bearings are developed when the crank shaft is below (that is, when the crank is on the top centre), because the weight of the flywheel and pressure of the piston are both exerted in the same direction.

In engines in factories and workshops, where there is a separate driving pulley at the side of the flywheel, the weight of the pulley ought to be taken into account. Its effect upon the stresses is, however, only small, and the tension of the belt may also be neglected.

We have to consider and test the—

1. *Strength* of the crank shaft.
2. *Surface pressure* on the journals (to ensure *cool running*).

* The moving parts must always be calculated for the **maximum** pressure, as has been done here; the mistake should never be made of calculating these parts for the actual loads coming on them during working (p. 59), and not allowing for the greater load thrown on them when starting or running slow. The inertia of the moving parts in small engines does not amount to much; in large engines, especially tandem engines, the inertia is very great, but it would not be advisable to allow for it in our calculation, for the reasons mentioned above; also it must be borne in mind that an engine which has been designed for a maximum ignition pressure of 350 lbs. per sq. inch may sometimes have to stand a pressure of 420 lbs., owing to a very complete mixture of the charge and consequent rapid ignition. Again, we must consider the mischief produced by pre-ignitions; however careful the designer may be to avoid projections or pockets in the combustion chamber, pre-ignitions occasionally occur in large gas engines driven at their maximum load with gases rich in hydrogen. Again, a careless driver may start pre-ignitions whilst shifting the ignition gear from the starting to the working position, therefore *the moving parts must always be calculated for the maximum pressure.*

It is also necessary to study the stresses coming on the crank shaft in two positions, namely—
 1. At ignition; the full initial pressure comes on the crank when on the dead centre.
 2. When the crank is at an angle of 34° , because, according to the turning moment diagram (p. 38), it is in this position that the maximum turning moment occurs.

(a) Crank on Dead Point at Explosion.

Horizontal Engines.		Vertical Engines.	
2 Bearings, 1 Fly-wheel.	2 Bearings, 2 Fly-wheels.	2 Bearings, 1 Fly-wheel.	2 Bearings, 2 Fly-wheels.
Pressure on bearing from load on piston P.	$A_1 = P \times \frac{a}{L}$ $A_2 = P \times \frac{g}{L}$ $V_1 = W \times \frac{l}{L}$ $V_2 = W \times \frac{L+l}{L}$	Pressure on bearing from weight of fly-wheel W.	$A_1 = P \times \frac{a}{L}$ $A_2 = P \times \frac{g}{L}$ $V_1 = W \times \frac{l}{L}$ $V_2 = W \times \frac{L+l}{L}$
Resultant pressure from the combined pressures A and V.	$R_1 = \sqrt{A_1^2 + V_1^2}$ $R_2 = \sqrt{A_2^2 + V_2^2}$	Resultant pressure from the combined pressures A and V.	$R_1 = \sqrt{A_1^2 + V_1^2}$ $R_2 = \sqrt{A_2^2 + V_2^2}$

This letter R must not be confounded with the R in equations 35 and 36.

* Compare footnote, p. 94.

(b) Crank in the Position where the Greatest Turning Moment is Developed (Fig. 93).

We must next determine in which position of the crank the greatest turning moment is developed. For this the diagram of tangential pressure or turning moment diagram may be used.



FIG. 93.—Position of Piston at Greatest Turning Moment.

presents the tangential pressure diagram of the third or working stroke of a single-acting four-cycle engine. It shows that the greatest rise in the pressure curve is at distance x from the dead point. If we take—

$$\frac{r}{L} = \frac{\text{throw of the crank}}{\text{length of connecting rod}} = \frac{1}{5.8}$$

we get from the indicator diagram (Fig. 95) an angle of 34° for the crank in this position. Figs. 94 and 95 also show that by plotting this distance x , the corresponding angle of the crank can be found at once.

Fig. 95 gives the indicator diagram for a pressure of explosion $p = 370$ lbs. per sq. inch, the scale of pressure being 1 inch = 180 lbs. In crank position x , where the greatest turning moment occurs, the height of the diagram = $1\frac{1}{8}$ inch approximately = 280 lbs. In this position of the piston, therefore, the pressure is—

$$p_{0.1} = \frac{280}{370} \times p = 0.75 \times p \quad (15)$$

or $\frac{3}{4}$ of the explosion pressure.

Thus for this position we get a pressure on the piston * of

$$P' = A \times 0.75 p \quad (16)$$

where A = sectional area of the piston in sq. inches, p = ignition or explosion pressure of the mixture in lbs. per sq. inch.

If $\alpha = 34^\circ$ and $\frac{r}{L} = 5.8$, the angle of inclination β of the connecting rod is given by equation 13, p. 27, as $\sin \beta = \frac{1}{5.8} \times \sin 34^\circ = 0.0965$, whence $\beta \sim 5^\circ 30$.

* Here, as at p. 55, load on the piston rod = load on the connecting rod.





FIG. 94.—Turning Moment Diagram, III. Stroke.

FIG. 95.—Indicator Diagram.

The pressures due to the thrust of the connecting rod may now be resolved into two components, viz. radial pressure C in the direction of the crank webs, and tangential pressure t at right angles to it (Figs. 96, 97).




FIGS. 96, 97.—Horizontal Engines. FIGS. 98, 99.—Vertical Engines.

The weight of the flywheel is similarly resolved into two components, C_f and t_f , which follow the same direction as C and t (Figs. 97 and 99).

Horizontal Engines.


2 Bearings, 1 Fly-wheel.



FIGS. 100-109.

Vertical Engines.


2 Bearings, 1 Fly-wheel.



3 Bearings, 1 Fly-wheel.



2 Bearings, 2 Fly-wheels.



For equations 17-20, we get, from p. 83—

$$\alpha = 34^\circ$$

$$\beta = 5^\circ 30'$$

$$\sin \alpha = 0.56$$

$$\cos \alpha = 0.83$$

$$\sin (\alpha + \beta) = 0.64$$

$$\cos (\alpha + \beta) = 0.77$$

Radial component due to pressure of piston

$$C = P' \cdot \cos (\alpha + \beta)$$

Tangential component due to pressure of piston

$$t = P' \cdot \sin (\alpha + \beta)$$

Radial component due to weight of fly-wheel

$$C_s = W \times \sin \alpha$$

Tangential component due to weight of fly-wheel

$$t_s = W \times \cos \alpha$$

Pressure on bearings due to radial component C

$$T_{P1} = C \times \frac{a}{L}$$

$$T_{P2} = C \times \frac{g}{L}$$

Pressure on bearings due to radial component C_s

$$T_{s1} = -C_s \times \frac{L+t}{L}$$

$$T_{s2} = C_s \times \frac{L+t}{L}$$

$$C = P' \cdot \cos (\alpha + \beta)$$

$$t = P' \cdot \sin (\alpha + \beta)$$

$$C_s = W \times \sin \alpha$$

$$t_s = W \times \cos \alpha$$

$$T_{P1} = C \times \frac{a}{L}$$

$$T_{P2} = C \times \frac{g}{L}$$

$$T_{s1} = -C_s \times \frac{L+t}{L}$$

$$T_{s2} = C_s \times \frac{L+t}{L}$$

$$C = P' \cdot \cos (\alpha + \beta)$$

$$t = P' \cdot \sin (\alpha + \beta)$$

$$C_s = W \times \sin \alpha$$

$$t_s = W \times \cos \alpha$$

$$T_{P1} = C \times \frac{a}{L}$$

$$T_{P2} = C \times \frac{g}{L}$$

$$T_{s1} = \text{zero}^*$$

$$T_{s2} = C_s \times \frac{L+t}{L}$$

$$T_{s3} = C_s \times \frac{L+t}{L}$$

$$C = P' \cdot \cos (\alpha + \beta)$$

$$t = P' \cdot \sin (\alpha + \beta)$$

$$C_s = W \times \cos \alpha$$

$$t_s = W \times \sin \alpha$$

$$T_{P1} = C \times \frac{a}{L}$$

$$T_{P2} = C \times \frac{g}{L}$$

$$T_{s1} = -C_s \times \frac{L+t}{L}$$

$$T_{s2} = C_s \times \frac{L+t}{L}$$

$$C = P' \cdot \cos (\alpha + \beta)$$

$$t = P' \cdot \sin (\alpha + \beta)$$

$$C_s = W \times \cos \alpha$$

$$t_s = W \times \sin \alpha$$

$$T_{P1} = C \times \frac{a}{L}$$

$$T_{P2} = C \times \frac{g}{L}$$

$$T_{s1} = C_s \times \frac{L+t}{L} - C_s \times \frac{L}{L} = C_s$$

$$T_{s2} = C_s \times \frac{L+t}{L} - C_s \times \frac{L}{L} = C_s$$

$$T_{s3} = C_s \times \frac{L+t}{L}$$

* Compare footnote, p. 94.

Horizontal Engines.

$$\begin{aligned}
 &\left. \begin{aligned} \text{Total pressure} \\ \text{on bearings} \end{aligned} \right\} \begin{aligned} T_1 &= T_{p1} + T_{s1} \\ T_2 &= T_{p2} + T_{s2} \end{aligned} \\
 &\left. \begin{aligned} \text{Pressure on} \\ \text{bearings due} \\ \text{to tangential} \\ \text{Component } t \end{aligned} \right\} \begin{aligned} N_{p1} &= t \times \frac{a}{L} \\ N_{p2} &= t \times \frac{g}{L} \end{aligned} \\
 &\left. \begin{aligned} \text{Pressure on} \\ \text{bearings due} \\ \text{to tangential} \\ \text{Component } t_s \end{aligned} \right\} \begin{aligned} N_{s1} &= -t_s \times \frac{L+l}{L} \\ N_{s2} &= t_s \times \frac{L+l}{L} \end{aligned}
 \end{aligned}$$

$$\begin{aligned}
 T_1 &= T_{p1} + T_{s1} \\
 T_2 &= T_{p2} + T_{s2} \\
 N_{p1} &= t \times \frac{a}{L} \\
 N_{p2} &= t \times \frac{g}{L} \\
 N_{s1} &= \text{zero}^* \\
 N_{s2} &= t_s \times \frac{L+l}{L} \\
 N_{s3} &= t_s \times \frac{L+l}{L}
 \end{aligned}$$

$$\left. \begin{aligned} \text{Total pressure} \\ \text{on bearings} \end{aligned} \right\} \begin{aligned} N_1 &= N_{p1} + N_{s1} \\ N_2 &= N_{p2} + N_{s2} \end{aligned}$$


These pressures on the bearings are combined into a resultant pressure, namely—

$$\left. \begin{aligned} \text{Resultant pres-} \\ \text{sure on bear-} \\ \text{ings} \end{aligned} \right\} \begin{aligned} \mathfrak{R}_1 &= \sqrt{T_1^2 + N_1^2} \\ \mathfrak{R}_2 &= \sqrt{T_2^2 + N_2^2} \end{aligned}$$

This letter $\mathfrak{R}$ must not be confused with the printed letter R in equations 13 and 14. The resulting pressures on the bearings obtained from equations 13, 14, and 35, 36 may now be used to determine the—

Bending and Twisting Moments and Stresses.

In the following calculations for the five types of crank sq. inch, and are taken from equations 8 to 36. All dimensions here considered, the pressures are given in lbs. per sq. inch.



Figs. 110, 111.

* Compare footnote, p. 94.

† R₁ equation 18 must not be confused with $\mathfrak{R}_1$ equation 35.

Vertical Engines.

$$\begin{aligned}
 T_1 &= T_{p1} + T_{s1} \\
 T_2 &= T_{p2} + T_{s2} \\
 N_{p1} &= t \times \frac{a}{L} \\
 N_{p2} &= t \times \frac{g}{L} \\
 N_{s1} &= -t_s \times \frac{L+l}{L} \\
 N_{s2} &= t_s \times \frac{L+l}{L}
 \end{aligned}$$

$$\begin{aligned}
 T_1 &= T_{p1} + T_{s1} \\
 T_2 &= T_{p2} + T_{s2} \\
 N_{p1} &= t \times \frac{a}{L} \\
 N_{p2} &= t \times \frac{g}{L} \\
 N_{s1} &= -t_s \times \frac{L+l}{L} \\
 N_{s2} &= t_s \times \frac{L+l}{L}
 \end{aligned}$$

$$\begin{aligned}
 T_1 &= T_{p1} + T_{s1} \\
 T_2 &= T_{p2} + T_{s2} \\
 N_{p1} &= t \times \frac{a}{L} \\
 N_{p2} &= t \times \frac{g}{L} \\
 N_{s1} &= -t_s \times \frac{L+l}{L} \\
 N_{s2} &= t_s \times \frac{L+l}{L}
 \end{aligned}$$

The resulting pressures on the bearings obtained

(a) Ignition with Crank on Dead Centre.

1. Crank Pin.

$$\begin{aligned}
 &\text{Resultant load on bearing } R_1 \dagger \text{ (from equation 13).} \\
 &\text{Bending moment } M_b = R_1 \times g \text{ in inch-lbs.} \quad (37) \\
 &\text{Modulus of resistance } Z_b \sim 0.1 \times d^3 \text{ in cubic inches} \quad (38) \\
 &\text{Stress due to bending } = f_b = \frac{M_b}{Z_b} \text{ in lbs. per sq.} \\
 &\text{inch} \quad (39) \\
 &\text{Allowable stress or safe working load } f_s = 14,000 \\
 &\text{to 17,000 lbs. per sq. inch} \quad (40)
 \end{aligned}$$

2. *Crank-shaft webs, side-shaft side* (see Figs. 110, 111).

Resultant load on bearing R_1 (equation 13).

Bending moment $M_b = R_1 (g - c)$ inch-lbs. (41)


Modulus of resistance $Z_b = \frac{1}{6} b^2 h$ in cubic inches (42)

Stress due to bending $f_b = \frac{M_b}{Z_b}$ lbs. per sq. inch (43)

Stress due to compression $f_c = 0.5 \frac{P}{bh}$ lbs. per sq. inch (44)

Combined stress $f = f_b + f_c$ lbs. per sq. inch (45)

Allowable stress or safe working load $f = 11,000$ to 12,500 lbs. per square inch (46)



3. *Crank-shaft webs, flywheel side.*

Resultant load on bearing R_1 from equation 13; maximum load on piston P from equation 7.

Bending moment $M_b = R_1 (g + c) - Pc$ in inch-lbs. (47)


Modulus of resistance $Z_b = \frac{1}{6} b^2 h$ in cubic inches (48)

Stress due to bending $f_b = \frac{M_b}{Z_b}$ lbs. per sq. inch (49)

Stress due to compression $f_c = \frac{0.5P}{bh}$ lbs. per sq. inch (50)

Combined stress $f = f_b + f_c$ lbs. per sq. inch (51)

Allowable stress, or safe working load $f = 11,000$ to 12,500 lbs. per sq. inch (52)



4. *Main bearing journal flywheel side.*

Maximum load on piston P from equation 7; load on bearing A_1 (equation 8); load on bearing V_1 (equation 10).

Bending moment $M_b = Pa - A_1 (g + a)$ in inch-lbs. (53)

Bending moment $M_b = V_1 (g + a)$ inch-lbs. (54)

* Compare footnote, p. 94.

Bending moment $M_b = \sqrt{M_{b1}^2 + M_{b2}^2}$ inch-lbs. (55)

Modulus of resistance $Z_b = 0.1 \frac{d^3}{6}$ cubic inches (56)

Stress due to bending $f_b = \frac{M_b}{Z_b}$ lbs. per sq. inch (57)

Allowable stress or safe working load $f_b = 4200$ to 5600 lbs. per sq. inch (58)

In shafts with three bearings (Fig. 82, p. 82) the bending moment M_b is zero.*

For crank shafts with an overhung flywheel, equation 55 should read as follows:—

Bending moment $M_b = W \times l$ in inch-lbs. (59)

(b) *Crank in Position where Greatest Turning Moment occurs* (see Fig. 93).

1. *Crank pin.*

Resultant load on bearing $\mathfrak{R}_1$ from equation 35; resultant load on bearing N_1 from equation 33.

Bending moment $M_b = R_e \times g$ inch-lbs. (60)

Twisting moment $M_t = N_1 \times r$ inch-lbs. (61)

Modulus of resistance to bending $Z_b = 0.1 \frac{d^3}{6}$ cubic inches (62)


Modulus of resistance to twisting $Z_t = 0.2 \times \frac{d^3}{6}$ cubic inches (63)

Stress due to bending $f_b = \frac{M_b}{Z_b}$ in lbs. per sq. inch (64)

Stress due to twisting $f_t = \frac{M_t}{Z_t}$ in lbs. per sq. inch (65)

Combined stress—
 $f = 0.35 f_b + 0.65 \sqrt{f_b^2 + 4f_t^2}$ (66)


Allowable stress or safe working load
 $f = 11,000$ to 14,000 lbs. per sq. inch (67)



2. Crank-shaft webs, side-shaft side.

Load T_1 on bearing equation 26.
 Load N_1 on bearing " 33.

In the middle of the longer sides of the webs.



Bending moment $M_b = T_1 (g - c)$ in inch-lbs. (68)
 Twisting moment $M_t = N_1 (g - c)$ inch-lbs. (69)
 Modulus of resistance to bending $Z_b = \frac{1}{8} b^3 h$ cubic inches. (70)
 Modulus of resistance to twisting $Z_t = \frac{2}{3} b^2 h$ cubic inches. (71)

Stress due to bending $f_b = \frac{M_b}{Z_b}$ lbs. per sq. inch. (72)
 " " twisting $f_t = \frac{M_t}{Z_t}$ " " (73)
 Combined stress—

$f = 0.35 f_b + 0.65 \sqrt{f_b^2 + 4 f_t^2}$ lbs. per sq. inch . . . (74)
 Allowable stress or safe working load—

$f = 8500$ to $10,000$ lbs. per sq. inch (75)
 At the point where the crank pin begins, in the middle of the shorter sides of the webs—

Bending moment $M_b = N_1 \left(r - \frac{d}{2} \right)$ inch-lbs. (76)
 Twisting moment $M_t = N_1 (g - c)$ " " (77)
 Modulus of resistance to bending $Z_b = \frac{1}{8} b h^3$ cubic inches : (78)
 " " twisting $Z_t = \frac{2}{3} b h^2$ " " (79)

Stress due to bending $f_b = \frac{M_b}{Z_b}$ lbs. per sq. inch (80)
 " " twisting $f_t = \frac{M_t}{Z_t}$ " " " " (81)
 Combined stress—


$f = 0.35 f_b + 0.65 \sqrt{f_b^2 + 4 f_t^2}$ lbs. per sq. inch . . . (82)
 Allowable stress or safe working load—

$f = 2800$ to 4200 lbs. per sq. inch (83)

3. Crank-shaft webs, flywheel side.

Load T_1 on bearing equation 26.
 Load N_1 on bearing " 33.

Tangential component t (eq. 18), radial component c (eq. 17).



In the middle of the longer sides of the webs.

Bending moment $M_b = T_1 (g + c) + C \times c$ inch-lbs. (84)
 Twisting moment $M_t = N_1 (g + c) + t \times c$ inch-lbs. (85)
 Modulus of resistance to bending $Z_b = \frac{1}{8} b^3 h$ cubic inches (86)
 Modulus of resistance to twisting $Z_t = \frac{2}{3} b^2 h$ " " (87)

Stress due to bending $f_b = \frac{M_b}{Z_b}$ lbs. per sq. inch (88)
 " " twisting $f_t = \frac{M_t}{Z_t}$ " " " " (89)
 Combined stress—

$f = 0.35 f_b + 0.65 \sqrt{f_b^2 + 4 f_t^2}$ lbs. per sq. inch. (90)
 Allowable stress or safe working load—

$f = 7000$ to 9000 lbs. per sq. inch (91)
 At the point where the shaft connects, stresses are also developed in the middle of the shorter sides of the webs, namely—

Bending moment $M_b = t \left(r - \frac{d_2}{2} \right) + N_1 \times 0.5 d_2$ inch-lbs. . . (92)
 Twisting moment $M_t = -N_1 (g + c) + t \times c$ inch-lbs. . . (93)
 Modulus of resistance to bending $Z_b = \frac{1}{8} b h^3$ cubic inches : (94)
 " " twisting $Z_t = \frac{2}{3} b h^2$ " " (95)


Stress due to bending $f_b = \frac{M_b}{Z_b}$ lbs. per sq. inch (96)
 " " twisting $f_t = \frac{M_t}{Z_t}$ " " " " (97)
 Combined stress—

$f = 0.35 f_b + 0.65 \sqrt{f_b^2 + 4 f_t^2}$ lbs. per sq. inch . . . (98)
 Allowable stress or safe working load—

$f = 5000$ to 6250 lbs. per sq. inch (99)

To check the above calculations, and verify the dimensions of the crank shaft on which they are based, the results are worked out in Table XXIII., for four different sizes of gas engines, from the equations at pp. 88-89. To calculate a complete example will take a beginner eight hours, a more advanced student five hours. The last column of the table is left blank, for inserting further examples.

Table VI.—Data for Calculating the Crank Shaft.



FIGS. 29, 30.—Dimensions of the Crank Shaft.

Calculated from equation	En- gine	Nominal H.P. Diam. of cylinder D Stroke S	Crank shaft with 2 bearings, 1 fly- wheel.		Crank shaft with 3 bearings, 1 fly- wheel.		H.P. inches. "
			0.6 3 1/2" 5"	17 10 1/2" 18 1/2"	42 14" 20"	132 24 28"	
3, p. 18	Area of piston	A =	8.3	82.5	154	452	sq. ins.
7, " 88	Press. on piston, with p =		3070	30,500	57,000	167,500	lbs.
16, " 84	Pressure on piston where max. turning moment occurs P' =		2300	23,000	43,000	126,000	"
	Weight of flywheel from Table I., p. 24 W =		485	2820	10,600	38,400	"
The values given are taken from Table II., (p. 78), the di- mensions given in this table re- fer to conti- nental engines built to mm.; for the sake of sim- plicity the near- est even dimen- sions in ins. have been taken for these calcula- tions.			$\delta_o = 1/50$		$\delta_o = 1/80$		inches
	r =		2 1/2"	6 1/2"	10"	14"	"
	a = g =		3 1/2"	11"	14 1/2"	23 1/2"	"
	L =		7 1/2"	22"	29 1/2"	46 1/2"	"
	l =		4 1/2"	11"	19 1/2"	29 1/2"	"
	l1 =		—	—	21 1/2"	32 1/2"	"
	L1 =		—	—	41 1/2"	62 1/2"	"
	d =		1 1/2"	5"	6 1/2"	10 1/2"	"
	d1 = d2 =		—	—	6 1/2"	9"	"
	d3 =		—	—	6 1/2"	7 1/2"	"
	d4 =		2 1/2"	6"	7 1/2"	11 1/2"	"
	b =		1 1/2"	3 1/2"	4 1/2"	7 1/2"	"
	h =		2 1/2"	6 1/2"	8 1/2"	12 1/2"	"
	c =		1 1/2"	4"	5 1/2"	8 1/2"	"
8, 9, p. 88	Press. on bearings A1 = A2 =		1585	15,250	28,500	88,750	lbs.
10, " "	" " V1 =		280	1410	Zero *	Zero *	"


* Compare footnote, p. 94.

From equation		Crank shaft with 2 bearings, 1 flywheel.		Crank shaft with 3 bearings, 1 flywheel.		
	Cyl. diam. and stroke of engine.	$3\frac{1}{2}"$ 5	$10\frac{1}{2}"$ 13 $\frac{1}{2}$	14" 20	24" 28	
11	Pressure on bearings $V_s =$	760	4,230	5,550	20,000	lbs.
12	" " $V_s =$	—	—	5,020	18,200	"
13	Resultant pressure $\{ R_1^* =$	1,560	15,310	28,500	88,750	"
14	on bearings $\{ R_2^* =$	1,712	15,800	29,000	86,100	"
17	Radial component $C =$	1,770	17,700	33,000	97,000	"
18	Tangential component $t =$	1,470	14,700	27,500	80,600	"
19	Radial component $C_s =$	270	1,600	5,920	21,500	"
20	Tangential component $t_s =$	400	2,340	8,800	32,000	"
21, 22	Pressure on bearings $\{ T_{p1} = T_{p2} =$	885	8,850	16,500	48,500	"
23	Pressure on bearings $T_{r1} =$	-154	-800	Zero †	Zero †	"
24	" " $T_{r2} =$	425	2,400	3,100	11,300	"
25	" " $T_{r3} =$	—	—	2,820	10,200	"
26	" " $T_1 =$	731	8,050	16,500	48,500	"
27	" " $T_2 =$	1,310	11,250	19,600	59,800	"
28, 29	Pressure on bearings $\{ N_{p1} = N_{p2} =$	785	7,850	13,750	40,800	"
30	Pressure on bearings $N_{r1} =$	-230	-1,170	Zero †	Zero †	"
31	" " $N_{r2} =$	625	3,500	4,680	16,800	"
32	" " $N_{r3} =$	—	—	4,200	15,200	"
33	" " $N_1 =$	505	6,180	13,750	40,800	"
34	" " $N_2 =$	1,860	10,850	18,380	57,100	"
35	Resultant pressure $\{ R_1^* =$	860	10,150	21,450	68,100	"
36	on bearings $\{ R_2^* =$	1,892	15,630	26,900	82,700	"
At the dead point—						
37	1. Crank pin $M_b =$	6,250	168,500	420,000	1,940,000	inch-lbs.
38	 $Z_b =$	4.8	12.5	30.7	116 †	inches. ³
39	$f_b =$	1,450	13,500	13,700	16,700	lbs. per sq. in.
41	2. Crank webs, side- $M_b =$	3,880	107,000	264,000	1,200,000	inch-lbs.
42	shaft side $Z_b =$	966	10	24.8	106	inches. ³
43	 $f_b =$	10,600	10,700	10,650	11,300	lbs. per sq. in.
44	$f_c =$	690	780	800	930	" "
45	$f =$	11,290	11,480	11,450	12,230	" "

* Compare note, p. 86.

† Compare footnote, p. 94.

‡ Crank pin, 10½ inches diameter.

From equation			Crank shaft with 2 bearings, 1 flywheel.		Crank shaft with 8 bearings, 1 flywheel.		
							
	Cyl. diam. and stroke of engine.		8½" 5	10½" 18½	14" 20	24" 28	
47	3. Crank webs, fly-wheel side	$M_b =$	4,000	108,000	268,000	1,205,000	in.-lbs.
48		$Z_b =$	0.866	10	24.8	106	ins. ³
49		$f_b =$	10,800	10,800	10,800	11,400	lbs. per sq. in.
50		$f_c =$	690	780	800	980	" "
51		$f =$	11,490	11,580	11,600	12,380	" "
	4. Main Bearings.						
							
55		$M_b =$	2,220	3,1000	Zero *	Zero *	in.-lbs.
56		$Z_b =$	4.2	12.3	Zero *	87.5	ins. ³
57		$f_b =$	580	2,520	Zero *	Zero *	lbs. per sq. in.
Where greatest turning moment occurs—							
60	1. Crank pin.	$M_b =$	3,440	112,000	326,000	1,315,000	in.-lbs.
61		$M_t =$	1,260	42,500	137,500	566,000	" "
62		$Z_b =$	4.2	12.3	80.2	113†	ins. ³
63		$Z_t =$	8.4	24.6	60.4	226	" "
64		$f_b =$	820	9,100	10,450	11,600	lbs. per sq. in.
65		$f_t =$	150	1,780	2,280	2,500	" "
66		$f =$	852	9,500	11,070	12,260	" "
68	2. Crank webs, side shaft side	$M_b =$	1,880	56,850	153,000	580,000	in.-lbs.
69		$M_t =$	1,260	43,200	127,000	580,000	" "
70		$Z_b =$	0.866	10.0	24.9	106	ins. ³
71		$Z_t =$	0.488	13.8	33.2	141.3	" "
72		$f_b =$	5,000	5,685	6,150	5,470	lbs. per sq. in.
72		$f_t =$	2,580	3,260	3,830	4,100	" "
73		$f =$	6,420	7,570	8,580	8,310	" "
75		$M_b =$	853	27,000	91,000	357,000	in.-lbs.
76		$M_t =$	1,260	43,250	127,000	580,000	" "
77		$Z_b =$	0.8	20.7	50.8	188	ins. ³
78		$Z_t =$	1.07	27.2	67	251	" "
79		$f_b =$	1,067	1,805	1,800	1,890	lbs. per sq. in.
79		$f_t =$	1,180	1,590	1,900	2,310	" "
80		$f =$	2,090	2,690	3,886	3,960	" "

* Compare footnote, p. 94.

† At 10½ inches diameter.

From equation

Crank shaft with
2 bearings,
1 flywheel.

Crank shaft with
8 bearings,
1 flywheel.

Cyl. diam. and stroke
of engine.

31"
5

10 1/2"
18 3/4

14"
20

24"
28

82
83
84
85
86
86
87
89
90
91
92
93
93
94

3. Crank webs, fly-
wheel side.

$M_b =$
 $M_r =$
 $Z =$
 $Z_t =$
 $f_b =$
 $f_r =$
 $f =$
 $M_b =$
 $M_r =$
 $Z_b =$
 $Z_t =$
 $f_b =$
 $f_r =$
 $f =$

-1860
-590
0.866
0.488
3720
1190
4160
2839
-590
0.8
1.07
3620
-542
3710
-51,100
-33,700
10
13.8
5,110
2,530
6,460
81,530
-33,700
20.7
27.2
3,940
-1,240
4,400

-153,500
-127,000
24.8
38.2
6,200
3,820
8,470
230,200
-127,000
50.3
67
4,780
1,895
5,590
-701,000
-582,000
106
141
6,570
4,150
9,180
933,800
-582,000
188
251
4,970
2,320
6,150

in.-lbs.
"
ins.³
"
lbs. per sq. in.
"
"
in.-lbs.
"
ins.³
"
lbs. per sq. in.
"
"
"

4. Main bearings.

98-105
99
100
101
102
102
103

$M_b =$
 $M_r =$
 $Z_b =$
 $Z_t =$
 $f_b =$
 $f_r =$
 $f =$

2220
3670
4.2
8.4
530
438
850
31,000
101,000
12.3
24.6
2,520
4,100
7,900

Zero *
275,000
26.9
58.8
Zero *
5,110
5,110 *
Zero *
1,128,000
87.5
175
Zero *
6,450
6,450 *

in.-lbs.
"
ins.³
"
lbs. per sq. in.
"
"
"

5. In the swell for the flywheel.

106
107
108
109
110
110
111


$M_b =$
 $M_r =$
 $Z =$
 $Z_t =$
 $f_b =$
 $f_r =$
 $f =$

—
1835
—
2.1
—
875
875
—
50,500
—
48.2
—
1,170
1,170

108,400
187,500
48
96
2,270
1,490
3,170
595,000
565,000
152
300
3,920
1,860
4,570



in.-lbs.
"
ins.³
"
lbs. per sq. in.
"
"
"

* Compare footnote, p. 94.

From equation	Cyl. diam. and stroke of engine.	Crank shaft with 2 bearings, 1 flywheel.		Crank shaft with 3 bearings, 1 flywheel.		
						
		$\frac{8\frac{1}{2}''}{5''}$	$\frac{10\frac{1}{2}''}{13\frac{3}{4}''}$	$\frac{14''}{20''}$	$\frac{24''}{28''}$	
6. Part where the main bearing joins the crank webs. Flywheel side. 						
114	$M_b =$	8,420	86,000	145,000	894,000	in.-lbs.
118	$M_t =$	3,670	101,000	275,000	1,128,000	"
115	$Z_b =$	4.2	12.8	26.9	87.5	ins. ³
116	$Z_t =$	8.4	24.6	53.8	175.0	"
117	$f_b =$	815	7,000	5,400	8,000	lbs. per sq. in.
117	$f_t =$	437	4,100	5,100	6,450	" "
118	$f =$	1,064	9,460	9,500	12,660	" "

To show more clearly the results as worked out for the crank shafts of four different sizes of engine, the stresses only are tabulated in Table VII. The part where greatest danger from stress may be apprehended appears in the larger engines to be the crank pin.

Table VII.—Summary of the Stresses on the Crank Shaft, for Two Positions of the Crank, in Six Different Places.



Size of engine.	Cross-section I.		II.		III.		IV.		V.	VI.		
	Dead point.	34°	Dead point.	34°	Dead point.	34°	Dead point.	34°	34°	34°		
0.6 H.P.	$f = 1,450$	852	11,290	6420	2090	11,490	4160	8710	580	850	875	1,064 lbs. per sq. in.
17 "	$f = 13,500$	9,500	11,880	7570	2690	11,580	6460	4400	2520	7000	1170	9,460 "
42 "	$f = 13,700$	11,070	11,450	8580	3886	11,600	8470	5590	Zero*	5110*	3170	9,500 "
132 "	$f = 16,700$	12,260	12,230	8310	2960	12,330	9180	6150	Zero*	6450*	4700	12,660 "

* According to Ensslin's method, the stresses due to bending can also be determined in crank shafts with three bearings (Fig. 82, p. 82). These may be stated approximately in the same way as the stresses due to twisting f_t (equation 102), and the combined stress $f = 1.7 f_t$.

Thus, Column IV. of above table should read—

Dead point.	34°
580	850
2520	7,000
5110	8,700
6450	11,000

In Table VII. the figures printed in *black type* are always the determining factors for the stresses. This summary clearly shows that—

For sections 1, 2, and 3, *i.e.* the crank pin and crank webs (Figs. 51, 52), we must calculate the stresses, in the engines here considered, from the crank at the dead centre, and for sections 4, 5 (*i.e.* the swell for the flywheel) and 6, from the crank when in the position where the greatest turning moment occurs ($\alpha = 34^\circ$, see p. 84). For sections 5 and 6 the dead-centre stresses need not be taken into account at all.

Multiple cranked shafts are only built for special purposes, and to calculate their dimensions and stresses would be outside the scope of this work.

Overheating the Bearings.

The smaller the changes produced by the stresses along the axis of the crank shaft, the less risk will there be of accident or fracture, and the less the tendency of the bearings to become overheated.

Let us first consider a vertical four-cycle engine (Fig. 53), because in this type the load on the piston and weight of the flywheel are exerted in the same direction. The results yielded by calculation of vertical, can also in general be applied to horizontal engines.




FIG. 53.



FIG. 54.




FIG. 55.

The pressure transmitted from the piston to the crank through the connecting rod, which reaches its maximum at the dead centre, seeks to distort the axis of the crank in the direction shown in Figs. 54 and 55.

The weight of the flywheel also produces a deformation of the crank shaft, and the brass only touches the shaft at the points *a a* (see Fig. 55, in which the effect is purposely exaggerated).

The result is local friction, and hence overheating of the bearings.

The so-called "limit of elasticity" is marked by the thick line — in Fig. 54. The angles ϕ_1 and ϕ_2 of the main bearing on the flywheel side, and β_1 and β_2 of the bearing on the side shaft side, all of which have to be considered, vary for each position of the piston. These angles can be determined by calculation. (See on this subject Ensslin : "Multiple Cranked Shafts," pp. 84-90.) [Ensslin : "Mehrfach gelagerte Kurbelwellen."]

As ϕ is relatively small, we may write: angle of inclination $\phi = \tan \phi$ in circular measure.

Ensslin has calculated the crank shaft of a 100 H.P. gas engine. From the results he has arrived at the conclusion may be drawn that, for crank shafts of gas engines with three bearings, in which the stress due to bending is 10,000 to 11,500 lbs. per sq. inch, the utmost deflection permissible within the limits of elasticity should be—

$$\phi_1 = \phi_2 = \frac{7}{10000}; \beta_1 = \frac{1}{1000}; \beta_2 = \frac{3}{10000}$$

These are the allowable ratios in circular measure, and therefore approximately $= \tan$ of the angle.

In Fig. 54 the angle ϕ marks the deviation from the horizontal induced by the bending stress.

A glance at it shows the inaccuracy of the usual method of calculation, according to which the bending moment of the crank shaft at A_2 in the centre of the main bearing (Fig. 56) should be equal to zero.

This method has, however, been retained here, as Ensslin's process of calculation is somewhat complicated and lengthy, but the latter should always be used for large engines.




FIG. 56.



FIG. 57.





FIG. 58.

FIG. 59.
Large Diameter,
Short Length.FIG. 60.
Small Diameter,
Long Length.

The longer the bearing, the greater is the deflection of the journal within it (Figs. 57, 58), and the less of its area takes the bearing stress. This is illustrated in Figs. 57-60. The conclusion may be drawn that—

The crank pin should be as large in diameter as possible, to withstand the bending stress } (120)

The crank pin should be as short as possible, to reduce $\tan \phi$

F = the friction in the bearing as expressed by the product $q \times v \times \mu$. As v increases with the diameter of the crank pin, the rule for crank shafts has hitherto been that the—

Diameter of the crank pin should be as small as possible, to reduce the radius of friction }
Length of crank pin should be as great as possible, to reduce the pressure per unit of } (121)
bearing surface }

These two rules, 120 and 121, contradict each other.

The length of the bearing should therefore depend, not on its diameter, but upon the pressure on the piston, and therefore on the diameter of the cylinder.

* q = pressure on area of bearing (in lbs. per sq. inch); v = circumferential velocity of the crank pin; μ = coefficient of friction = 0.05 (see p. 98).

Strength and Overheating of the Bearings.

To test the *strength of the journals, etc., does not in itself afford sufficient data* for determining finally the dimensions of the crank shaft. Both the crank pin and the journals should be tested for the pressure on the bearing surface q and the product $q \times v$, for upon this depends the permissible friction in the journals.

The effect of the tension of the belt is very small, and may be neglected. (See the Author's "Steam Engines," 7th Edition, pp. 48 *et seq.*)

(In steam engines it has hitherto been usual to base the calculations on the admission pressure p , although the amount of friction, upon which overheating mainly depends, is chiefly determined by the mean pressure, p_m , above atmosphere.)

In any case the pressure on the bearing surfaces q cannot be determined from the pressure of explosion because, except in the case of double-acting two-cycle gas engines, strokes continually occur during which there is no pressure on the crank pin.

We have therefore to consider—

1. How many strokes intervene between two consecutive working strokes?
2. In what sequence do the working strokes follow each other? (On this point see the developed diagrams, pp. 16 and 17.)
3. In how many cylinders do the pistons work upon the same crank?

In a four-cycle engine we must take count of the inertia curve for the admission and exhaust (Ist and IVth strokes), the different areas must be planimeted, and the arithmetical mean calculated from them. For instance, in a single-acting four-cycle engine with an explosion pressure of 370 lbs. (diagram, Fig. 3, p. 36), we have—

I st	Stroke Admission	$p_I = 7$ lbs. per sq. inch.
II nd	Compression	$p_{II} = 24$ „ „
III rd	Expansion	$p_{III} = 110$ „ „
IV th	Exhaust	$p_{IV} = 7$ „ „
Total = 148 „ „		

or, pressure per stroke $p_r = \frac{148}{4} = 37$ lbs. per sq. inch.

The figures in Table VIII. have been calculated in this way. Note further that in a double-acting two-cycle gas engine $p_r = p_m$.

Table VIII.—Values of p_r calculated for a Single Crank-pin Bearing.

p_r = lbs. } per sq. in. }	For meaning of symbols of gas engines, see p. 3.								Steam engines.							
	Single-acting four-cycle.				Double-acting four-cycle.				Double-acting two-cycle.		Single cylinder.	Tandem.	Compound.	Triple expansion. 3 cranks.	Triple expansion. 2 cranks.	
	E 4, 1 c.	G Z 4, 2 c.	Z 4, 2 c.	R 4, 2 c.	Z 3 Z 4, 4 c.	D 4, 1 c.	Z D 4, 2 c.	R D 4, 2 c.	R Z D 4, 4 c.	Korr. D 2, 1 c.						Oech. D 2, 1 c.
37	57	37	67	57	57	85	85	85	55	48	34	17	11	20		

Example 2.—In a 500 HP double acting two-cycle engine, Koert. D 2, 1 cyl., with 3 bearings, let $A = 493$ sq. inches; $n = 100$, and $W = 26,500$ lbs. Table VIII. gives us $p_r = 85$ lbs. per sq. inch, and by Table IX.—

<i>Crank Pin.</i>	<i>Main Bearing (flywheel side).</i>
$d = 12\frac{1}{2}"$ dia., $b = 14\frac{1}{2}"$ long	$d = 12\frac{1}{2}"$ dia., $b = 20\frac{1}{2}"$ long
$q_{\max} = \frac{370 \times 498}{12\frac{1}{2} \times 14\frac{1}{2}} = 1000$ lbs. per sq. in. (approx.)	$q_{\max} = \frac{185 \times 498 + 0.6 \times 26,500}{12\frac{1}{2} \times 20\frac{1}{2}} = 410$ lbs. per sq. in.
$q = \frac{85 \times 498}{12\frac{1}{2} \times 14\frac{1}{2}} = 233$ lbs. per sq. in.	$q = \frac{0.5 \times 85 \times 498 + 0.6 \times 26,500}{12\frac{1}{2} \times 20\frac{1}{2}} = 141$ lbs. per sq. in.
$v = \frac{12\frac{1}{2} \times \pi \times 100}{12 \times 60} = 5.45$ ft. per sec.	$v = \frac{12\frac{1}{2} \times \pi \times 100}{12 \times 60} = 5.45$ ft. per sec.
$F = 233 \times 5.45 \times 0.05 = 63.25$ ft.-lbs. per sec.	$F = 141 \times 5.45 \times 0.05 = 38.5$ ft.-lbs. per sec.

Thus the effect of the weight of the flywheel on the main bearing in the first example is 0.73, in the second 0.43 of the value of q .

In the bearing on the side-shaft side, which is generally of the same dimensions as the main bearing, q is less, as the effect of the weight of the flywheel is *nil*. For the example given above $q = 84$ lbs. per sq. inch.

For the out-end bearing only part of the weight of the flywheel need be taken into account, and the pressure on this bearing is approximately $= 0.5 \times W$. For this reason the out-end bearing is generally made somewhat smaller ($\frac{1}{4}$) than the main bearing.

If the same method be used for calculating a steam engine, and the effect of the weight of the flywheel be allowed for, the values given in Table X. are obtained for a 300 HP engine. The figures are taken from Haeder "Steam Engines," 7th Edition.

Table X.—Values of q and F for a 300 HP Steam Engine.

<i>Type.</i>	<i>Crank Pin.</i>	<i>Main Bearing.</i>
Single cylinder	$q_{\max} = 1065$; $q = 410$ lbs. per sq. in., $F = 57.5$ ft.-lbs./sec.	$q_{\max} = 330$; $q = 114 + 43 = 157$ lbs. per sq. in., $F = 26.6$ ft.-lbs./sec.
Compound . . .	$= 1050$; $q = 455$ " " " $F = 55$ ft.-lbs./sec.	$= 330$; $q = 114 + 57 = 171$ " " " $F = 25.6$ ft.-lbs./sec.
Tandem . . .	$= 1149$; $q = 500$ " " " $F = 60.6$ ft.-lbs./sec.	$= 380$; $q = 147 + 57 = 204$ " " " $F = 30.3$ ft.-lbs./sec.

Since the differences in working out these calculations for both classes of engines are very slight, it seems desirable to adopt p_r instead of p as a uniform basis of calculation for steam as well as for gas engines.

Section II. The Main Bearings of a Gas Engine.

SMALLER engines are usually built with two bearings only, and as, in order to keep the crank shaft as light as possible, these bearings are placed close against the crank webs, the design of the main bearings should be very carefully considered. The types in most general use are—



FIG. 62.




FIG. 63.


Adjustable bearings with horizontal cap (or keep), or inclined towards the centre (Figs. 62, 63).

Self-lubricating bearings with one or two loose oiling rings (Fig. 64, 65).

Self-lubricating bearings, with fixed oiling ring and wiper (Figs. 66, 67).



FIGS. 64, 65.—Loose Ring.



FIGS. 66, 67.—Fixed Ring (Wülfel).

The oiling ring R (Figs. 64, 65), is rotated with the crank shaft, dips into the reservoir O, and delivers oil to the bearing above.

In Figs. 66, 67, the oil on the surface of the fixed ring R on the shaft is deflected by the wiper plate B into the pockets A (cast in the top of the bearing brass), and flows from thence to the shaft through the holes r.




FIG. 68.—Two Loose Rings.

It has sometimes been found that bearings fitted with *two oiling rings* have a tendency, after the engine has been working some time, to run hot in the middle of the journal, *i.e.* in the part between the two rings. Engineers are not yet agreed as to the causes of this phenomenon. Some think that the oil flowing out of the lubricating rings draws out the rest of the oil by suction to the ends of the bearings, thus leaving the part of the journal between the rings dry.

Others are of opinion that, where there are two lubricating rings, the oil between them, as shown at Fig. 68, is driven inwards, and can neither escape nor be replenished.

In either case, to get over the difficulty, a small hole should be drilled in the bottom brass, midway between the rings (a, Fig. 68), through which the oil escapes from the middle of the journal.

Upon this subject see a paper in Haeder's "Zeitschrift," 1901, p. 197. Mention is there made of a method of lubricating the crank-shaft bearings of a steam engine by means of two loose oiling rings (Fig. 69), which did not fulfil its object, and the bearings frequently ran hot.

To remedy the evil, two fixed rings were fitted on the shaft, and brasses of the Wülfel type put in (Fig. 70), after which the bearing ran smoothly.

In other cases, however, loose rings have been found quite satisfactory.

The remarks in the author's book "Konstruiren und Rechnen," 3rd Edition, in the chapters on "Main Bearings" and "Transmission" should also be noted.

Four part bearings with wedge (see Fig. 71), or set screw adjustment (see Fig. 72), similar to those customary in steam engine practice, are not used in medium sized and small gas engines.

Where wedges are fitted, they are usually adjusted at the back, and care is taken not to put them in the front, where the pressure due to explosion comes upon the bearing.




FIG. 69.—
Main Bearing with
Lubricating Ring.




FIG. 70.—Lubricating Ring with Wiper (Wülfel System).




FIG. 71.




FIG. 72.

Rules for constructing Crank-shaft Bearings.*

1. The *brasses* should have as much *external bearing surface* as possible in the housing (Fig. 73). If they are made with narrow bearing strips, as shown in Fig. 74, the brass

* See also p. 106.

soon works loose in the housing because, owing to the great pressure on the bearing, and especially the shock due to the high explosion pressure, the metal of the brass becomes impressed into that of the housing (see "Die kranke Dampfmaschine," 3 Ed. p. 109).




FIG. 73.




FIG. 74.



FIG. 75.




FIG. 76.




FIG. 77.



FIG. 78.




FIG. 79.




FIG. 80.






FIG. 81.

Top halves of Brass.



Bottom halves of Brass.

FIGS. 82-88.—Oil Grooves.

L, holes for steady pins to hold the brass in position.

2. It is easy to prevent the *brasses turning round* in the housing, by steady pins in the side flange (Fig. 75), or in the middle of the brass, Fig. 76 (see Table XI., Figs. 83-88).

3. If the brass is of bronze, it should have a *narrow facing* on the flange (Fig. 78), which makes it easier to fit into position than when there is a wide flange, as in Fig. 77.

4. The dove-tailing of the white metal lining of the bearing should be conical (Fig. 79), that it may not be forced out sideways by the pressure on it.

5. If the white metal projects from $\frac{1}{8}$ inch to $\frac{1}{4}$ inch as at E, Fig. 79, and the crank web or oil fender ring presses against it (Fig. 81), the white metal is easily forced out and broken up, and the side play of the shaft rapidly increases, and causes uneasy running of the engine. It seems, therefore, better to design the bearing as at Fig. 80, and not to allow the white metal to project; V should be about $\frac{3}{8}$ inch or $\frac{1}{2}$ inch.

6. The grooves for the oil should be shown on the drawing and not left to the caprice of the workman.

Design and dimensions are given in Table XI., Figs. 82-88.

Table XI.—Oil Grooves and Check Screws.
Dimensions in inches.

Diameter of bearing =	2 ins. to 3 $\frac{1}{4}$ ins.	4 ins. to 5 $\frac{1}{4}$ ins.	5 $\frac{1}{2}$ ins. to 7 $\frac{1}{4}$ ins.	7 $\frac{1}{2}$ ins. to 11 $\frac{1}{4}$ ins.	11 $\frac{1}{2}$ ins. to 15 $\frac{1}{4}$ ins.
Width b =	ins. $\frac{1}{8}$	ins. $\frac{3}{8}$	ins. $\frac{1}{4}$	ins. $\frac{5}{16}$	ins. $\frac{3}{8}$
Depth t =	$\frac{1}{16}$	$\frac{1}{8}$	$\frac{1}{8}$	$\frac{5}{32}$	$\frac{3}{16}$
Distance from end e =	$\frac{5}{16}$	$\frac{7}{16}$	$\frac{3}{4}$	$1\frac{3}{16}$	$1\frac{9}{16}$
Diam. of check screw s =	$\frac{3}{8}$	$\frac{1}{2}$	$\frac{5}{8}$	$\frac{3}{4}$	$\frac{7}{8}$

Table XIa.—Oil Grooves and Check Screws.
Dimensions in millimetres.

Diameter of bearing.	50 to 95.	100 to 145.	150 to 195.	200 to 295.	300 to 400.
Width b =	5	6	7	8	10
Depth t =	2	3	3	4	5
Distance from end of brass e =	8	12	20	30	40
Diam. of check screw s =	10	13	16	16	20

7. To prevent waste of the oil running out on either side of the journal, and thrown off from the oil fender ring, it is caught in small *troughs*, F, and returned through the openings *r* into the oil reservoir below.





Fig. 89.

Table XII.—Oil Guard for Crank-shaft Bearing (Figs. 90, 91).



Dimensions in millimetres.

Diameter of bearing.	a	b	c	e	f	g	h	s
100 to 145	10	27	10	5	8	11	30	10
150 „ 195	12	33	12	6	10	14	40	13
200 „ 295	15	42	15	8	13	17	60	16
300 „ 400	20	50	20	10	16	20	80	20

Dimensions in inches.

Diameter of bearing.	a	b	c	e	f	g	h	s
ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.
4-5 $\frac{3}{4}$	$\frac{3}{8}$	1 $\frac{1}{8}$	$\frac{3}{8}$	$\frac{1}{8}$	$\frac{1}{8}$	$\frac{1}{8}$	1 $\frac{1}{8}$	$\frac{3}{8}$
5 $\frac{1}{2}$ -7 $\frac{1}{4}$	$\frac{1}{8}$	1 $\frac{1}{4}$	$\frac{1}{8}$	$\frac{3}{16}$	$\frac{1}{8}$	$\frac{1}{8}$	1 $\frac{1}{8}$	$\frac{1}{2}$
7 $\frac{1}{2}$ -11 $\frac{1}{8}$	$\frac{1}{8}$	1 $\frac{3}{8}$	$\frac{1}{8}$	$\frac{1}{8}$	$\frac{1}{8}$	$\frac{1}{8}$	2 $\frac{1}{8}$	$\frac{1}{2}$
11 $\frac{1}{2}$ -15 $\frac{1}{4}$	$\frac{1}{4}$	2	$\frac{1}{4}$	$\frac{1}{8}$	$\frac{3}{8}$	$\frac{1}{8}$	3 $\frac{1}{8}$	$\frac{1}{2}$

The countersunk-headed screws *s* for securing the oil guards to the bearing must be so arranged that they do not penetrate the cap (see Figs. 90, 91), otherwise it would be impossible to remove the bearing cap without first taking out these screws. A sound joint should be made between the lower faces of the guard, as oil readily leaks through a bad joint.

8. The *cap* should only fit the bearing closely at two places, say at *b, b* (Fig. 92), and be clear of it at *a, a*, otherwise it is difficult to loosen and remove it. If the cap is large, it is easier to lift if two eyebolts, *o, o* (Fig. 92), are fitted in it.




FIG. 92.

9. The cap is not often shaped as at Fig. 93, but usually as at Figs. 94, 95. The sharper curve in Fig. 95 looks better and stronger than the simple rounded outline at Fig. 94.




Figs. 98, 94, 95.

In many cases the whole top of the cap is shaped like a parabola. To arch the middle of the cap as much as possible, as in Figs. 105-112, p. 107, gives a pleasing effect.

10. In the same way, to make the bearing and side frame *taper* from the plinth to the top, as in Fig. 96, has a neat and good appearance.

11. The cross section of the *oil ring* of the crank-shaft bearing should not be rectangular (Fig. 97), otherwise it may stick at the sides, but either semi-circular (Fig. 98), or preferably trapezium-shaped (Fig. 99). When the shaft is rotating rapidly, the ring swings out of the perpendicular (Fig. 101). When in this position, it should be well clear of the housing and bearing; if it touched anywhere, the ring would not rotate with the shaft.



Figs. 96,



97,



98,




99,



100,



101,



102.

It is advisable to make the oiling ring in *two parts*, as at Fig. 102, otherwise it cannot be easily removed when the engine is erected or dismantled. The two parts are dove-tailed one into the other at the joint, and held together by a small grub screw *s* (Fig. 102).

12. The *lids over the oil boxes* in the main bearing cap should be hinged on to the cap and of a neat pattern, and should have a projecting lip *N* (Figs. 103, 104) by which to lift them.

Table XIII.—Oil-box Lids (Figs. 103, 104).


Dimensions in millimetres.

<i>d</i>	<i>a</i>	<i>b</i>	<i>c</i>	<i>e</i>	<i>f</i>	<i>g</i>
20-40	4	6	12	4	10	8
41-70	6	8	16	5	12	10
70-100	8	10	20	6	15	15

Table XIIIa.—Oil-box Lids (Figs. 103, 104).

Dimensions in inches.

<i>d</i>	<i>a</i>	<i>b</i>	<i>c</i>	<i>e</i>	<i>f</i>	<i>g</i>
ins.	ins.	ins.	ins.	ins.	ins.	ins.
$\frac{3}{4}$ -1 $\frac{1}{4}$	$\frac{1}{8}$	$\frac{1}{4}$	$\frac{1}{2}$	$\frac{1}{8}$	$\frac{3}{8}$	$\frac{5}{8}$
1 $\frac{1}{8}$ -2 $\frac{1}{4}$	$\frac{3}{16}$	$\frac{1}{2}$	$\frac{3}{4}$	$\frac{5}{16}$	$\frac{1}{2}$	$\frac{3}{4}$
2 $\frac{1}{4}$ -4	$\frac{1}{4}$	$\frac{3}{8}$	1	$\frac{3}{8}$	$\frac{3}{4}$	1



Figs. 103, 104.—Oil-box Lids.

Table XIV.—Main Bearing with Oiling Ring. (Ring in two parts.) (Figs. 105-114.)

Dimensions in millimetres.

Engine.			Main bearing brass.					Housing of bearing.								Cap of main bearing.										Oiling ring.			
HP	S	D	d	l	a	b	c	e	f	g	h	i	k	m	o	p	q	r	s	No.	t	u	v	w	x	y	z	No.	
0.6	125	80	42	72	7	—	11	9	14	72	30	40	60	10	10	7	45	22	16	2	7	15	17	—	70	10	14	1	
1.2	160	100	50	90	8	—	12	10	15	84	35	40	70	11	10	8	52	22	16	2	8	17	21	—	85	10	14	1	
2	190	125	60	108	9	—	13	10	17	100	42	55	75	12	10	9	58	25	20	2	9	20	27	—	95	12	16	1	
3.5	220	145	70	125	10	—	14	12	19	114	48	55	80	14	11	9	65	25	20	2	10	23	35	—	110	12	16	1	
7	270	185	95	170	13	—	16	12	24	146	65	55	85	16	12	10	80	30	20	4	14	30	54	10	150	14	18	1	
11	310	220	110	195	15	—	18	14	28	170	75	55	90	18	14	11	90	35	20	4	16	35	62	11	175	14	18	1	
17	350	260	125	230	23	6	20	15	31	204	85	70	100	20	16	12	95	40	26	4	18	40	80	12	200	16	20	1	
25	400	300	145	265	26	7	22	16	35	234	95	70	120	22	18	13	110	45	26	4	22	45	90	13	230	16	20	1	
33	450	330	155	290	28	7	24	17	38	250	100	80	135	24	20	14	115	50	29	4	23	47	100	14	250	18	22	1	
42	500	360	165	305	30	8	26	18	40	270	110	80	160	26	22	15	125	55	29	4	24	50	105	16	265	18	22	1	
55	550	400	180	340	32	8	28	20	45	290	120	85	180	30	26	16	135	65	32	4	26	55	114	18	290	12	16	2	
80	600	480	200	395	35	9	32	22	51	324	130	85	210	32	28	18	150	40	32	4	28	60	145	20	320	14	18	2	
132	700	600	245	480	42	10	35	25	65	390	160	95	230	34	30	20	180	50	35	4	32	70	170	24	390	16	20	2	

For bearings up to about 4 inches diameter, the brasses or steps are of gun metal; for diameters of the bearings of 5 inches and upwards, cast iron or cast steel is used for the steps, with white metal linings.

* The bearings illustrated by Figs. 105-114 belong to German engines, and are dimensioned in millimetres in Table XIV. For the convenience of readers not accustomed to working in millimetres Table XIVa. gives the nearest equivalent in inches.

Parts of a Crank-shaft Bearing with Two Oiling Rings.




FIG. 115.

Main Bearing Brasses (see p. 107).

- S_1, S_2, S_3 Top brasses } see bottom of last page.
 S_4 Bottom brass }
 r Slots for oiling rings.
 M Steady pins for holes m .
 z Opening in bottom brass, to allow the oil to circulate.




FIG. 116.

Main Bearing Cap or Keep (p. 107).

- A Cap or keep.
 r Slots for oiling rings.
 B Cap studs for holes b .




FIG. 117.

Housing of Bearing (p. 107).

- b Holes for cap studs B .
 r Slots for oiling rings.
 n Opening to allow the oil to pass from the oil guard to the reservoir (see Fig. 89, p. 108).
 c Facing for oil guard.
 h Tapped holes for studs fastening the oil guard to the bearing.
 z Opening to allow the oil to circulate.



FIG. 118.

- Oiling Rings* (p. 107).
 R_1, R_2 Halves of oiling rings.
 K Grub screw, to hold them together.





FIG. 119.

Oil Guard (Table XII., p. 108).

- H_1 Upper, H_2 lower half of ring.
 G Small screws fitting holes g .



Figs. 120, 121, 122.

Hinged Oil-box Lids (Table XIII., p. 104).


To cover the oil boxes on the cap.

Section III. Frame and Cylinder.

Frame.

Gas engines, as already mentioned, are almost exclusively made with cranked shafts (*i.e.* not overhung crank pins). Figs. 123–125 show a usual type for engines up to about 18 inches stroke.

For frames with overhung cylinders (Fig. 123) the same rule holds good as for steam engines, and they are only used for small gas engines, because of the vibration and bending strain upon the cylinder. In larger engines they should be avoided, and the frame should support the cylinder throughout its length (Fig. 126).



FIGS. 123–125.—Frame and Cylinder for Engines up to 18-inch Stroke.

R Frame.

E Liner.

L Cap for bearing.

M Water jacket cast with frame.

N Boss for oil-splasher guard (Fig. 141).

S Facing for side-shaft bracket, and oil-splasher guard protecting the side-shaft worm gear.

G Boss for cock for cooling water to jacket.

W Boss for cock for cooling water passing from breech end to water jacket.

W₁ Cooling water outlet.

O Boss for piston lubricator.




FIG. 126.—Frame and Cylinder for Engines above 20-inch Stroke.

Many makers build the frame as shown at Fig. 127, but the object of enclosing the crank in the casing W is not very apparent. This type of construction, originally adopted only for small power engines, has now been applied to larger sizes.




FIG. 127.

Rules for Constructing the Frame.*

1. The side of a frame, *i.e.* the part between the body of the main bearing and the hood of the frame, should be carried up as high as possible. For large engines the arrangement shown at Fig. 128 is not desirable; the heavy bending stresses coming on the side of the frame are more easily taken if the engine is built as at Fig. 129.




FIG. 128.




FIG. 129.




FIG. 130.

edges *a*, and the curve at the side, *b*, of the frame.




FIG. 131 (wrong).




FIG. 132 (right).




FIG. 133.

Table XV.—Holding down Bolts.

Dimensions in millimetres.

Stroke.	400	500	600	700	800	1000	1250
$d =$	$1\frac{1}{2}''$	$1\frac{1}{2}''$	$1\frac{3}{4}''$	$1\frac{7}{8}''$	$2''$	$2\frac{1}{4}''$	$2\frac{3}{4}''$ engl.
$s =$	48	52	56	60	65	75	87 mm.
$s_1 =$	60	66	70	76	85	95	115 "
$s =$	100	105	115	125	135	150	170 "

Table XVa.—Bolts to hold down the Frame, and Corresponding Holes (Fig. 133).

Dimensions in inches.

Stroke of engine.	16 ins.	20 ins.	24 ins.	28 ins.	32 ins.	40 ins.	48 ins.
	ins.	ins.	ins.	ins.	ins.	ins.	ins.
$d =$	$1\frac{1}{8}$	$1\frac{1}{8}$	$1\frac{3}{8}$	$1\frac{7}{8}$	2	$2\frac{1}{4}$	$2\frac{3}{4}$
$s =$	$1\frac{7}{8}$	2	$2\frac{3}{8}$	$2\frac{5}{8}$	$2\frac{9}{8}$	3	$3\frac{7}{8}$
$s_1 =$	$2\frac{5}{8}$	$2\frac{11}{8}$	$2\frac{3}{4}$	$2\frac{13}{8}$	$3\frac{1}{8}$	$3\frac{3}{4}$	$4\frac{1}{8}$
$b =$	$3\frac{1}{8}$	$4\frac{1}{8}$	$4\frac{1}{2}$	$4\frac{7}{8}$	$5\frac{5}{8}$	6	$6\frac{3}{4}$

3. Good material should be used for the frame, and care taken that the diminution in the thickness of the walls is made gradually, not suddenly. All sharp corners must be avoided. These rules apply specially to engines of more than 20" stroke.

4. It is advisable to carry the metal surrounding the lugs for the bolts of the frame down to the bed plate, as shown at Fig. 132, to avoid the stresses due to bending which may otherwise be set up in the frame

* The rule given at p. 23 is here of special application.

when these bolts are suddenly tightened up. To tighten them two or three men are often required, who use a piece of gas pipe, from 4 to 6 feet long, on the spanner.


In order not to expose the washers, the diameter of the holes may be rather smaller at the top than at the bottom.

5. The frame should have a *fairly large surface* in contact with the foundation, and be made as at Fig. 135, and not as at Fig. 134, although the part at the foot of the frame does not add much to its strength. For this reason the metal at *a*, Fig. 135, should not be made too thick.



FIGS. 134, 135.

6. An arrangement should be made to drain off the *lubricating oil* collecting in the crank pit through a small pipe (Fig. 137). The oil from the piston and piston rod should be caught in a separate drip tray B, and discharged, preferably through a cock at the side.



FIGS. 136, 137.

7. To prevent the *lubricating oil* from *leaking* through to the foundation, gutters (Fig. 138) should be provided round the bed plate.

8. A facing should be cast on the side of the frame, on to which the side-shaft brackets and worm-gear guard can be bolted (see Fig. 139). For medium sized and larger engines a second facing, S, Fig. 140, is needed to take a second bracket for the side shaft, if one is required, and also, if necessary, for the oil pump and governor.



FIG. 138.

9. An *oil-splasher guard* is fitted over the crank, to prevent the lubricating oil being




FIG. 139.




FIG. 140.—Extended Frame.

flung out from the crank pin. It should be of sheet iron, as light as possible, and easily removed. To afford convenient access to the crank shaft it is advisable to have the guard hinged, as at *s*, Fig. 141, that it may be raised into the position shown by the dotted lines.

It has stiffeners at the sides, either riveted (Figs. 142–144), or rolled into it (Fig. 145). Since, as we have said, it should be extremely light, it is best to strengthen it with a beading rolled in it, as at Fig. 145, but this is only applicable to engines up to 20 inches stroke; above that size separate stiffeners are necessary.




FIG. 141.



FIG. 142.



FIG. 143.





FIG. 144.



FIG. 145.

Table XVI.—Crank Splasher Guard (Figs. 146-148).




Figs. 146-148.—Splasher Guard.

Dimensions in millimetres.

Stroke.	Splasher guard.				Bolts.		
	a	b	c	e	f	g	i
100-290	0.5	15	10	25	20	16	4
300-440	0.75	20	12	35	24	20	5
450-600	1	25	15	45	28	23	6

Dimensions in inches.

Stroke.	Splasher guard.				Bolts.		
	a	b	c	e	f	g	i
ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.
4-11½	⅜	⅝	⅜	1	¾	⅝	⅜
12-17½	⅝	⅞	⅞	1½	1	¾	⅞
17½-24	¾	1	1	1¾	1½	1	1

FIG. 149.— $x = 0.18 \times \text{Stroke}$. R to be determined later.

The dimensions of B and h, Figs. 146-148, must be determined when designing the oil splasher guard in conjunction with the frame.

In *large gas engines* the oil splasher guard cannot be made with a hinge, and to remove it easily it is fitted into two pockets, T, Fig. 149, cast in the sides of the frame.

A slot U is left in it, to clear the connecting rod.

The Cylinder.

The liner and water jacket are either *cast in one* (Fig. 150), or made in *two separate parts*, at at Fig. 151.

In small engines, in which there is no great pressure of water, the jacket is sometimes replaced by a *sheet iron casing* (Fig. 152), but in large engines the pressure of water in the jacket is as much as 14 to 20 lbs. per sq. inch (see chapter on "Water cooling").



FIG. 150.—Jacket and Cylinder cast in one.




FIG. 151.—Water Jacket and Separate Cylinder Liner.




FIG. 152.—Sheet-iron Casing in place of Water Jacket.

The advantage of a *separate liner* is that specially good tough material, preferably close grained cast iron, can be used, and if the liner becomes worn, it can quickly be renewed or re-bored (see Fig. 151).

The cylinder is either bolted to the frame, Figs. 153, 154, or cast in one with it, Fig. 155. For securing the cylinder to the frame the bolts should be few in number, but as strong as possible. The bolts and studs in Figs. 153, 154 are calculated for a pressure on the piston of $D^2 \frac{\pi}{4} \times 380$ lbs. per sq. inch, and an allowable stress per section area at bottom of thread of 4200 to 5600 lbs. per sq. inch.*




FIG. 153.
Cylinder and Jacket in one,
bolted to Frame. Usual
type for small engines.




FIG. 154.
Jacket bolted to Frame.
Separate Cylinder Liner.
Seldom made.




FIG. 155.
Jacket and Frame cast in
one. Most usual and
popular type.

If there is a separate liner the jacket is generally cast in one with the frame (Fig. 155).

To allow the liner to expand in conformity with the high temperatures developed, it should only be bolted at one end (usually the back), and permitted to expand freely at the other.

In many engines there is no special packing at *a*, Fig. 156, to prevent leakage from the water jacket. The jacket is heated up to 390° Fahr., then shrunk over the liner, which is turned about $\frac{1}{4}$ per cent. larger than the bore of the water jacket. Grooves




FIG. 156.—Without
Packing.




FIG. 157.—Stuffing Box Packing.




FIG. 158. (Deutz.)




FIG. 159.

Packing of Rubber Rings.

are often turned in the jacket and liner at *a*, which are supposed to check any leakage. In the packing shown at Figs. 157–159, allowance is made for the expansion of the liner.

If the engine has a long stroke, it is not advisable to cast the cylinder and jacket in one, as at Fig. 150, because of the unequal expansion of the walls. Taking 20° C. = 68° F. as the temperature of the jacket, and 100° C. = 212° F. as that of the cylinder liner, these figures represent a difference in temperature of 212° – 68° = 144° F. Thus—

Length of cylinder	20"	30"	40"	60"	80"
Corresponding expansion	0.017"	0.026"	0.035"	0.051"	0.069"

* TRANSLATOR'S NOTE.—5000 lbs. per sq. inch should not be exceeded, if possible. See Table of Bolts at end of book.

Table XVII.—Liner Joint Ring and Stuffing Box, for packing the Joint between the Liner and Jacket, in Larger Single-acting Four-cycle Engines.

Dimensions in millimetres.




FIG. 160.

<i>D</i>	<i>a</i>	<i>a</i> ₁	<i>b</i>	<i>c</i>	<i>d</i>	<i>e</i>	<i>f</i>	<i>g</i>	Studs.	
									<i>s</i>	No.
400	32	36	46	48	14	14	70	75	16	8
450	35	40	48	50	15	15	80	80	16	8
500	38	45	56	58	18	16	90	85	20	9
550	41	50	58	56	20	18	95	90	20	10
600	44	54	60	60	23	20	105	95	20	12
700	50	60	64	66	28	24	120	105	20	14
800	56	70	72	70	30	25	140	110	23	16
1000	68	82	74	78	35	28	160	120	23	20
1200	80	95	82	85	40	30	180	130	26	24

Dimensions in inches.

<i>D</i>	<i>a</i>	<i>a</i> ₁	<i>b</i>	<i>c</i>	<i>d</i>	<i>e</i>	<i>f</i>	<i>g</i>	Studs.	
									<i>s</i>	No.
ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	
15 $\frac{1}{2}$	1 $\frac{1}{4}$	1 $\frac{3}{8}$	1 $\frac{1}{2}$	1 $\frac{1}{2}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	2 $\frac{3}{4}$	3	1 $\frac{1}{2}$	8
17 $\frac{1}{2}$	1 $\frac{3}{8}$	1 $\frac{1}{2}$	1 $\frac{1}{2}$	1 $\frac{1}{2}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	3 $\frac{1}{4}$	3 $\frac{1}{4}$	1 $\frac{1}{2}$	8
19 $\frac{1}{2}$	1 $\frac{1}{2}$	1 $\frac{3}{4}$	2 $\frac{1}{4}$	2 $\frac{1}{4}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	3 $\frac{3}{4}$	3 $\frac{3}{4}$	1 $\frac{1}{2}$	9
21 $\frac{1}{2}$	1 $\frac{3}{4}$	2	2 $\frac{1}{2}$	2 $\frac{1}{2}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	3 $\frac{3}{4}$	3 $\frac{3}{4}$	1 $\frac{1}{2}$	10
23 $\frac{1}{2}$	1 $\frac{3}{4}$	2 $\frac{1}{4}$	2 $\frac{3}{4}$	2 $\frac{3}{4}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	4 $\frac{1}{4}$	3 $\frac{3}{4}$	1 $\frac{1}{2}$	12
27 $\frac{1}{2}$	2	2 $\frac{3}{4}$	2 $\frac{3}{4}$	2 $\frac{3}{4}$	1 $\frac{1}{8}$	1	4 $\frac{3}{4}$	4 $\frac{3}{4}$	1 $\frac{1}{2}$	14
31 $\frac{1}{2}$	2 $\frac{3}{8}$	2 $\frac{3}{4}$	2 $\frac{7}{8}$	2 $\frac{3}{4}$	1 $\frac{1}{8}$	1	5 $\frac{1}{4}$	4 $\frac{3}{4}$	1 $\frac{1}{2}$	16
39 $\frac{1}{2}$	2 $\frac{3}{8}$	3 $\frac{1}{4}$	2 $\frac{1}{2}$	3 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	6 $\frac{1}{4}$	4 $\frac{3}{4}$	1 $\frac{1}{2}$	20
47 $\frac{1}{2}$	3 $\frac{1}{8}$	3 $\frac{3}{4}$	3 $\frac{1}{4}$	3 $\frac{3}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	7 $\frac{1}{4}$	5 $\frac{1}{8}$	1	24

To pack (or stanch) the

Joint between the Breech End and the Liner

requires special care, as it is here that the highest pressures and temperatures are developed.

The joint between the two can be made in various ways.

A few methods are shown below. Scale 1 to 10.




FIG. 161.—(Deutz, 6 HP). Diam. of cyl. (170 mm.) 6 $\frac{3}{4}$ " ; 4 studs 7" diam.




FIG. 162.—(Niel Engine). Diam. of cyl. (350 mm.) 13 $\frac{1}{4}$ " ; 8 1 $\frac{1}{4}$ " studs.




FIG. 163.—(Deutz, 60 HP). Cyl. diam. 390 mm. = 15 $\frac{3}{8}$ " ; 10 1 $\frac{1}{4}$ " studs.

The design of breech end shown at Fig. 166 has many good points; the walls *W* of the combustion chamber are quite free of the flange *V* on the outer shell, so that all strains set up in casting are avoided; the disadvantage is that the liner

joint cannot be tightened after the engine has warmed up. For further particulars see Part B.




FIG. 164.—(Deutz, 60 HP).
Diam. of cyl. (440 mm.) $17\frac{1}{2}$ ";
12 $1\frac{1}{8}$ " studs.




FIG. 165.—Diam. of cyl. (650 mm.) $25\frac{1}{2}$ "; 18 $1\frac{1}{8}$ " studs.




FIG. 166.—(Bollenckx).
Cyl. diam. 400 mm. = $15\frac{1}{2}$ ".

For this packing only heat-resisting substances, such as asbestos, vulcanised fibre, etc., can, of course, be used.




FIG. 167.—(Körtling 160 HP).
Diam. of cyl. (665 mm.) $26\frac{1}{2}$ "; 20 $1\frac{1}{8}$ " studs.




FIG. 168.—(Deutz, 250 HP).
Diam. of cyl. (840 mm.) $33\frac{1}{2}$ "; 24 $2\frac{1}{8}$ " studs.

In Figs. 169–172, the packing consists of an intermediate layer of thin *asbestos paper*, about $\frac{1}{32}$ inch thick. A stouter layer should be avoided, because it may easily be blown out




FIG. 169.




FIG. 170.




FIG. 171.




FIG. 172.

by the pressure of the gas, unless the bolts are unnecessarily tightened, to hold it in position.




FIG. 173.




FIG. 174.




FIG. 175.




FIG. 176.

Asbestos string is often used for packing (Figs. 173–176).

If a joint is blown out when the engine is running, and a temporary packing has to be put in, *cardboard soaked in linseed oil* has sometimes been used for the purpose, but it does not always answer.

As the *arrangement of the bolts* must depend on the shape of the breech end, the calculation and standard sizes of these bolts will be found under "*Breech ends*." Whenever possible, the designer should arrange that the pitch circle of the bolts, securing the breech end to the water jacket, should be the same as the mean diameter of the water jacket shell, as shown in Figs. 169–176, to avoid bending stresses on the flange.

For *standard dimensions* of the frame and cylinder, see pp. 116–120.

FIG. 178.





FIG. 177.

FIG. 179.




FIG. 180.






FIG. 184.

FIG. 183.

FIG. 182.—View of Underside.

FIG. 181.—Side Elevation.

FIGS. 177-184.—Frame and Cylinder of an Engine with $D = 220$ mm. ($8\frac{3}{4}$ "); $S = 310$ mm. ($12\frac{3}{16}$ "). Scale 1 to 15.

ing rod.																											
HP	S	D	L	a	b	c	d	e	f	g	h	i	i ₁	k	k ₁	l	m	o	p	q	r*	s	t	u	v	w	x
0.6	5	31	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.
1.2	6	4	14	31 ¹⁶	5 ¹⁶	15 ¹⁶	16 ¹⁶	16 ¹⁶	24 ¹⁶	24 ¹⁶	61 ¹⁶	11 ¹⁶	—	3	13	107	1	7	5 ¹⁶	15 ¹⁶	54 ¹⁶	ins.	ins.	ins.	ins.	ins.	ins.
2	7	5	18 ¹⁶	41 ¹⁶	6 ¹⁶	12 ¹⁶	16 ¹⁶	16 ¹⁶	24 ¹⁶	24 ¹⁶	71 ¹⁶	2 ¹⁶	—	3	13	131	1	13	13 ¹⁶	18 ¹⁶	64 ¹⁶	ins.	ins.	ins.	ins.	ins.	ins.
3.5	8	5	21 ¹⁶	54 ¹⁶	7 ¹⁶	13 ¹⁶	16 ¹⁶	16 ¹⁶	24 ¹⁶	24 ¹⁶	81 ¹⁶	3 ¹⁶	—	3	13	16	1	13	7 ¹⁶	22 ¹⁶	74 ¹⁶	ins.	ins.	ins.	ins.	ins.	ins.
5	10	6	25 ¹⁶	64 ¹⁶	8 ¹⁶	14 ¹⁶	16 ¹⁶	16 ¹⁶	24 ¹⁶	24 ¹⁶	10 ¹⁶	3 ¹⁶	—	3	13	183	2	13	16 ¹⁶	25 ¹⁶	91 ¹⁶	ins.	ins.	ins.	ins.	ins.	ins.
7	12	7	31 ¹⁶	81 ¹⁶	11 ¹⁶	15 ¹⁶	16 ¹⁶	16 ¹⁶	24 ¹⁶	24 ¹⁶	12 ¹⁶	3 ¹⁶	—	3	13	233	18	11 ¹⁶	30 ¹⁶	111 ¹⁶	ins.	ins.	ins.	ins.	ins.	ins.	ins.
9	14	8	34 ¹⁶	91 ¹⁶	13 ¹⁶	16 ¹⁶	16 ¹⁶	16 ¹⁶	24 ¹⁶	24 ¹⁶	13 ¹⁶	4 ¹⁶	—	3	13	25	13	118	34	128	ins.	ins.	ins.	ins.	ins.	ins.	ins.
11	16	9	40	111 ¹⁶	1	17 ¹⁶	16 ¹⁶	16 ¹⁶	24 ¹⁶	24 ¹⁶	16 ¹⁶	4 ¹⁶	—	3	13	28	13	25 ¹⁶	18	139 ¹⁶	ins.	ins.	ins.	ins.	ins.	ins.	ins.
13	18	10	46	111 ¹⁶	1	17 ¹⁶	16 ¹⁶	16 ¹⁶	24 ¹⁶	24 ¹⁶	16 ¹⁶	4 ¹⁶	—	3	13	28	13	25 ¹⁶	18	139 ¹⁶	ins.	ins.	ins.	ins.	ins.	ins.	ins.
17	23	13	40	111 ¹⁶	1	17 ¹⁶	16 ¹⁶	16 ¹⁶	24 ¹⁶	24 ¹⁶	16 ¹⁶	4 ¹⁶	—	3	13	28	13	25 ¹⁶	18	139 ¹⁶	ins.	ins.	ins.	ins.	ins.	ins.	ins.
20	25	15	46	131 ¹⁶	1 ¹⁶	18 ¹⁶	16 ¹⁶	16 ¹⁶	24 ¹⁶	24 ¹⁶	18 ¹⁶	4 ¹⁶	—	3	13	34	1 ¹⁶	23	11 ¹⁶	451 ¹⁶	ins.	ins.	ins.	ins.	ins.	ins.	ins.
25	25	15	46	131 ¹⁶	1 ¹⁶	18 ¹⁶	16 ¹⁶	16 ¹⁶	24 ¹⁶	24 ¹⁶	18 ¹⁶	4 ¹⁶	—	3	13	34	1 ¹⁶	23	11 ¹⁶	451 ¹⁶	ins.	ins.	ins.	ins.	ins.	ins.	ins.

The beading O at the top may be omitted, and the beading at the side thinned off into the upper wall.

Length x (from back end of piston, at the end of the stroke, to liner joint) will be calculated later, with the dimensions of the breech end.

For engines of less than 10½ inches stroke five bolts for holding down the frame are sufficient. As shown at Fig. 179, to the left in p. 116, the two bolts nearest the cylinder are in that case placed behind the frame, the bosses marked F are omitted, and replaced by the boss N, indicated by dotted lines in the centre of the frame.

* The frame can be made much lighter by reducing the dimension h , and allowing the crank pit to project below the base line of the frame; the dimension r can be settled after drawing in the connecting rod in several positions, and allowing good clearance (see next page).

Table XIX.—Frame and Cylinder for Engines E 4 up to 700 mm. (27½") Stroke (Figs. 185–191).

Engine.			Comp. rod.	Cylinder.								Frame.																	
HP	S	D		a*	b	c	d	e	f	g	m	h	i	i ₁	k	k ₁	k ₂	l†	o	p	q	r	s	t	u	v	w	y	
29	310		1800	870	32	27	35	45	20	34	450	150	480	185	50	18	20	24	480	550	705	1100	865	42	1220	270	22	120	350
33	450	380																											
36	385		1450	390	34	29	38	50½	22	38	480	160	515	150	55	20	22	26	525	600	750	1180	915	46	1380	300	24	190	370
42	500	360																											
45	370		1575	440	38	32	42	57	24	42	525	180	565	175	60	28	25	28	590	660	880	1300	1010	50	1490	380	25	150	400
55	550	400																											
65	480		1700	520	42	37	45	70	26	46	600	220	645	200	65	26	28	30	710	760	970	1520	1200	50	1520	380	26	175	500
80	600	480																											
110	540		1950	680	46	44	78	80	28	48	700	280	750	230	75	28	30	32	890	920	1180	1850	1500	53	1840	460	30	220	620
132	700	600																											

NOTE.—The frames and cylinders illustrated by Figs. 185–191 are for German engines, and are dimensioned in millimetres; in Table XIXa, the nearest equivalent in inches is given.

Table XIXa.—Frame and Cylinder for E 4 Engines up to 27½" Stroke (Figs. 185–191).

Engine.				Cylinder.										Frame.															
HP	S	D	L	a*	b	c	d	e	f	g	m	h	i	i ₁	k	k ₁	k ₂	l†	o	p	q	r	s	t	u	v	w	y	
29	12½		51½	14½	1¼	1¼	1½	1½	1½	1½	57	18½	5½	1½	1½	2	2	18½	21½	27½	43½	34	18	48	108	18	41½	13½	
33	17½	13																											
36	19½	13½																											
42	21½	14½																											
45	21½	15½																											
55	23½	17																											
65	27½	18½																											
80	27½	21½																											
101	27½	23½																											
132	27½	23½																											

The bearing surfaces between the frame and the foundation, especially the part below the main bearing, should be as ample as possible; in other words, the base O must be well splayed out. The outline of the side of the foot of the main bearing must be parabolic, as in Fig. 184, p. 116.

For a view in perspective of this frame, see Fig. 126, p. 109. For standard types and dimensions of bearings, see p. 107; of crank shafts, p. 73. The dimensions of α will be given later, with those of the breech end.

In large engines hand holes should be arranged in the water jacket, for removing mud and scale; these holes must be compensated by casting a deep facing around them (equivalent to the metal removed). Cleaning doors should be fitted over these holes, secured by studs; screwed plugs should be avoided.

* The dimensions of α correspond to those in column 3, Table I., p. 140.

† When calculating the length of l , room must be allowed for the connecting rod, that it may not foul the splash guard anywhere.

Calculation of the Strength of a Frame.

To explain the method adopted in calculating the strength of the frame, we will consider a few very simple types to begin with. The cross section where there is *greatest danger* of fracture is at A (Fig. 192). *All dimensions to be given in inches.*

1. Simplest Type of Frame,

In which the neutral axis of the two beams connecting the sides of the frame to the bearing and cylinder is in the same plane as the middle of the shaft. Thus at cross-section A, Fig. 192 (the metal of the beams being in pure tension)—





FIG. 192.

FIG. 192A.
M centre line
of crank shaft.

$$\text{Tension } k_t = \frac{P}{2f} \text{ in lbs. per sq. in.} \quad (124)$$

where $P = \frac{\pi}{4} D^2 p$, the load on the piston in lbs. per sq. inch and f = sectional area of one side frame in sq. inches; if the whole area be taken $f = b \times h$.

The thickness of the shell of the water jacket should also be calculated for the tensile stress, P , without taking into account the foot of the frame, this stress should never exceed 1400 lbs. per sq. inch (the allowable stress is low in order to allow for a slight shifting of the core).





FIG. 193.

FIG. 193A. FIG. 193B.
MM centre line of
crank shaft.

2. Where the neutral axis of the side beams lies below the centre or axial line of the crank shaft.

Here the dangerous cross section is close to the bearing (Figs. 193-193B). In this case the metal of the frame is exposed to a combined stress due to tension and bending. Let l = Distance of centre of gravity of the cross section of the frame from the axis of the crank shaft MM , Z_b = Modulus of resistance of the cross section of the frame, in

cubic inches, reduced to the horizontal axis of its centre in sq. inches (i.e. $b \times h$).

From Figs. 193-193B. Bending moment $M_b = P \times l$ (125)

Stress due to bending $k_b = \frac{M_b}{2Z_b}$ in lbs. per sq. inch (126)

„ „ tension $k_t = \frac{P}{2f}$ „ „ (127)

Combined stress $k = k_b + k_t$ „ „ (128)

If the cross section were rectangular—

$$k = k_b + k_t = \frac{P \times l}{\frac{2bh^3}{3}} + \frac{P}{2bh} \text{ in lbs. per sq. inch} \quad (129)$$




FIG. 194.

3. Where the side frames are connected by a bottom plate, as shown at p. 116.

The stresses are calculated in the same way as before, but to determine the modulus of resistance of the section is more complicated. For instance, the cross section of the frame (Fig. 194) must be divided up into three sections, f_1, f_2, f_3 , the area of each of these sections calculated, and the distance of their centres of gravity from the top of the section, i.e. x_1 for f_1, x_2 for f_2 , as shown in Fig. 194, must be found. The centre of gravity of the whole cross section will be—

$$e = \frac{2(f_1 x_1) + f_2 x_2}{2f_1 + f_2} \text{ in inches} \quad (130)$$

The moment of inertia is determined by the equation—

$$I = \frac{2bh^3}{12} + 2bhe_1^2 + \frac{wd^3}{12} + wd_e^2 \text{ in inches}^4 \quad (131)$$

$$\text{Modulus of resistance } Z_b = \frac{I}{e} \text{ in inches}^3 \quad (132)$$

$$\text{Bending moment } M_b = Pl \text{ inch-lbs.} \quad (133)$$

$$\text{Stress due to bending } k_b = \frac{M_b}{Z_b} \text{ lbs. per sq. inch} \quad (134)$$

$$,, \text{ tension } k_t = \frac{P}{\Sigma f} \text{ lbs. per sq. inch} \quad (135)$$

$$\text{Combined stress } k = k_b + k_t \text{ lbs. per sq. inch} \quad (136)$$

4. Hollow cast-iron box frame. The design is taken from Fig. 186, p. 119.

Distance of the centre of gravity (see Fig. 195).

$$e = \frac{f_1x_1 + f_2x_2 + f_3x_3 + f_4x_4}{f_1 + f_2 + f_3 + f_4} \text{ in inches} \quad (137)$$

The moments of inertia of the separate areas are determined as follows:—

$$I_1 = \frac{b_1h^3}{12} + b_1he_1^2 \text{ inches}^4$$

$$I_2 = \frac{wb_2^3}{12} + wb_2e_2^2 \text{ inches, and so on.}$$

The moment of inertia of the whole section is the sum of the separate moments of inertia—

$$I = I_1 + I_2, \text{ etc.} \quad (138)$$

$$\text{Modulus of resistance } Z_b = \frac{I}{e} \text{ inches}^3 \quad (139)$$

$$\text{Again, the stress due to tension } k_t = \frac{P}{f_1 + f_2 + \dots} \text{ in lbs. per sq. inch} \quad (140)$$

$$\text{Stress due to bending } k_b = \frac{M_b}{Z_b} = \frac{Pl}{Z_b} \quad (141)$$

$$\text{Combined stress } k = k_b + k_t \text{ in lbs. per sq. inch} \quad (142)$$

Allowable stress, or safe working load

$$k = 1400 \text{ to } 2000 \text{ lbs. per sq. inch.}^* \quad (143)$$

Calculation of the Front Part of the Frame (Fig. 196).

In this case—

$$M_b = 0.5 Pl \text{ inch-lbs.} \quad (144)$$

$$k_b = \frac{M_b}{Z_b} \text{ lbs. per sq. inch} \quad (145)$$

Z_b can either be more accurately calculated from the moment of inertia of this box section, or approximately determined by the formula—

$$Z_b = 0.9 \frac{bh^2}{6} \text{ inches}^3 \quad (146)$$

Allowable stress or safe working load—

$$k = 1400 \text{ to } 2000 \text{ lbs. per sq. inch} \quad (147)$$

* As explained in more detail in Haeder's "Konstruiren und Rechnen," 2nd Edition, p. 288, a cast-iron frame of the above type gives way when loaded up to 9800 lbs. per sq. inch, whereas a straight bar frame will bear a load up to 84,000 lbs. per sq. inch without breaking.




FIG. 195.




FIG. 196.

Calculation of the thickness of the Cylinder Wall.

Let D = diameter of cylinder in inches. p = Explosion pressure in lbs. per sq. inch. k_t = Stress due to tension in lbs. per sq. inch. δ = Thickness of cylinder wall in inches, then according to Bach, "Maschinenelemente"—

$$\delta = \frac{D}{2} \left(\sqrt{\frac{k_t + 0.4p}{k_t - 1.3p}} - 1 \right) \text{ inches} \quad (148)$$

As the full pressure of explosion only occurs at the back end of the cylinder, where it is stiffened with a deep flange, and as, to increase the cooling action of the jacket, the metal of the cylinder should be as thin as possible, considerable allowance may be made for the stress due to tension, namely—

Allowable stress, k_t or safe working load about = 4200 lbs. per sq. inch. (149)

With a maximum pressure $p = 440$ lbs. per sq. inch and $k_t = 4200$ lbs. we get from equation 148—

$$\delta = \frac{D}{2} \left(\sqrt{\frac{4200 + 0.4 \times 440}{4200 - 1.3 \times 440}} - 1 \right) = \text{about } 0.5D \text{ inches} \quad (150)$$

Having regard to a possible re boring of the cylinder, after a few years' wear, then—

$$\delta = 0.05D + x \text{ inches.} \quad (151)$$

Table XX.—Values for x and δ in Centimetres.

$D =$	10	15	20	25	30	35	40	45	50	60	70	80	100	120
$0.05D =$	0.5	0.75	1.0	1.25	1.5	1.75	2.0	2.25	2.5	3.0	3.5	4.0	5.0	6.0
$x =$	0.9	0.95	1.0	1.05	1.1	1.15	1.2	1.25	1.3	1.4	1.5	1.6	1.8	2.0
$\delta =$	1.4	1.7	2.0	2.3	2.6	2.9	3.2	3.5	3.8	4.4	5.0	5.6	6.8	8.0

Table XXa.—Values of x and δ in Inches.

Diam. of cyl. $D =$	4"	6"	7 $\frac{7}{8}$ "	9 $\frac{7}{8}$ "	11 $\frac{7}{8}$ "	13 $\frac{3}{4}$ "	15 $\frac{3}{4}$ "	17 $\frac{3}{4}$ "	19 $\frac{3}{4}$ "	23 $\frac{5}{8}$ "	27 $\frac{9}{16}$ "	31 $\frac{1}{2}$ "	39 $\frac{3}{8}$ "	47 $\frac{1}{4}$ "
$0.05D =$	$\frac{2}{16}$	$\frac{3}{16}$	$\frac{3}{8}$	$\frac{1}{2}$	$\frac{9}{16}$	$\frac{11}{16}$	$\frac{13}{16}$	$\frac{7}{8}$	1	$1\frac{3}{16}$	$1\frac{3}{8}$	$1\frac{9}{16}$	2	$2\frac{3}{8}$
$x =$	$\frac{9}{16}$	$\frac{11}{16}$	$\frac{3}{8}$	$\frac{13}{16}$	$1\frac{1}{16}$	$1\frac{3}{16}$	$1\frac{5}{16}$	$1\frac{7}{16}$	$1\frac{9}{16}$	$1\frac{13}{16}$	$1\frac{15}{16}$	$2\frac{1}{16}$	$2\frac{11}{16}$	$3\frac{1}{16}$
$\delta =$	$\frac{15}{16}$	$\frac{14}{16}$	$\frac{7}{8}$	$\frac{15}{16}$	$1\frac{1}{16}$	$1\frac{3}{16}$	$1\frac{5}{16}$	$1\frac{7}{16}$	$1\frac{9}{16}$	$1\frac{13}{16}$	$1\frac{15}{16}$	$2\frac{3}{16}$	$2\frac{11}{16}$	$3\frac{1}{16}$

In larger cylinders, with diameters of 24 inches and upwards, the thickness of the cylinder may often be reduced gradually, or step by step towards the crank end, to economise weight and quantity of metal. Large cylinders are also often stiffened with circumferential ribs, in which case the thickness of the walls δ is somewhat less than the values given in Table XX.




FIG. 198.

maximum explosion pressure $p = 440$ lbs. per sq. inch.

And from equation 2, p. 126, vertical thrust $k = \frac{\pi}{4} D^2 \times 0.8 \times 440 \times 0.11 = 38 \times D^2$ in lbs. (152)

Again, $M_b = k \frac{a^3}{l}$ in lbs. per sq. inch; $Z_b = 0.8 D_m^2 \delta$ in inches³; $k_b = \frac{M_b}{Z_b}$ in lbs. per sq. inch (153)

Neglecting the weight of the piston itself, deflection $= k \times \frac{a^2 b^3}{EI_s l}$ in inches*. (154)

$E = 12,000,000$ modulus of elasticity for cast iron.

$I = 0.05 (D_a^4 - D^4)$ moment of inertia in inches.

In ordinary four-cycle engines, with the thicknesses of cylinder given in Table XX., the deflection does not exceed $\frac{1}{3000}$ inch or $\frac{1}{200}$ mm. for small, and $\frac{1}{1250}$ inch or $\frac{1}{100}$ mm. for large engines, and is thus very slight.

* See Haeder's "Konstruieren und Rechnen," 2nd edit., p. 292.

As an open-ended or trunk piston also serves as a cross head, a further stress due to bending comes upon the cylinder, for which allowance must be made in large gas engines, and especially in engines with a long stroke.

As shown at p. 126, the maximum turning moment under ordinary working conditions occurs when the piston has travelled through 10 per cent. of its stroke from the dead point. In this position the pressure on the piston is about $0.8p$, with a

Section IV. The Pistons of the Engine.

The style of piston varies with the type of engine, whether *single* or *double acting*, and the kind of crosshead guide adopted. The most usual types are given below, Figs. 6 to 15, and are shown in outline in Figs. 1 to 5.




FIG. 1.
Open-ended Piston
without water cooling.



FIG. 2.
Open-ended Piston,
water cooled.



FIG. 3.
Box Piston,
generally water
cooled.



FIG. 4.
Piston Rod
without water
cooling.



FIG. 5.
Piston Rod,
water cooled.

1. Open-ended or Trunk Pistons (see also p. 3).




FIG. 6. E 4.
Guide inside Cylinder. Most usual type
for engines up to 28" stroke.




FIG. 7. E 4.
Outside Guide (seldom used, and only for
large engines).

FIG. 8. E 4.—Outside Crosshead
Slipper and Guide, and Guide Piston
T inside (large Nuremberg engine).




FIG. 9. R 4.—Piston of first
cylinder forms guide.




FIG. 10. R 4.
Outside Guide.





FIG. 11. D 2.—Oechelhaeuser Engine.

2. Box Pistons (see p. 3).

Open-ended or trunk pistons are almost universally used for small, and box pistons for larger engines. In double-acting engines the latter are, of course, a necessity.




FIG. 12. D 4.—Without Tail Rod and Guide (not often made).




FIG. 13. D 4.—Tail Rod and Guide (usual type).



FIG. 14.
R D 4.





FIG. 15. D 2. Körting.

Open-ended or Trunk Piston for Single-acting Four-cycle Engines.

For engines up to 120 HP an *open-ended trunk piston without water cooling* is almost invariably adopted.




FIGS. 16, 17.—Open-ended Piston.

A Trunk of piston, B piston ring, C piston pin or crosshead, b grooves for piston rings B, c bored hole to receive piston pin C, E taper pin for piston pin C, m boss for oil hole (p. 130), o oil hole (p. 130), p lugs for turning the piston in the lathe, and to take the eye bolts when fitting it into the cylinder, q hole for taper pin E, rr stiffening ribs.

For standard measurements, see pp. 139, 140.

The piston also acts as a slide block, and to take the vertical thrust due to the obliquity of the connecting rod.



Pressure on the Guide.

The pressure with which the body or trunk of the piston is forced downwards against the liner (Fig. 18) is given by the equation—

$$K = P \tan \beta \quad \dots \dots \dots (1)$$

in which P = load on the piston at a given point in the stroke, in lbs., and
 β = angle formed by the connecting rod and the axial line of the cylinder.

This pressure K , equation 1, will reach its maximum when the piston has travelled through 10 per cent. of its stroke. According to the diagram, Fig. 19, the pressure in the cylinder at this point is about 300 lbs. per sq. inch.* Taking as the mean value $\frac{L}{r} = 5.5$ we get—




FIG. 18.

Angle of inclination of the connecting rod = $\beta = 6^\circ 15'$
 $\tan \beta = \text{about } 0.11$

and further—

$$K = \frac{\pi}{4} \times D^2 \times 300 \times 0.11 = 26D^2 \quad \dots \quad (2)$$

Assuming that the piston pin is in the centre of the bearing surface of the piston, and taking as the width of the bearing surface—

Width of bearing surface = $0.85D$ (as the pressure falls only on one-third of the circumference of the piston) (see Fig. 20).

Length of bearing surface = $0.8l$ (deducting the piston rings) (Fig. 18).

The pressure on the bearing surface will thus be—

$$q = \frac{26D^2}{0.85D \times 0.8l} = \frac{38.2D}{l} \text{ lbs. per sq. inch.} \quad (3)$$




FIG. 19.




FIG. 20.

* With a pressure of explosion of 380 lbs. per sq. inch.

If a mean ratio be taken for $\frac{D}{l}$ of 0.5 to 0.65, equation 3 gives—

$$q = 19 \text{ to } 25 \text{ lbs. per sq. inch of area of guide} \quad (4)$$

(In steam engines the pressure on the cross head is usually $q = 30$ to 40 lbs. per sq. inch, if calculated from the pressure over the whole area of the piston, and when the crank is in its highest position.)

Position of the Piston Pin in the Piston.




FIG. 21.

In practice the distance from the centre of the piston pin to the back of the piston is—

$$a = 0.4l \text{ to } 0.7l$$

To maintain a uniform pressure on the surface of the guide the moment to the right must equal the moment to the left (see Figs. 21-23). Therefore—

$$W \times s + K \times a = (K + W) \times 0.5(l + zb) \quad (5)$$

where W = weight of the piston in lbs.

s = distance of the centre of gravity of the piston from the back end in inches.

a = distance from the centre of the piston pin to the back end in inches.

K = vertical pressure on the piston pin in lbs.

z = number of piston rings.

b = width of piston rings in inches.




FIG. 22.

FIG. 23

$$0.5(l + zb) = \text{distance from the back end of the piston to the middle of the bearing surface (} z \times b \text{ is not reckoned as forming part of the bearing surface, as the piston rings must be free to move in the grooves).}$$

Taking as the approximate mean value—

$$s = 0.4l; \quad z \times b = 0.2l$$

from equation 5 we get—

$$a = l \left(0.6 + 0.2 \frac{W}{K} \right) \quad (6)$$

As the weight W does not much affect the result, the last part of the equation may be written = zero, whence—

$$a = \text{about } 0.6l \quad (7)$$

In a water-cooled piston the temperature at the back end is practically the same as that of the cylinder liner (Fig. 25), but when the piston is *not cooled* (i.e. cooled only by the air) (Fig. 24), the difference in temperature, assuming the back end of the piston to be $250^\circ \text{C.} (= 482^\circ \text{F.})$ and that of the liner $90^\circ \text{C.} (= 194^\circ \text{F.})$, will be $482 - 194 = 288^\circ \text{F.}$ The piston will consequently expand more than the liner, namely—

$$D \times \frac{0.00061 \times 288}{100} = \text{abt. } \frac{1}{570} D \quad (8)^*$$

* The expansion of cast iron is about 0.00061 inch per inch of length, for every 100°Fahr. difference of temperature.

As the length affected by this unequal expansion is about $\frac{1}{10}$ of the total length of the piston, it will be advisable to reduce its diameter conically for one-tenth of the length, measured from the back end, by—

$$\frac{1}{570} D \text{ at back end} \dots \dots \dots (9)$$

For example, in a cylinder 40 inches diameter, the diameter of the piston for one-tenth of its length at the back end will be $39\frac{15}{16}$ inches, and the clearance $\frac{1}{16}$ inch. Similarly in a liner of 20 inches, the diameter of the piston for one-tenth of its length at the back end will be $19\frac{31}{32}$ inches, and the clearance $\frac{1}{32}$ inch.

As the back end of such an uncooled piston, where the diameter is reduced, does not, strictly speaking, form part of the bearing surfaces, the piston pin may be moved slightly forward, the length of a increased, and therefore in this case—

$$\text{Distance between centre of piston pin and back end of piston } a = 0.63l \dots \dots \dots (10)$$

(In practice $a = 0.4l$ to $0.7l$.)

The nearer the piston pin is to the back end of the piston, the more injurious is the effect upon it of the temperatures in the combustion chamber.

In the accompanying figure (Fig. 26) a better circulation of air to cool the piston is said to be obtained by the fanlike action of the end of the piston rod.

In practice, in engines of large diameter (i.e. single-acting four-cycle engines with cylinders above 24 inches diameter), it is always necessary to have a separate water-cooling system for the piston.

Rules for Constructing the Piston.

1. *The material used is cast iron, or, for pistons of large engines, cast steel lined with white metal.*

2. *The weight of the piston should be reduced as much as possible, that is, it should be made no heavier than is usually considered necessary, with ample allowance for stress, and shifting of the core in casting. The weight of the piston affects the balance of the reciprocating parts (see Chapter IV.).*

3. *Two or more lugs (N N, Fig. 27) should be cast near the front end of the piston, to hold it when machining it on the lathe, and to take eye bolts for mounting and withdrawing it from the cylinder.*

4. *The piston should be removable at the crank-shaft end of the cylinder (see Fig. 28); this should be borne in mind when designing the frame or bed. It should never be removed at the back end, if it can possibly be avoided, for with pressures of 350 to 450 lbs. per sq. inch it is difficult, when replacing it, to make the joint between the cylinder and breech end tight.*

5. *The piston is lubricated by oil delivered under pressure from a pump. The oil pipe should be screwed into the liner but free in the water jacket (to allow for difference in expansion); the oil should be delivered behind the second ring, when the piston is on the outer dead point.*

The larger the engine, the more important it is to lubricate the piston efficiently, because the area of the cylinder increases with the diameter $\times$ by the stroke, while the proportion

FIG. 24.
Piston not cooled.




FIG. 25.
Water-cooled Piston.



FIG. 26.




FIG. 27.




FIG. 28.

of dust (*i.e.* products of combustion) increases with the charge, or as $D^2 \times S$. Assuming gas of the same composition, and that the exhaust gases in both cases contain the same





FIG. 29.



FIGS. 30, 31.

proportion of dust per unit volume, then the volume of the products of combustion will be *five times greater per square inch of cylinder area* in a cylinder 20 inches diameter than in one 4 inches diameter. It is also more difficult to

distribute the oil uniformly over a *large* than over a *small* surface.

Lubricating the Cylinder (Deutz) German Patent. Nr. 97, 144.

This method of lubrication consists of an oil pump with a plunger piston K, shaped like a differential piston, and working to and fro along a screw. The oil in small and variable quantities is forced into the engine cylinder through the glass sight feed G and the non-return valve R behind it. The object of this valve is to check the pressure during the explosion stroke, that the oil drops may be properly formed, and not blown off, and that the sight feed glass, which controls the quantity of oil passing to the cylinder, may not be dimmed.

As the lubricating oil collects in the cylinder and evaporates, it forms a highly inflammable gaseous vapour, which might easily cause pre-ignition. In the lower part of the piston, therefore, five or six grooves 6 inches long are turned, in which the oil is carried off and flung to the bottom of the frame, the piston, of course, being always in a horizontal position.

The Piston and Piston Pin should be separately lubricated.

Fig. 30 shows a trough B at the front end of the piston, with a wiper which wipes off the oil from the wick on the sight feed lubricator S. From the trough the oil passes




FIG. 32.




FIG. 33 (Figs. 38, 39 belong).

through small pipes *rr*, on either side of the brasses, into the recesses *FF*, and is delivered through grooves on to the piston pin.

The long trough (R, Fig. 32) has been found useful for engines with a *short stroke* and high speeds, and the oil does not splash out over the trough, as might have been expected.


Lubricating the Piston and Piston Pin from an Oil Pump.

In Fig. 33 the oil from a hole drilled in the upper part of the piston is fed to the piston pin through the pipe *r*.

(To cut a long groove in the top of the piston trunk to take the oil for lubricating the piston pin is said not to work well in practice.)

Instead of the pipe (Fig. 33), an oil hole is sometimes drilled in the upper part of the piston trunk, to lubricate the piston pin (Figs. 34-37).

Thus the oil passes into the passage at the top of the piston when the speed is at its lowest. This is a very important point, because otherwise with this method of lubrication the pin does not get enough oil.



FIGS. 34-36.—Gasmotorenfabrik Deutz 18 HP.




FIG. 37.

In order to be quite certain that the oil reaches the pin through this hole, care must be taken to allow the passage between the oil supply and the channel W (Fig. 37) to remain open for an appreciable time. The oil way must be so arranged that the hole in the liner communicates with the one in the piston at about the end of the stroke, when the speed is lowest. This is the object of the oil passage shown at Fig. 35.

Figs. 38, 39, show the position of the lubricator on the cylinder, and the length of the oil pipe or recess, and correspond to Figs. 33-37.

When the crank is on the out stroke dead centre, the oil should be admitted in the space between the *second* and *third* piston rings, and not further back, otherwise it might filter through to the combustion chamber, and be burnt and wasted.


Taking approximately $u = 0.25a$, and assuming that the oil is admitted to the piston, i.e. that the recess overruns the oil hole in the liner when the piston is within 3 per cent. of the outer dead point, then—

$$e = 0.97 \times \text{stroke} + u - a \quad \dots \dots \dots (11)$$

but it is well to determine these values more accurately from Figs. 38, 39.

For larger and vertical engines the oil is delivered through the boss on the piston pin (Fig. 40), either by the leather pipe,* Schl., or through trombone pipes and the spring grease pot B. The liner is in that case separately lubricated.

* For various reasons a leather pipe cannot be recommended. It is better to have a groove in the piston and force the oil into it under pressure (see drawing at the side).



FIGS. 38, 39.





FIG. 40.



6. A hole should be provided, to take the gear actuating the indicator, if the lugs mentioned under head 3 do not suffice for this purpose. The indicator is often driven from a pin on the crank shaft.

Calculation of the Piston End.

The end of the piston is usually made flat, but often convex or dished; the curve of the ends, if rounded, is struck from a radius $r = 2D$ or $2.5D$.


The stresses coming on the piston are—

(a) For flat-ended pistons—

$$k_1 = 0.16D_1^2 \times \frac{p}{\delta^2} \dots \dots \dots (12)$$

(b) For convex-ended pistons—

$$k_2 = \frac{r}{2} \times \frac{p}{\delta} \dots \dots \dots (13)$$



FIGS. 42, 43.

Allowable stress, or safe working load, neglecting the stiffening due to the ribs—


$$k_1 = 6400 \text{ lbs. per sq. inch; } k_2 = 4260 \text{ lbs. per sq. inch} \dots \dots (14)$$

If $p = 360$ lbs. per sq. inch, this works out at—

$$\text{For flat-ended pistons } \delta = 0.11D_1 \text{ in inches} \dots \dots \dots (15)$$

$$\text{„ convex-ended pistons } \delta = 0.042r \text{ „} \dots \dots \dots (16)$$

Number of ribs usually 4; thickness of ribs 0.5δ .



FIGS. 44, 45.

Body or Trunk of Piston.

As grooves must be recessed to take the piston rings, the thickness of the metal must be more than would otherwise be required. Little is saved by making the piston as at Fig. 45, and it is more difficult to make.

We may take $m = 0.04D$; $s = 1.6 - 1.8 \times \text{depth of groove}$; $w = 0.05D$; $u = 0.7w$.



FIG. 46.
Sharp edges.



FIG. 47.
Rounded corners.

Whether the back end of the piston should be left square (Fig. 46), or the edges rounded off (Fig. 47), is a much debated point. It is generally considered better, however, to round it off, as the burnt products are not so likely to adhere to it as to a piston with sharp corners.

For pistons *not water cooled*, see note on p. 127.

Bore of the Cylinder.

It is not usual in gas engines, as in steam engines, to allow the piston to overrun the working part of the cylinder at the back. The liner is turned of the same diameter up to the breech end (Fig. 48), where it is exposed to the highest temperatures, and therefore to its utmost limit of expansion.

In steam engines the general rule obtains that the cross head is allowed to overrun the guide by $\frac{1}{8}$ the length of the cross-head slipper guide. In gas engines, to avoid rocking, and jamming the piston, care must be taken that the cross-head pin never projects beyond the cylinder. Therefore—

$$x \text{ (Fig. 48) should be } = 0.2 + \text{stroke} \dots \dots \dots (17)$$

The space between the end of the piston and the breech end of the cylinder, *i.e.* the clearance, depends on various circumstances ; we will for the present represent it by s .




FIG. 48.

Thus—

$$\text{Working length of the cylinder} = s + a + \text{stroke} + x \dots \dots (18)$$

Piston Rings

are usually made of cast iron, occasionally of steel.

The so-called Ramsbottom rings are almost exclusively used. The more rings there are, the less is the pressure they have to exert. The following table gives the tension of these rings.

Table I.—Piston Rings. Empirical values of q . (Pressures on the bearing surface of the rings.)

Number of rings.	Pressure in the cylinder in lbs. per sq. inch.						
	70	140	210	280	350	420	560 lbs. per sq. inch
z							
2 to 3	$q = 2.3$	2.8	3.4	—	—	—	— lbs. per sq. inch
4 „ 5	1.7	2.0	2.4	3.1	3.5	4.3	(5.0) „ „
6 „ 8	1.4	1.7	2.1	2.5	2.8	3.5	4.0 „ „

The figures printed in *black type* should be used for gas engines, those, namely, which are applicable if there are six to eight rings, in which case—

$$q = 3.5 \text{ to } 4.8 \text{ lbs. per sq. inch} \dots \dots \dots (1)$$

that they may be easily stretched over the body of the piston.

Thickness of Self-adjusting Piston Rings.

These rings are turned and polished before being stretched over the trunk. They should be sufficiently elastic to bend out as much as $D + 2c$ of their diameter, without breaking or losing their spring.

Calculation of the Piston Rings.

D = diameter of the cylinder in inches.

c = depth of the ring in inches.

q = pressure on the bearing surface of the rings, in lbs. per sq. inch (from Table I. and equation 1).

$E = 11,500,000$. Modulus of elasticity for cast iron.

e = length of piece cut out of ring in inches.

k_a = bending stress on the ring when passing it over the piston body, in

lbs. per sq. inch.

k_i = bending stress on the ring under working conditions, in lbs. per sq. inch.

Equations 2 to 4, next page, have been worked out from Reinhardt's calculations * combined with Grashof's theory of bent iron bars.




FIG. 1.

Table II.—Ramsbottom or Self-adjusting Piston Rings (equations 1 to 4).

	$k_i = 8500$	11,100	14,000	17,000 lbs. per sq. inch.
$q = 1.4$ {	$\frac{D}{C} = 45$ $k_a = 9000$ $e = 0.08D$	52 6800 0.12D	58 5500 0.17D	64 4500 lbs. per sq. in. 0.23 D in ins.
$q = 2.1$ {	$\frac{D}{C} = 36$ $k_a = 13,600$ $e = 0.07D$	42 10,000 0.1D	47 8800 0.14D	52 6800 lbs. per sq. in. 0.18D in ins.
$q = 2.8$ {	$\frac{D}{C} = 32$ $k_a = 18,000$ $e = 0.06D$	36 14,000 0.09D	40 11,400 0.12D	45 9000 lbs. per sq. in. 0.16D in ins.
$q = 3.5$ {	$\frac{D}{C} = 28$ $k_a = 23,000$ $e = 0.05D$	33 16,800 0.08D	37 13,400 0.11D	40 11,400 lbs. per sq. in. 0.14D in ins.
$q = 4.2$ {	$\frac{D}{C} = 26$ $k_a = 27,500$ $e = 0.05D$	30 20,000 0.07D	33 16,800 0.1D	37 18,500 lbs. per sq. in. 0.13D in ins.
$q = 5.7$ {	$\frac{D}{C} = 22$ $k_a = 36,300$ $e = 0.04D$	26 25,400 0.06D	29 21,600 0.09D	22 18,000 lbs. per sq. in. 0.11D in ins.

* *Zeitschrift des Vereines deutscher Ingenieure*, 1901, pp. 232 et seq.

Bending stress due to stretching the ring over the piston body—

$$k_a = \frac{Ec^2}{2.5(0.5D)^2} = 18,400,000 \left(\frac{c}{D}\right)^2 \quad (2)$$

$$\text{Bending stress under working conditions } k_i = \frac{12q(0.5D)^2}{c^2} = 3q\left(\frac{D}{c}\right)^2 \quad (3)$$

$$\text{Length of piece cut out of ring } e = 1'' \frac{D^2}{c} \times \frac{k_i}{E} \quad (4)$$

$$\left. \begin{array}{l} \text{Allowable stress, or safe working load } k_a = 17,000 \text{ lbs. per sq. inch} \\ \text{ } k_i = 14,000 \text{ } \end{array} \right\} (5)$$

Table II. has been calculated from equations 1 to 4.

The required thickness of metal c , and the length of the piece to be cut from the ring can be determined from Table II. for a given pressure q on the bearing surface of the ring. For gas engines it is advisable to adopt the figures printed in thick type, namely—

$$c = \frac{1}{33}D; e = 0.08D \quad (6)$$

$$\text{then } q = 3.5; k_i = 11,000; k_a = 16,500 \text{ lbs. per sq. inch} \quad (7)$$

Having calculated the thickness of the ring c , and the length of the piece to be cut out e , the diameter of the cylinder from which the ring is to be cut can next be determined. The various stages in the process of cutting the ring are as follows:—

Let D = diameter of the cylindrical piece from which the ring is cut, in inches.

c = thickness " " " "
 d = $D - 2c$ inside diameter in inches of the finished ring.

$$D_r = D + \frac{e}{\pi} + \frac{3}{8}'' = \text{outside diameter in inches of the cylindrical piece before machining} \quad (8)$$

$$d_r^2 = d + \frac{e}{\pi} - \frac{3}{8}'' = \text{inside diameter of the same} \quad (9)$$

(The flange is for holding the cylindrical piece when turning it.)

$$D_s = D + \frac{e}{\pi} + \frac{1}{16}'' = \text{outside diameter of the machined ring} \quad (10)$$

$$d_s = d + \frac{e}{\pi} - \frac{1}{16}'' = \text{inside } , , , , \quad (11)$$




$e = 0.08D$ = length of piece cut out.

$$D + \frac{1}{8}'' = \text{outside diameter of the ring when the two ends are sprung together} \quad (12)$$

$$d = D - 2c = \text{inside diameter of the finished ring when sprung together} \quad (13)$$

D = outside diameter of the piston ring when sprung together after machining.

d = $D - 2c$ inside diameter of piston ring.



Example.—To calculate the piston rings in a gas engine of $15\frac{3}{4}$ inches diameter. We will take the stress on the ring due to bending, under working conditions $k_1 = 11,000$ lbs. per sq. inch; stress on the ring due to bending, in stretching the ring over the body of the piston $k_a = 17,000$ lbs. per sq. inch.

From equation 6: Thickness of ring $c = \frac{1}{33} \times 15\frac{3}{4}'' = \frac{1}{2}''$ (bare $0.475''$).

„ „ 6: Length cut out $e = 0.08 \times 15\frac{3}{4}'' = 1\frac{1}{4}''$.

(Both these values may be taken from Table II., p. 133.)

Again, from equation 8: $D_r = 15\frac{3}{4} + \frac{1\frac{1}{4}}{\pi} + \frac{3}{8}'' = 16\frac{1}{2}''$.*

„ „ 9: $d_r = (15\frac{3}{4} - 2 \times \frac{1}{2}'') + \frac{1\frac{1}{4}}{\pi} - \frac{3}{8}'' = 14\frac{3}{4}'' + \frac{1}{16}''$.

„ „ 10: $D_o = 15\frac{3}{4} + \frac{1\frac{1}{4}}{\pi} + \frac{3}{16}'' = 16\frac{5}{16}''$ (full).

„ „ 11: $d_o = (15\frac{3}{4} - 2 \times \frac{1}{2}'') = \frac{1\frac{1}{4}}{\pi} - \frac{8}{16}'' = 15''$.

Figs. 7 to 10 illustrate the successive operations in machining the ring.



FIG. 7.
Rough casting.




FIG. 8.
Turned and bored.



FIG. 9.
Cut.




FIG. 10.
Sprung together
and machined.

Number of Rings.

As the rings must be stretched over the body of the piston, and therefore the pressure on their bearing surfaces cannot exceed $q = 3\frac{1}{2}$ lbs. per sq. inch, several rings must be fitted to the piston. The best and most usual number is—

$$\text{Number of rings} = 7 \text{ or } 8 \quad (14)$$

To draw the Ring

over the piston body requires great care, as with clumsy handling the limit of elasticity may be exceeded, and the ring break. For this operation Reinhardt† has laid down the following theoretical rule:—

* If the casting is carefully made, it is sufficient to allow $\frac{1}{8}$ inch to $\frac{3}{8}$ inch instead of $\frac{1}{2}$ inch, as given above. The measurements in equations 8 to 11 must be re-calculated, to correspond with this alteration.

† *Zeitschrift des Vereines deutscher Ingenieure*, 1901, p. 376.

If the rings are to be sprung out by hand, and slipped into place, they cannot be properly adjusted unless they are opened to an angle of 30° (Fig. 11). It is better, therefore, especially with rings of large diameter, which it is impossible to stretch by hand, to use Reinhardt's device, as shown in Fig. 11. The angle at which the instrument opens the ring should be set at 30° , as it naturally diminishes when drawing the ring on.





FIG. 11.

FIG. 12.



FIGS. 13-15.—Not often used.

The piece is cut from the ring at right angles to the side edges. To make the ends overlap (Fig. 12), or fit a tongue over the joint, as in Figs. 13-15, does not give satisfactory results in gas engine practice.

Care should be taken to prevent the rings turning in their recesses, and the joints

View of underside.




FIG. 16.





FIG. 17.




FIG. 18.



should be made at the bottom of the piston (see Fig. 16).

The simplest way to secure the rings from shifting is to fit in a peg (see Fig. 17). Many engine builders cut away a portion of the side of the last piston ring (A, Fig. 18). This allows the pressure to pass behind the ring, and thus the ring is forced outwards against the walls of the cylinder liner.

Another method to secure the piston rings and prevent them from turning is shown in Figs. 19, 20. The rings are held in position by a pin S, screwed into the body of the piston. To increase the tension of the first two rings, they have two steel springs F which cannot twist, but are kept in place by the bosses N riveted to the piston body.



FIGS. 19-22.

The Piston Pin.

(a) Fitting the Piston Pin in the Boss.

The piston pin must be *very carefully* secured in the bosses cast in the piston to receive it, and also easily taken out, as it has to be removed whenever the connecting rod is disconnected. It can be secured in several ways, as follows:—




FIG. 1.

1. By *set screws* with pointed ends and square heads locked with check nuts (Fig. 1). Diameter of the set screws = $s = 0.3d$. The feather key *K* prevents the pin from turning round.

2. If the head of the connecting rod is made with a side key, these set screws cause difficulty.

In that case a *taper pin*, *o*, shown in Fig. 2, is used, which prevents the piston pin both from slipping sideways, and from turning.




FIG. 2.

Diameter of the pin $o = 0.2d$.

Neither of these two methods has proved entirely satisfactory in practice, as it is difficult with either to get the piston pin back into position, if it works slack, or is driven in.

3. In the arrangement shown in Fig. 4 (Deutz), if the cross-head pin is tightened up, it may spring the piston out of shape, if, for instance, there is more wear on the cone of the pin at *a* than at *b*. This is a difficulty which has been experienced with cross heads in steam engines. Fig. 3 shows a locking plate.

4. It is better to make the connection by turning the piston pin conical at each end (Fig. 5). The cross head is secured in the conical end, *c*, by the nut at *d*, and the other end, *e*, is then forced into the boss by the nut at *f*; but on this side allowance must be made for the pin projecting a little way into the boss.




FIG. 3.

FIG. 4.

FIG. 5.

If the piston pin is not perfectly tight in the boss, the shocks on the connecting rod will be considerable.

To put stiffening ribs (*rr*, Fig. 6) between the bosses of the piston pin might counteract the pressure on the piston, but these ribs check the circulation of air, and hinder the cooling of the piston.




FIG. 6.—Stiffening ribs.




FIG. 7.—Swiderski.

The piston pin being near the working end of the cylinder is exposed to high temperatures, and the difficulty of keeping it in good working order is considerable, especially as it is not easy of access.

In Fig. 7 a partition, *r*, is supposed to prevent the heat reaching the piston pin, and causing the lubricating oil to burn. By piercing a few holes above and below in the wall a circulation of air is set up, which is extremely important for keeping the bottom of the piston cool. These holes are, of course, necessary for removing the cores.

(b) Calculation of the Piston Pin or Cross Head.

The maximum load on the cross head works out at—

$$P = \frac{\pi}{4} D^2 \times 380 = \text{about } 300 \text{ lbs. per sq. inch} \times D^2 * \quad (1)$$

According to Bach's formula: Bending moment $M_b = \frac{P}{2} \left(\frac{l}{2} - \frac{e}{4} \right)$ (2)

Modulus of resistance to bending for a round cross section—

$$Z_b = 0.1d^3 \quad (3)$$

Stress due to bending (lbs. per sq. inch) $f_b = \frac{M_b}{Z_b}$

Allowable stress or safe working load $f_b = 11,000$ to $13,000$ lbs. per sq. inch (4)

The piston pin must also be tested for pressure on the bearing surface—

$$p = \frac{P}{d \times e} \text{ lbs. per sq. inch} \quad (5)$$

Safe working load for—

$$p = 1700 \text{ to } 2000 \text{ lbs. per sq. inch} \quad (6)$$

(The working load on the cross head pin of a steam engine is usually 1100 to 1400 lbs. per sq. inch.)

In a gas engine a higher load per sq. inch on the piston pin can be allowed for, because the maximum pressure is only developed at every fourth stroke, and for a very short time, whereas in steam engines this pressure is exerted at every stroke. Moreover, it would be difficult to fit a larger pin into the piston. In any case the piston pin is still a weak point in gas engine practice.




FIG. 8.

Taking the length of the piston pin brass $e = 0.5D$, then $l = \text{about } 0.75D$

$$\text{and } M_b = 150 D^2 \left(\frac{0.75D}{2} - \frac{0.5D}{4} \right) = 37.5 D^3 \text{ inch-lbs.} \quad (7)$$

Allowing a stress $f_b = 12,000$ lbs. per sq. inch.

$$d = D \sqrt[3]{\frac{37.5}{0.1 \times f_b}} = D \sqrt[3]{\frac{37.5}{0.1 \times 12,000}} = 0.31D \quad (8)$$

From these values equation 5 gives—

Pressure on the bearing surface of the piston pin—

$$p = \frac{300 \cdot D^2}{0.5D \times 0.31D} = 1940 \text{ lbs. per sq. inch}$$

* The stresses coming on the working parts are generally calculated for an explosion pressure of 380 to 440 lbs. per sq. inch.

Standard Types of Piston and Piston Pin for E 4 Engines.

FIG. 1.





FIG. 3.




FIG. 5.

FIG. 2.





FIG. 4.




FIG. 6.—Up to 5" Cylinder Diameter.




FIG. 7.—With Wiper (Diam. of Cyl. 16". Scale 1 to 8).

T, Sight feed lubricator.

M, Bracket fixed on cylinder.

B, Wiper.

S, Bracket to take oil pipe R.

Cooling the Cylinder.*

(a) Heat Developed in the Cylinder.

It is necessary to bestow special attention on this part of our subject, because an accurate knowledge of the movements of heat is required when designing not only the cylinder and piston, but also the *breech end* and *exhaust valve* of a gas engine (see "Valve gear").

During the working cycle *very high temperatures* are developed in the cylinder of a gas engine, the range of which is more or less in accordance with the following classification.

Table I.—Temperatures in the Working Cylinder.

Period of admission.—The unburnt gases remaining in the cylinder after the exhaust valve has closed are at a temperature of 400° C. The fresh charge is admitted at a temperature of, say, 20° C. Therefore we may assume that during—			Four-cycle engine.	Two-cycle engine.
			Centigrade.	Centigrade.
Admission of the charge of gas and air the temperature falls from			400° to 125°	—
Compression	"	"	125° " 500°	125° to 500°
Ignition (explosion)	"	"	500° " 1500°	500° " 1500°
Expansion	"	"	1500° " 700°	1500° " 700°
Exhaust lead (i.e. release)	"	"	700° " 500°	700° " 500°
Discharge of exhaust gases	"	"	500° " 400°	500° " 125°

(Compare with the above the following known temperatures of metals: temperature of iron when heated to: dull red, 600° C.; to cherry red, 800° C.; bright red, 1180° C.; white heat, 1500° C.; melting points of zinc, 230° C.; bronze, 900° C.; cast iron, 1150° C.; wrought iron, 1550° C.)

To gain a clear idea of the processes taking place in the cylinder of a gas engine, a knowledge of the *curves* of the *indicator diagram* is as necessary as when studying the working cycle, as explained at pp. 8 *et seq.*

A rough calculation of the temperatures in an E 4 engine (single-acting four-cycle) may be made from Table I. and Fig. 1, as follows:—

$$\text{Mean temperature during expansion} = \frac{1500^\circ + 700^\circ}{2} = 1100^\circ \text{ C.}$$

$$\text{" " " exhaust} = \frac{500^\circ + 400^\circ}{2} = 450^\circ \text{ C.}$$

$$\text{" " " compression} = \frac{500^\circ + 125^\circ}{2} = 310^\circ \text{ C.}$$

$$\text{" " " admission} = \frac{400^\circ + 125^\circ}{2} = 260^\circ \text{ C.}$$




FIG. 1.

Thus the mean temperature of the gases, when in contact with the walls at the explosion end of the cylinder (breech end) would be—

$$T_m = \frac{1100 + 450 + 310 + 260}{4} = \text{about } 530^\circ \text{ C.} \quad (1)$$

* The following pages (142–150) should be taken as the author's contribution towards the solution of this still obscure problem.

(For the front end of the cylinder in a single-acting four-cycle engine (**E 4**) the mean temperature is calculated in a different way, because work is only done in it at certain times, and there is also a different range of temperature in the middle of the cylinder of a double-acting four-cycle engine (**D 4**)).

This rough method of calculation must not, however, be relied on, but a more accurate determination of the temperatures should be made.

For this a clear and comprehensive view may be obtained from the developed diagrams; if the values in Table I. are plotted vertically the temperatures may be read off for each position of the piston, and the mean temperature determined from them by a planimeter.

1. Temperature Diagrams for the Combustion Chamber and Back End of Piston.

To illustrate the working cycle better, the diagrams of pressure are shown below the temperature diagrams; *v* denotes the front or crank end, *h* the back or breech end of the cylinder.





Fig. 2 is applicable both to single acting (**E 4**) and double-acting four-cycle engines (**D 4**); for the latter it shows one side of the piston only.

The mean temperatures are indicated in the diagrams by dotted lines, thus

2. Mean Temperatures in the middle of the Cylinder.

While the back end of the piston is always in communication with the combustion chamber (breech end) of the cylinder, and always exposed to the same high temperatures, the heat is differently communicated to the middle and front end of the cylinder. The temperatures in front of and behind the piston must be considered for every position of the crank, for which the diagrams (Figs. 5 to 8) may be worked out in the same way as before.

Temperature Diagrams for the Middle of the Cylinder.

The mean temperatures are indicated in the diagrams by a dotted line, thus

Calculation of the Mean Temperature T_m .

If the temperature diagrams (Figs. 2 to 8) are planimeted, they will give the mean temperatures shown in the following table.

Table II.—Determination of the Mean Temperature T_m .

	E 4 engine.	D 4 engine.	D 2 engine.	Steam engine 570° F. of superheat.
Breach end of cylinder and back end of piston—together	—	—	—	—
Beginning of stroke	460° C.	460° C.	560° C.	190° C.
Middle	180° C.	360° C.	420° C.	180° C.
End	Zero	460° C.	400° C.	190° C.
Mean temperature T_m =	320° C.	425° C.	460° C.	185° C.

FIG. 9.—Single-acting Engine (E 4), not cooled with water.





FIG. 10.—Double-acting Engine (D 4), not cooled with water.



In a double-acting four-cycle gas engine the temperature is about twice as high in the middle of the cylinder as in a single-acting engine of the same type, because in the latter

this part is covered by the piston, and thus shielded from the heat of explosion during two out of the four strokes of the cycle.

If during a working cycle heat were not artificially withdrawn from the cylinder of the engine, either by water circulating round it, or by air cooling, the temperatures in it, calculated from Table I., would correspond to those indicated in Figs. 9, 10. In that case only the *admission valve* would be slightly cooled by the incoming charge.

It must be evident that neither cast iron, cast steel, nor other metal could resist *such great heat*. These high temperatures must, as far as possible, be reduced by cooling the cylinder externally, which is done by surrounding it with *water*.




FIG. 11.

A certain *loss of work* is of course entailed by thus cooling it, because the heat carried off in the water cannot do work in the cylinder.

If there were no cooling, the *expansion curve* of the indicator diagram would be higher.

The greater the number of heat units taken up by the cooling water, the larger the shaded area in the diagram (Fig. 11), and therefore the greater is the *loss of energy*, and the less the work done by the engine.

(b) Cooling the Cylinder with Water.

Main Objects aimed at: To reduce the temperature of the cylinder walls within practical working limits; to avoid excessive waste of energy, the quantity of heat withdrawn from the motor cylinder should be as small as possible.

To prevent such a catastrophe as *cracking the breech end*, and to obtain the most uniform distribution of heat throughout the cylinder walls, the water must be admitted in such a way that those parts of the cylinder which, according to Figs. 9, 10, and 15, 16, are exposed to the greatest heat are surrounded by the coldest water.

The following seven parts of the cylinder are cooled in this way:—

Smaller engines E 4 up to 36" stroke, single cylinder, 150 HP.	Besides the parts cooled under heads 1, 2, and 3, the following are also usually cooled in large engines.	In exceptional cases; for example, in the B&W engine.
1. Water circulation in the jacket 2. Water circulation around the breech end. 3. Water circulation around the exhaust pipe.	4. Piston. 5. Piston rod. 6. Exhaust valve.	7. Cooling the charge by injecting water into the motor cylinder. (Generally done in petrol and naphtha engines of about 8 to 10 HP.)

The Admission Valve.

As the top of the cone of this valve is in contact with the unheated charge of gas and air before explosion, it must be at the same temperature as the breech end of the cylinder (see Temperature Diagrams, Figs. 2 to 4).

Exhaust Valve.

This valve is a source of much trouble and anxiety in gas-engine practice, as the bottom of the cone is always in communication with the exhaust pipe, and therefore exposed to temperatures varying from 400° C. to 500° C.




FIG. 12.—Temperature Diagram of the Exhaust Valve.

In Fig. 12 the higher temperatures correspond to those above (cylinder side) and the lower to those below the cone of the valve (exhaust-valve side). The mean temperature of the cone must thus be taken at 600 C. without, and 450° C. with water cooling.

In small valves the valve seat may to a certain extent exert a cooling effect on the cone, but in larger engines




FIG. 13.




FIG. 14.

the temperature of the cone is always reduced by water cooling (Fig. 13).

Attempts have also been made to cool it by injecting water from below (Fig. 14), but the steam thus generated has given rise to other difficulties.

In E 4 suction gas engines of about 15 HP (stroke = 12" ; $p_c = 140$ lbs. per sq. inch ; $p = 370$ lbs. per sq. inch), it is necessary to cool the cone of the exhaust valve.

(c) The Actual Temperatures.

The temperatures, in actual practice, of the walls of the cylinder and combustion chamber, and of the cone of the exhaust valve, if cooled with water in the usual way, can only be approximately arrived at, as no exact determinations have been made.

FIG. 15.
Cylinder and Combustion Chamber cooled with Water (Single-acting E 4 Engine).





FIG. 16.
Cylinder, Cylinder Cover, Exhaust Valve Box and Pipe, Piston and Piston Rod cooled with water (Double-acting D 4 Engine).



If the cooling system is carefully carried out, the temperatures indicated in Figs. 15, 16, should approximate to those realized in practice.

(d) Calculation of the Quantity of Water required to Cool a Gas Engine.

IHP (Indicated Horse-power).

BHP (Brake Horse-power).

M = area in contact with the water, in sq. feet (calculated from the dimensions of the engine). For data for these, see Table III.

Q = quantities of cooling water, in gallons per hour.

t_1 = temperature of cooling water at inlet; t_2 = temperature of cooling water at outlet, in degrees Centigrade.

$t_2 - t_1$ = difference in temperature of the water at inlet and outlet.

$t_m = \frac{t_1 + t_2}{2}$ = mean temperature of water varying from 15° C. to 50° C. according to the system of cooling adopted, i.e. whether fresh water is run through or water is circulated from cooling tanks.

T_m = mean temperature of the charge, from Table II., p. 144.

$T_m - t_m$ = actual mean difference of temperature between gases on one side and water on the other side of the cylinder (compare equation 2 and Table III.).

k = coefficient of heat transmission, namely, the number of British thermal units transmitted to the water per sq. foot of cylinder area per hour, for each degree Centigrade difference in temperature (k depends upon the kind of metal used, its thickness, and the more or less vigorous circulation of the water).

H = number of British thermal units transmitted from the cylinder to the water per BHP hour.

$$\text{Therefore—} \quad \underbrace{H \times \text{BP}}_{\substack{\text{Quantities of heat} \\ \text{withdrawn from} \\ \text{the gases.}}} = \underbrace{(T_m - t_m) \times k \times M}_{\substack{\text{Quantities of heat trans-} \\ \text{mitted through the} \\ \text{cylinder walls.}}} = \underbrace{Q \times (t_2 - t_1)}_{\substack{\text{Quantities of heat} \\ \text{in the cooling} \\ \text{water.}}} \quad \dots (2)$$

If, as at p. 22, we take the normal, $\text{BHP} = C \times D^2 \times S \times n \quad \dots (3)$

$$\text{then—} \quad n \times H = \frac{(T_m - t_m)kM}{C \times D^2 \times S} \quad \dots (4)$$

Table III.—Number of British Thermal Units per HP hour transmitted to the Water, and Maximum Permissible Number of Revolutions from equation 4. (D and S to be given in feet.)

	E 4 engine.		D 4 engine.	D 2 engine.
	Piston not cooled.	Piston cooled with water.	Piston cooled with water.	Piston cooled with water.
If fresh water be used $T_m - t_m =$	320° C.	320° C.	425°	460° C.
If circulating water be used $T_m - t_m =$	290° C.	290° C.	400°	430° C.
Constant for suction, power, and } $C =$	0.0655	0.0655	0.136	0.285
blast furnace gases }				
Approximate value of $M =$	$2.2DS + 3D^2$	$2.2DS + 8.8D^2$	$4.8D^2 + 4D^2$	$8.65DS + 4D^2$
Usual ratio in large gas engines of $S:D =$	1.1	1.1	1.2	1.73
British thermal units per HP hour } $=$	$23,120 \times k$	$26,670 \times k$	$22,950 \times k$	$11,820 \times k$
transmitted to the water }	$n \times D$	$n \times D$	$n \times k$	$n \times D$
If $H = 4000$, $k = 63$ $n_{\max.} =$	$\frac{370}{D}$	$\frac{430}{D}$	$\frac{365}{D}$	$\frac{231}{D}$

If an excessive quantity of water be used (say 22 to 26½ gallons per HP hour), the number of revolutions may under favourable conditions be increased 10 per cent.

In very large blast furnace gas engines the cooling of the engine causes considerable difficulty.

In a Cockerill engine (E 4) $D = 51''$; $S = 55''$; $n = 90$, the consumption of fresh water per HP hour is 24 gallons.

In a Nuremberg engine (E 4) $D = 52''$; $S = 55''$; $n = 90$, the consumption of fresh water per HP hour is 22 gallons.

To run the engine with less water has produced burning of the *piston rings* and *pre-ignition*.

With such a large consumption of water (22 gallons) $t_2 - t_1$ will work out = 12°C. , $t_m = 15^\circ \text{C.}$; $T_m - t_m$ will be about 4 per cent., k about 8 per cent., and maximum number of revolutions about 10 per cent. higher.

(e) Consumption of Cooling Water.

Taking from equation 2 $B.T.U. \times BHP = Q \times (t_2 - t_1)$ and making—

$$\left. \begin{array}{l} H = 4000 \text{ B.T.U. per IHP hour}^* \\ H = 4800 \text{ " " BHP hour} \end{array} \right\} \dots \dots \dots (5)$$

then— $Q = \frac{222 \times \text{IHP}}{t_2 - t_1} = \text{about } \frac{266 \times \text{BHP}}{t_2 - t_1}$ in gallons per hour (6)

If for the heat transmitted to the water we take figures realized in actual practice they work out as in Table IV.

Table IV.—Consumption of Water per HP per Hour.

		$t_2 - t_1 =$	35°	30°	25°	20°	15°	13°	12	11	10 degrees Centigrade
		Q : IHP =	6.35	7.4	8.9	11.1	14.8	17.1	18.5	20.2	22.2 gallons per HP hour
		Q : BHP =	7.6	8.9	10.6	13.3	17.7	20.4	22.2	24.2	26.6
With	BHP	= 10, Q =	12.2	14.3	17.0	21.3	28.4	32.7	35.6	38.7	42.6 cub. ft. per HP hour
"	"	= 100, Q =	122	143	170	213	284	327	356	387	426 "
"	"	= 500, Q =	610	715	850	1065	1420	1635	1780	1935	2130 "

By retaining the number of revolutions per minute given in Table III., we get—

If fresh water be used, $t_2 - t_1 = 30^\circ \text{C}$. therefore consumption of water per BHP hour 8.9 gallons.
 If circulating water be used, $t_2 - t_1 = 13^\circ \text{C}$. " " " " " " 20.4 "
 (If the speed be increased, the consumption of water will also be greater (see bottom of p. 147).)

The opening for the inlet and outlet of the water should be calculated for the higher consumption, viz. about 20 gallons; and about $\frac{1}{2}$ gallon to 1 gallon of fresh water per HP hour should be allowed, to replace evaporation, if the water is circulated.

Cooling the Piston.

Of the water consumption given in Table IV., about 70 per cent. in large gas engines is used for the breech end and the cylinder jacket, and about 30 per cent. for the piston and exhaust valve. The water in the jacket should be at a pressure of 20 lbs. per sq. inch, that in the piston at 50 to 80 lbs. pressure. If the pressure is less, the necessary quantity of water cannot be forced through the parts which require cooling.

About 120 HP is the limit of size in E 4 engines, below which it is not necessary to cool the piston.




FIG. 1.—Cooling the Piston with Water, *Single-acting Engine.*



FIG. 2.—Cooling the Piston with Water, *Double-acting Engine.*

Fig. 1 is a diagram of the system of *cooling the piston* in a single-acting engine. To prevent one side of the piston rod getting hot, while the other side is cooled, the water

* H = 4000 B.T.U. is the smallest number of heat units which can be withdrawn. Measurements of the heat under practical working conditions give B.T.U. = 4000 to 6000 for small, and 3600 to 4400 B.T.U. for large engines.

is admitted and discharged through the centre of the rod, as at Fig. 2. It should be admitted at the *bottom* of the piston, and carried off at the *top*, to prevent air collecting in "pockets."




FIG. 8.—Position of the Air Vessel.

As the piston travels to and fro the water in it and in the rod is flung about; an air vessel is therefore placed at the end of the cylinder, to cushion it.

In engines in which the acceleration of the mass of the piston ϕ is great (compare pp. 25 *et seq.*), an air vessel is a necessity, because the water carried to and fro in the piston follows the same laws of acceleration as a solid body.

A usual arrangement is that shown at Fig. 3 in which the water is admitted through "trombone" pipes and a stuffing box. It enters the air vessel in the direction of the arrows, passes thence through the horizontal pipe into the piston, and is finally discharged into the waste pipe through slots at the back of the piston rod guide.

(f) Dimensions of Inlet and Outlet Water Pipes.

If *fresh water* be used (from a spring or from the main), we may take—

Quantity of water required—

$$Q = 11 \text{ gallons per HP hr.}$$

Speed of the water $v = 3.3$ ft. per second.

Hence, *Sectional area* of the pipe—

$$\begin{aligned} \frac{\pi}{4} \times d^2 &= \frac{11 \times 1728 \times \text{HP}}{3600 \times 6.24 \times 39} \\ &= \text{about } 0.0215 \times \text{HP in sq. inches.} \end{aligned}$$

Diameter of the pipe—

$$d = 0.165 \times \sqrt{\text{HP}} \text{ in inches.}$$

If the water discharged *be circulated and cooled and used over again*, we may take—

$$Q = 22 \text{ gallons per HP hr.} \quad (7)$$

$$v = 1.5 \text{ ft. per second.} \quad (8)$$

$$\begin{aligned} \frac{\pi}{4} \times d^2 &= \frac{22 \times 1728 \times \text{HP}}{3600 \times 6.24 \times 18} \\ &= \text{about } 0.094 \text{ HP in sq. inches.} \quad (9) \end{aligned}$$

$$d = 0.346 \times \sqrt{\text{HP}} \text{ in inches} \quad (10)$$

HP here denotes the BHP of the engine for *one* cylinder.

From the above equation (10), the values in Table V. may in round numbers be calculated.

Table V.—Diameter of Cooling Water Pipes for Engines up to 110 HP.


Horse-power of engine,	HP =	1	2	3	6	10	15	22	28	35	45	65	110
Diameter of pipes } if fresh water be used,	$d =$	$\frac{1}{8}$ "	$\frac{1}{4}$ "	$\frac{3}{8}$ "	$\frac{1}{2}$ "	$\frac{5}{8}$ "	$\frac{3}{4}$ "	1 "	$1\frac{1}{8}$ "	$1\frac{1}{4}$ "	$1\frac{3}{8}$ "	$1\frac{1}{2}$ "	$1\frac{3}{4}$ "
of pipes } if circulating water be used.	$d =$	$\frac{1}{8}$ "	$\frac{1}{4}$ "	$\frac{3}{8}$ "	$\frac{1}{2}$ "	$\frac{5}{8}$ "	$\frac{3}{4}$ "	1 "	$1\frac{1}{8}$ "	$1\frac{1}{4}$ "	$1\frac{3}{8}$ "	$1\frac{1}{2}$ "	$1\frac{3}{4}$ "
Diameter of pipe connection,	$d =$	$\frac{1}{8}$ "	$\frac{1}{4}$ "	$\frac{3}{8}$ "	$\frac{1}{2}$ "	$\frac{5}{8}$ "	$\frac{3}{4}$ "	1 "	$1\frac{1}{8}$ "	$1\frac{1}{4}$ "	$1\frac{3}{8}$ "	$1\frac{1}{2}$ "	$1\frac{3}{4}$ "

In larger engines, in order to regulate the supply carefully, the water is admitted and discharged through separate pipes to the breech end of the cylinder and to the jacket. The sectional area of each pipe connection is $\frac{3}{4}$ the value found by equation 9.


In the smaller engines the water enters at the breech end, and passes out from the jacket, and therefore only one inlet and outlet pipe are necessary.

Section V. The Connecting Rod.

Gas engines are always built with *cranked shafts* (i.e. not with overhung crank pins), and therefore the big end or crank-shaft end of the connecting rod is fitted with a *loose* or *adjustable cap or keep*. The *marine type* (Fig. 12) is a favourite design with engine builders for this end of the rod. The small or piston end has sometimes a cap, sometimes a solid forged eye.



FIGS. 1-4.—Design for Smaller E 4 Engines.



FIGS. 5, 6.—Design for Larger E 4 Engines.

A = Shaft or body of connecting rod.

Small end (piston end): BB₁ = brasses; C = tapped hole for adjusting screw *c*; *c* = adjusting screw for brasses; E = oil hole; F = holes for cap bolts *f*; *f* = small end cap bolts; G = cap or keep.

Big end (crank-pin end): JJ₁ = big end brasses; K = cap or keep; L = holes for big end cap bolts *l*; *l* = cap bolts; S = liner (see Fig. 12).

Rules for Constructing the Connecting Rod.

1. The ratio $\frac{\text{length of connecting rod } L}{\text{radius of crank } r}$ varies from 6 in smaller to 5.5 in larger engines. The smaller this ratio $L:r$, the greater is the pressure on the cross-head guide, and therefore on the surface of the trunk piston in four-cycle E 4 engines (see p. 126).

2. Whether it is better to fit a solid forged eye or a cap or keep at the small end of the piston rod will depend on the available space, which in smaller engines is limited.

The cost of manufacture must also be considered. In general it is advisable to have a forged eye for engines up to about 12 inches cylinder diameter, and a cap (or keep) for engines above that size.




FIG. 7.—Small End of a Connecting Rod for a Trunk Piston.


In any case, to make sure that ample room is allowed for the connecting rod in all its various positions, care must always be taken to design the piston *with the connecting rod attached* (Fig. 7). From lack of space, and to reduce the diameter of the cap, it is often necessary to have four cap bolts (Fig. 10).

3. *Adjusting the brasses.* To detect and provide for the wear on the brasses of both the


piston pin and the crank pin, they should be readjusted from time to time. The usual practice, to take up the slack between the brasses and the pin, is to *file away the surfaces* where the brasses butt.

(In steam engines it was formerly customary to leave a space between the joints of the brasses. This space was filled up with a liner made up of several plates, so that one of these could be removed and the brasses could at any time be tightened up by the cap bolts, without having to be filed. The joints are now always butted, and tightly bolted up.)

A simple method of adjusting the *piston-pin brasses* by means of a *set screw*, where there is a solid forged eye, is shown in Figs. 8, 9. The disadvantage of this type of piston-rod end is that the brasses can only be adjusted when the connecting rod is taken



FIGS. 8, 9.—Adjusting the Bearings for a Connecting Rod End with Solid Eye.



FIGS. 10, 11.—Small End with Cap or Keep.

out and a strong set screw is also necessary. The back end brass B must be *fairly thick* (Fig. 9), as it bears on the flat end of the adjusting screw after the bearings are fitted together; if this brass were thin it might bend or give way when the screw was tightened up.

In the small end of a connecting rod with cap or keep, shown in Figs. 10, 11, the brasses are let together, *i.e.* the ends butted and the cap bolts tightened up.

In the marine type of connecting-rod end there is a *thin liner* *z* (Fig. 12) which can easily be taken out, filed, and replaced in position.

In most cases these liners are made up of *several thin metal plates*, for instance, say five sheet copper plates $\frac{1}{128}$ inch thick, four of $\frac{1}{64}$ inch thickness, two of $\frac{1}{32}$ inch, and one brass plate $\frac{1}{8}$ inch thick, making a total thickness of $\frac{1}{2}$ inch. As the brasses wear away, one or more of these thin metal plates are removed, and filing is thus avoided.

If the liner is shaped as at Fig. 13, one or more of the thin plates can be slipped out of place without drawing the cap bolts.

4. To prevent the greatest stress coming on the threaded part, both in the marine and the cap type of end, the *body of the cap bolts* is turned down to the same diameter as that at the bottom of the thread (see Fig. 12).

Care must be taken to prevent the bolts *turning*; this is usually done by putting a small snug key under the head, the recess for which should not be inside, as at Fig. 14, but outside the head, as at Fig. 15.

Here, or at the side, the recess is easily made, and the metal cut away in this part of the jaw is not of much value.

5. Nor must the brasses be allowed to turn in the jaw; this is usually avoided by driving the cap bolt into the brass (see Figs. 16, 17.)

6. In *large* marine type ends four cap bolts, two on either side, are usually fitted. This arrangement gives a neater-looking end than where there is only one cap bolt on each side.

7. For connecting rods with marine ends, the *nuts for the cap bolts* are very deep, and check nuts are often used to prevent the main nuts from slacking back (Fig. 19).

* The end and the shaft are forged in one piece; machined and parted by planing through at Z (Fig. 12).




FIG. 12.—Connecting Rod End * with Liner.



FIG. 13.—Connecting Rod Liner.

FIG. 14.—Wrong.




FIG. 15.—Right.




FIG. 16.

FIG. 17.

Where the small end is fitted with a cap the same result is obtained if the cap bolts are made with deep nuts, and split pins in the ends of the bolts (Fig. 18).




FIG. 18.—Small End with Cap.




FIG. 19.—Marine Type End.





FIG. 20.

8. The same arrangement serves for *locking the nuts on the cap bolts on marine type connecting rods* (p. 152), or special recessed nuts and check screws are fitted, as in Fig. 20. It is a good plan to use a gas thread, as the screws can be more firmly tightened up, and do not easily wear loose.

Table I.—Measurements of Recessed Nuts and Check Screws for Cap Bolts in Marine Type Ends of Connecting Rods.

Diameter of bolt $d =$	$\frac{1}{2}''$	$\frac{5}{8}''$	$\frac{3}{4}''$	$\frac{7}{8}''$	$1''$	$1\frac{1}{8}''$	$1\frac{1}{4}''$	$1\frac{3}{8}''$	$1\frac{1}{2}''$	$1\frac{5}{8}''$	$1\frac{3}{4}''$	$2''$	$2\frac{1}{4}''$	$2\frac{1}{2}''$	$2\frac{3}{4}''$	$3''$	$3\frac{1}{4}''$
$D =$	$\frac{3}{4}$	$1\frac{1}{8}$	$1\frac{1}{4}$	$1\frac{3}{4}$	$1\frac{3}{4}$	$1\frac{5}{8}$	$2\frac{1}{8}$	$2\frac{1}{4}$	$2\frac{3}{8}$	$2\frac{3}{4}$	$2\frac{3}{4}$	$3\frac{1}{8}$	$3\frac{3}{8}$	$3\frac{3}{4}$	$4\frac{1}{8}$	$4\frac{1}{2}$	$4\frac{3}{4}$
$b =$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$
$g =$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$	$\frac{1}{4}$



FIGS. 21-23.

9. The method of lubricating the piston pin is explained in the chapter on "Pistons" (pp. 128 *et seq.*).

The crank pin is usually oiled by a centrifugal lubricator (pp. 75 *et seq.*).

10. When the brasses get hot (especially if of bronze), they have a tendency to *close in at the joints* and *grip the pin*. It is usual, therefore, not to allow the brass to *bear right round* the pin, and to bore it out about 4 per cent. larger than the pin.

11. It is essential, when designing the end of the connecting rod, to determine the exact shape it will have when machined. Figs. 21-23 show how this is done, and need no further explanation.

12. Connecting rods are usually *forged* from wrought iron or mild steel.


13. *Calculating the strength of the connecting rod.* To make this calculation it is


Table II.—Dimensions of Connecting Rod (in millimetres) (Figs. 24-38).

Engine.			Piston end (small end).												Crank end (big end).											
HP	S	D	L	a	b	c	e	f	g	A	i	k	l	m	n	o	p	q	r	s	t	u	u ₁	v	w	
0.6	130	80	375	30	40	30	25	6	5	—	—	—	—	42	50	8	—	40	16	13	12	40	38	30	70	
1.2	160	100	460	35	50	40	30	8	6	—	—	—	—	50	58	10	—	45	18	13	13	47	44	35	82	
2	190	125	550	45	60	45	35	10	6	—	—	—	—	60	65	11	—	50	20	16	15	54	50	40	94	
3.5	220	145	640	50	70	55	40	15	7	—	—	—	—	70	80	12	—	60	22	16	16	60	56	45	105	
7	270	185	800	60	90	70	45	18	8	—	—	—	—	95	105	15	—	80	26	20	21	78	72	55	133	
11	310	220	875	70	110	90	55	20	9	—	—	—	—	110	120	17	—	95	30	23	24	90	81	65	155	
17	350	260	1025	85	130	105	65	22	10	—	—	—	—	125	125	19	—	100	34	26	27	100	90	75	175	
25	400	300	1175	95	150	125	70	24	12	—	—	—	—	145	145	21	—	115	38	30	30	115	108	85	200	
33	450	380	1300	105	165	135	80	26	14	24	84	22	23	155	155	23	—	120	42	32	33	122	110	95	217	
42	500	360	1450	115	180	150	85	28	16	26	38	25	26	170	170	26	—	130	46	35	37	135	122	110	245	
55	550	400	1575	130	200	160	95	32	18	30	40	28	29	185	185	28	—	140	52	40	42	150	135	115	265	
80	600	480	1700	150	240	190	105	38	20	36	48	32	32	215	215	32	—	165	63	48	46	170	155	125	295	
132	700	600	1950	190	300	230	140	48	24	45	58	36	35	260	260	38	—	200	80	58	55	210	190	160	370	

The connecting rods illustrated in Figs. 24-38 belong to German engines, and are dimensioned in millimetres and must be used to prevent the brasses from turning.

Smaller connecting rods, i.e. for engines of less than 8½" stroke, have gun metal bearings without white metal.






Figs. 24-36.—Connecting Rod for Engines with Cyl. Diam. 400 mm. (15 $\frac{1}{2}$ "), Stroke 550 mm. (21 $\frac{3}{8}$ ").

Figs. 37, 38.

For smaller connecting rods (up to about 2 HP), as the space in the piston is very cramped, the small end is made as at Figs. 37, 38.



necessary to divide the connecting rod into several parts, and consider the strength of each part separately. We will deal with—

1. The shaft or body of the rod (*a*).
2. The big or crank end (*b*).
3. The small or piston-rod end (*c*).

Table III. shows the maximum loads coming on the connecting rod, on which the calculations are based.

Table III.—Maximum Stresses on the Connecting Rod.

	Single-acting engine.	Double-acting engine.
Maximum stress due to compression	$P = p \times A = \text{about } 380 \times A$	$P = p \times A = \text{about } 380A$
" " " tension . .	$P = 0.1W \frac{n^2 \times r}{78} + (1 - p_c)A = 64A$	$P = p \times A = \text{about } 380A$

For meaning of the different symbols used, see p. 59.

It will be seen from this table that the stress due to compression in the rod of a single-acting E 4 engine is as great as that on the rod of a double-acting D 4 engine, but there is a great difference in the stress due to tension in the rods of the two engines.

(a) Shaft or Body of the Connecting Rod.

The shaft or body of the rod is usually of round or rectangular cross section (Figs. 42–48). (For very small engines cast steel I-shaped rods are often used.)




FIG. 39.

FIGS. 40, 41.

The shaft is first treated as a *strut*, and its strength calculated under a breaking load. Referring to Fig. 39—

Let d_1 at d_2 = diameter of a round shaft in inches (Fig. 39).

b = width, h_1 h_2 = depth of a rectangular shaft in inches (Fig. 46).

L = length of rod in inches (*i.e.* distance between crank pin and piston pin centres).

J = moment of inertia of a round shaft having cross section $\frac{\pi}{4} d^2$; or a rectangular shaft $b \times h$ in inches.

E = modulus of elasticity in lbs. per sq. inch (for wrought iron $E = 29,000,000$).

m = constant for different piston speeds.

P = maximum load due to compression in lbs. (Table III.).

For a round cross section $J = 0.05d^4$ in inches⁴ (1)

„ rectangular „ $J = \frac{1}{12}b^3h$ „ (2)

Constant for different piston speeds $m = \frac{10 \times J \times E}{P \times L^2}$ (3)

Table for the Conversion of Round into Rectangular Cross Section.

$h : b$	1.5	1.75	2	2.25	2.5
$b : d$	0.79	0.76	0.74	0.72	0.7
$h : d$	1.19	1.33	1.48	1.62	1.75

The constant m depends upon the number of revolutions or piston speed. Table IV. gives its usual values.

Table IV.—Constant m .

Piston speed in ft. per minute $c =$	200	400	600	800
Constant $m =$	30	20	15	10

For the smallest cross section of the rod we must also know—

Stress due to *compression* $k_c = \frac{\text{compression load by Table III.}}{\text{smallest cross section of rod}}$ in lbs. per sq. in. (4)

Stress due to *tension* $k_t = \frac{\text{tension by Table III.}}{\text{smallest cross section of rod}}$ " " (5)

Allowable stress or safe working load $k_t = 7000$ lbs. per sq. in. (6)

In *single-acting* engines the stress due to *tension* is generally so small that it may be neglected.

The stress due to the inertia of the rod may be determined from the formula (in Haeder's "Konstruiren und Rechnen," 3rd Ed.)—

For circular section $k_b = 0.49 \left(\frac{n}{100} \right)^2 \times r \times \frac{L^2}{d}$ in lbs. per sq. inch. (7)

For rectangular section $k_b = 0.366 \left(\frac{n}{100} \right)^2 \times r \times \frac{L^2}{h}$ " " (7A)

when n = revs. per min.; r = radius of crank in feet; L = length between centres of connecting rod in inches; d = diameter of connecting rod in inches; h = depth of connecting rod; b = breadth of connecting rod in inches.

The combined stress works out at $k = k_c + k_b$ (8)

Allowable stress or safe working load for wrought iron $k = 8400$ lbs. per sq. inch.

(9)

It has a neater appearance if a round rod is made to taper from a larger diameter at the crank end to a smaller one at the piston end (Figs. 42-44), thus—


$$\left. \begin{aligned} d_1 &= 0.9d \\ d_2 &= 1.1d \end{aligned} \right\} \quad (10)$$

For engines above 50 HP the shaft of the rod is often made rectangular in section, as in Figs. 45-48, where—


$$h : b = 1.5 \text{ to } 1.7 \quad (11)$$

$$\left. \begin{aligned} h_1 &= 0.8h \\ h_2 &= 1.2h \end{aligned} \right\} \quad (12)$$

Figs. 42-44.—Shaft with Round Cross Section.



Figs. 45-48.—Shaft with Rectangular Cross Section.



Example.—Required to find the size of the shaft or body of a connecting rod for a single-acting four-cycle gas engine (**E4 1 cyl.**) having a cylinder of $15\frac{3}{4}$ " (or 400 mm.) diameter; stroke = $21\frac{1}{8}$ " (or 550 mm.); running at $n = 175$ revolutions per minute.

From Figs. 39, 40, and Table II, and IIA. (pp. 154–157), $d_1 = 3\frac{3}{4}$ " (or 95 mm.); $d_2 = 4\frac{1}{2}$ " (or 115 mm.)

$d = \frac{3\frac{3}{4} + 4\frac{1}{2}}{2} = 4\frac{1}{4}$ "; $L = 62$ " (or 1575 mm.); and from Table II. (p. 28) $W = 1165$ lbs. (or 530 kilos).

From Table III.: Stress on the rod due to *compression* = 380 lbs. $\times \frac{\pi}{4} \times 15\frac{3}{4}^2 = 194.8 \times 380 = 74,000$ lbs.

„ „ „ *tension* = 64 lbs. $\times \frac{\pi}{4} \times 15\frac{3}{4}^2 = 194.8 \times 64 = 12,500$ lbs.

From equation 1: Moment of inertia $J = 0.05 \times 4\frac{1}{4}^4 = 0.05 \times 290 = 14.5$

„ 3: Constant $m = \frac{10 \times 14.5 \times 29,000,000}{74,000 \times 62^3} = \text{about } 15$

„ 4: Stress due to *compression* $k_c = \frac{74,000}{\frac{\pi}{4} \times 3\frac{3}{4}^2} = 6700$ lbs. per sq. inch.

„ 5: *Tensile* stress $k_t = \frac{12,500}{\frac{\pi}{4} \times 3\frac{3}{4}^2} = 1130$ lbs. per sq. inch.

„ 7: $k_b = 0.49 \times \left(\frac{175}{100}\right)^2 \times 0.9' \times \frac{62''^2}{4\frac{1}{4}^4} = 1260$ lbs. per sq. inch.

„ 8: $k = 6700 + 1260 = 7960$ lbs. per sq. inch.

(b) Big End (or Crank-pin End) of the Connecting Rod.

As the engine is usually made with a cranked shaft, there is always a cap or keep to the head of the connecting rod.

This is generally turned at the end, but in order to determine the cross section and modulus of resistance quickly and simply, it is usual to consider the actual section as if it were rectangular (Fig. 49) and so take the mean depth at—





FIG. 49.

$$h = \frac{h_1 + h_2}{2} \quad \dots \dots \dots (13)$$

1. The Marine Type Big End, with Cap (Figs. 50–52).



FIGS. 50–52.

End with $s = 2$ Cap Bolts (p. 160).

The stresses coming on the cap due to bending (Section I.) must be determined from the maximum load P , Table III. In a single-acting engine this load is very small, and the cap or keep may be made lighter than that of a steam engine.

With reference to Figs. 50–52, let—

a = diameter of jaw (outside diameter of brasses) in inches.

l = distance between centres of bolts in inches.

b = width of cap in inches.

h and c = thickness of respective cross sections, determined from equation 13 and Fig. 49, in inches.

P = maximum load due to *tension*, from Table III.

For *Cross Section I.*, according to Bach's formula—

$$\text{Bending moment } M_b = 0.5 P \left(\frac{l}{2} - \frac{a}{4} \right) \text{ inch-lbs.} \quad (14)$$

$$\text{Modulus of resistance } Z_b = \frac{bh^2}{6} (15)$$

$$\text{Stress due to bending } k_b = \frac{M_b}{z_b} \text{ lbs. per sq. inch} \quad . \quad . \quad . \quad (16)$$

Allowable stress or safe working load $k_s = 8500$ lbs. per sq. inch (17)

The tensile stress on the *cap bolts* at both ends of the rod must also be calculated, and varies from zero (during the working stroke) to stress P, Table III.

If s = diameter of the bolt at the bottom of the thread in inches, and z = number of bolts e , then—

$$\text{Tensile strength } k_t = \frac{P}{\frac{\pi}{4}s^2} \text{ in lbs. per sq. in.} \quad \dots \quad (18)$$

Allowable stress, k_t = 4200 to 5600 lbs. per square inch. . . . (19)

(c) Small End, or Piston Pin End.

Here, as already mentioned, we shall have to deal with both the solid forged eye type, and the type with adjustable cap or keep.

1. Small End of Connecting Rod (Solid Forged-eye Type).

Cross section I. must be calculated for stress due to bending.

Cross section II. must be calculated for stress due to *tension*, from the tensile stress P, Table III.

In Figs. 53-55 let—

a = diameter of jaw in inches.

$l = a + c$ = length of corresponding arm of beam in inches.

b = width of connecting rod end,
inches.

h and c = thickness of respective sections determined from equation 13 and Fig. 49.

Then for *Cross Section I.*—

$$\text{Bending moment } M_b = 0.5 P \left(\frac{l}{2} - \frac{a}{4} \right) \text{ inch-lbs.} \quad . \quad . \quad . \quad (20)$$

$$\text{Modulus of resistance } Z_b = \frac{bh^2}{6}; k_b = \frac{M_b}{Z_b} \dots \dots \dots (21)$$


For Cross Section II.—

Tensile stress $k_t = \frac{P}{2bc}$ in lbs. per sq. inch (22)

Allowable stress or safe working load—

$$k_b = 8500 \text{ lbs. per square inch} \quad . \quad . \quad . \quad . \quad . \quad . \quad (23)$$


$$k_i = 4200 \quad " \quad " \quad . \quad . \quad . \quad . \quad . \quad . \quad . \quad . \quad (24)$$



FIGS. 53-55.

2. Connecting Rod Small End, with Adjustable Cap.

Figs. 56-58 illustrate a type of end similar in principle to that given in Figs. 50-52. Keeping the same lettering as at page 160, the dimensions can be determined in the same way.



Figs. 56-58. End with $z = 4$ bolts.

Thus taking the tensile stress P , Table III., p. 157, for *Cross Section I.*, we get—

$$M_b = 0.5P \left(\frac{l}{2} - \frac{a}{4} \right) \text{ inch-lbs.} \quad (25)$$

$$Z_b = \frac{bh^2}{6} \quad (26)$$

$$k_b = \frac{M_b}{Z_b} \quad (27)$$

Allowable stress—

$$k_b = 8400 \text{ lbs. per sq. in.}; k_t = 4200 \text{ lbs. per sq. in.} \quad (28)$$

$$\text{Cap bolts } k_t = \frac{P}{\frac{\pi}{4}s^2} \text{ in lbs. per sq. in.} \quad (29)$$

$$\text{Allowable stress, 4200 to 5600 lbs. per sq. in.} \quad (30)$$

Example.—Required to design a connecting rod with adjustable cap at each end for a four-cycle gas engine (E4 1 cyl.) with cylinder diameter 400 mm. = $15\frac{3}{4}$ ", stroke 550 mm. = $21\frac{3}{8}$ ".

The *crank pin* is 185 mm. or $7\frac{1}{4}$ " diameter, and 185 mm. or $7\frac{1}{4}$ " long.

The *piston pin* is 125 mm. or $5\frac{1}{8}$ " diameter, and 200 mm. or $7\frac{7}{8}$ " long.

According to the example given on p. 159, the stress due to compression P will be 74,000 lbs., and the stress due to tension 12,500 lbs. per sq. inch.

(a) Marine Type End.

Referring to Figs. 50-52 and pp. 155, 156, we get—

$$a = 185 + 2 \times 28 = 241 \text{ mm., or } 7\frac{1}{4}" + 2 \times 1\frac{1}{8}" = 9\frac{1}{4}"$$

$$b = 140 \text{ mm., or } 5\frac{1}{2}"; e = 40 \text{ mm., or } 1\frac{5}{8}"$$

$$l = 185 + 2 \times 42 \text{ mm.} = 269 \text{ mm., or } 7\frac{1}{4}" + 2 \times 1\frac{5}{8}" = 10\frac{1}{4}"$$

Number of bolts $z = 2$.

$$\text{From above figures } c = 43 \text{ mm., or } 1\frac{5}{8}"; h = 45 \text{ mm., or } 1\frac{3}{4}"$$

$$\text{Wherefore by equation 14: } M_b = 0.5 \times 12,500 \left(5\frac{1}{4}" - 2\frac{3}{8}" \right) = 18000 \text{ inch-lbs.}$$

$$15: Z_b = \frac{5\frac{1}{4} \times (1\frac{3}{4})^2}{6} = 2.8 \text{ cubic inches}$$

$$16: k_b = \frac{18,000}{2.8} = 6450 \text{ lbs. per sq. inch.}$$

Allowable stress from equation 17, 8500 lbs. per sq. inch.

From p. 155, area of the bolts at the bottom of the thread $s = 1.472$ sq. inches (i.e. $1\frac{5}{8}"$ bolt).

Therefore by equation 18—

$$k_t = \frac{12,500}{2 \times 1.472} = 4250 \text{ lbs. per sq. inch.}$$

Allowable stress or safe working load, from equation 19, up to 5600 lbs. per sq. inch.

(b) **Small End (Piston End) with Adjustable Cap.**

From Table II., p. 155, and Figs. 56-58—

$$a = 130 + 2 \times 18 = 166 \text{ mm. or } 5\frac{1}{8}'' + 2 \times 1\frac{1}{8}'' = 6\frac{1}{2}'' \text{ diameter.}$$

$$b = 160 \text{ mm. or } 6\frac{5}{8}''; e = 29 \text{ mm. or } 1\frac{1}{8}''.$$

$$l = 125 + 2 \times 28 \text{ mm.} = 181 \text{ mm. or } 5\frac{1}{8}'' + 2 \times 1\frac{1}{8}'' = 7\frac{3}{8}''.$$

$$h = 32 \text{ mm. or } 1\frac{1}{4}''; c \text{ (from the drawing) } = 35 \text{ mm. or } 1\frac{3}{8}''.$$

Number of cap bolts $z = 4$.

$$\text{Wherefore by equation 25: } M_b = 6250 (3\frac{3}{8}'' - 1\frac{5}{8}'') = 12,500 \text{ inch-lbs.}$$

$$26: Z_b = \frac{6\frac{5}{8} \times (1\frac{1}{4})^2}{6} = 1.65 \text{ cubic inches.}$$

$$26: k_b = \frac{12,500}{1.65} = 7570 \text{ lbs. per sq. inch.}$$

Allowable stress 8500 lbs. per sq. inch, from equation 28.

From p. 155: Area of each *cap bolt* at the bottom of the thread $s = 0.697''$.

$$\text{By equation 29: } k_t = \frac{12,500}{4 \times 0.697} = 4500 \text{ lbs. per sq. inch.}$$

Allowable stress from equation 30, 5600 lbs. per sq. inch.

Explanation of Table IV., p. 163.

To make the subject clearer the dimensions of the *connecting rod*, *crank-shaft bearings*, *crank pin*, *piston* and *piston pin*, or cross head, have been tabulated in Table IV. Besides the *maximum piston loads* (see Table III., p. 157), this table also contains the constant m for the connecting rod, and the values of F , q , and q max., which determine the pressure on the bearing, causing it to wear or to run hot.

With the help of this table, if the maximum load on the piston is known, it is possible to determine the corresponding dimensions of the engine. If the number of revolutions in a given engine differs from the values in column 4, the dimensions of the crank-shaft bearings and the crank pin are determined from the friction work F (*i.e.* load on the bearings per sq. inch $\times$ circumferential velocity of the pin in feet per second $\times$ by the coefficient of friction = 0.05). Thus, taking n_1 as the speed of the engine in question—

$$\frac{n_1}{n} \times F \text{ ft.-lbs. per sec. per sq. in. of bearing} \quad (31)$$

(n = number of revolutions given in the table, F to be taken from the table for dimensions of crank pin and maximum piston load corresponding to this speed.)

The figures thus obtained when checked by the calculations at p. 97 *et seq.*, show whether the safe working load has been exceeded or not.

As regards the figures printed in italic type, note that they refer only to engines built in special workshops, where engines of this size exclusively are made. In general it is advisable, for engines the dimensions of which are printed thus, to take the dimensions of the engine of the next size larger, having the same stroke.

Table IV.—Connecting Rod, Crank-shaft Bearings, Crank Pin, Piston Pin (Cross Head), and Piston.
For Single-cylinder, Four-cycle Engines, with an explosion pressure = 370 lbs. per square inch (see explanation, p. 162).

ENGINE.		CONNECTING ROD.		MAIN BEARINGS.		CRANK PIN.			PISTON.		PISTON PIN OR CROSS HEAD.									
Column 1 gives power developed with light- ing gas. With suc- tion or power gas, 25 per cent. less.		(For method of calculation, see p. 157.) (For standard dimensions, see p. 154.)		(For method of calculation, see p. 97.) (For standard dimensions, see pp. 106, 107.)		(For method of calculation, see p. 97.) (For standard dimensions, see p. 73.)			(For method of cal- culation, see p. 128.) (For standard di- mensions, see p. 140.)		(For method of cal- culation, see p. 138.) (For standard di- mensions, see p. 146.)									
HP	Stroke N ins.	Diam. D ins.	Diameter.		Con- stant w.	d ins.	l ins.	q lbs. per sq. in.	F.	q lbs. per sq. in.	Mean pressure K lbs.	l ins.	q lbs. per sq. in.							
			Piston end ins.	Crank- pin end ins.																
Load on piston.		P max. lbs.																		
0-6	5	3 1/8	1 3/8	14 1/2	31	1 1/8	2 1/2	426	132	11-2	18	2	940	94	275	61	20	1 3/8	1 1/2	1650
1-2	6 1/4	4	1 3/8	18 1/2	27	1 3/8	3 1/2	425	117	11-9	2	2 1/2	1030	103	416	7 1/2	20	1 3/8	2 1/8	1700
2	7 1/2	5	1 3/8	21 1/2	22	2 1/8	4 1/2	455	122	14-4	2 3/8	3 1/8	1200	120	650	9 1/2	20	1 3/8	2 3/8	1750
3-5	8 1/2	5 1/2	1 3/8	23 1/2	21	2 3/8	5 1/2	440	118	16-3	3 1/8	3 3/8	1100	110	857	11 1/2	17	2 3/8	2 3/8	1750
5	10 1/2	6 1/2	2 1/8	31 1/2	20	3 1/8	5 3/4	352	84-2	13-5	3 3/8	3 3/8	980	98	980	13 1/2	17	2 3/8	3 1/8	1800
7	10 1/2	7 1/2	2 1/8	31 1/2	20	3 1/8	6 1/4	397	88	18-1	3 3/8	4 1/8	990	99	1,365	13 1/2	17	2 3/8	3 1/8	1800
9	12 1/2	7 1/2	2 1/8	34 1/2	21	4 1/8	7 1/8	373	88	17-3	4 1/8	4 1/2	1030	103	1,610	16 1/2	18	2 3/8	4 1/8	1880
11	12 1/2	8 1/2	2 1/8	34 1/2	21	4 1/8	7 1/8	398	94	19-7	4 1/8	4 1/2	1090	109	2,110	16 1/2	18	2 3/8	4 1/8	1880
13	13 1/2	9	3	40 3/8	18	4 1/8	8 1/4	405	94-5	22-2	5	5 1/2	1220	122	2,730	19 1/2	20	3 3/8	5 1/8	1760
17	15 1/2	10 1/2	3 1/8	43 1/2	19	4 1/8	9 1/4	390	88	20-7	5 1/2	5 1/2	1240	124	2,940	22 1/2	20	3 3/8	6	1830
20	15 1/2	11 1/2	3 1/8	43 1/2	16	5 1/8	10 1/4	408	98	25-5	5 1/2	5 1/2	1240	124	3,660	22 1/2	20	3 3/8	6	1830
25	17 1/2	12 1/2	3 3/8	51 1/2	16	5 1/8	10 1/4	410	103	25-8	6	6 1/2	1210	121	3,900	24 1/2	19	4 1/8	6 1/2	1830
29	17 1/2	13 1/2	3 3/8	51 1/2	16	6 1/8	11 1/4	426	108	27-8	6 1/2	6 1/2	1300	130	4,400	24 1/2	19	4 1/8	6 1/2	1830
33	17 1/2	13 1/2	4	51 1/2	15	6 1/8	11 1/4	415	108	27-3	6 1/2	6 1/2	1300	130	4,500	25 1/2	20	4 1/8	7 1/8	1820
36	19 1/2	14 1/2	4 1/8	57 1/2	15	6 1/8	12	460	119	31-2	6 3/8	6 3/8	1300	130	5,300	25 1/2	21	4 1/8	7 1/8	1820
45	21 1/2	14 1/2	4 1/8	62	15	6 3/8	12 1/2	450	123	31-1	6 3/8	6 3/8	1300	130	5,500	28 1/2	21	5 1/8	7 1/8	1790
55	21 1/2	15 1/2	4 1/2	67	15	7 1/8	13 1/4	472	128-5	34-7	7 1/8	7 1/8	1370	137	6,450	28 1/2	21	5 1/8	7 1/8	1790
65	23 1/2	17 1/2	4 1/2	67	13	7 1/8	14 1/4	487	141	38	7 1/8	7 1/8	1440	144	7,500	33 1/2	21	6	9 1/2	1850
80	23 1/2	18 1/2	5	73	13	7 1/8	15 1/4	536	156	44-3	8 1/8	8 1/8	1420	142	9,250	33 1/2	21	6	9 1/2	1850
110	27 1/2	21 1/2	5 1/2	76 3/4	12	8 1/8	17	580	183	52-3	9 1/8	9 1/8	1530	153	11,750	41 1/2	20	7 1/8	11 1/2	1830
132	27 1/2	23 3/8	6	76 3/4	12	9 1/8	18 1/4	575	172	54-2	10 1/8	10 1/8	1540	154	14,600	41 1/2	22	7 1/8	11 1/2	1830

Column 1 gives power developed with light gas. With suction or power gas, 25 per cent. less.

Section VI. The Flywheel.

It is often said that a gas engine requires a very much *heavier flywheel* than a steam engine, and can never be run with the same degree of uniformity. For the same reason the mechanical efficiency of a gas engine is less than that of a steam engine.

The subject cannot be dismissed in such a cursory way, and a distinction must be made between the four following working conditions:—


1. Degree of irregularity (or of uniformity) in running at *full load, the load remaining constant.*
2. Degree of uniformity at less than full load, the load remaining constant.
3. Fluctuations in the speed, with *variations in the load.*
4. " " " *rapidly repeated variations in the load.*

1. Degree of Irregularity in running at Full Load, the Load remaining Constant.

The method of governing has a great influence on the degree of irregularity δ , (at constant load), and therefore on the weight of flywheel required. The following considerations will make this clearer.

We will suppose that several developed diagrams taken from the same engine are plotted consecutively, as shown in Table I. The more regular the curves (that is, the more closely they approximate to a straight line), the lighter will be the flywheel required.

Table I.—Diagram showing the Fluctuations in the Power developed in a Single-cylinder Gas Engine.



Although hit-and-miss governing gives a more economical consumption of gas, in an engine running at normal or light load, the explosions when produced being always of

the same strength, to govern by varying the quantity or quality of the charge is more usual, because it gives a greater degree of uniformity, as shown in Table I.

Table Ia.—The Degree of Irregularity δ_0 is expressed in—

Decimals, i.e. $\delta_0 =$	0.005	0.007	0.01	0.012	0.015	0.02	0.025	0.03	0.035	0.04
Percentages „ =	0.5%	0.7%	1%	1.2%	1.5%	2%	2.5%	3%	3.5%	4%
Fractions „ =	$\frac{1}{200}$	$\frac{1}{143}$	$\frac{1}{100}$	$\frac{1}{83}$	$\frac{1}{66}$	$\frac{1}{50}$	$\frac{1}{40}$	$\frac{1}{33}$	$\frac{1}{29}$	$\frac{1}{25}$
Degree of Uniformity 1 : $\delta_0 =$	200	143	100	83	66	50	40	33	29	25

The degree of irregularity in running affords a scale for determining the variations in the speed ; δ_0 shows these variations for a single stroke of the piston, and is determined, under given working conditions, by means of the tangential pressure diagram, pp. 34 et seq. For this calculation the main dimensions of




FIG. 1.

the engine, weight of the flywheel, and an indicator diagram to scale are required.

According to the data given on pp. 34 et seq.—

ub = equivalent rectangle.

$\frac{S\pi}{l}$ = length of base of the rectangle reduced to the circle described by the crank in feet.

b = height of rectangle in lbs. per square inch.

Let A denote sectional area of the cylinder in square inches.

S „ stroke of the engine in feet.

n „ number of revolutions per minute.

V „ circumferential velocity of centre of gravity of the rim in feet per second by equation 2, p. 39.

IHP „ maximum output of the engine (indicated horse-power).

BHP „ „ „ „ (brake horse-power).

δ_0 „ degree of irregularity in running, to be allowed for, at maximum load ; δ_0 only shows the fluctuations in the speed when the power developed is a constant, not at varying loads.

Therefore by equation 4, p. 39, weight of flywheel rim $W = 92 \times \frac{u}{l} b \frac{AS}{V^2} \times \frac{1}{\delta_0}$

$$\text{Inserting in this equation the value } A = \frac{550 \text{ IHP}}{p_i \times \frac{2Sn}{60}} \dots \dots \dots (1)$$

$$\text{the weight of the rim works out at } W = 1,518,000 \frac{u}{l} \times b \times \frac{1}{p_i} \times \frac{\text{IHP}}{nV^2} \times \frac{1}{\delta_0} \dots \dots (2)$$

(Here $p_i = \frac{z}{T} \times pm$ is the mean pressure on one working face of the piston throughout the stroke. See Table II., p. 20.)

To avoid very high numbers in Table II., let—

$$100 \times i = 1,518,000 \times \left(\frac{u}{l} \times b \right) \times \frac{1}{p_i} \dots \dots \dots (3)$$

and the result is the same equation as in the Author's book on "Steam Engines."

$$\text{Weight of the rim } W = 100 \times i \times \frac{\text{IHP}}{n \times V^2} \times \frac{1}{\delta_0} \dots \dots \dots (4)$$

If, as at p. 173, we use the expression denoted by $\bar{W} \times D^2$ and $V = \frac{D\pi n}{60}$ be inserted in equation 4, then—

$$\bar{W} \times D^2 = \frac{400}{n^2} \times 100 \times i \times \text{IHP} \times \frac{1}{\delta_0} \text{ in lbs.-feet}^2 \quad . \quad . \quad (5)$$

V = circumferential velocity in circle described by centre of gravity of rim section in feet per second.

IHP = indicated horse-power ; n revolutions per minute ; δ_0 degree of irregularity ; $\frac{1}{\delta_0}$ degree of uniformity ; D diameter of circle described by centre of gravity of the rim in feet.

$\bar{W}$ = about 1·1W, weight of the masses in rotation in lbs., from p. 173.

The values calculated with the help of the diagram of tangential pressures at p. 34 *et seq.* work out as follows :—

Table II.—Values of i for calculating the Flywheel according to Equations 4 and 5, taking account of the Degree of Irregularity δ_0 .

Number of cylinders.	Four-cycle (gas engine).						Two-cycle (gas engine).			Steam engine.				
	Single-acting.			Double-acting.			Single-acting.	Double-acting.		Single cyl.	Tan-dem.	Com-pound.	Triple.	
	1	2*	4	1	2	4	1	1	2	1	2	2	2 crks.	3 crks.
													3	3
$\frac{u}{l} \times b =$	28.4	24.5	6.25	38.5	9.5	5.4	2.5	—	—	5.4	2.85	1.85	1.4	0.85
$\frac{1,518,000}{100} \times \frac{u}{l} \times b =$	432,000	372,000	94,500	584,000	144,000	82,000	380,000	—	—	82,000	43,200	28,000	21,300	12,900
p_i = lbs. per sq. in.	20.6	41.1	82.2	41.1	82.2	164	41.1	82.2	164	40	22.7	22.7	25.5	25.5
i calcu- } IHP	21,000	9050	1150	1420	1750	500	9230	360	46	2050	1902	1233	836	506
lated for } BHP	25,000	10,440	1310	1650	1990	550	—	—	—	2280	2120	1375	990	562

Example from Table II.—To calculate the weight of the flywheel rim, in a double-acting four-cycle two-cylinder gas engine, it would be necessary to make i (equation 4) = 1750 if the IHP, and = 1990 if the BHP be taken.

The difference between steam engines and gas engines in this respect is shown by the values of i in Table II., and still more clearly in Table III. (next page).

First Example from Table III.—To make a single-cylinder four-cycle gas engine (type *a*) run with the same degree of uniformity as a single-cylinder steam engine, the flywheel would have to be 9·3 times heavier, or have a circumferential velocity $\sqrt{9·3} = 3·05$ times greater than that of the steam engine.






Second Example.—A two-cylinder four-cycle gas engine (type *c*) requires a flywheel seven times heavier than a compound steam engine.

Third Example.—A four-cylinder double-acting four-cycle gas engine—
 with 90° angle of the crank requires a flywheel 0·9 times the weight } of the flywheel of a
 „ 180° „ „ „ „ 2·9 „ „ } triple steam engine.

* A twin *vis-a-vis* four-cycle gas engine (Type *b*, Table III.) has a flywheel of the same size as a double-acting four-cycle engine (Type *f*, Table III.).

Table III.—Comparative Weights of the Flywheel in Gas and Steam Engines.

(The numbers show how many times greater the weight of the flywheel must be in gas engines than in steam engines, for the same power IHP, circumferential velocity V , and number of revolutions n .)

Type.		STEAM ENGINES.			
		Single cylinder.	Tandem.	Compound.	Triple.
Single acting.	(a) 	9.3	10	16	38
	(b) 	6.3	6.7	11	26
	(c) 	4	4.3	7	16.5
	(d) 	0.5	0.55	0.9	2
	(e) 	0.5	0.55	0.9	2
Double-acting.	(f) 	6.3	6.7	11	26
	(g) 	0.86	0.84	1.85	3.2
	(h) 	0.86	0.84	1.85	3.2
	(i) 	0.22 (0.7)	0.24 (0.76)	0.38 (1.2)	0.9 (2.9)
		The upper numbers apply to cranks set at an angle of 90°. The lower " " " " 180°.			

2. Degree of Irregularity at Light Loads, the Load remaining Constant.

(a) Hit-and-miss Governing.

This (the oldest method of governing, and the most economical as regards the consumption of gas) is only applied to gas engines for industrial purposes; for driving dynamos it would require an impossibly heavy flywheel. With this system, as already explained at p. 19, when the governor is in its highest position the gas valve is held closed from time to time; no gas can enter, and no explosions can occur. The time

elapsing, in other words, the number of piston strokes intervening between two explosions, is thus increased. In an E 4 engine the explosions at full load succeed each other every four strokes, or, what is the same thing, each working cycle comprises two revolutions of the crank shaft.

Supposing, for instance, that such an engine is running at half-load, a certain number of explosions must naturally be missed, and in theory each ignition should be followed by a missfire.




FIG. 6.—Diagram of Tangential Pressures (or Turning-moment Diagram).

Fig. 6 shows the tangential pressure or turning moment diagram of an E 4 single-cylinder engine, for one working cycle (see Fig. 9, p. 38). At full speed, therefore, this diagram would be consecutively reproduced, and each cycle of work would be spread over four piston strokes. If the engine is run at half load, the cycle of work will occupy twice the time, and be distributed over eight strokes (Fig. 7). To draw correct conclusions from the work of the engine, we must assume that it is governed with absolute regularity, and that missfires alternate invariably with explosions. Deviations from this regular sequence of operations would render a proper study of the conditions impossible.




FIG. 7.—Diagram of Tangential Pressures for Eight Piston Strokes (at Half Load).

In this pressure diagram (Fig. 7) the mean resistance BC is naturally less than at full load, that is, the line CC₁ approximates more closely to the line of no pressure BB₁, and thus the equivalent rectangles are larger. According to the method described at pp. 39 *et seq.*, the largest of these rectangles is taken as the basis for calculating the weight of the rim for a given degree of irregularity, δ . The larger this rectangle, therefore, for the same δ , the heavier will be the flywheel required (see equation 4, p. 39), or, if the weight of the flywheel is not increased, the greater will be the degree of irregularity δ , i.e. the less satisfactorily will the engine work.

If the diagram of tangential pressures (or turning-moment diagram) be drawn for the engine at full load, the increase in the size of the equivalent rectangles, due to diminutions in the load, and hit-and-miss governing, may be numerically determined as follows:—

The work done in the cylinder during one stroke to and fro is taken at—

$$X_2 = A \times p_m \times 2r \quad \dots \dots \dots (6)$$

The work of resistance R , which of course $= X_z$, is in an **E4** single cylinder engine spread over a distance of $2 \times l = 4r\pi$ (Fig. 6), and if the length BC = mean resistance per square inch p_w , we get—

$$X_z = R = Ap_w 2l = Ap_w 4r\pi \quad \dots \dots \dots (7)$$

$$\text{then } Ap_w 2r = Ap_w 4r\pi \quad \dots \dots \dots (8)$$

and at full load—

$$p_w = \frac{p_m}{2\pi} \text{ for E 4 single-cylinder engines } \dots (9)$$

For double-acting and multi-cylinder engines equation 9 is written thus—

$$p_w = \frac{z}{1} \times \frac{p_m}{2\pi} \dots \dots \dots (10)$$

where z = sum of the cylinder ends in which work is done, and—

T = number of strokes (see page 20).

(The same values are obtained if the curve of tangential pressures is planimeted, as described in Chapter V.)

If the engine is run under light load p_w becomes less, because the distance over which R is distributed is greater (compare Fig. 7). Thus at half load, according to Fig. 7, we get—

$$X_z = R = Ap_w 4l = Ap_w 8r\pi \quad \dots \dots \dots (11)$$

and hence—

$$p_w = \frac{p_m}{4\pi} \quad \dots \dots \dots (12)$$

Example.—Let us take the example given at p. 40, and determine the degree of irregularity δ_0 , the mean pressure on the piston, with a pressure of explosion of 370 lbs. per sq. inch being $p_m = 90$ lbs. per sq. inch.

$$\text{From equation 9 at full load } p_w = \frac{90}{2\pi} = 14\frac{1}{2} \text{ lbs. per sq. inch.}$$

$$\text{" " 12 at half load } p_w = \frac{90}{4\pi} = 7\frac{1}{4} \text{ lbs. per sq. inch.}$$

The largest equivalent rectangle (see Fig. 8) will thus be $(14\frac{1}{2} - 7\frac{1}{4}) \times u$ larger in ft.-lbs.

According to the example given at p. 40, $u = 0.131$ ft., $b = 65$ lbs. per sq. inch; therefore the equivalent rectangle at half load will be—

$$u \times b + (14\frac{1}{2} - 7\frac{1}{4}) \times u = 0.131 \times 65 + 7\frac{1}{4} \times 0.131 = 9.45 \text{ lbs.* per ft.}$$

$$\text{As equation 4, p. 39, gives } \delta_0 = 92 \times \frac{ub}{l} \times \frac{AS}{V^2} \times \frac{1}{W} \quad \dots \dots \dots (13)$$

therefore at half load—

$$\delta_0 = 92 \times \frac{9.45}{0.29} \times \frac{113 \times 1.33}{72^2} \times \frac{1}{6280} = \frac{1}{72} \text{ as against } \frac{1}{80} \text{ at full load.}$$

(For meaning and value of the different symbols, see pp. 39 and 40.)

Table IV. shows the effect on δ_0 of various loads, the load being assumed to be constant at each of the different powers developed.

Table IV.—Values of δ_0 at less than Full Load, the Load remaining Constant at each Change.

Hit-and-miss governing. Quantitative or qualitative governing	Degree of irregularity } =	Full load	0.85	0.75	0.60	0.40	0.20 of full load
		δ_0	1.08 δ_0	1.06 δ_0	1.09 δ_0	1.14 δ_0	1.18 δ_0
Under unfavourable conditions it is possible to have		δ_0	0.97 δ_0	0.94 δ_0	0.91 δ_0	0.86 δ_0	0.82 δ_0
		1.8 δ_0	1.7 δ_0	1.6 δ_0	1.5 δ_0	1.4 δ_0	1.2 δ_0

* This value should be used for $u \times b$ at full load.

In actual practice, however, when governing is by hit-and-miss, the ignitions do not follow each other in regular sequence. Not unfrequently also, when the engine is running under light load, ignitions are missed, even when the governor acts by varying the quantity and quality of the charge. It is to these spasmodic ignitions that the degree of irregularity shown in the last line in Table IV. refers.

(b) Quantity or Quality Governing.

With this method of governing the working conditions are different to those described under head *a*. The ignitions always follow each other in the sequence prescribed by the working cycle, but the areas of the diagram are reduced in proportion to the smaller output of the engine. The equivalent rectangles also vary and become smaller, the degree of irregularity is less, and the efficiency is improved (compare bottom line of Table IV.).

If an engine with *hit-and-miss* governing is not to exceed a certain degree of irregularity even when run at *light loads*, and if, as is usual, the weight of the flywheel is determined from the maximum output, a lesser value of δ_0 must be chosen from Table IV. than that corresponding to full load, in order to obtain the requisite steadiness in running at light loads. With quantity or quality governing it is sufficient to take the degree of irregularity at maximum load as a basis for determining the weight of the flywheel, because, as shown in Table IV., δ_0 improves as the load diminishes.

3. Fluctuations in the Speed with Variations of Load.

The degree of irregularity δ_0 affords an index to the fluctuations in the speed when the *power developed* by the engine *remains constant*. In engines in which the output varies more or less rapidly, δ_0 does not form a guide for regulating the speed.

The *kinetic energy* stored up in the flywheel, in other words, the

Energy of the Flywheel

here plays an important part. Let—

V be the circumferential velocity at normal speed, in feet per second.

v " " " " at diminished speed, in feet per second.

t " " time in seconds during which the speed diminishes, in other words, the time elapsing while the circumferential speed falls from V to v .

Then $E = \frac{W}{g} \times \frac{V^2}{2}$ in ft.-lbs. is the kinetic energy of the rotating masses of the flywheel at normal speed (see p. 173) (14)*

$HP. = \frac{1}{550} \times \frac{W}{g} \times \frac{V^2 - v^2}{2} \times \frac{1}{t} = HP$ developed by the flywheel while the speed is diminishing (15)

(Thus, to determine HP, it is necessary to know the time t and the difference between the highest and lowest speeds $V - v$.)

Let us take, for instance, a modern steam *rolling mill*, in which the output varies greatly. Taking the *normal power* developed = 1500 HP, maximum power $1.35 \times 1500 =$ about 2000 HP, $n = 100$, weight of the flywheel, including that of the arms $W = 88,000$ lbs., circumferential speed of the rim $V = 130$ ft. per second. For the work done by the flywheel as the power required for the rolling mill increases, we get the following:—

* For meaning of W , see p. 173.

Table V.—Work done by the Flywheel, $\frac{W}{32} = 88000$ lbs. $V = 130$ ft. per second.*

$$\left(\text{Energy of the Flywheel} \frac{88,000}{32} \times \frac{130^2}{2} = 23,300,000 \text{ ft.-lbs.} \right)$$

Change of speed =		Speed falling from —				
		100 to 90 revs.	100 to 80 revs.	100 to 50 revs.	100 to 30 revs.	100 to zero revs p. m.
		10 %	20 %	50 %	70 %	100 %
Time in which the change of speed is effected.	1 second	HP, = 8050	HP, = 15,300	HP, = 31,800	HP, = 38,600	HP, = 42,400
	3 seconds	2690	5,100	10,600	12,866	14,190
	5 "	1610	3,060	6,360	7,720	8,480
	10 "	805	1,530	3,180	3,860	4,240
	20 "	402	765	1,590	1,930	2,120
	30 "	269	510	1,060	1,286	1,413

If, for instance, the speed of the engine here considered falls in five seconds from 100 to 90 revolutions, the flywheel, according to Table V., will develop 1640 HP.

In practice it sometimes happens that the work done by the flywheel is occasionally much greater† than the normal output of the engine; and for this reason the HP printed in thick type in Table V. have often been obtained under working conditions.

Practically at the same time (after perhaps a second's interval) the governor falls to its lowest position, showing that the maximum load has been thrown upon the engine. Thus with 10 per cent. variation in the speed we get—

$$\text{Mean output} = \frac{1 + 0.9}{2} = 0.95$$

$$\text{Work of the engine } 0.95 \times 1.35 \times 1500 = \text{about } 1920 \text{ HP}$$

$$\text{,, ,, flywheel } 1610 \text{ ,,}$$

$$\text{Total . . . } 3530 \text{ ,,}$$

If the engine were required to develop this power without a flywheel, the sectional area of the motor cylinder would have to be $\frac{3530}{1920} = 1.8$ times larger, whether the engine were driven by steam or gas.

* TRANSLATOR'S NOTE.—These flywheels are of course built-up steel flywheels; the maximum rim velocity for a built-up cast iron wheel is 90 ft. per second.

† The figures printed in black type in Table V. occur in ordinary practice in every rolling mill. It has been observed, however, that the work of the flywheel may be as much as eight times greater than that in the motor cylinder of a steam engine.

The power developed by the engine and the energy of the flywheel must *supplement each other*, that is, the less the work done by the engine the greater must be the energy of the flywheel, and *vice versa*. But in any case the amount of work done by the engine, when running light, must be sufficient, when combined with the work of the flywheel, to allow the engine, within the allotted time, to resume its normal speed. To determine this point observations must be made on engines while running.

Degree of Uniformity $\frac{1}{\delta_0}$ and Energy of the Flywheel.

An engine may work very steadily, for instance with a variation, as is often required for driving dynamos, of $\frac{1}{\delta_0} = 250$, and yet be of no use if run with rapidly varying loads, say in a rolling mill.

What is the reason of this?

Because it is not only the degree of uniformity, but as already shown, the kinetic energy stored up in the flywheel, which must be studied to explain the anomaly.

According to equation 14, the kinetic energy in the rim of the flywheel at normal load, and thus the—

$$\text{Energy of the flywheel per HP is } \frac{E}{\text{HP}} = \frac{n^2}{23,500} \times \frac{\text{dia} \times \text{dia}^2}{\text{IHP}} \text{ in ft.-lbs.} \quad (16)$$

$$\text{Degree of uniformity } \frac{1}{\delta_0} = \frac{n^3}{40,000} \times \frac{1}{i} \times \frac{\text{dia} \times \text{dia}^3}{\text{IHP}} \quad (17)$$

Thus the energy of the flywheel increases as the square of n , the degree of uniformity as the cube of n .

What conclusions respecting gas engines may be deduced from our study of flywheels in the preceding pages (164–171)?

1. If a given *degree of uniformity* $\frac{1}{\delta_0}$ is required (as for driving dynamos, spinning mills, etc.), gas engines must have heavier flywheels than steam engines (see Tables II. and III., pp. 166, 167).

2. In engines run *under varying loads*, but in which the degree of uniformity is not a point of great importance, the flywheel need not be heavier than that of a steam engine, as it is the energy stored up in the flywheel which has to be considered. The output of the engine should be rated from 1.3 to 1.4 times higher than the normal output of a *steam engine* of the same dimensions. As far as the action of the flywheel is concerned, there is *nothing to prevent* the use of blast furnace gases for driving rolling mills, if the power developed by the engine is rated from 30 per cent. to 40 per cent. higher than that of a *steam engine* doing the same work, and having a flywheel of the same dimensions.

3. For engines for power purposes, with *varying loads*, and which are used at the *same time* to drive *dynamos* for electric light, the rule given under head 1 applies, since in both cases the degree of uniformity δ_0 is the main point to be considered.

Further, if n and δ_0 be given, the energy of the flywheel can be directly calculated by combining equations 16 and 17, thus—


$$\text{Energy per IHP, } E \div \text{IHP} = \frac{40 \times i}{n} \times \frac{1}{\delta_0} \text{ in ft.-lbs. per HP} \quad (18)$$

Here again it is obvious that the energy of the flywheel $E \div \text{HP}$ and degree of uniformity $\frac{1}{\delta_0}$ do not stand in direct ratio to each other, but are affected by the number of revolutions n .

The method of calculation in use hitherto, namely, to take the degree of uniformity $\frac{1}{\delta_0}$ as a basis for determining the weight of the flywheel, even in engines run at varying loads, must yield *erroneous* and *misleading* results.* For this reason the energy of the flywheel necessary to develop the HP required in different industries, and the values of $\frac{1}{\delta}$, calculated from equation 18, are shown side by side at p. 177.

Moment of Rotation of the Flywheel.

Let W be the weight of the rim and arms reduced to the circle described by the centre of gravity of flywheel rim, in lbs.



Let D be diameter of circle described by the centre of gravity in feet, or diameter of gyration, then the value $W \times D^2$ is called the moment of rotation, in lbs. per foot².

This expression represents the effect, and therefore the characteristic of a flywheel for a given engine, since according to equation 5 it is proportional to the degree of uniformity $\frac{1}{\delta_0}$, if n be the same. The *moment of rotation* $W \times D^2$ in lbs. per foot² is always used for calculation in electrical work. If the engine is coupled direct to the dynamo, the moment of rotation $W \times D^2$ is either referred to the armature only, or part to the armature and the other part to the flywheel.

Approximately, as at p. 39—

$$W \times D^2 = 1.1 W_r \times (2 \times R)^2 = 0.9 \times W \times D_s^2 \quad \dots \quad (19)$$

* The following table shows these determining factors in *modern* rolling mills. The column left blank is to be filled in by the student.

Table VI.—Energy of the Flywheel, and Degree of Irregularity in Rolling Mills.

	Pig iron.	Rails.		Smooth rolled sheet iron.	Boiler plate.	Fine iron wire.	
		72 ft. long.	164 ft. long.				
Brake horse-power BHP =	800	1,500	3,000	600	1,500	1,000	BHP
Number of revolutions n =	100	100	90	50	70	100	per min.
Diameter of flywheel † D =	23' 0"	26' 8"	27' 10"	26' 3"	26' 8"	21' 4"	ft. and ins.
Weight W =	88,000	66,000	141,000	88,000	88,000	44,000	lbs.
Weight of rim W =	68,200	51,700	109,000	68,200	68,200	34,000	lbs.
Circumferential velocity † V =	112	128	131	64	89	92	ft. per sec.
Energy of the flywheel per HP, E. + HP =	16,700	8,780	9,660	7,220	5,600	4,450	ft.-lbs.
Degree of irregularity δ_0 =	2.25	2.15	3.05	1.11	1.25	1.15	

The last line in the above table gives the "calculated δ_0 ," but in reality the variations in the speed are about 20 times greater, being 1 in 25 to 1 in 8; that is to say, they amount to from 4 per cent. to 15 per cent.

† See Translator's Note, p. 171.

The last two columns of Table VI. afford a fresh proof that the energy of the flywheel does not stand in a direct ratio to the "calculated" degree of irregularity δ_0 .

According to the above table the utmost limit of circumferential speed for rolling mill engines should be—

$$\text{Circumferential velocity } V \leq 130 \text{ ft. per second} * \quad . \quad . \quad . \quad (20)$$

Determination of the Weight of the Flywheel.

As already explained under heads 1 to 3 (p. 164), it is always necessary in determining the weight of the flywheel to consider in what way the power developed is utilised; that is to say, whether the degree of uniformity δ_0 , or the energy of the flywheel, or both together, are the main points to be studied. For approximate calculations under these heads, see Table IX., p. 177.

(a) Engines for Driving Dynamos.

The method of generating the current must here be taken into account, whether (1) continuous current; (2) three-phase (alternating) current; or (3) single-phase alternating current is employed.

1. *Continuous current* is used for *electric light* and *power transmission over medium distances*, also for installations in which the power required fluctuates much (such as electric cranes and electric railways), and auxiliary batteries are provided to regulate the output. Maximum allowable tension for large plants = about 1000 volts. The motors are started under load.

2. *Alternators*, 2-phase and 3-phase alternating current, are well suited for generating light and power, especially for the transmission of large powers over long distances, 3-phase and 2-phase (asynchronous) current motors start under full load, will bear loads much above the normal, and require little attention. A less degree of irregularity is permissible with them than with continuous-current motors.

3. *Alternators* (single phase) are well suited for electric lighting, but not so well for the transmission of power, because the motors cannot start under load, and if more than their normal output is required they break step. They are also not suitable for lifts if worked intermittently, or for electric railways, iron rolling mills, elevators, etc. The same remarks respecting δ_0 apply to them as to 3-phase and 2-phase current motors.

Engines run in Parallel.

If one dynamo does not supply sufficient current for a circuit, two or more dynamos are switched on to the mains in parallel, that is, they all work upon the same mains. Continuous-current dynamos may be driven either through separate power engines (gas or steam) or by one engine driving them all, by means of ropes, belts, or other transmission, the quantity of the current (ampère) is equal to that of all the dynamos together, but the tension does not vary. The tension (volt) must be the same in all the dynamos before they are paralleled. Alternators must be driven independently of each other (otherwise it is impossible to run them in parallel), and must have the same angular velocity.

* TRANSLATOR'S NOTE.—These wheels must be built-up steel wheels; the maximum rim velocity for a built-up cast iron flywheel is 90 ft. per second.

If quivering in the electric light and irregularities in the angular velocity of the dynamo shaft are to be reduced as much as possible, then—

Table VII.—Lowest Allowable Values of δ_0 .

	Directly coupled.		Driven by pulley or belt.		Driven through counter shafting.	
	Running singly.	Running in parallel.	Running singly.	Running in parallel.	Running singly.	Running in parallel.
Continuous current } $\delta_0 =$	$1\frac{1}{2}0$	200	200	$1\frac{1}{2}0$	30	$\frac{1}{10}$
3-Phase alternating current } $\delta_0 =$	200	$2\frac{1}{2}0$	100	$1\frac{1}{2}0$	30	$1\frac{1}{2}0$
Single-phase alternating current }						

In *gas engines* a lower value for δ_0 should be taken than in the above table, because even with quantitative or qualitative governing misfires are not infrequent (see Table IV., p. 169). For *steam engines* it is allowable to make δ_0 higher, and as a rule the values assigned to it for "continuous" current may also be used for two or three phase current engines.

In engines coupled direct, the moment of rotation of the flywheel, $\frac{W R^2}{2}$, found by equation 5 (p. 166), is referred either to the armature of the dynamo alone, or part to the armature and part to the flywheel.



The greater the distance between the engine and the counter shaft, and between the counter shaft and the dynamo, the greater the degree of uniformity, since the masses in rotation which transmit the power, and the elasticity of the pulley belt equalize each other. The values for δ_0 given in Table VII. apply up to a variation of $\frac{1}{4}$ in the load, if the rheostat on the switchboard is very slowly and carefully manipulated, otherwise the light may flicker while the switches are shifted.

If the power required varies considerably, as in cranes and electric railways, *auxiliary or storage batteries* (continuous current) are used, which run in parallel with the dynamo. These batteries form a kind of elastic link between the generators and the motors, and thus help to equalize the load on the dynamo.

If the engine is run under a heavy load, the battery supplies current to the mains; if under a light load it absorbs it.

Example.—The 3-phase current alternator installed in a 500 BHP central power station is to be coupled direct to a 2-cylinder driving engine. Having regard to future possible increase of the plant, it is considered advisable to run the alternator in parallel. According to Table VII. δ_0 should be $= 2\frac{1}{2}0$, but we will take it $= 300$.

Taking provisionally $n = 100$, i from Table II. (p. 166), δ from equation 5 (p. 166), we get—

Engine.	Coefficient f . From Table II.	δ being = 15 ft. 9 ins., δ becomes
 R 4, 2 cylinders	10,440	62,640,000 253,000 lbs.
 RD 4, 2 "	1,990	11,940,000 48,300 "
Steam engine	Tandem, 2 "	2,120 12,720,000 51,200 "
	Compound, 2 "	1,875 8,250,000 33,400 "

From the above we see that, the number of revolutions being the same, a *compound steam engine* will have the lightest flywheel, while the R 4 2-cyl. engine (four-cycle single-acting two cylinder) is quite unsuitable for the proposed object.

(b) Engines for Various Purposes.

In many power generating stations the more or less rapid *changes in the load* play a great part.

If the degree of irregularity δ , only were taken as a basis of calculation, the engine might under certain conditions work very badly; in other words, the flywheel might not be able to regulate the variations in the load, without excessive fluctuations of speed. This would greatly affect the efficiency of the engine, and if it were used to generate electric light, a steady light could hardly be obtained.

The difficulty cannot be solved theoretically; approximate results arrived at in actual practice must be used as a basis of calculation. Table IX. shows an attempt in this direction, and the values there given may be corrected and amplified for various working conditions.

As a general rule changes in the load produce much greater variations in the work of a small than of a large engine. Suppose, for instance, in a small carpenter's shop the power required to drive all the machines is 16 HP, of which 8 HP are absorbed by the circular saw.

We may take, as follows :—

Table VIII.—Variations in the Load occurring in Various Industrial Processes.

Plants.	Pumps and stamp mills.	Mechanical carpenter's shop with circular saws and saw mills.	Mechanical workshops.	Grinding mills, cement works, joinery.	Paper and spinning mills.	Iron rolling mills.
	Per cent.	Per cent.	Per cent.	Per cent.	Per cent.	Per cent.
Small . . .	15	50	30	25	15	—
Medium . . .	10	30	20	15	10	—
Large . . .	5	20	10	10	5	up to 80

Example.—In a moderate-sized carpenter's shop the variations in the power required would, according to the above table, be reckoned at about 30 per cent.

Table IX.—Approximate Values for Determining the Weight of the Flywheel.

Kind of machinery.	Size of plant.	For steady running would suffice if $\frac{1}{\delta_0}$	Taking count of variations in the load (Table VIII.), we should have		For electric light if the dynamo be driven by a pulley $\frac{1}{\delta_0}$ should not be less than
			E + BHP not less than	Hence $\frac{1}{\delta_0}$	
Pumps, stamp mills . . .	—	20	—	—	—
* Brick kilns	Small 20 HP	30	2180	1440 $\frac{n}{i}$	100
	Medium 80 „		1810	1200 $\frac{n}{i}$	85
	Large		1450	960 $\frac{n}{i}$	60
Mechanical carpenters' shops, with circular saws and saw mills	Small 20 HP	35	2900	1920 $\frac{n}{i}$	150
	Medium 120 „		2540	1680 $\frac{n}{i}$	90
	Large		2180	1440 $\frac{n}{i}$	60
Mechanical workshops	Small 10 HP	40	1450	960 $\frac{n}{i}$	100
	Large		1090	720 $\frac{n}{i}$	60
Spinning mills above 300 HP	For low-graded yarn	65	2540	1680 $\frac{n}{i}$	—
	„ high- „ „	80	3150	2090 $\frac{n}{i}$	—
Paper mills	—	67	2540	1680 $\frac{n}{i}$	—

The weight should be calculated from the *highest* of the three above values of δ_0 .

Example from Table IX.—Required, a 70 BHP plant in a brick kiln. Let $n = 150$. Diameter of gyration of rim of flywheel $D = 10.5$ ft.; therefore $V = \frac{10.5 \times \pi \times 150}{60} = 82$ ft. per second. It is proposed to make a comparison between the weight of flywheel required, and power developed in an **E 4** single-cylinder gas engine and a *single-cylinder steam engine*.

Gas engine **E 4**. BHP = 70; $n = 150$.

According to Table II.—

$$i = 2500$$

According to Table IX.—

$$\frac{1}{\delta_0} \text{ should be } > \frac{1200 \times n}{i} = \frac{1200 \times 150}{25000} = 7.2.$$

If the engine is worked without a dynamo, $\frac{1}{\delta_0} = 30$. The higher value being $\frac{1}{\delta_0} = 30$, the weight of the rim of the wheel, according to equation 4, will be: Weight of rim—

$$W = 100 \times 25000 \times \frac{70}{82^2 \times 150 \times \frac{1}{30}} = 5200 \text{ lbs.}$$

If the engine drives a dynamo, $\frac{1}{\delta_0} = 85$. Therefore weight of flywheel rim—

$$W = 100 \times 25,000 \times \frac{70}{82^2 \times 150 \times \frac{1}{85}} = 14,700 \text{ lbs.}$$

Single-cylinder steam engine BHP = 70; $n = 150$.

According to Table II.—

$$i = 2280$$

According to Table IX.—

$$\frac{1}{\delta_0} \text{ should be } > \frac{1200 \times n}{i} = \frac{1200 \times 150}{2280} = 79.$$

If the engine is worked without a dynamo, $\frac{1}{\delta_0} = 30$. The higher value being $\frac{1}{\delta_0} = 78$, the weight of the rim of the flywheel, according to equation 4, will be: Weight of rim—

$$W = 100 \times 2280 \times \frac{70}{82^2 \times 150 \times \frac{1}{78}} = 1230 \text{ lbs.}$$

If the engine drives a dynamo, $\frac{1}{\delta_0} = 85$. Therefore weight of rim—

$$W = 100 \times 2280 \times \frac{70}{82^2 \times 150 \times \frac{1}{85}} = 1340 \text{ lbs.}$$

* If the material is very soft, the flywheel may be from 30 per cent. to 50 per cent. lighter.

Thus for the same HP and same speed, the flywheel of the gas engine must be considerably heavier than that of the *steam engine*; namely, four times as heavy if worked without, and eleven times as heavy if worked with a dynamo.

To make the duty of both types of engine equal we should further require the—

Maximum output of the gas engine = *maximum output of the steam engine* ;
that is, the normal power developed by the gas engine should be about 25 per cent. to 30 per cent. more than that of the steam engine.

Rules for Constructing the Flywheel.

Method of Transmitting the Power.

According to the type of machine to be driven, either the flywheel itself acts as a driving pulley, or a separate driving pulley is fitted on to the shaft.

1. For high-speed machinery such as dynamos for generating electricity, fans, exhaustors, centrifugal pumps, etc., the *fly-wheel acts as the pulley*, as shown in Fig. 13.

Of the different arrangements of fly-wheel and driving pulley combined given in Figs. 14–16, the best is Fig. 16.




FIG. 13.—10 HP Engine. Scale 1 : 80.




FIG. 14.




FIG. 15.




FIG. 16.

2. A *separate pulley* is used for driving counter shafting or machinery running at moderate speeds.

As gas engines must run at relatively high speeds, if the belt is driven off the flywheel, the dimensions of the pulley on the counter shaft (which usually makes 160 to 200 revolutions per minute) will be too large.

The most usual arrangement is that shown at Fig. 20, where the pulley is placed between




FIG. 17.—With Separate Pulley.




FIG. 18.




FIG. 19.




FIG. 20.


the flywheel and the out end bearing.

Diameter of the Flywheel and of the Driving Pulley respectively.

In gas as in steam engines the ratio adopted is generally—

$$\frac{\text{Diameter of flywheel}}{\text{Stroke}} = 4 \text{ to } 7, \text{ or a mean of } 6 \dots (21)$$

The diagram (Fig. 21) shows this ratio plotted vertically for a number of working engines.



Diagram, Fig. 21.

$$\text{Ratio : } \frac{\text{Diameter of flywheel}}{\text{Stroke of piston}}$$

Engines built by the same makers are denoted by similar symbols in Fig. 21.

The values shown on the lower curve may be taken as a basis for calculating the mean for—

Flywheels and Driving Pulleys combined,

and those on the upper curve for—

Separate Driving Pulleys,

or for engines coupled direct, as, for instance, blast furnace gas engines directly coupled to the blowers, etc.

For engines up to 50 HP the flywheel always serves as the driving pulley, and space is provided for a separate pulley, because with this type of engine several of the same size are usually machined at once, and kept in stock as a reserve.

To avoid *too heavy flywheels* their diameter is generally made as large as possible, without regard to the ratio $D : S$ (Fig. 21), but the rim speed should be—

For flywheels and driving pulleys combined : circumferential velocity $V < 90$ ft. per second (22)

For solid flywheels „ „ „ $V \leq 100$ ft. per second (23)

The diameter of separate driving pulleys should always be determined by the purpose for which the pulley is intended, but it is desirable to make it as large as possible, because the larger the pulley the less the strain upon the belt.

If $n = 160$ be taken as the usual number of revolutions per minute of the counter shaft, we may write—

$$\text{Diameter of driving pulley on engine} \geq 2.5 \text{ Stroke} \dots (24)$$

(In practice the values range from 1.5 to 2.8.)

This rule makes ample allowance for the dimensions of the pulley on the counter shaft.

Width of Flywheels and Pulleys.

1. *Pulley flywheels.* The flywheel acts as the pulley, and the dimensions of the pulley on the counter shaft are taken as unknown.

In Fig. 22, let—

- b be the width, δ thickness of belt in inches.
 BHP „ power transmitted by the flywheel.
 D_s „ diameter of flywheel in feet.
 n „ number of revolutions per minute.

Taking into account that with this arrangement the belt is mounted on a very narrow face, we will take the sectional area of the belt—

$$b \times \delta = \frac{64 \times \text{BHP}}{D_s \times n} \text{ in sq. inches.} \quad (25)$$

$$\text{Width of rim } B = 1.1b \times \frac{3}{8} \text{ inches.} \quad (25A)$$




FIG. 22.

Table X.—Approximate Thickness of Belts.

Output HP = from 2	3-15	16-30	30-50	above 50 HP.
Thickness of belt $\delta = \frac{3}{16}$ "	$\frac{7}{32}$ "	$\frac{7}{32}$ "	$\frac{1}{4}$ "	$\frac{9}{32}$ "

Example.—A 22 HP engine driven by lighting gas is, according to p. 24, of the following dimensions: $D = 11\frac{3}{4}$ "; $S = 15\frac{1}{2}$ "; $n = 210$ revolutions per minute. Diameter of flywheel $D_s = 7' 3"$. What should be the width of the belt?

From equation 25. Sectional area of belt $b \times \delta = \frac{64 \times 22}{7.25 \times 210} = 0.93$ sq. inches.

From Table X. Thickness of belt $\delta = \frac{7}{32}$ inches

$$\text{Width of belt } b = \frac{0.93}{\frac{7}{32}} = 4\frac{1}{4} \text{ inches.}$$

From equation 25A. Width of rim $B = 1.1 \times 4\frac{1}{4} + \frac{3}{8} = 5$ inches.

In practice, the rim is usually made wider (see p. 182).

2. *Separate pulley at the side of the flywheel* (Fig. 17, p. 178). The diameter of this pulley on the crank shaft is determined from equation 24.

$$\text{Provisional cross section of belt } b \times \delta = \frac{51 \times \text{HP}}{d \times n} \text{ in square inches.} \quad (26)$$

For the example given above the dimensions would be—

From equation 24. Diameter of pulley $d = 2.5 \times 15\frac{3}{4} = 3$ ft. 4 inches.

„ „ 26. Sectional area of belt $b \times \delta = \frac{51 \times 22}{3.28 \times 210} = 1.63$ sq. inch.

„ Table X. Thickness of belt $\delta = \frac{7}{32}$ inch.

$$\text{Therefore width of belt } b = \frac{1.63}{\frac{7}{32}} = 7.5 \text{ inches.}$$

Thus from equation 25A, Width of rim $B = 1.1 \times 7.5 + \frac{3}{8} = 8\frac{5}{8}$ inches.

3. *Double belts.* Single belts are used up to a width of about 12 inches and $8\frac{1}{4}$ square inches cross section; above that double belts are preferable; if possible, the diameter of the pulley should not be less than 1008.

Double belts do not transmit twice as much power as single belts of the same width, as they are not so flexible. If their width is the same, they will transmit 1.7 times as much power.

4. The size of the belt can only be accurately determined if the position and number of revolutions of the counter shaft are known. A full explanation of this will be found in "Konstruieren und Rechnen," 3rd Edition, pp. 180*b et seq.* Also see table of horsepower of belts and rim speeds of pulleys at the end of the book.

Standard Dimensions of Flywheels up to 10 ft. 10 ins. Diameter (3300 mm.).
(For larger types, see chapter on Large Gas Engines.)




FIG. 24.

FIG. 23.

Engine.		Weight of rim W in lbs.		D _s	Radius of centre of gravity of rim A in sq. ins.	Rim.		Nave.		Arms.						
HP	S	D	D ₀ = 1/80			With d ₀ = 1/50		With d ₀ = 1/30		L* ins.	O* ins.	Number	With d ₀ = 1/50		With d ₀ = 1/30	
						B	A	B	A				i	k	i	k
				sq. ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	
				eq. ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.
0.6	5	31	363	15½	24½	31	43	47	5½	41	7	1	2	28	1½	1½
1.2	6½	4	506	17½	28	33	51½	58	41½	18	18	1½	28	2½	1½	3
2	7½	5	725	21½	34	41	51½	68	58	1	1	1½	3	38	1½	18
3.5	8½	5½	970	25½	41	4½	58	68	5½	18	18	1½	3	4	2	28
7	10½	7½	1,260	27	43	4½	68	78	5½	11	11	28	4½	5	2½	5½
11	12½	8½	1,650	31½	50½	5½	71	81	58	18	18	28	58	5½	3	6½
17	13½	10½	2,250	38½	61½	58	78	9	68	18	18	31	61	6½	3½	7½
25	15½	11½	3,200	49½	80	6½	81	9½	81	12	12	31	71	78	4½	8½
33	17½	13½	4,150	59	95	7½	9	10	81	12	12	31	71	81	4½	9½
42	19½	14½	5,200	68	110	8½	98	108	98	2	2	41	81	91	5½	10½
55	21½	15½	7,050	88	142	91	108	118	118	21	21	61	91	101	6½	11½
80	23½	19½	11,100	132	210	131	107	13	161	21	21	61	111	121	7½	14½
132	27½	23½	18,800	194	310	171	121	148	211	28	28	71	131	158	8½	18½

* The measurements for e, L, and o apply to engines with three bearings, the figures printed in small type to engines with two bearings, and the flywheel overhung at the end of the shaft.

2nd Example from Table X. In a 110 HP engine driven with lighting gas, the main dimensions as given at p. 24 are as follows: $D = 24$ inches; $S = 28$ inches; $n = 150$ revolutions per minute; $D_1 = 10$ feet 10 inches. What should be the width of the belt if the power is transmitted to it from the flywheel?

According to equation 25, cross section of belt $b \times s = \frac{64 \times 110}{10.8 \times 150} = \text{about } 4\frac{3}{8} \text{ sq. inches.}$

From Table X., if $b \times s = 4\frac{3}{8} \text{ sq. inches, } s = \frac{9}{32} \text{ inch (bare).}$

Therefore width of the belt $b = \frac{4\frac{3}{8}}{\frac{9}{32}} = 15\frac{1}{2} \text{ inches.}$

If, again, we take the ratio of the driven pulley to the flywheel as 1 : 5, then diameter of the driven pulley = $1\frac{1}{3} \times 26 = 26$ inches, or about $100 \times s$, the thickness of s being = $\frac{1}{32}$ inches (bare).

Table XI. gives dimensions of flywheel for standard engines, type E 4, single cylinder, taken from Table I., p. 24.

The measurements are worked out for two different degrees of irregularity in running, namely, $\delta_0 = \frac{1}{50} = 2$ per cent. variation, and $\delta_0 = \frac{1}{80} = 1.25$ per cent. ($1\frac{1}{4}$) variation in the speed. Engines for industrial purposes can have lighter flywheels, with $\delta_0 = \frac{1}{50}$; for driving continuous-current dynamos $\delta_0 = \frac{1}{80}$ is generally sufficient (compare Table VII., p. 175). The engineer must be content with a lesser degree of uniformity in running gas engines than steam engines, otherwise the weight of the flywheel becomes excessive.

For weights of the flywheel corresponding to both degrees of irregularity the same measurements apply for the nave, while those for the rim and arms are different, corresponding to the variations in the weight.

The stress of the arms upon the rim of the flywheel varies from 1400 to 1550 lbs. per sq. inch, calculated from equation 61, p. 196.

Width of the Flywheel.

The width of the belt is determined from the power to be transmitted (see pp. 180 *et seq.*). The width of the face of the rim may (according to "Konstruieren u. Rechnen," 3rd Edition, p. 183) be taken at,—

$$B = 1.1b + \frac{3}{8} \text{ inch} \quad \dots \dots \dots (27)$$

To make gas engines run as steadily as possible, it is necessary, as we have said, to have comparatively heavy flywheels, and this requires a large rim cross section. The width of the flywheel rim cannot, however, altogether depend on the width of the belt (see equation 27), but to avoid too great a depth of rim, flywheels must under certain circumstances be made broader than the width given in equation 27. Too deep a rim has not a neat appearance, and if h is unduly large, there will be waste of material.

Let D_1 be the outside diameter of the flywheel in feet ;

R .. radius of circle described by centre of gravity in feet
(radius of gyration) ;

W .. weight of rim in lbs. from equation 4 (p. 165).

γ .. lbs. per cubic inch of material composing the flywheel ;
(B , a , and h , are measured in inches from Fig. 25.)

$f = \text{approx. } h \times a$. Cross section of rim in sq. inches.

Then—

$$\text{Rim section } f = \frac{W}{\gamma \times 2 \times R \times \pi \times 12} \text{ about } 0.051 \frac{W}{R} \text{ in sq. inches.} \quad (28)$$




FIG. 25.

$$\text{Hence depth of rim } h = \frac{f}{a} \text{ in inches ; } a = \frac{f}{h} \text{ in inches} \quad . \quad . \quad . \quad (29)$$

We may take approximately—

$$R \sim 0.45D; \quad a = 0.9B; \quad \gamma = 0.262 \text{ lbs. per cubic inch} \quad . \quad . \quad . \quad (30)$$

$$\text{in other words—} \quad \left. \begin{array}{l} h \leq \frac{1}{8}D, \text{ if } D \leq 2 \text{ ft. } 8 \text{ ins.} \\ h \leq \frac{1}{7} \text{ to } \frac{1}{10} D, \text{ if } D > 2 \text{ ft. } 1 \text{ in.} \end{array} \right\} \quad . \quad . \quad . \quad . \quad (31)$$

The circumference of the rim is made either flat or convex. Where power is transmitted from the driving to the counter pulley, Gehrckens recommends that the former be made flat (not rounded), and the driven pulley convex. It ought to suffice if, B being width of rim in inches (Fig. 22, p. 180), the convexity is—

$$\text{For the large pulley } w = 0.02B \text{ in inches} \quad . \quad . \quad . \quad (32)$$

$$\text{For the smaller pulley } = (d \div D) \times w + \frac{1}{16} \text{ in.} \quad . \quad . \quad (33)$$

(Compare “Konstruieren u. Rechnen,” 3rd Edition, p. 183*l*.)

Calculation of the Tensile Strength of the Flywheel.*

(a) Shape and Dimensions of Rim Cross Section (see Fig. 1, next page).

Let W = weight of the rim in lbs. calculated from equation 4, p. 165;

D_e = external diameter of the rim in feet (or of the pitch circle, if the flywheel is grooved for ropes);

S = centre of gravity of rim section;

f = cross section of rim in sq. inches;

γ = specific weight = about 0.262 lbs. per cubic inch for *cast iron*.

The main dimensions of the cross sections must be considered for: solid flywheels, pulley flywheels (*i.e.* for belts), and flywheels grooved for ropes.

$$\begin{array}{l} \text{The following approximate} \\ \text{values may be taken for} \\ R:— \end{array} \quad \left\{ \begin{array}{ll} \text{For solid flywheels} & R = 0.45D_e \quad . \quad . \quad (1) \\ \text{,, pulley flywheels (i.e. for belts)} & R = 0.485D_e \quad . \quad (2) \\ \text{,, flywheels grooved for ropes} & R = 0.475D_e \quad . \quad (3) \end{array} \right.$$

Therefore weight of rim $W = 2 \times \pi \times R \times 12 \times f \times \gamma$

$$W = 0.262 \times 2\pi \times R \times 12 \times f = 19.7 \times R \times f \text{ in lbs.} \quad (4)$$

$$\text{Whence approximate rim section } f = \frac{W}{19.7 \times R} \text{ in sq. inches.} \quad . \quad . \quad (5)$$

R must for the present be found by equations 1–3, in feet, since only D_e is known.

With solid flywheels the depth of the rim is taken provisionally at = 1.2 of the width.

An outline drawing of the rim corresponding to the area f and the above dimensions should be made, and the exact radius of the circle described by the centre of gravity R determined; if this radius differs from the first rough estimate, the area f must be corrected to make them agree.

$$\text{Distance of the centre of gravity } x_0 \text{ from the outer edge of the rim: } x_0 = \frac{\sum f \times x}{\sum f} \quad . \quad . \quad (6)$$

* In order to work from the usual allowable stresses (or safe working loads), when calculating the flywheel rim fastenings, and at the same time to keep practical conditions of work in view, some engineers do not calculate from the normal number of revolutions, but from speeds, say, 10 per cent. to 15 per cent. higher. As this method complicates the subject, the author has always based his figures on the normal speed n , and has simply taken the allowable stresses at less than the values usually assigned them.

Σ signifies a total

Σf signifies the sum (or total) of all the cross sections

therefore $f_1 + f_2 + f_3 + \dots$

$\Sigma f \times x$. Sum of the products of the separate cross sections, multiplied by the corresponding distances x of their centres of gravity from the edge of the rim; thus—

$$f_1 \times x_1 + f_2 \times x_2 + f_3 \times x_3 + \dots$$




FIG. 1.

(b) Centrifugal Force and Tensile Stress in the Flywheel Rim.

Referring to Fig. 2, let—

V = circumferential speed in circle described by the centre of gravity

$$= \frac{R \times \pi \times n}{30} \text{ in ft. per sec.} \quad (7)$$

S' = centre of gravity of one half of the wheel.

v = circumferential velocity of centre of gravity S' in ft. per sec.

e = distance of centre of gravity S' from the centre of the flywheel in feet.

σ_t = tensile stress on the rim in lbs. per sq. inch.




FIG. 2.

The centrifugal force tends to rend the flywheel into two opposite rim sections, therefore half the weight of the rim $\left(\frac{W}{2}\right)$ must be considered. The centrifugal force exerted in one half of the flywheel is thus—

$$C = \frac{W}{2} \times \frac{1}{g} \times \frac{v^2}{e} = \frac{W}{2g} \times \frac{2V^2}{\pi R} = 0.195 \frac{W V^2}{R} \text{ in lbs.} \quad (8)$$

$$\text{Furthermore } e = \frac{2R}{\pi}; v = \frac{e}{R} \times V = \frac{2V}{\pi} \quad (9)$$

Taking half the cross section of the rim, we get—

$$0.5C = 0.098 V^2 \times f \text{ in lbs.} \quad (10)$$

From equations 8 and 9 we can determine the

$$\text{Theoretical stress due to tension } \sigma_t = \frac{0.5C}{f} = 0.098 V^2 \text{ in lbs. per sq. inch.} \quad (11)^*$$

This value is increased by the effect of the arms, and important bending stresses are set up, which hinder the free expansion of the rim (Fig. 3), and increase the stress coming upon it.

Let us take the

$$\text{combined stress} = x \times \sigma_t \text{ in lbs. per sq. inch} \quad (12)$$




FIG. 3.

* The size and shape of the rim cross section has thus no effect on the theoretical stress due to tension.

Table I.—Approximate Values for Factor α in Equation 12.

$\frac{12 \times (R \text{ in feet})}{h \text{ in inches}}$ $\frac{R \text{ in feet}}{h \text{ in inches}}$	Pulley flywheels.		Pulleys for belts and rope-grooved wheels.				Solid flywheels.		
$\frac{12 \times R}{h} =$	65	50	40	80	20	15	10	7	5
$\alpha =$	2.9	2.7	2.4	2.1	1.9	1.7	1.5	1.4	1.3

The values of α given in the above Table apply to carefully turned flywheels divided along the arms (as shown at Fig. 7, see next page).

If the flywheel is divided between the arms (Fig. 6) the stresses should be taken at 20 per cent. higher.

Example.—Let $R = 5$ ft.; $h = 5\frac{1}{2}$ ins.; $V = 74$ ft. per sec.; according to equation 11, the theoretical stress due to tension will be $\sigma_t = 0.098 \times 74^2 = 540$ lbs. per sq. in. Again, from Table I., $\alpha = 1.58$, therefore the combined stress (if the flywheel is divided along the arms) will be $530 \times 1.58 = 835$ lbs. per sq. in. If the flywheel is divided between the arms, the combined stress will be $1.2 \times 835 = 1000$ lbs. per sq. in. We may take, therefore, the actual stress between the arms of the flywheel, according to Table I., as approximately *—

$$\text{For belt pulleys and rope grooved wheels} = 1.9 \sigma_t \quad (13)$$

$$\text{For solid flywheels} = 1.4 \sigma_t \quad (14)$$

Therefore, from equations 13 and 14, for wheels divided along the arms (Fig. 7, next page) we get

Table II.—Combined Stress.

Circumferential speed $V =$	40	60	80	90	100	150	200	270	300 feet per second
Belt pulleys =	300	680	1220	1540	1900	4250	7600	13,800	17,000 lbs. per sq. in.
Solid flywheels† =	225	500	900	1130	1400	3150	5600	10,200	12,600 „ „

Allowable stress with this method of calculation from equations 11 to 14.

$$\text{For cast iron} = 1500 \text{ lbs. per sq. inch.} \quad (15)$$

(Table II. shows that in belt pulleys the allowable stress is attained at a circumferential speed of 90 ft. per sec., that the limit of elasticity is reached at a circumferential speed of 260 ft. per sec., and the breaking load at 320 ft. per sec.)

Thus, within the usual limits of speed ($V = 30$ to 100 ft. per sec.) there is never a risk of fracture with a solid rim.

But if the rim is grooved, or the symmetry of the section destroyed (as in Figs. 43 and 44, p. 194, for example), the combined stress must be increased in the same ratio as the total rim section bears to the effective rim section.

* These values can be accurately determined for a given engine from Goebel's rule (*Zeitschrift des Vereines deutscher Ingenieure*, 1898, p. 351). The values given in Table I. apply only if the flywheel rotates at a uniform speed. If through a sudden increase in the load (and therefore a rapid fall of the governor) the speed is retarded, the engine will hunt badly, but the amount of retardation cannot be determined beforehand. If the rim fastenings (clamps, shrunk rings, bolts, etc.) are comparatively far from the circle described by the centre of gravity of the rim section, this hunting may under certain conditions set up important bending stresses, the extent of which must be determined by Goebel's rule mentioned above.

† In gas engines only solid flywheels need be considered $\frac{12 \times R}{h} = < 15$.

TRANSLATOR'S NOTE.—Nearly all larger gas engines in England have built-up flywheels.

(c) Rim Joints.

The principal methods of constructing flywheels are shown in Figs. 6 to 8.

The *best way* is to divide it along the arms as shown at Fig. 7, as by this means the fastenings and bolts are exposed to tensile stresses only, the bending stresses being taken by the arms; the tensile stress c can be calculated by equation 11, p. 186.




FIG. 5.—Solid Wheel.




FIG. 6.—Divided between the Arms.




FIG. 7.—Divided along the Arms.




FIG. 8.—In Several Segments with Wrought Iron Arms.

Many engineers are of opinion, however, that if the flywheel is built as shown in Fig. 7 undesirable strains may be set up in the metal, owing to the unequal rate of cooling in the mould after casting.

1. Joints and Bolts.*

We must here distinguish between—

Stress on the bolts due to tightening up.

Stress on the bolts when the wheel is in motion.

The stress† to be here considered is that set up when the flywheel is in motion. Care must be taken to see that the joints on the segments are bedded well down on to one another, and the bolts well tightened up.

* For a fuller account, see Haeder's *Zeitschrift*, 1904, p. 132.


† The stress due to tightening up is taken at—

$$s = \frac{0.85P}{f_s} \text{ in lbs. per sq. inch where } f_s = \text{the area of the bolts in sq. inches} \quad (16)$$

If the bolts are tightened up more than is necessary, then if S represents the stress due to tightening up in lbs. per sq. inch, the stresses on the bolts when the flywheel is in motion—

$$= \sigma_s = \frac{S + 0.95P}{f_s} \text{ in lbs. per sq. inch} \quad (17)$$

But if the bolts are not tightened up to the extent given in equation 16, there will be working at the joints (see Haeder's "Steam Engines," 8th Edition, pp. 282 *et seq.*).



Let—

f be the sectional area of the rim in sq. ins.

V be circumferential speed in circle described by centre of gravity, in ft. per second by equation 7, p. 186.

$P = 0.0971V^2 \times f$, total tensile stress on the bolts in lbs.

$1.2P$ denotes the effect due to tightening up the bolt.

f_s Total cross section at the bottom of the thread of all the bolts in sq. ins., then—

Working stresses on the bolts (when in motion) $\sigma_s = 1.2P + f_s$ in lbs. per sq. in. (18)

Corresponding cross section of the bolts at the bottom of the thread $f_s = 1.2P\sigma_s$ in sq. ins. (19)

Allowable stress = 4250 – 5700 – 7000 lbs. per sq. in. . . . (20)*

Example.—Let a flywheel have a rim cross section of $F = 57$ sq. in. (see Fig. 10). The circumferential speed is 77 ft. per second. The rim is held together by three bolts, each $1\frac{1}{4}$ in.

The stresses will be as follows—




FIG. 10.

FIG. 11.

FIG. 12.

Total stress due to tension $P = 0.0971 \times 77^2 \times 57 = 32,800$ lbs.

Total cross section at the bottom of the thread $f_s = 3 \times 1.986$ sq. in. = 5.95 sq. in.

According to equation 18, working stresses $\sigma_s = 1.2 \times 32,800 + 5.95 = 6600$ lbs. per sq. in.

2. Fastening with Cotters.

This method of fastening the rim is shown in detail in Figs. 13, 14.




FIG. 13.




FIG. 14.

The bolts are replaced by the round or square dowel N , and the cotter M , Fig. 15.



FIG. 15.

As explained in the section on bolt fastenings, p. 188, we have in both cases two separate kinds of stresses to consider, namely, that due to tightening up,† and the working stresses on the fastenings (when in motion).

The same symbols as those for bolts can be used, except that f_s denotes the cross section of the dowel in square inches.

* See Table of Bolts, etc., at end of book.

† The footnote, p. 188, applies to a certain extent to these fastenings.

Therefore—

$$\text{Working stresses on the dowel (when in motion) } \sigma_z = 1.2P + f_0 \text{ in lbs. per sq. in.} \quad (21)$$

$$\text{Corresponding cross section of dowel } f_0 = 1.2 P + \sigma_z \text{ in sq. ins.} \quad (22)$$

$$\text{Allowable stress} = 4250 - 5700 - 7000 \text{ lbs. per sq. in.} \quad (23)$$

The cross section of the dowel is shown by the shaded area in Fig. 16, for which we may take—

$$\text{For round dowels } f_0 = (\pi + 4) \times d^2 - d \times b \text{ in sq. ins.} \quad (24)$$

$$\text{" square dowels } f_0 = a \times c - a \times b \quad (25)$$



FIG. 16.




FIG. 17.

The cotters must be calculated for stresses due to bending, as shown in Fig. 17. The three places on which the stresses are assumed to fall are indicated by curved lines, which in any rough design of this kind of fastening would mark them with sufficient accuracy.

The calculation is worked out as follows :—

$$\text{Bending moment } M_b = 1.2 Pl + 4 \text{ in inch-lbs.} \quad (26)$$

where $P = f_0 \times \sigma_z$ in lbs.*

$$\text{Modulus of resistance to bending } Z_b = \frac{1}{8} bh^3 \text{ in cub. ins.} \quad (27)$$

$$\text{Actual stress due to bending } \sigma_b = \frac{M_b}{Z_b} + \sigma_z \text{ in lbs. per sq. in.} \quad (28)$$

$$\text{Allowable stress for steel, 14,000 lbs. per sq. in.} \quad (29)$$

The length l should be approximately :—

$$\text{For dowels of round section } l = 1.7d \quad (30)$$

$$\text{" " square section } l = 1.5a \quad (31)$$

To calculate the rim fastenings we must also consider the surface pressure of the cotter upon the cast-iron surface of the flywheel rim (see Fig. 18)—

$$\sigma = \frac{\sigma_z f_0}{2zb} \text{ in lbs. per sq. in.*} \quad (32)$$

Surface pressure of the cotter upon the dowel—

$$\sigma = \frac{\sigma_z f_0}{bd} \text{ or } \sigma = \frac{\sigma_z f_0}{ba} \text{ in lbs. per sq. in.*} \quad (33)$$

Allowable surface pressure of the cotter upon the flywheel rim—

$$\left. \begin{array}{l} \text{Allowable surface pressure of the cotter upon the flywheel rim—} \\ \text{5700 to 8500 lbs. per sq. in.} \\ \text{Allowable surface pressure of the cotter upon the dowel—} \\ \text{11,000 to 14,000 lbs. per sq. in.} \end{array} \right\} \quad (34)$$

* See footnote, p. 188, which to a certain extent is applicable here.






FIG. 18.

Dowels are made round, but it is better to have them of rectangular cross section, because the holes in the rim are then easier to machine (Figs. 19-21).

Dowels for heavy flywheels (Figs. 22, 23) are convenient when fitting the parts together. They



FIGS. 19-21.




FIGS. 22, 23.

are entered from the inner surface of the rim, but cannot always be recommended, because, firstly, they are expensive to manufacture, and, secondly, the core may be wasted away in casting.

Although *round dowels* are much used they are not so good as dowels of rectangular section, because if the holes are cored, they are apt to be out of truth. On the other hand, it is easy to bore

out the holes if they are not quite true. Dowels of rectangular section are, however, better, as we have said, because it is easier to machine the holes for them.



FIGS. 24, 25, 26.

To ensure that the two halves, or several segments of the rim, shall run true, it is usual to design the flywheel with a tongue piece in one segment fitting into a recess in the next. Another method is to make the dowels accurately fit the holes in the flywheel, which are bored out to a depth of $\frac{3}{8}$ in. to $1\frac{1}{8}$ in. from the face of the joint (Figs. 24-26). The other part of the hole can be carefully cored out, allowing a clearance of $\frac{1}{8}$ in. to $\frac{3}{8}$ in. round the dowel.

The faces of the joint where the segments of the rim butt against one another is often cast with chipping-strips, and afterwards finished off with chisel and file; and the hole for the bolt, after trueing up the joint, may be simply and accurately marked off. To cast the segments of heavy flywheels with the chipping strips is not

considered "good practice," because the edges may easily be damaged in transit, or when erecting the flywheel, and it is always better to plane the surfaces. To avoid unnecessary work when fitting the cotter a clearance of $\frac{1}{8}$ in. to $\frac{3}{8}$ in. should be left at the sides.




FIG. 27.





FIG. 28.

Shrunk clamps are also much used, although considerable skill is required to fit them accurately, and gauge the correct amount of shrinkage. The heads must be well recessed. It is easy to file or turn the faces of the clamps flush with the side of the rim afterwards; they must fit exactly. Boiler plate scrap is used to hold them together provisionally while on the lathe, and is knocked off afterwards.

The *dove-tailed fastening* shown at Fig. 28 should on no account be used, as it has a tendency to work out, and acts like a wedge to split the rim (see *Zeitschrift des Vereines deutscher Ingenieure*, 1898, p. 357).

Shrunk rings with a corresponding projection or shoulder on the rim can only be used if fitted to both sides of the rim, in the circle described by the centre of gravity of the cross section, or on both the inner and outer sides of the rim, and not on the inside only. To prevent them from flying at

the outside edge, as sometimes happens while hammering them in, they should be of trapezium-shaped section. The opening for them on the rim should be as short as possible (Fig. 31). When



Figs. 29, 30.




FIG. 31.

the ring has cooled, the recesses are filled in with white metal and caulked, and the ring is also held in position by a couple of grub screws.

3. Calculation of the Shrunk Rings.

It is not intended to repeat here the exhaustive dissertation on shrunk rings in Haeder's "Konstruiren und Rechnen" (3rd Edition), but only to give the results theoretically determined. Let—

P be the tension in the rim, that is the force which seeks to tear the ring asunder, in lbs.


$1.2P$ is taken as the actual load.

s the shrinkage tension, that is, the tensile stresses set up in the shrunk ring as it cools, in lbs. per sq. in.

f_1 cross section of the shrunk rings of a rim fastening in sq. ins.

P_s pressure on the joints when at rest, that is, the pressure with which the surfaces of the joints are tightened against each other, while stationary, in lbs.

σ_s working pull on the rings, that is, the actual stress coming upon the shrunk ring when in motion, in lbs. per sq. in.



Then we have the tension in the rim $P = 0.0971 V^3 \times f$ in lbs. . . . (35)

(in which V is the circumferential velocity of the circle described by the centre of gravity from equation 7, p. 186, and f is cross section of rim in sq. ins.).

Cross section required $f_1 = 1.2 P + k_s$ in sq. ins. . . . (36)

Pressure on the joints when not in motion $P_s = s \times f_1$ in lbs. . . . (37)


" " " in motion = $\sigma_s \times f_1 - P$ in lbs. . . . (38)

Tension due to shrinkage $s = 0.8 \sigma_s$ in lbs. per sq. in. . . . (39)

DIMENSIONS OF THE SHOULDER.

(a) Round Shrunk Rings.

To determine these dimensions we must take count of the *strength of the shoulder*. It is exposed to a shearing stress, in consequence of the tension set up during shrinkage, therefore



$$\underbrace{\frac{1}{8} \pi a^3 k_s}_{\text{Resistance of one-half of the shoulder}} = \underbrace{2abk_s}_{\text{Tensile stress of the shrunk ring}} \dots (40)$$

If, to make sure that the shoulder is strong enough, we calculate from $k_s : k_z = 4$,* it works out at—

$$d = 4.5\sqrt{a \times b} \text{ in ins.} \quad (41)$$


If P be determined from the normal number of revolutions (see footnote on p. 185), then the

$$\text{Stress on the shrunk ring } k_z = 5700 \text{ lbs. per sq. in.} \quad (42)$$

Table III.—Examples worked out from Equations 36 and 41 ($k_z = 5700$ lbs. per sq. in.).

(The fastening consists of two shrunk rings of square section.)

$P = 22,000$	44,000	88,000	132,000	176,000	220,000 lbs.
$a = 1\frac{1}{8}$	$1\frac{1}{2}$	$2\frac{1}{8}$	$2\frac{3}{8}$	$3\frac{1}{8}$	$3\frac{3}{8}$ inches.
$d = 4\frac{1}{2}$	$6\frac{1}{2}$	10	12	$13\frac{1}{2}$	$15\frac{1}{2}$ "



The shrunk rings and hoops forming the fastening of the flywheel rim cannot be machined with absolute accuracy. The necessary allowance for shrinkage is obtained by making the clear width of the ring less than the diameter of the shoulder by about 1 per cent. The less careful the workmanship of the fastening, the greater difference must be allowed between the dimensions of these two parts.

(b) Elliptical Shrunk Rings (Shrunk Hoops).

$$\text{For these, as for round rings, } r l k_s = 2 a b k_z \quad (43)$$

As regards the permissible stresses k_s and k_z , the remarks under head (a) apply, from whence we get—

$$r l = 8 a b \quad (44)$$

$$\text{For instance, if } l = 6r, \text{ then } r = 1.2\sqrt{ab}; l = 7\sqrt{ab}. \quad (45)$$

Table IV.—Examples worked out from Equations 36 and 45 ($k_z = 5700$ lbs. per sq. in.).

(The fastening consists of two shrunk rings of square section.)

$P = 22,000$	44,000	88,000	132,009	176,000	220,000 lbs.
$a = 1\frac{1}{8}$	$1\frac{1}{2}$	$2\frac{1}{8}$	$2\frac{3}{8}$	$3\frac{1}{8}$	$3\frac{3}{8}$ inches.
$b = 7\frac{1}{2}$	$10\frac{1}{2}$	$15\frac{3}{8}$	$18\frac{1}{2}$	$21\frac{1}{8}$	24 "




FIG. 38.

FIG. 39.

FIG. 40.

FIG. 41.

For rolling mill engines. Shrunk ring recessed in.

For steam engines, gas engines, etc. Flywheel turned. Shoulder for shrunk ring projecting.

With $V = 98.5$ ft. per second; $f = 234$ sq. inches; $P = 220,000$ lbs.

For the method of allowing for shrinkage, see the remarks at p. 192. The clear width of the ring must be 1 per cent. smaller than the length of the shoulder.

* If space allow, $k_s : k_z = 5$.

For fastening the flywheel, round shrunk rings are sometimes used (Figs. 38 and 40), but elliptical shrunk rings are more general (Figs. 39 and 41).

As the shoulder must be of a certain size to resist the shearing stress on it, a round shoulder takes up more room than one for an elliptical shrunk ring. If Figs. 38 and 40 be compared with Figs. 39 and 41, in all of which the value of P is the same, it will be seen that in the two latter the full depth of the rim is not utilised. If the cross section of the ring were larger, a greater circumferential velocity would be permissible, the size of the shoulder being also naturally increased.




FIG. 42.


If the circumferential velocity be very high, it is advisable to utilise both the outer and inner sides of the rim for the fastenings, and to have three or four shrunk rings on each joint.

The rings are either of rectangular or square section.

To put a third ring on the inside of the rim only does not seem to be good practice; a corresponding ring should be fitted also to the outside of the rim.


(c) Usual Forms of Rim Fastenings.

The most usual method of fastening the rim together is with *screwed bolts*, *dowels*, and *cotters*, or *bolts* only. With flywheels running at high speeds, *shrunk rings* are preferred. Figs. 47, 48 illustrate the usual arrangement for bolts, dowels, and cotters; Figs. 43-46 for bolts and shrunk rings.



FIGS. 43, 44.

Fig. 43 should not be adopted if the rim is deep and the circumferential velocity great, because the bolts and shrunk rings are too far from the circle described by the centre of gravity of the rim.



FIGS. 45, 46.

Calculation * of Rim Fastenings with Screwed Bolts and Dowels.

As far as possible the dowel and cotter fastenings should be in the circle described by the centre of gravity of the rim (Fig. 48A), and the bolts should go through the arms where they intersect the flywheel. As they cannot always be put in with heads, they should have nuts at either end, and lock nuts or other means of preventing any risk of their slacking back whilst running.

* See also footnote on p. 185.

Let P = tension on the fastening in lbs. from equation 35, p. 192 (compare Figs. 47, 48).

s = diameter of the rim bolts at the bottom of the thread in ins.

$a \times c$ = cross section of the dowel in sq. ins.

$b \times h$ = " " " cotter " "

Then—


$$\left. \begin{aligned} \text{Sectional area of the bolts } f' &= 2 \times \frac{\pi}{4} s^2 \\ \text{dowel } f'' &= (c - b)a \end{aligned} \right\} \text{ in sq. ins. (46)}$$

Hence stress due to tension—

$$\sigma_s = \frac{1.2P}{f' + f''} \text{ in lbs. per sq. in. (47)}$$

Allowable stress or safe working load for wrought iron—

$$k_s = 4250\text{--}5700\text{--}7000 \text{ lbs. per sq. in. (48)}$$



FIGS. 47, 48.—Rim Fastenings with Screwed Bolts and Dowels.

FIG. 48A.

The *strength of the cotter* is taken at—

$$P' = \frac{1.2P}{f' + f''} \times f'' \text{ in lbs. (49)}$$

and must further be tested for bending, thus—

$$\text{Bending moment (from Bach's formula)} = M = \frac{P'}{2} \times \left(\frac{a}{4} + \frac{z}{2} \right) \text{ (50)}$$

$$\text{Modulus of resistance to bending } Z = \frac{b \times h^2}{6}; \text{ therefore } \sigma_s = \frac{M}{Z} \text{ lbs. per sq. in. . . (51)}$$

Allowable stress or safe working load with best mild steel—

$$k_s = 8500\text{--}11,000 \text{ lbs. per sq. in. (52)}$$

Surface pressure of the cotter on the cast iron surface of the wheel—

$$\sigma = \frac{P'}{f_0} \text{ lbs. per sq. in. ; } f_0 = 2z \times b \text{ sq. ins. (53)}$$

$$\text{Safe working pressure } k = 7000\text{--}10,000 \text{ lbs. per sq. in. (54)}$$

Shearing the dowel at either end (2 surfaces)—

$$f_0 = 2am \text{ in sq. ins. (55)}$$

$$\text{Therefore } \sigma = \frac{P'}{f_0}; \text{ allowable stress } k_s = 3500 \text{ to } 4250 \text{ lbs. per sq. in. . . (56)}$$

(d) Flywheel Arms.

These are usually solid, of oval section (Fig. 52), or circular and hollow (Fig. 53), while the Γ form (Fig. 49) is also often used. For high-speed flywheels the arms are of sharp-ended oval




FIG. 49.




FIG. 50.

section (Fig. 50), to diminish the friction of the air. Very large flywheels, for rolling mill engines, etc., have wrought-iron arms of rectangular cross section.

1. Tensile Stress on the Arms, due to the Centrifugal Force of the Rim.

The centrifugal force of a segment of the rim is calculated by the formula—

$$C' = \frac{W}{z} \times \frac{1}{g} \times \frac{V^2}{R} \quad \dots \quad (57)$$

where z denotes the number of arms.

$V = \frac{R\pi n}{30}$ circumferential velocity of the centre of gravity of the rim section in feet per second. (The radius of the centre of gravity of the rim segment is taken as approximately equal to the radius of the centre of gravity of the cross section of the whole rim.)

Under the most unfavourable conditions, when the arm is in its lowest position, half the weight of the rim must be added to C' .

$$\text{Therefore } P = C' + \frac{W}{2} \text{ in lbs.} \quad \dots \quad (58)$$

Here the tensile strength of the rim is neglected.

Cross section of the arms *near the flywheel rim.*

$$\text{For solid oval arms (Fig. 52)} f_1 = ab \frac{\pi}{4} \text{ sq. ins.} \quad \dots \quad (59)$$

$$\text{For hollow arms, of circular section (Fig. 53)} f_1 = \frac{\pi}{4} (d^2 - c^2) \text{ sq. ins.} \quad \dots \quad (60)$$

$$\text{Therefore stress due to tension } \sigma_t = \frac{P}{f_1} \text{ lbs. per sq. in. ; } f_1 = \frac{P}{k_t} \text{ sq. ins.*} \quad \dots \quad (61)$$

2. Stress due to Tension and Bending at the Nave.

Let B.H.P. = effective horse-power of the engine.

$0.5D_r$ = radius of the flywheel rim in ft.

P = tangential effort at the rim at the normal output in lbs.

n = revolutions per minute.

$$\text{Then we have } P = \frac{5250 \text{ BHP}}{n \times 0.5D_r} \text{ in lbs.} \quad \dots \quad (62)$$

When calculating the maximum moment about the flywheel, P must be taken at *double* (belt pull) the value given by equation 62, therefore—

$$\text{Bending moment of one arm at the nave } M = \frac{2P}{z} \times l \text{ inch-lbs.} \quad \dots \quad (63)$$

z being = number of arms.

l being = distance from the circumference of the wheel to the arm at the nave (see Fig. 51) in inches.

Modulus of resistance—

$$\text{For arms of solid oval section (Fig. 52), } Z = 0.1ab^2 \text{ cub. in.} \quad \dots \quad (64)$$

$$\text{For hollow arms of circular section (Fig. 53), } Z = 0.1 \left(\frac{d^4 - c^4}{d} \right) \text{ cub. ins.} \quad \dots \quad (65)$$

$$\text{Therefore stress due to bending } \sigma_b = \frac{M}{Z} \text{ in lbs. per sq. in.} \quad \dots \quad (66)$$

$$\text{To this must be added the stress due to tension } \sigma_t = \frac{C'}{f'} \text{ lbs. per sq. in.} \quad \dots \quad (67)$$

C' is calculated by equation 57, f' = cross section of the arm near the nave in sq. ins., therefore the combined stress will be—

$$\sigma = \frac{M}{Z} + \frac{C'}{f'} \text{ lbs. per sq. in.} \quad \dots \quad (68)$$

$$\text{The allowable stress or safe working load is } \left. \begin{array}{l} \text{taken at} \\ \text{For cast iron at the rim} \end{array} \right\} k = 2100 \text{ to } 2550 \text{ lbs. per sq. in.} \quad \dots \quad (69)$$

* For allowable stress, see equations 70, 71 on the next page.





FIG. 51.

FIG. 53.

The allowable stress or safe working load is } $k = 1700$ to 2100 lbs. per sq. in. . (70)
 taken at For cast iron at the nave
 The allowable stress or safe working load is } $k = 3550$ to 5700 lbs. per sq. in. . (71)
 taken at For wrought iron

(e) Nave Fastenings.

The nave is usually split into several parts to avoid casting strains, or rather strains set up due to the unequal cooling of the flywheel in the mould; it is afterwards secured by shrunk rings or screwed bolts; care must be taken to divide the nave, so as to distribute the weight evenly. Figs. 54 to 58 illustrate the most usual types of nave fastenings.



FIGS. 54-58.—Flywheel Naves.

If the flywheel is split into two or more parts, it requires considerable skill to make a good job with shrunk rings, and even then the tension due to two or more segments of the wheel will never be quite the same. Except therefore for large gas engines, shrunk rings are no longer used, but the nave is usually split in two parts, and bolts screwed at both ends; the thread on these bolts is usually a fine thread,* and the nuts are prevented from slacking back by lock nuts, or split pins, etc. The bolts should be made of the best mild steel, and can be stressed up to 11,000 lbs. per sq. inch.

To avoid a great mass of metal in one place, the type of nave shown at Fig. 59 should be used for flywheels 11 ft. 6 ins. and upwards in diameter.

According to equation 8, p. 186, the centrifugal force of one-half of the wheel is—

$$C = \frac{W}{2g} \times \frac{2V^2}{\pi R} = 0.01 \frac{WV^2}{R} \text{ lbs. (72)}$$

Combined sectional area of bolts and shrunk rings—

$$f_2 = 4 \times \frac{\pi}{4} s^2 + 4ab \text{ in sq. ins. (73)}$$

where s = diameter of the bolts at the bottom of the thread.

Tensile stress on these fastenings $\sigma_2 = \frac{C}{f_2}$ in lbs. per sq. in. (74)

Allowable stress or safe working load for wrought iron—

$$k_2 = 3500-6500 \text{ lbs. per sq. in. (75)}$$

Bursting of Flywheels.

The cause of these constantly recurring accidents with flywheels running at usual circumferential speeds of 3000 to 6000 ft. per minute is not to be attributed to the weakness of the rim. It is nearly always due to—

(f) Defects in the Lugs cast on the Rim for coupling the Wheel together.

With *solid* flywheels, the segments of which are fastened together by dowels and cotters, shrunk rings, or clamps, such accidents hardly ever occur, nor is there any danger of the rim giving way from weakness of cross section. But with pulley flywheels and flywheels grooved for ropes, the risk of fracture of the lugs coupling the segments, or of the rim itself at the junctions, is great, especially if the rim is grooved for ropes or of weak cross section. Particular attention should be paid to the design of the lugs, and also to the arms where they join the rim; flywheels having a *high* rim velocity must always be divided along the arms.

* [TRANSLATOR'S NOTE.—It is usual to fit bolts with six threads per inch up to $3\frac{1}{4}$ " diameter.]

Let W' = weight of a segment of a rim of length a .

W'' = " " lug together with the bolts.

The centrifugal forces $C' = \frac{W'}{g} \times \frac{V^2}{R}$ and $C'' = \frac{W''}{g} \times \frac{V^2}{R}$ in lbs. . . . (76)

exert a bending stress on the cross section cc , Figs. 60-62. To this must be added the bending moment Px through the bolts, etc. The load P is equal to half the centrifugal force of one-half of the wheel, and must therefore be calculated from equation 10, p. 186, the nave fastenings being practically neglected. The total bending moment thus works out at—

$$M = C'l' + C''l'' + 1.2 Px \quad (77)$$

To this must be added the stress due to tension of cross section $f = Bh$, acting on cross section cc , according to equation 11, p. 186.

In Haeder's book on the "Steam Engine," 8th Edition, p. 282, the stresses on a pulley flywheel causing it to burst have been calculated.

Example.—Required the dimensions of a pulley wheel for a single cylinder four-cycle gas engine (driving a continuous-current dynamo). Diameter of cylinder 400 mm. = 15½ ins.; stroke 550 mm. (say 21½ ins.); revolutions $n = 190$ per minute. Diameter of flywheel = 2750 mm. = 9 feet.

1. Determination of the Output.

By equation 3, p. 18, effective piston area $A = \frac{\pi}{4} \times 15\frac{1}{2}''^2 = 195$ sq. inches.

„ 7, p. 20, mean piston speed $v = \frac{2 \times 21\frac{1}{2} \times 190}{12} = 681$ feet per minute.

From Table II., p. 20, mean pressure on piston $p_1 = 20\frac{3}{4}$ lbs. per sq. inch.

By equation 8, p. 20, maximum output or IHP—

$$= \frac{195 \times 681 \times 20\frac{3}{4}}{33,000} = 83\frac{1}{4} \text{ IHP.}$$

From Table I., p. 18, mechanical efficiency $\eta = 0.84$

By equation 2, p. 18, actual output of engines = $0.84 \times 83\frac{1}{4} = 70$ BHP.

2. Determination of the Weight of the Rim.

From Table II., p. 166, coefficient $i = 21,000$ based on the IHP.

By equation 5, p. 39, radius of centre of gravity of rim section

$$R = 9' 0'' \times 0.45 = 4.05 \text{ feet.}$$

By equation 2, p. 39, circumferential velocity $V = \frac{4.05 \times \pi \times 190}{30} = 80\frac{1}{2}$ ft. per second.

From Table VII., p. 175, degree of irregularity in running $\delta_0 = \frac{1}{8}$.

By equation 4, p. 165, weight of rim $W = 100 \times 21000 \times \frac{83\frac{1}{4}}{190 \times 80\frac{1}{2}} \times \frac{1}{8} = 11,350$ lbs. (approx.).



3. Width of Flywheel Rim (approximate estimate).

By equation 28, p. 184, cross section of rim $f = 0.051 \times \frac{11350}{4.05} = 143$ sq. inches.


„ 31, p. 185, depth of rim $h = \frac{1}{8} \times 9' 0'' = 12$ inches.

„ 29, p. 185, dimension $a = 1\frac{1}{2}''^2 = 11\frac{3}{4}$ inches (approx.).

„ 30, p. 185, width of rim $B = \frac{11\frac{3}{4}}{0.9} = 13$ inches (approx.).



FIGS. 60-62.—Flywheel divided between the Arms.



4. Calculation of the Flywheel.

An outline of the rim corresponding to the dimensions of the cross section given under head 3 is drawn (Fig. 65), the positions of the centres of gravity of the different areas are then determined, and x_0 calculated from them by equation 6, p. 185—





FIG. 65.

$$\begin{aligned} f_1 &= 13'' \times 1\frac{1}{2}'' = 18 \text{ sq. inches} \\ f_2 &= 11\frac{5}{8}'' \times 10\frac{5}{8}'' = 124 \text{ ,,} \\ f &= 142 \end{aligned}$$

$$\begin{aligned} f_1 \times x_1 &= 18 \times 1\frac{1}{8}'' = 12.4 \text{ inches}^3 \\ f_2 \times x_2 &= 124 \times 6\frac{1}{8}'' = 828 \text{ ,,} \end{aligned}$$

$$\Sigma fx = \frac{840.4}{2}$$

By equation 6, p. 185, $x_0 = \frac{840.4}{142} = 5.92$ inches; $R = 4' 6'' - 6'' = 4$ feet.

„ 4, p. 185, weight of rim $W = 0.262 \times 2 \times \pi \times 12 \times 4 \times 142 = 11,200$ lbs. (approx.).

From equation 11, p. 186, theoretical tensile stress in the flywheel rim $\sigma = 0.098 \times 80\frac{1}{2}^2 = 630$ lbs. per sq. in.

$$\begin{aligned} \text{Since } \frac{12R}{h} &= \frac{12 \times 4}{12} = 4 \\ x &= 1.3 \end{aligned}$$

then from Table I., p. 187, therefore from equation 12, p. 186—

$$\text{combined stress} = 1.3 \times 630 = 820 \text{ lbs. per sq. inch.}$$

5. Flywheel Arms.

(a) *Tensile Stress on the Rim* (see p. 196).

The centrifugal force in a rim segment by equation 57 is—

$$C' = \frac{11,200 \times 80.5^2}{6 \times 32 \times 4} = 95,500 \text{ lbs.}$$

Combined tensile stress by equation 58, p. 196—

$$P = 95,500 + 5650 = 101,150 \text{ lbs.}$$


Cross section of the arms at the rim. By equation 59—

$$f_1 = \frac{\pi}{4} \times 6\frac{1}{8}'' (155 \text{ mm.}) \times 11\frac{1}{8}'' (300 \text{ mm.}) = 57 \text{ sq. ins.}$$

Therefore the tensile stress on the rim (equation 61)—

$$\sigma_t = \frac{101,150}{57} = 1780 \text{ lbs. per square inch.}$$

FIGS. 66, 67.



(b) *Stresses on the Nave due to Tension and Bending* (see p. 196).

By equation 62, p. 196, circumferential pressure or tangential tension $P = \frac{5250 \times 70}{190 \times 4.5} = 430$ lbs. per sq. in.

„ 63, p. 196, bending moment $M_b = \frac{2 \times 430}{6} \times 41.5 = 5950$ inch-lbs.

„ 64, p. 196, modulus of resistance $Z = 0.1 \times 6\frac{1}{8}'' \times 11\frac{1}{8}''^2 = 85$ inches³ (approx.).

„ 66, p. 196, stress due to bending $\sigma_b = \frac{5950}{85} = 70$ lbs. per square inch.

Add to this the stress due to tension.

„ 59, p. 196, cross section of arm where it joins the rim $f_1 = \frac{\pi}{4} \times 6\frac{1}{8}'' \times 12\frac{1}{8}'' = 66$ square inches.

„ 67, p. 196, stress due to tension $\sigma_t = \frac{95,500}{66} = 1450$ lbs. per square inch.

„ 68, p. 196, combined stress due to bending and tension $\sigma = 70 + 1450 = 1520$ lbs. per square inch.

Thus it is the stress due to tension produced by the centrifugal force and weight of the flywheel which is the chief factor in determining the load upon the arms.

6. Width of the Belt.

By equation 25, p. 180, cross section of belt $b\delta = \frac{64 \times 67}{9 \times 180} = 9.65$ square inches.

By Table X., p. 180, thickness of belt $\delta = \frac{9}{32}$ inches

therefore the width of the belt $b = \frac{2.65}{\frac{9}{32}} = 9\frac{1}{2}$ inches.

Rules for fitting together the Different Parts of the Flywheel.

1. Boring out the Nave.

This must be done carefully because the least inaccuracy of workmanship produces "wobbling."*

The American practice of machining the flywheel is as follows:—

The hole in the nave is bored out to exactly fit the shaft, then a clearance is slotted out as shown to the left hand in Fig. 68; the two keys are then fitted and driven home, and the process pulls the wheel over so that the true part of the original bore at a bears on the shaft.




FIG. 68.
Boring out the Nave.

2. Securing the Flywheel to the Shaft.

For small flywheels up to 10 ft. diameter, a single feather or sunk key is generally used, for larger wheels two so-called tangential keys are fitted; to receive the latter two recesses are cut in the wheel, and two keys are bedded in each recess (Fig. 70).

According to Bach:—if d be given in inches, then—

For flat (or sunk) keys $b = 0.9\sqrt{d}$ inches (78)

$h = 0.5\sqrt{d}$ „ (79)

For tangential keys $b = 0.25d$ „ (80)

$h = 0.06d$ „ (81)

Angle a generally 120° .




FIG. 69.
Sunk Key.




FIG. 70.
Tangential Keys.

Heavy flywheels, especially if intended to drive dynamos for electric lighting, are always secured by two keys fitted 90° or 120° apart, and the keyways are in the same plane as the arms. This method is supposed to secure the flywheel more firmly, and to prevent "creeping" along the shaft.

Figs. 69 and 70 show the arrangement of single and double keys.

As a rule the flywheel shaft is of round section, but for very large flywheels like those for rolling mill engines the flywheel is sometimes staked on to a square shaft.

3. Nave secured by Shrunk Rings.

Flywheels up to about 10 ft. in diameter are usually cast in one piece (Fig. 5, p. 188); above this size they are always made in two or more parts, because of the difficulties of transport by rail. If the metal is badly distributed, and if the rim or the nave is very heavy, flaws may be developed and serious strains set up in the casting, due to contraction and to unequal cooling in the mould. In order to guard against these dangers it is usual to split the nave into three or more parts, which gives a certain amount of freedom, and relieves the arms from these strains. To part the nave, wrought iron plates coated with graphite are laid in the mould, in positions shown in Fig. 71; these plates are knocked out after the wheel is cast, the spaces thus formed filled in with zinc or white metal, and a ring R is shrunk on either side over the nave.




FIG. 71.

* For method of correcting "wobbling" of the flywheel, see Haeder's "Machinenmeister."

4. Keys for securing the Flywheel.


The tables used in different engineering workshops show differences of 50 per cent. in the width of these keys. Their dimensions can hardly be determined theoretically.

The recess t to take the key is usually cut deeper into the shaft than the depth given in Table IV., but a deeper recess increases the twisting strains on the shaft.

In round keys (which are rarely used) b is generally smaller.

Table IV.—Keys.

(Dimensions in millimetres.)




Flat key.

Sunk key.

Tangential key.

Round key.

Shaft.	Width.	Sunk key.		Tangential key.	Light keys for eccentrics, valve gear and governors, etc.		
d	b	h	t	h	b	h	t
30—39	12	7	2	—	—	—	—
40—49	14	8	3	—	—	—	—
50—59	16	9	3	—	—	—	—
60—69	18	10	3	—	—	—	—
70—79	20	12	4	—	—	—	—
80—89	23	13	4	—	—	—	—
90—99	26	14	4	—	—	—	—
100—119	30	16	5	—	—	—	—
120—139	34	18	6	—	18	10	3
140—159	38	20	6	—	20	12	4
160—179	42	22	7	—	22	13	4
180—199	46	24	8	—	24	13	4
200—219	50	26	8	15	26	14	4
220—239	55	29	9	16	28	14	5
240—259	60	32	10	17	30	15	5
260—279	65	35	11	18	32	16	6
280—299	70	38	12	20	34	17	6
300—324	75	40	13	22	36	18	6
325—349	80	44	14	23	40	20	7
350—374	85	48	15	25	42	21	7
375—399	90	50	17	26	44	22	7
400—449	95	54	19	28	46	23	8
450—500	100	58	21	30	50	25	8




Hollow key.

Hollow keys are only used as temporary fasteners, i.e. when setting the valve gear or for small powers.

Feather keys should be bedded into a recess $1.3t$ deep, and the depth of the key should be about $0.3t$ deeper.

Table IVa.—Keys.

(Dimensions in inches.)




Flat key.

Sunk key.

Tangential key.

Round key.

Shaft d.	Width.	Sunk key.		Tangential key.	Light keys for excentrics, valve gear and governors, etc.		
		b	t	h	b	h	t
ins.	ins.	ins.	ins.	ins.	ins.	ins.	ins.
1 $\frac{3}{8}$ to 1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	—	—	—	—
1 $\frac{1}{8}$ " 2 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	—	—	—	—
2 " 2 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	—	—	—	—
2 $\frac{1}{8}$ " 3	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	—	—	—	—
2 $\frac{1}{8}$ " 3 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	—	—	—	—
3 " 3 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	—	—	—	—
3 $\frac{1}{8}$ " 4	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	—	—	—	—
4 " 4 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	—	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$
4 $\frac{1}{8}$ " 5 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	—	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$
5 " 6	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	—	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$
6 " 7	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	—	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$
7 " 7 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	—	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$
8 " 8	2	1	1	1 $\frac{1}{8}$	1	1	1
8 $\frac{1}{8}$ " 9	2 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$
9 " 10	2 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$
10 " 11	2 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$
11 " 11 $\frac{1}{8}$	2 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$
11 $\frac{1}{8}$ " 12	3	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$
12 " 13	3 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$
13 " 14	3 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$
14 " 15	3 $\frac{1}{8}$	2	1 $\frac{1}{8}$	1	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$
15 " 17	3 $\frac{1}{8}$	2 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$
17 " 19	4	2 $\frac{1}{8}$	1 $\frac{1}{8}$	1 $\frac{1}{8}$	2	1	1 $\frac{1}{8}$



Hollow key.

Hollow keys are only used as temporary fasteners, i.e. when setting the valve gear or for small powers.

Feather keys should be bedded in a recess 1·3*t* deep, and the depth of the key should be about 0·3*t* deeper.

Main Dimensions of a Gas Engine.

Pages 18 to 24 continued.

The following Tables, I. to VI., will be found useful for *determining* approximately the principal dimensions of gas engines easily and *quickly*. To calculate them in small and medium-sized engines, power gas (suction or pressure) has been taken as the motive agent, with a mean pressure on the piston $p_m = 60$ to 70 lbs. per sq. inch (p. 22).* In the larger engines the motive power is assumed to be *blast furnace gas*, and the mean pressure $p_m = 57$ to 68 lbs. per sq. inch. There is no fixed rule for p_m ; in practice it will be found to vary by about 25 per cent. Therefore the values given in the following tables must only be taken as *rough* and *approximate estimates*.

For the number of revolutions Table III., p. 147, has been used, and this table also shows for what sizes and types of engine it is necessary to cool the piston with water.

The maximum output is about 1.2 to 1.4 times more than the normal output (HP) given in Tables I. to VI.

Table I.— **Single-cylinder Engine.**

(Dimensions in millimetres.)

Normal output . BHP =	10	15	20	25	30	40	50	60	80	100	125	150	175	200
Cylinder diameter . D =	245	285	325	360	390	435	485	525	590	655	730	800	860	925 mm.
Stroke S =	340	400	440	480	520	560	600	630	680	720	800	880	950	1020 "
Number of revolutions n =	280	215	200	187	180	173	165	160	153	145	138	120	113	105 per min.

(Dimensions in inches.)

Normal output . BHP =	10	15	20	25	30	40	50	60	80	100	125	150	175	200
Cylinder diameter . D =	9½	11½	12¾	14½	15½	17	19	20¾	23½	25¾	28¾	31½	34	36½ ins.
Stroke S =	13½	15½	17½	19	20½	22	23½	24¾	26¾	28½	31½	34½	37½	40 "
Number of revolutions n =	280	215	200	187	180	173	165	160	153	145	138	120	113	105 per min.

Table II.— **Two-cylinder Engines.**
Z 4 = " "


(Dimensions in millimetres.)

Normal output . BHP =	120	150	175	200	225	250	275	300	350	400	450	500
Cylinder diameter . D =	525	580	640	650	690	725	760	800	860	920	975	1030 mm.
Stroke S =	630	670	720	720	760	800	840	880	950	1000	1070	1130 "
Number of revolutions n =	162	146	133	150	140	134	128	120	113	106	100	94 per min.

(Dimensions in inches.)

Normal output . BHP =	120	150	175	200	225	250	275	300	350	400	450	500
Cylinder diameter . D =	20¾	23	25½	25½	27½	28½	30	31½	34	36½	38½	40½ ins.
Stroke S =	24¾	26½	28½	28½	30	31½	33	34½	37½	39½	42	44½ "
Number of revolutions n =	162	146	133	150	140	134	128	120	113	106	100	94 per min.

* TRANSLATOR'S NOTE.—The most modern English gas engines work with mean pressures of 90 to 95 lbs. per sq. inch for lighting gas, and 80 to 85 lbs. per sq. inch for producer gas; therefore the power of these engines can be increased in proportion.



Table III.—  D 4 Single-cylinder Engine.

(Dimensions in millimetres.)

Normal output . . BHP =	200	225	250	275	300	350	400	450	500	550	600
Cylinder diameter . . D =	660	690	730	770	800	865	925	980	1030	1085	1130 mm.
Stroke S =	790	830	880	920	960	1040	1100	1170	1240	1300	1350 "
Number of revolutions n =	130	124	116	110	106	98	92	87	83	78	75 per min.

(Dimensions in inches.)

Normal output . . BHP =	200	225	250	275	300	350	400	450	500	550	600
Cylinder diameter . . D =	26	27	28½	30½	31½	34	36½	38½	40½	42½	44½ ins.
Stroke S =	31	32½	34½	36½	37½	41	43½	46	49	51	53 "
Number of revolutions n =	130	124	116	110	106	98	92	87	83	78	74 per min.


Table IV.—  R D 4, Two-cylinder,
 Z D 4, Two-cylinder Engine.

(Dimensions in millimetres.)

Normal output . . BHP =	600	650	700	750	800	900	1000	1100	1200	1300
Cylinder diameter . . D =	790	820	850	880	910	965	1020	1070	1120	1160 mm.
Stroke S =	950	980	1020	1060	1100	1160	1230	1280	1350	1400 "
Number of revolutions n =	108	104	100	97	93	88	83	80	76	73 per min.

(Dimensions in inches.)

Normal output . . BHP =	600	650	700	750	800	900	1000	1100	1200	1300
Cylinder diameter . . D =	31	32½	33½	34½	36	38	40	42	44	46 ins.
Stroke S =	37½	38½	40	41½	43½	45½	48½	50	53	55 "
Number of revolutions n =	108	104	100	97	93	88	83	80	76	73 per min.

Table V.—  R Z D 4 Four-cylinder Engine.

(Dimensions in millimetres.)

Normal output BHP =	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400
Cylinder diameter . D =	770	800	840	865	900	920	950	975	1000	1025	1050	1075	1100 mm.
Stroke S =	920	960	1000	1040	1080	1100	1140	1170	1200	1230	1260	1300	1320 "
Number of revolutions n =	110	106	100	98	95	92	90	87	85	83	81	80	77 per min.

Table V.—*continued.*

(Dimensions in inches.)

Normal output BHP =	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400
Cylinder diameter . D =	30½	31½	33	34	35½	36½	37½	38½	39½	40½	41½	42½	43½ ins.
Stroke S =	36	37½	39½	41	42½	43½	45	46	47	48	50	51	52 "
Number of revolutions <i>n</i> =	110	106	100	98	95	92	90	87	85	83	81	80	77 per min.

Table VI.—Double-acting, Two-cycle, Single-cylinder Engine (D 2 1 Cyl.).

(Dimensions in millimetres.)

Normal output . BHP =	200	250	300	350	400	450	500	550	600	700	800	900	1000
Cylinder diameter . D =	480	540	590	635	680	725	760	795	835	900	965	1020	1075 mm.
Stroke S =	820	920	1000	1080	1160	1230	1300	1350	1420	1530	1640	1730	1820 "
Number of revolutions <i>n</i> =	108	96	88	82	77	72	68	66	62	57	54	52	48 per min.

(Dimensions in inches.)

Normal output BHP =	200	250	300	350	400	450	500	550	600	700	800	900	1000
Cylinder diameter . D =	19	21½	23½	25	26½	28½	30	31½	33	35½	38	40	42 ins.
Stroke S =	32½	36	39	42½	45½	48½	51	53	56	60	64½	68	71½ "
Number of revolutions <i>n</i> =	108	96	88	82	77	72	68	66	62	57	54	52	48 per min.

These engines, *i.e.* D 2 with two cylinders, if of the same dimensions and arranged side by side or twin, will give twice as much power as stated above.

If the above tables be used to determine the approximate dimensions of a large gas engine, the values must be expressed in round numbers.

Example I.—Required to determine the approximate dimensions of a 250 BHP R 4 2 cyl. engine (four-cycle tandem), and of a D 2 single-cyl. engine (double acting, two-cycle).

For an R 4 2-cyl. engine, Table II. gives : D = 28½"; S = 31½"; *n* = 134.

For a D 2 single-cyl. engine, Table VI. gives : D = 21½"; S = 36"; *n* = 96.

Example II.—A blast furnace gas engine, driving a blowing engine, is required to develop 2400 BHP (normal output). What size of engine would be best for the purpose? The most suitable would, according to Table V., be an R Z D 4 2-cyl. engine, with—

$$D = 43\frac{1}{2}"; S = 52"; n = 77.$$

Example III.—According to Table IV., a 1000 HP R D 4 2-cyl. engine (tandem, double-acting, four-cycle) should have D = 40"; S = 48½"; *n* = 83. If the engine runs at the lower speed of 72 revolutions per minute, what will be the HP developed?

Since the output is in proportion to the number of revolutions, if *n* = 72, then—

$$\text{Output} = \frac{1000 \times 72}{83} = \text{say } 870 \text{ HP.}$$

To make the subject clearer, and to afford means of drawing a better comparison, we subjoin tables giving the power developed by steam engines, and their corresponding dimensions.

As already mentioned at p. 30, it is necessary to run gas engines at a higher speed than steam engines of the same power. The number of revolutions given in the following Tables, VII. to IX., correspond to those in present practice :— *

Table VII.—Single-cylinder Condensing Engine. Boiler Pressure 100 lbs. per sq. inch.

p_m taken at = 33 lbs. per sq. inch; $\eta = 0.88$; $S = 1.7D$; hence normal output BHP = $\frac{D^3 \times n}{5100}$

$$D = 17.2 \times \sqrt[3]{\frac{\text{BHP}}{n}}$$

(Increased output 1.25 times the normal, maximum output 1.5 times the normal output.)

(Dimensions in millimetres.)

Normal output BHP =	10	15	20	25	30	40	50	60	80	100	125	150	175	200	250	300	400	500	600	700
Cylinder diameter D =	170	195	220	240	250	280	310	340	390	430	470	510	540	570	630	680	750	830	970	930 mm.
Stroke S =	290	330	380	410	440	490	540	580	660	730	800	870	920	970	1070	1150	1300	1400	1500	1600 "
No. of revolutions n =	175	168	163	158	153	143	135	127	114	104	98	95	92	89	84	80	77	75	74	72 per min.

(Dimensions in inches.)

Normal output BHP =	10	15	20	25	30	40	50	60	80	100	125	150	175	200	250	300	400	500	600	700
Cylinder diameter D =	6 $\frac{7}{8}$	7 $\frac{7}{8}$	8 $\frac{7}{8}$	9 $\frac{1}{2}$	10	11	12 $\frac{1}{2}$	13 $\frac{1}{2}$	15 $\frac{1}{2}$	17	18 $\frac{1}{2}$	20	21 $\frac{1}{2}$	22 $\frac{1}{2}$	25	26 $\frac{3}{4}$	29 $\frac{1}{2}$	32 $\frac{3}{4}$	34 $\frac{1}{2}$	36 $\frac{1}{2}$ ins.
Stroke S =	11 $\frac{1}{2}$	13	15	16 $\frac{1}{2}$	17 $\frac{1}{2}$	19 $\frac{1}{2}$	21 $\frac{1}{2}$	23	26	28 $\frac{3}{4}$	31 $\frac{1}{2}$	34 $\frac{1}{2}$	36 $\frac{1}{2}$	38 $\frac{1}{2}$	42	45 $\frac{1}{2}$	51 $\frac{1}{2}$	55 $\frac{1}{2}$	59	63 "
No. of revolutions n =	175	168	163	158	153	143	135	127	114	104	98	95	92	89	84	80	77	75	74	72 per min.

Table VIII.—Tandem Condensing Engine. Boiler Pressure 130 lbs. per sq. inch.

p_m taken at = 33 lbs. per sq. inch; $\eta = 0.88$; $S = 1.15D$; hence normal output HP = $\frac{D^3 \times n}{7550}$

$$D = 19.6 \sqrt[3]{\frac{\text{HP}}{n}}$$

(Increased output 1.2 times the normal, maximum output 1.4 times the normal output.)

(Dimensions in millimetres.)

Normal output BHP =	40	50	75	100	150	200	250	300	400	500	600	700	800	900	1000	1200	1400	1500	1750	2000
Diam. of HP cyl. d =	190	210	245	270	325	370	410	440	490	540	585	620	650	680	720	760	800	830	875	930 mm.
Diam. LP cyl. D =	315	340	400	450	530	605	670	720	810	890	960	1020	1080	1125	1180	1250	1325	1360	1440	1510 "
Stroke S =	360	400	460	510	610	700	770	830	930	1020	1105	1170	1240	1300	1360	1440	1520	1560	1660	1740 "
No. of revs. n =	158	154	145	137	122	111	102	98	92	87	84	82	80	78	76	75	74	73	72	71 per min.

* The number of revolutions in Tables VII. to IX. correspond to those in the Author's book on "Valve Gear," Edition 1903, p. 368.

Table VIII.—*continued.*

(Dimensions in inches.)

Normal output } BHP . . }	40	50	75	100	150	200	250	300	400	500	600	700	800	900	1000	1200	1400	1500	1750	2000
Diam. of HP cyl. $d =$	$7\frac{1}{2}$	$8\frac{1}{2}$	$9\frac{1}{2}$	$10\frac{1}{2}$	$12\frac{1}{2}$	$14\frac{1}{2}$	$16\frac{1}{2}$	$17\frac{1}{2}$	$19\frac{1}{2}$	$21\frac{1}{2}$	23	$24\frac{1}{2}$	$25\frac{1}{2}$	$26\frac{1}{2}$	$28\frac{1}{2}$	30	$31\frac{1}{2}$	$32\frac{1}{2}$	$34\frac{1}{2}$	$36\frac{1}{2}$ ins.
" LP cyl. $D =$	$12\frac{1}{2}$	$13\frac{1}{2}$	$15\frac{1}{2}$	$17\frac{1}{2}$	20	24	$26\frac{1}{2}$	$28\frac{1}{2}$	32	35	38	40	$42\frac{1}{2}$	$44\frac{1}{2}$	$46\frac{1}{2}$	$49\frac{1}{2}$	$52\frac{1}{2}$	$53\frac{1}{2}$	57	$59\frac{1}{2}$ "
Stroke . . . $S =$	$14\frac{1}{2}$	$15\frac{1}{2}$	18	20	24	$27\frac{1}{2}$	$30\frac{1}{2}$	$32\frac{1}{2}$	$36\frac{1}{2}$	40	$43\frac{1}{2}$	46	$48\frac{1}{2}$	$51\frac{1}{2}$	$53\frac{1}{2}$	$56\frac{1}{2}$	60	$61\frac{1}{2}$	$65\frac{1}{2}$	$68\frac{1}{2}$ "
Number of revs. $n =$	158	154	145	137	122	111	102	98	92	87	84	82	80	78	76	75	74	73	72	71 per min.

Table IX.—Compound Condensing Engine. Boiler Pressure 130 lbs. per sq. inch.

p_m taken at = 33 lbs. per sq. inch; $\eta = 0.88$; $S = 1.15D$; hence normal output HP = $\frac{D^3 \times n}{7550}$

$$D = 19.6 \sqrt[3]{\frac{\text{BHP}}{n}}$$

(Increased output 1.2 times the normal, maximum output 1.4 times the normal output.)

(Dimensions in millimetres.)

Normal output . BHP =	40	50	75	100	150	200	250	300	400	500	600	700	800	900	1000	1200	1400
Diameter of HP cyl. . $d =$	200	215	255	285	340	390	430	460	520	570	615	660	690	720	750	810	850 mm.
" LP " . $D =$	325	360	420	470	560	630	700	755	850	940	1010	1080	1130	1180	1230	1320	1400 "
Stroke $S =$	375	410	490	540	645	730	810	870	980	1060	1160	1240	1300	1360	1420	1520	1610 "
Number of revolutions $n =$	143	136	126	117	105	97	89	86	80	75	72	69	68	67	66	64	63 per min.

(Dimensions in inches.)

Normal output . BHP =	40	50	75	100	150	200	250	300	400	500	600	700	800	900	1000	1200	1400
Diameter of HP cyl. . $d =$	8	$8\frac{1}{2}$	10	$11\frac{1}{2}$	$13\frac{1}{2}$	$15\frac{1}{2}$	17	$18\frac{1}{2}$	$20\frac{1}{2}$	$22\frac{1}{2}$	$24\frac{1}{2}$	26	$27\frac{1}{2}$	$28\frac{1}{2}$	$29\frac{1}{2}$	32	$33\frac{1}{2}$ ins.
" LP " . $D =$	$12\frac{1}{2}$	$14\frac{1}{2}$	$16\frac{1}{2}$	$18\frac{1}{2}$	22	$24\frac{1}{2}$	$27\frac{1}{2}$	$29\frac{1}{2}$	$33\frac{1}{2}$	37	$39\frac{1}{2}$	$42\frac{1}{2}$	$44\frac{1}{2}$	$46\frac{1}{2}$	$48\frac{1}{2}$	52	55 "
Stroke $S =$	$14\frac{1}{2}$	$16\frac{1}{2}$	$19\frac{1}{2}$	$21\frac{1}{2}$	$25\frac{1}{2}$	$28\frac{1}{2}$	32	$34\frac{1}{2}$	$38\frac{1}{2}$	$42\frac{1}{2}$	$45\frac{1}{2}$	49	$51\frac{1}{2}$	$53\frac{1}{2}$	56	60	$63\frac{1}{2}$ "
Number of revolutions $n =$	143	136	126	117	105	97	89	86	80	75	72	69	68	67	66	64	63 per min.

Example I.—Required to determine the approximate dimensions of a 250 BHP single-cylinder condensing steam engine, and of a compound condensing steam engine.

For the single-cylinder engine Table VII. gives $D = 25''$, $S = 42''$, $n = 84$. For the compound engine Table IX. gives $d = 17''$, $D = 27\frac{1}{2}''$, $S = 32''$, $n = 89$.

Example II.—A steam engine driving a rolling mill develops at normal load 1500 BHP; what size of engine should be chosen?

According to Table VIII., the best size will be a tandem engine having $d = 32\frac{1}{2}''$, $D = 53\frac{1}{2}''$, $S =$ (in round numbers) $62''$, $n = 73$.

Example III.—According to Table IX., in a 1200 HP engine $d = 32''$, $D = 52''$, $S = 60''$, $n = 64$. What HP will be developed if this engine runs at 52 revolutions per minute?


As the output is in proportion to the speed, if $n = 52$, we shall have—

$$\text{Output} = \frac{1200 \times 52}{64} = 975 \text{ BHP.}$$

The values given for the stroke in Tables VII. to IX. must be expressed in round numbers in the same way as those of gas engines, and made to agree with the standard dimensions in Haeder's book on "Steam Engines."

Speed in Gas and Steam Engines.

The diagram, Fig. 1, shows the number of revolutions at which gas and steam engines are at present usually run. In the larger gas engines blast furnace gas is taken as the motive power, as suction and power gas plants are not made for higher powers.



Normal Output in Brake HP.

FIG. 1.—Number of Revolutions per minute for a given HP developed.

The lines in the above diagram denote—

— — — — —	E 4 single cyl.	Single-acting, four-cycle engine, one cylinder.
.....	E 4 two cyl.	„ „ „ two „
—	D 4 single cyl.	Double-acting „ „ one „
—	D 4 two cyl.	„ „ „ two „
— — — — —	D 4 four cyl.	„ „ „ four „
.....	D 2 single cyl.	„ two-cycle engine, one „
—	D 2 two cyl.	„ „ „ two „
— — — — —	Single cylinder, compound and triple expansion steam engines.*	
— — — — —	Tandem steam engine.*	

Example.—What would be the number of revolutions in a D 4 two-cylinder (double-acting, four-cycle) blast furnace gas engine, having a normal output of 950 BHP?

The diagram, Fig. 1, at this power, gives $n = 84$ revolutions per minute.

* The speed is often much higher in these engines, especially if vertical.

Section VII.* Costs of Working Gas and Steam Engines.

In estimating the relative cost of working different kinds of engines, a wide margin may be allowed in comparing the economies realised. The steam engineer manipulates his figures in favour of steam plants, and the gas engine builder does the same for gas engines.

Working Costs.

To separate the cost of the fuel from the cost of maintenance, we will make the

$$\text{Working costs} = \text{subsidiary costs} + \text{cost of fuel.}$$

(a) Cost of the Plant.

In determining these costs we must assume a proportionally higher output for the gas engine, because in order to have the *same reserve of power* in both cases the

Maximum output of the steam engine should be = maximum output of the gas engine.

We must therefore put the cost of the gas engine and producer higher than is sometimes done, because specifications are often based on the maximum output, or on $0.85 \times$ maximum output, whereas in steam engines it is always understood that 0.7 of the maximum output is taken as the basis of calculation (in Germany).

Table I.—Cost of Installation, including Buildings, etc. (therefore of Plant complete) per HP at Normal Load.

Normal load = 0.7 of maximum load.

		Maximum output =		14	42	70	100	140	210	420	700	1400 BHP					
		Normal output =		10	30	50	70	100	150	300	500	1000	„				
Cost of complete plant per HP at normal load	Gas engine =	£	£ s.	£	£ s.	£	£ s.	£	£ s.	£ s.	£	£ s.					
	Steam engine =	36	23 10	18 10	15 15	14	12 5	10 15	10	9 5	36	24 0	21 0	18 0	14 0	12 0	11

Example.—A plant developing 100 HP at normal power costs, if worked with power gas, $100 \times 14 = £1400$; if worked with steam, $100 \times 16 = £1600$. Under specially favourable circumstances the costs of construction and erection may be taken at 25 % less.

(b) Depreciation.

As explained at p. 59 *et seq.*, the *forces acting on the cross head, etc.*, and the *inertia of the moving parts* are greater per HP in gas than in steam engines. To keep the dimensions of the crank shaft, for instance, within moderate limits, it is usual to allow for *greater stresses* in the former engines. The following Table II. gives the comparative values of the stresses on the crank shafts of various engines.

* This section is added to form a guide for the student in estimating the first cost and running expenses, etc., of a gas engine installation, but the figures do not clearly show the enormous saving to be effected by replacing steam plants by gas engines, as they relate to gas engines worked with producers stoked with anthracite or lignite briquettes (both most expensive fuels), whereas the steam engines are supplied with steam generated by boilers under which cheap coal is burnt. As it is now possible to generate gas in a producer from any kind of fuel or even refuse (some classes of refuse which are converted into gas in producers cannot be burnt under boilers at all), in order to make a fair comparison between the costs of the two systems, it is necessary to use the same fuel in both cases. Again, the cost of attendance is taken as the same in both cases, whereas the attendance in a power gas plant has been reduced to a minimum.

Table II.—Stresses on Crank Shafts.





FIG. 1.—With two bearings.

FIG. 2.—With three bearings.

FIG. 3.—Two-throw crank shaft.

Section.		1	2	3	4	5	6	Mean.
Crank shaft, Fig. 1, <i>gas engine</i> developing	5 HP	12,200	11,400	12,000	7,800	—	10,000	10,700
" " 2, " "	35 "	11,700	10,000	10,000	7,000	2,800	8,900	8,500
" " 2, " "	110 "	14,000	10,000	10,000	8,800	4,350	11,300	9,800
" " 2, " "	100 "	11,500	7,800	7,800	6,000	5,700		7,600
By Ensslin's method, Fig. 3, <i>gas engine</i> de- veloping	100 "	9,000	5,500	7,500	10,000	5,700	Not determined	7,600
Crank shaft, Fig. 3, <i>steam engine</i> developing	650 "	5,500	3,500	4,500	3,800	3,800		4,000
By Ensslin's method, Fig. 3, <i>steam engine</i> developing	650 "	5,500	4,000	3,900	5,600	3,100		4,500

To compare the stresses in gas and in steam engines, it is necessary to take those which have been calculated by the same method. Thus, from the above table, if we use the method described at p. 83 *et seq.*—

$$\text{Allowing for the inertia of the moving parts} \quad \left\{ \begin{array}{l} \text{mean stresses on a 100 HP gas engine} = 7600 \text{ lbs. per sq. in.} \\ \text{mean stresses on a 650 HP steam engine} = 4000 \text{ " " " "} \end{array} \right. = 1.9$$

By Ensslin's method . . $\frac{\text{mean stresses on a 100 HP gas engine} = 7600 \text{ lbs. per sq. in.}}{\text{mean stresses on a 650 HP steam engine} = 4500 \text{ ,, ,,}} = 1.7$

Both methods show that the average stresses on the crank shaft of a gas engine are about 17 times greater than the stresses on a steam engine shaft.

Neglecting the various changes in the stresses and taking the average as given above, we get—

Stresses in a gas engine = 7600 lbs. per sq. in. Stresses in a steam engine = 4000 lbs. per sq. in.
(Table II.).

Taking again the life of a steam engine crank shaft = 30 years, and the breaking load = 70,000 lbs. per sq. in. (say 31 tons per sq. in.), the diagram plotted at the side shows that the life of a gas engine crank shaft under the same conditions = 18 years.

Breaking Load (Tons per Sq. In.)	Life (Years) - Steam Engine (Solid Line)	Life (Years) - Gas Engine (Dashed Line)
20	60	50
30	30	18
40	30	20

The same rule applies to the stresses in the other parts of the engine. For instance, the effects of the high temperatures on the cylinder and valves, to which the frequent cracking of badly designed breech ends, and distortion of the exhaust valve bear witness, are considerably greater in gas than in steam engines.

The allowance for *depreciation*, therefore, should after ten years be three-quarters the original value of a gas engine, and half the original value of a steam engine. In other words, for depreciation and interest on capital—

9 % of the value, when new, of a steam engine, and
11 % " " " of a gas engine, should be written off.

(c) Subsidiary Costs.

These are made up as follows: Interest on capital, depreciation of engine and buildings, maintenance and repairs, lubrication and cleaning, attendance, lighting, insurance, cleaning the boilers, and general overhauling.

To determine these subsidiary costs accurately, they should be separately calculated for each case. Only the results of approximate values and rough averages are given in Table III. below. Rather more, as has been explained, is written off for gas than for steam engines, but the consumption of lubricating oil, attendance, maintenance, and so forth, are taken as the same for both.*

Table III.—Subsidiary Costs per HP hour, for Gas and Steam Engines, exclusive of Cost of Fuel.

Normal output . . .	10	30	50	70	100	150	300	500	1000 BHP
Cost for gas engines .	0.53	0.375	0.28	0.235	0.222	0.188	0.177	0.17	0.15 penny
„ steam engines	0.53	0.38	0.30	0.25	0.22	0.19	0.17	0.15	0.14 „

These figures are calculated on a basis of 3000 working hours in the year. For night and day shifts they vary slightly, because the interest on capital is spread over almost twice as much time.

(d) Price of Coal and Steam.

Anthracite in pieces of from $\frac{3}{4}$ to $1\frac{1}{4}$ inch is used for suction gas producers, also lignite briquettes, $2\frac{1}{2}'' \times 2\frac{1}{2}'' \times 1\frac{1}{2}''$; and bituminous coal, lignite, peat, wood chippings and shavings, or any kind of fuel, or even refuse.

It is possible to determine approximately the prices, in various districts, of German and English anthracite, and of lignite briquettes,† for driving gas engines. Allowing for the unavoidable waste in screening the coal before use, and in transport, we may take the

$$\text{Price delivered at the engine house} = 1.1 \times \text{price of the anthracite at the pit's mouth, plus} \\ 1.1 \times \text{cost of transit by rail.‡}$$

If the coal is required for small industries, in quantities of less than 10 tons, 15% to 25% must be added to the prices. For steam engines the different kinds of coal used must be considered. Even in the same district, and from the same pit, the characteristics of the coal (its heating value, clinker ash, etc.) will be found to vary greatly. To accustom the student to calculate examples, a few average values for various coals are given in Table IV. (and in greater detail in Haeder's "Dampfkessel," 4th Edition, p. 407).

Since in generating steam many different kinds of fuel are used (poor coal, cheap coal, wood refuse, etc.), it is hardly possible to take the consumption of coal per HP hour as the unit of comparison. Better and more reliable results will be obtained if the calculations for steam engine consumption are based on the

Cost of the quantity of coal required to generate 10 lbs. of steam.

This can always be easily determined. Table V. gives approximate values of the cost of fuel on this basis for various districts.

According to the type of boiler plant, whether more or less efficient, it is possible to generate from 8 to 12 lbs. of steam, say a mean, easily attained, of 10 lbs. from coal containing 16,200 thermal units per lb.

* TRANSLATOR'S NOTE.—The cost of attendance for a gas engine plant in England is from 30% to 75% less than for a steam engine plant.

† Very little used in England.

‡ The further the coal has to travel, and the more often it is transhipped, the greater will be the waste in screening.

Table IV.—Residual Products, Heating Value, Evaporative Power (mean) and Price of Coal and Steam in Various Colliery Districts.

1. Anthracite.

	Residual products in %. Mean %.	Heating values. B.Th.U. per lbs.	1 lb. coal yields, of steam, lbs.	Price in neighbourhood of colliery of	
				1 lb. coal. Pence.	10 lbs. steam.* Pence.
Westphalian	3	14,300	—	0·01	—
Belgian	2·5	14,300	—	0·01	—
English	1·6	14,700	—	—	—

2. Hard or Bituminous Coal.

Ruhr	10	13,150	8·5	0·048	0·059
Saar	12	11,850	7·8	0·058	0·07
Upper Silesia	5	12,600	8·0	0·087	0·059
Northern Silesia †	9	11,150	7·3	0·048	0·08
Saxony †	7·5	11,150	6·8	0·048	0·089
Aix-la-Chapelle	19	11,250	7·2	0·048	0·07

3. Lignite or Brown Coal.

Bohemia	10	9,000	5·6	0·087	0·07
Province of Saxony †	10	5,950	2·7	0·022	0·059
Southern Bavaria	17	7,850	5·1	0·087	0·096
Cologne and Aix-la-Chapelle	10	9,000	5·6	0·048	0·07

To determine the average values, the freight charges by rail or water, and the cost of transport of the coal to its destination, must be taken into account.

Tables V. and X. give approximate values of the cost of fuel, which should be checked and additions made.

To determine the prices of anthracite and steam in various *widely separated districts*, the author has procured information through inquiries in Haeder's *Zeitschrift*, No. 1, 1904, and other sources, and also from Reports issued by the Imperial Ministry of the Interior (the latter, however, only gives prices for house anthracite). Several of the places mentioned below show considerable differences in price.

Table V.—Comparative Values of the Cost of Fuel.

Normal output	Cost, including all expenses, of— 1 lb. anthracite 10 lbs. steam *	Duisburg.		Königsberg.		Kattowitz in Silesia.		Bitterfeld, Saxony.		
		Gas.	Steam.	Gas.	Steam.	Gas.	Steam.	Gas.	Steam.	
		0·112		0·2		0·21		0·19		Pence
		0·095		0·19		0·088		0·082		"
50 BHP.	Consumption per BHP: 1 lb. anthracite 20 lbs. steam	0·12	0·176	0·21	0·28	0·22	0·16	0·2	0·15	Pence ‡
										"
300 BHP	0·9 lb. anthracite 14·5 lbs. steam	0·1	0·126	0·18	0·2	0·2	0·116	0·17	0·108	Pence ‡
										"

* By cost of steam must be understood only the cost of the coal required to generate it. The other subsidiary costs will be found under Working Costs, head (c).

† In these districts lignite and hard coal are used.

‡ If lignite briquettes are used, the price will be 0·01d. less, if there are lignite mines in the neighbourhood as, for instance, at Bitterfeld.

The cost of fuel in Table V. has been worked out from Tables VIII. and IX. These tables show that the question of the economy to be effected in fuel by using gas engines in place of steam engines can only be determined separately for each case.

For instance, Table V. shows that

For engines developing 50 BHP at Königsberg, it is 25 % cheaper to drive them with gas than with steam.
 „ „ „ 300 BHP „ „ 9.3 % cheaper to drive them with gas than with steam,

when the producers are stoked with anthracite (a most expensive fuel) and the steam boilers stoked with cheaper fuel.

If the same fuel is used in both cases, the saving in favour of gas engines will be still greater.

(e) Consumption of Fuel.

Gas engine builders generally give the consumption of fuel only at maximum load, although they do not draw attention to the fact. In practice this maximum load is seldom attained; it is of more importance to determine the consumption at lesser loads, because, as already explained at pp. 209, 210, it is necessary at the outset to select an engine giving higher powers than those usually required of it.

GAS ENGINES.

The best consumption of fuel (*i.e.* the most economical) is realised when the engine is running at maximum load.

Consumption of fuel in gas engines (mean values).

Output = 1 0.9 0.8 0.7 0.6 0.5 0.4 of full load.
 Ratio of consumption
 = 1 1.05 1.10 1.20 1.30 1.50 1.7

Consumption when running light = 0.45 of consumption at full load.

Example.—A suction gas plant in which the consumption at maximum load is $1\frac{1}{2}$ lb. of lignite per HP hour, is to run under 0.4 of the maximum load. Therefore we may calculate consumption = $1.5 \times 1.7 = 2.55$ lbs. lignite per HP hour.

In oil engines in which the oil is injected into the combustion chamber (as in the Diesel, Trinkler, etc.), the relative consumption does not increase with diminishing load to the same extent as in gas engines.

Consumption of fuel in oil injection engines.

Output = 1 0.9 0.8 0.7 0.6 0.5 0.4
 Ratio of consumption = 1 1.01 1.04 1.09 1.14 1.22 1.34
 Consumption running light } = 0.3 of the consumption at full load.

Example.—A Diesel engine consumes at maximum load 0.44 lb. of crude oil per HP hour; at one-half the maximum load, therefore, the consumption will be—

$$0.44 \times 1.22 = 0.54 \text{ lb. per HP hour.}$$

STEAM ENGINES.

In steam engines the normal output or load is taken to mean the output at which the cost of working, including interest on capital, sinking fund, and repairs to engine and boiler, are reduced to a minimum.

The most economical consumption of fuel is obtained when the engine is running at about 0.85 of the maximum load. Mean experimental values show that the consumption of fuel in steam engines is (normal load being = 1)—

Output =
 1.4 1.2 1 0.85 0.6 0.4

Ratio of consumption =
 1.10 1.05 1 0.96 1.02 1.07

Consumption when running light
 = 0.12 of consumption at full load.

Example.—A steam plant at normal output consumes 2.64 lbs. coal per HP hour. At 0.4 of the normal load the consumption will be

$$= 2.64 \times 1.07 = 2.8 \text{ lbs. per HP hour.}$$

To make an *accurate comparison** between a steam and a gas engine, we must allow for the consumption of fuel in the same way as for the cost of the plant (see p. 210), namely—

Normal load = 0.7 of the maximum load.

* **TRANSLATOR'S NOTE.**—To make an accurate comparison the same fuel should be burnt under the boilers as that used in the producer.

If, for instance, 100 HP are required to drive a factory, the choice lies between a steam engine and a gas engine with a maximum of 140 HP; thus, in both types of engine we shall have the same reserve of power. Under normal conditions 70 % of the maximum power will be utilised, and the calculation of the working costs must be based on this percentage of output.

Table VII.—Comparative Values of the Cost of Consumption of Fuel in Proportion to the Percentage of Maximum Power developed.

Output	Full load (maximum).	0.9	0.8	0.7	0.6	0.5	0.4	0.3	0.2	0.1 of max.
Gas engines { Hit-and-miss governing . . .	1	1.05	1.10	1.17	1.26	1.40	1.6	1.9	2.5	4.5
Quantity or quality governing . . .	1	1.06	1.15	1.25	1.40	1.6	1.85	2.4	3.4	6.4
Steam engines	1.1	1.05	1.02	1	0.96	1.02	1.07	1.15	1.3	1.6

In Table VIII. the figures given for the consumption of anthracite in gas engine plants at maximum load are based on actual practice, and have been re-calculated for lesser loads with the help of Table VII.

In Table IX. the consumption of steam experimentally determined is given for the normal output, or about 0.7 of the maximum.

The figures printed in *black type* in Table VIII., giving the consumption at normal load = 0.7 of the maximum load for gas engines, may be compared with the similar figures in Table IX. for steam engines.

In a gas engine the smaller the load, the less favourable (*i.e.* the less economical) is the consumption, as a comparison of the figures in Table VII. will show. The higher the load in these engines, the more economical the consumption.

Table VIII.—Consumption of Anthracite in a Gas Engine Plant in lbs. per BHP hour.

(Hit-and-miss governing.)

Maximum output	HP _{max} =	14	40	70	100	140	210	420	700	1400 BHP
Normal output	HP =	10	30	50	70	100	150	300	500	1000 "
Consumption of anthracite in lbs. per BHP hour	at maximum HP =	1.2	0.95	0.9	0.88	0.86	0.82	0.77	0.75	0.7 lbs.
	" 0.7 " " =	1.4	1.11	1.05	1.03	1.00	0.96	0.9	0.88	0.84 "
	" 0.5 " " =	1.68	1.33	1.26	1.23	1.20	1.20	1.08	1.05	0.98 "

If lignite briquettes are used, the values in the above table must be multiplied by 1.65.

Table IX.—Consumption of Steam in a Modern Steam Engine Plant, per BHP hour, taking the Normal Output = 0.7 of the Maximum Output.

Maximum output	=	14	40	70	100	140	210	420	700	1400 BHP
Normal output	=	10	30	50	70	100	150	300	500	1000 "
Consumption of steam: lbs. per BHP hour	Saturated steam .	= 38.1	27.6	22.5	21.2	19.4	17.5	16.3	15.5	14.8 lbs.
	Superheated steam .	= 28.7	25	19.9	18.5	17.2	15.5	14.6	14.1	13.5 "
	Highly " "	= 24.3	22	17.6	16.3	15	13.7	12.8	12.6	11.9 "

Example from Tables VIII. and IX.—A 100 HP engine is required for a factory at Cologne. We take the maximum output = 100 ; 0·7 = 140 HP.

100 HP Suction Gas Plant.

From Table VIII. Consumption of anthracite *
= 1·0 lb. per HP hour.

„ „ X. Price of anthracite per lb.
= 0·13*d.* per lb.*

Therefore cost of fuel = $0·13 \times 1·0 = 0·130*d.*$

From Table III. Subsidiary costs = 0·222*d.*

At 0·7 of maximum output—

Total working costs per HP hour = 0·352*d.*

At 0·5 (half) maximum load—

$$1·2 \times 0·13 + 0·22 = 0·376*d.*$$

At maximum load—

$$0·86 \times 0·13 + 0·22 = 0·332*d.*$$

100 HP Steam Engine Plant with Superheated Steam.

From Table IX. Consumption of steam
= 17·2 lbs. per HP hour.

„ „ X. Cost of 10 lbs. = 0·1*d.*

Therefore cost of fuel = $\frac{17·2 \times 0·1}{10} = 0·17*d.*$

From Table III. Subsidiary costs

= 0·22*d.* per BHP hour.

Total working costs per BHP hour = 0·39*d.*

$$1·02 \frac{17·2 \times 0·1}{10} + 0·22*d.* = 0·40*d.*$$

$$1·1 \frac{17·2 \times 0·1}{10} + 0·22*d.* = 0·41*d.*$$

According to these figures the working costs at Cologne of a gas engine and producer using the most expensive fuel (anthracite), and a steam engine working with cheap coal, show a considerable saving in favour of the gas engine.

The following Table X. shows the results calculated for different towns in Germany. Places in which coal is exceptionally cheap, as in Table V., are omitted. The calculations are worked out for the normal load, viz. 0·7 of the maximum.

Table X.—Working Costs and Costs of Fuel in Pence per Brake HP hour.

(8000 working hours in the year. The steam is assumed to be moderately superheated. The figures to the right in each column show the total cost of working.)

		Subsidiary costs.	Essen.	Cologne.	Hanover.	Magdeburg.	Dresden.	Frankfort.	Breslau.	Berlin.									
Cost including freight charges—		—	0·11	0·13	0·15	0·17	0·2	0·155	0·225	0·18	Pence								
Westphalian anthracite per lb.		—	0·85	0·1	0·11	0·12	0·16	0·11	0·11	0·11	„								
Coal to evaporate 10 lbs. of steam		—	0·85	0·1	0·11	0·12	0·16	0·11	0·11	0·11	„								
Normal output 10 HP	{ Gas	0·53	0·15	0·68	0·17	0·71	0·21	0·74	0·24	0·76	0·28	0·81	0·21	0·74	0·32	0·85	0·26	0·79	Pence
	{ Steam	0·53	0·15	0·79	0·3	0·79	0·32	0·85	0·35	0·89	0·46	1·0	0·31	0·84	0·32	0·85	0·32	0·85	„
Normal output 50 HP	{ Gas	0·28	0·11	0·41	0·13	0·41	0·15	0·46	0·18	0·46	0·21	0·5	0·16	0·45	0·24	0·52	0·19	0·52	„
	{ Steam	0·3	0·165	0·5	0·2	0·5	0·23	0·54	0·25	0·54	0·33	0·61	0·21	0·51	0·23	0·52	0·23	0·52	„
Normal output 300 HP	{ Gas	0·18	0·106	0·3	0·12	0·3	0·14	0·32	0·15	0·33	0·19	0·36	0·14	0·32	0·2	0·38	0·16	0·34	„
	{ Steam	0·17	0·13	0·32	0·15	0·32	0·17	0·33	0·18	0·33	0·24	0·39	0·15	0·32	0·165	0·33	0·16	0·33	„

If the gas generator is stoked with lignite briquettes, see remarks at Table IX., p. 214.

Example from Table X.—For a 300 HP plant at Dresden the working costs would be: with suction gas, 0·36*d.*; with steam, 0·39*d.* per HP hour.

The above figures are only available for the *normal output* of an engine = 0·7 of the maximum load. The cost of driving it at maximum load can also be worked out from Tables VII. to IX. It will be seen that the cost of fuel is in that case 20 % less for gas engines $\frac{1·25 - 1}{1·25} \times 100 = 20\%$, and 10 % higher for steam engines.

On the other hand, at half load, the cost of the fuel in a gas engine is 27 % higher, and in a steam engine 5 % higher; for instance—

At Cologne	{ Output = 420 HP maximum.	300 HP normal.	210 HP half load.	
Normal	{ Gas = 0·108	0·12	0·15	} Pence per HP hour.
Output 300 HP	{ Steam = 0·13	0·12	0·125	

* Lignite works out at 0·19*d.*

Besides the special *local conditions*, therefore, the *load* at which an engine will usually be run must, in comparing gas and steam, be also carefully kept in view.

The gas engines show the greatest superiority over steam engines in cases where the load is intermittent, or where the engine is only run for a few hours a day.

If fuel in the form of gas, such as blast furnace gas or coke oven gas, is available, it is better to drive an engine direct with gas, instead of burning the gas under boilers, since gas engines are now quite reliable and run continuously day and night for long periods.

Heating Value of Exhaust Steam in Steam Engines up to 30 HP.

If the exhaust in non-condensing engines can be completely utilised for industrial purposes, the cost of fuel may be halved; if it is used in winter only, for heating, the cost may be reduced by 25 %. The exhaust gases in gas engines contain only from $\frac{1}{3}$ to $\frac{1}{4}$ the heat units carried off in the exhaust of steam engines. According to the size of the plant, the

Exhaust in non-condensing steam engines contains about 24,000 to 30,000 B.Th.U. per HP hour.

„ gas engines „ „ 4,750 to 3,000 „ „ „

To utilise the exhaust gases in a gas engine does not produce so great an economy as in a steam engine. It is also well known that as steam is a more perfect conductor of heat, it is better suited to heating purposes than the class of permanent gases to which the exhaust in a gas engine belongs.

Nevertheless the heat in the exhaust of gas engines is always made use of wherever possible.

In making a comparison between gas and steam, it is also necessary to study the *degree of irregularity in running, weight of the flywheel, and inertia of the moving parts.*

For further details on these subjects, see pp. 159 *et seq.* and 53 *et seq.*

Many of the phenomena in a gas engine are still imperfectly understood. For instance, neither the pressure of explosion nor the mean pressure on the piston can at present be determined beforehand with any degree of accuracy in a new type of engine, and a correct theory of the processes taking place in the cylinder has not been formulated.

EXERCISES.

A GOOD knowledge of steam-engine construction and practice in calculating steam plants are assumed on the part of the learner.

The following exercises are intended to afford the beginner an incentive to diligent study. The numbers on the right-hand side show the page in the book giving the explanation of the question.

	PAGE
1. What do we understand by a <i>four-cycle</i> engine ?	1
2. " " " <i>two-cycle</i> engine ?	1
3. How many revolutions does a four-cycle engine make during one working cycle ?	1
4. How many revolutions does a two-cycle engine make during one working cycle ?	1
5. How many strokes does a steam engine make during one cycle of work ?	1
6. Explain the meaning of the term <i>single-acting</i> ?	1
7. " " " <i>double-acting</i> ?	1
8. Can a <i>double-acting</i> four-cycle engine be called a <i>two-cycle</i> engine ?	2
9. Which are the best-known types of two-cycle engines ?	2
10. How can it be known, by looking at the outside of an engine, whether it is a two- or a four-cycle engine ?	2
11. Name the most usual types of single-acting four-cycle engines	3
" " " double-acting " "	3
" " " two-cycle engines	3
12. After studying Table I., draw the different types from memory, and put to each the shortened symbols denoting them	3
13. What is meant by combustion chamber ?	4
14. " " explosion pressure ?	5
15. " " compression pressure ?	5
16. What effect has the size of the combustion chamber on the final pressure of compression ?	5
17. Give a free-hand tracing of the diagram of the E 4 engine shown at Fig. 1, p. 2	5
18. Insert from memory the meaning of the lines forming the diagram, as given in Fig. 16	7
19. Pages 8-15 to be carefully studied	8-15
20. Give a free-hand sketch of the continuous diagrams of the following engines : E 4 single cyl., D 4 single cyl., D 4 four cyl., D 2 single cyl., D 2 two cyl.	16
21. What is meant by the mechanical <i>efficiency</i> of an engine ?	18
22. As sufficient experimental results are not available to determine the efficiencies, we must be content with approximate values. At what may the efficiency of a D 4 two-cyl. engine be rated ?	18

68. *Addition to p. 83.*

At pp. 83 *et seq.*, and also in the examples given at pp. 90 *et seq.*, the forces acting on the crank pin are determined, without taking count of the inertia of the moving parts; therefore the calculated stresses are valid only when starting the engine.

To know the stresses set up in the crank shaft when the engine is running, the inertia force required to set the reciprocating parts in motion must be subtracted from the pressure of the piston.

In the figure at the side (comp. pp. 25 *et seq.*), let—

q_1 be the inertia force in lbs. per sq. inch of piston area at the dead point;

q_x be the inertia force in lbs. per sq. inch of piston area at crank position x ; and referring to pp. 83 and 84, we get—

(1) For position of crank at the dead point. Thrust on the connecting rod—

$$P = A \times (p - q_1).$$

(2) For position of the crank at the maximum turning moment. Thrust on the connecting rod—

$$P' = A \times (p_x - q_x).$$


If $\alpha = 34^\circ$ —

$$p_x = 0.75p; \quad q_x = 0.78q_1, \text{ approximately.}$$

These calculations apply only to single-acting engines; with double-acting engines both faces of the piston must be taken into account, the higher value thus obtained for $p_x - q_x$ determined, and the calculations worked out from it.

The ratio $p_x : p$, $q_x : q$, and the angle α must be determined graphically.

If account be taken of the inertia of the moving parts in making the calculations at pp. 83 *et seq.*, some of the results, as worked out on pp. 90 *et seq.*, will yield the values shown in the following table:—



Dimensions of engine. Diam./stroke= From Table I., p. 24, n =	3 ins. × 5 ins. 240		10½ ins. × 13¼ ins. 220		14 ins. × 20 ins. 185		24 ins. × 28 ins. 150	
	at dead point.	at α = 34°	Dead point.	α = 34°	Dead point.	α = 34°	Dead point.	α = 34°
From Equation 5, p. 26 φ ₁ =	158	122	360	282	360	282	331	260 ft. per second*
From Equations 7 and 9, p. 26 } q ₁ =	13.8	10.8	54	42	65.5	51.2	66.2	51.3 lbs. per sq. in.
p - q ₁ , p _x - p _x respectively =	355	265	315	234	305	221	305	226 „ „
Without inertia of moving parts P and P ₁ respectively } =	2600	1950	30,500	22,800	57,000	42,200	167,000	124,000 lbs.
With inertia of moving parts P and P ₁ respectively } =	2500	1870	26,000	19,300	46,900	34,500	138,000	102,000 „
Maximum stress on crank pin } σ =	—	—	—	—	—	—	—	lbs. per sq. in.

Calculating in this way (with allowance for the inertia of the moving parts) the permissible values of σ (allowable stress or safe working load) given at pp. 86 to 89 must be correspondingly reduced. These stresses apply to actual crank shafts, and are *only* valid if the calculations are worked out as at p. 89. With regard to the inertia of the moving parts, the following corrections may be made:—

In equations	73	79	85	91	100	107	114	121	128	137	145	152
k (lbs. per sq. in.) up to }	12,800	11,300	11,300	4200	11,300	8500	3500	7800	5000	7100	4250	11,300

	PAGE
69. What conditions affect the <i>overheating</i> of the bearings ?	95
70. What method must be adopted to calculate the tendency of the bearings to overheating ?	97
71. Have <i>self-lubricating bearings</i> been found suitable for gas engines ?	100
72. How many oiling rings are required in self-lubricating bearings ?	100
73. Draw the <i>frame</i> of an engine of 15/21 ins. to scale	120
74. Calculate the stresses on the sides of the frame of an engine for an explosion pressure of 420 lbs. per sq. ins.	121
75. Draw the different types of <i>piston</i> from memory	124, 125
76. Determine the <i>vertical pressure</i> on the guide of the piston of an engine of 16/22 ins.	126
77. Calculate the length, <i>a</i> , from the piston pin to the back end of the piston for an engine of the above dimensions	127
78. What is the limit of thickness of the <i>piston rings</i> , to allow of their being drawn over the piston ?	134
79. Required to calculate the piston rings of an engine 15 $\frac{3}{4}$ /22 ins. according to the example given at p. 135, making an allowance for casting of only $\frac{3}{16}$ in.	135
80. What is the <i>mean temperature</i> in— The combustion chamber of a four-cycle engine ?	143
" " " two-cycle engine ?	143
The clearance space in a steam engine ?	143
81. Why is it necessary to withdraw heat from the cylinder of a gas engine by cooling it with water ?	142
82. What are the principal methods of cooling the cylinder of an engine, and which parts are of most importance to cool ?	145
83. Give an approximate estimate of the size, in sq. feet, of the water jacket required for a single-acting four-cycle engine of 24/28 ins., in which the piston is cooled with water	147
84. How many gallons of <i>cooling water</i> are allowed per HP hour for a gas engine in which— (a) Fresh water is used ?	148
(b) Circulating water is used ?	148
85. A 53 HP engine requires $53 \times 8.8 = 466$ gallons of water per hour to cool it. Temperature at admission 12° C. ; at discharge 31° C. How many heat units per HP hour pass into the water ?	148
86. What is the object of an air vessel on the pipe conveying the cooling water to the piston ?	149
87. Draw the connecting rod for an engine 24/28 ins. according to the dimensions given at pp. 155, 156, and calculate the constant, <i>m</i> , for the shaft, and the stresses on the two caps of the rod	157-161
88. An $\mathbb{N}$ 4 engine works with a piston load of 70,000 lbs. What should be the approximate dimensions of the connecting rod, main bearing, crank pin, and piston pin	163
89. What is the symbol denoting the <i>degree of irregularity in running</i> an engine ? .	165
90. What does $\mathbb{C} \times \mathbb{M}^2$ represent ?	166

	PAGE
91. How many times heavier must the flywheel of a single-acting four-cycle gas engine (4 1 cyl.) be than that of a single-cylinder steam engine, other working conditions being the same?	167
92. What do we mean by <i>energy</i> of the flywheel? and what equation is used to denote it?	170
93. The rim of a flywheel weighs 70,000 lbs., the circumferential velocity is 80 ft. per second. What is the kinetic energy stored up in the flywheel?	170
94. In what class of manufactures does the energy of the flywheel play an important part?	173-177
95. What expression is used in electrical work for calculating the size of the flywheel?	173
96. In what connection do the degree of uniformity in running and the energy of the flywheel stand to each other?	172
97. What system of generating the electric current requires a greater degree of uniformity in the driving engine; in other words, less irregularity in running?	175
98. Two dynamos (directly coupled to the driving engines) are to be run in parallel. For what degree of irregularity in running must the masses in rotation be calculated— (a) for continuous current? (b) for alternating current?	175
99. Calculate the example given at p. 175 for an HP plant, with $\delta_0 = 1/220$	175
100. Upon what variation in the load (in percentage of the normal output) must the calculation of a medium-sized grinding mill be based?	176
101. What degree of irregularity should be allowed for a large mechanical workshop, and what should be the energy of the flywheel per HP— (a) If the dynamo does not supply electric light? (b) " " supply electric light?	177
102. Required a 25 HP engine to drive a mechanical carpenter's shop with circular saw. To what degree of uniformity in running and of energy must the flywheel correspond?	177
103. What should be the circumferential velocity of the flywheel in gas engines?	179
104. At what loads, below 100 HP, do small single-acting gas engines have a separate pulley, and at what loads does the flywheel act as the driving pulley?	179
105. Draw the pulley flywheel for a 35 HP gas engine to scale	182
106. For the above flywheel (Exercise 105) determine the degree of irregularity δ_0 , the energy of the flywheel, and the stresses in the arms, at a speed of $n = 185$ revolutions per minute.	

APPENDIX I.
DESCRIPTION OF THE HUMPHREY PUMP.

APPENDIX I.

Description of the Humphrey Pump.*

In the simplest case of Humphrey pump, as illustrated in Fig. 1, water has to be raised from supply tank ST to an elevated tank ET. C is the combustion chamber, W the water valve box with valve V opening inwards, and D the discharge pipe. In the top of the combustion chamber are fitted an inlet valve A and an exhaust valve E. A simple interlocking gear is arranged between these two valves, so that when valve A opens and closes it locks itself shut and releases the valve E, and when valve E opens and closes it locks itself shut and releases valve A. Consequently each time that suction occurs in the chamber these valves open in turn.

Imagine a charge of gas and air to be compressed in the top of chamber C, and fired by a sparking plug which projects through the top casting. All the valves are shut when explosion occurs, and the increase in pressure drives the water downwards in the pump and sets the whole column of water in the discharge pipe in motion. The column of water attains kinetic energy while work is being done upon it by the expanding gases, so that when these gases reach atmospheric pressure the column of water may be moving with considerable velocity. The motion of this column of water cannot be suddenly arrested, hence the pressure in C tends to fall below that of the atmosphere, the exhaust valve E opens and also the water valve V. Water rushes in through the water valves mostly to follow the moving column in pipe D, but partly to rise in chamber C in an effort to reach the same level inside the chamber as exists in the suction tank.

When the kinetic energy of the moving column has expended itself by forcing water into the high-level tank, it comes to rest, and there being nothing to prevent a return flow, the column starts to move back towards the pump, and gains velocity until the water reaches the level of the exhaust valve, which it shuts by impact. A certain quantity of burnt products is now imprisoned in the cushion space F, and the energy of the moving column is expended in compressing this gas cushion to a greater pressure than that due to the static head of the water in tank ET. Hence a second outward movement of the column results, and when the water reaches the level of valve E the pressure of the space F is again atmospheric, and further movement of the water opens valve A against a light spring and draws in a fresh charge of gas and air. If there were no friction the water would fall to the same level as that from which the last upward motion started, but the amount of combustible charge drawn in is slightly less than this movement would represent. Once more the column of water returns under the elevated tank pressure and compresses the charge of gas and air, which is then ignited to start a fresh cycle of operations.




FIG. 1.

* Reprinted, by permission of the author, from a paper read by Mr. H. A. Humphreys, M.I.C.E., before the Manchester Association of Engineers on Nov. 12, 1910.

The action of the pump is not altered if, instead of delivering into an elevated tank, it discharges into an air vessel, as shown in Fig. 2, or into an open top stand pipe or tower, as shown in Fig. 3, and both these arrangements are useful if a continuous flow from the outlet O is desired. In many cases the pump can be placed directly in a concrete pit, which serves also as a foundation, and the discharge can be by an inclined pipe, as shown in Fig. 4, where the water valve box is shown vertical. This arrangement is very satisfactory, and is economical in material.

In the simple form of pump the degree of compression of the combustible charge prior to ignition



FIG. 2.




FIG. 3.




FIG. 4.

depends on the height to which the water is raised, and exceeds the static equivalent of the head. This can be made clear by reference to Fig. 5, where water returning under a pressure AB, and moving through a stroke AD, does work in compressing the gas equal to ABCD. The gas is compressed from A to E, and the work of compression is AED, consequently the shaded area above the line CB must be equal to the shaded area below it, and E, the maximum compression pressure, is much above C. This result is obvious if one remembers that the kinetic energy acquired by the liquid column on its return flow is utilized in compressing the combustible gas, while the compression brings the column to rest.

The same considerations enter into the question of the cushion pressure attained, but here we are dealing with the compression of a volume of gaseous fluid which occupies the clearance space only, and the stroke of the water column is greater in proportion, because for the first part of the stroke exhaust products are being expelled and no compression occurs. Without going into the mathematics of the subject, it is sufficient to say that the cushion pressure rises rapidly as the height to which the water is lifted increases, and at the maximum lift of about 40 ft. to which the simplest type of pump is limited, it may exceed the explosion pressure when using producer gas, or may approxi-

mately equal the explosion pressure when working with town gas or petrol.

Without much sacrifice of simplicity the cushion space may be kept separate from the combustion chamber, and can then be made relatively large because the products or air in the cushion do not then mix with the new charge. This forms one way of keeping the cushion pressure low, and is explained later. Again if air scavenging is employed, as is now usual, the residual burnt products left in the clearance space are mixed with air and the latter may constitute the greater part of the mixture; a rather excessive clearance is then permissible as compared with an ordinary gas engine, and the simple pump will work throughout its whole range of lift with very moderate cushion pressures.

No simple means of indicating the work done by the expanding gases has been found, so that the indicated horse-power of a Humphrey pump cannot be directly ascertained, but indicator cards




FIG. 5.

showing pressures on a time basis are interesting. Such an indicator card is given in Fig. 6, and is taken from a 45 water HP four-stroke pump, lifting to 39.4 ft. head, and working on town gas. The figures relating to this card are:—

Compression pressure at ignition, 56.5 lbs. per square inch.
 Explosion pressure 168 lbs. " "
 Cushion pressure 185 lbs. " "
 The pump was delivering 806 gallons per working stroke.

The card may be explained as follows:—

Compression of charge from *a* to *b*.
 Explosion from *b* to *c*.
 Expansion from *c* to *d*.
 Taking in water and scavenging air and partly exhausting, *d* to *e*.
 Return stroke completing exhaust till valve shuts, *e* to *f*.
 Cushioning, *f* to *g*.
 Cushion expansion, *g* to *h*.
 Intake of new charge, *h* to *j*.
 Next compression of charge, *j* to *k*.




FIG. 6.

The stiff spring used does not permit the suction to be shown on this card, but the partial vacuum at the end of cushion expansion may momentarily be as much as 4 lbs. per square inch, and the water suction may at first be equal to two or three feet of water, both dying down to atmospheric pressure during the respective strokes.

If one thinks of the reciprocating column of water as representing the pendulum of a clock, it is easy to appreciate the fact that the length of the column governs the period of the swing; and if one assumes other things to be equal, and the column to be of uniform section, then the period is almost

proportional to the square root of the length. Mr. H. M. Martin, of *Engineering*, has worked out a number of examples illustrating the effect of the length of the discharge pipe under a given set of conditions, and his results are here reproduced from *Engineering* of 11th February, 1910 :—

Diameter of play pipe, 2 feet.				
Maximum velocity of flow permitted, 14 feet per second.				
Length of pipe, feet	25	50	100	200
Cycles per minute	61	31	14.3	7.0
Discharge, cubic feet per minute	527	486	447	417
Efficiency $\frac{\text{PHP}}{\text{IHP}}$	0.98	0.95	0.91	0.82




FIG. 7.

Evidently, for a simple type of pump taking in its charge at atmospheric pressure, the first and last columns do not represent practical conditions, the cycles being too rapid in the first and too

slow in the last, the two middle columns are possible cases, and a length of 60 to 80 ft. is generally found advisable. The maximum velocity chosen is merely an example and may be exceeded.

The four-cycle pump has been dealt with at some length because its construction is exceedingly simple, and it is the key to all the others. Moreover, its reliability has been amply proved, and its elasticity in meeting changes of lift without altering the mixture of gas and air or the clearance volume has been demonstrated. The four unequal strokes which result from the free oscillations of the water column give rise to a cycle which is superior to the Otto cycle, and is in fact the theoretically perfect heat cycle described in text-books. On the subject of heat efficiency more will be said later, but we must now pay a little attention to mechanical details.




FIG. 8.

Fig. 7 is a sectional view of the Humphrey pump exhibited in operation at the Brussels International Exhibition, and which obtained two "highest possible" awards, namely, a Grand Prix in the class for gas engines, and a Grand Prix in the class for pumps. Its construction can be seen at a glance, and explanation is not needed till we come to the valve gear shown in Figs. 8 and 9. It will be observed that a bolt B sliding horizontally must lock either the admission valve A or the exhaust valve E by engaging under collars a or e, which are fixed on the stems of their respective valves. Now the bolt is urged right or left, according to whether spring s_1 or s_2 is pulling the hardest, and this again depends on whether the link l to which the springs are attached has been shifted to the right or left. Suppose the exhaust valve opened last, then its washer m engaging against cam arm p moved the system pq so that it leans to the right, in which position it is retained

by the tension of spring s_3 . This puts tension on spring s_1 and loosens spring s_2 , bolt B, therefore, tries to move to the right, but until the exhaust valve shuts it can only press upon collar c . However, when valve E comes on its seat the bolt instantly locks under c , and the same motion which holds valve E shut has released valve A, so that next time a suction occurs in the combustion chamber A only can open. Precisely the same kind of action occurs when A shuts and is locked and E is released again. Thus valves A and E are automatically allowed to act alternately, the difference between them being that while E remains open till shut by the rising water, A shuts under the action of its supporting spring so soon as the suction in the chamber permits the spring to lift the valve to its seat.

The scavenging valve V is shown in the plan of the combustion head, Fig. 9, and as it operates at the end of each expansion stroke its locking and release periods correspond with those of the




FIG. 9.

exhaust valve, and are made simultaneous by a lever pivoted at K, and operated by a pin on the bolt B. If the water could rush in fast enough when the pressure falls to atmosphere there would be no scavenging action, but the incoming water has to be accelerated, and that just gives rise to a sufficient suction to effect the desired scavenging. In the exhaust outlet there is a light non-return valve, to prevent burnt products being drawn back into the chamber.

When an internal bell is to be used to provide a separate cushion of burnt products a slight modification of the gear is required to control the three valves. Instead of a scavenging valve we have a valve S opening into the top of the internal bell, as shown in Fig. 10, and on its spindle is a loose non-return valve Q. The valve S is released to fall at the same time as the admission valve opens, but the valve Q prevents any inlet into the top of the bell. The action is as follows. When explosion occurs the bell is full of water and all valves are shut. Expansion below the open bottom of the bell allows the water to escape from the bell, which becomes filled with burnt products. On the first instroke of the water the exhaust valve E is found open as usual and allows the products to

escape, but valve S is shut, so that the burnt products in the bell are trapped, and suffer compression by the rising water, which clears away all the other burnt products outside the bell. The compressed cushion in the bell now expands, and the second outstroke occurs, during which the suction opens the admission valve A to let in the fresh charge as usual, and in addition valve S opens.

The second outstroke being shorter than the first does not lower the water to the bottom of the bell, and the pure combustible charge outside the bell does not mix with the products inside. Lastly, the second instroke occurs, and the water rising in the bell forces the exhaust gases out past the non-return valve Q until valve S is reached. The water then shuts valve S, and the return column of water having gained velocity, depending on the volume of gases discharged from the bell, compresses the pure combustible charge outside the bell. Since the volume of the bell is not limited, the water column may attain a high velocity, and so give a high compression pressure, thus ensuring good efficiency.

One other important modification of the single-barrel pump depends for its successful operation upon the fact that in the Humphrey pump the burnt gases are so well cooled at the end of the long expansion stroke that they will not ignite an incoming combustible charge. It therefore becomes possible to have a true two-cycle pump, and the action will be understood by reference to Figs. 10A and 10B, which show alternative arrangements of the top of the combustion chamber. Dealing first with Fig. 10A, the combustion chamber has to be specially shaped so that the incoming charge, which may be preceded by pure air, displaces the burnt products and mixes as little as possible with them.




FIG. 10.




FIG. 10A.




FIG. 10B.

Thus, in the figure, A is the admission valve at the top of a tall but narrow part of the chamber B, in which the full charge volume extends down to the level cc. A number of exhaust valves E lead to a common exhaust outlet O, which may be fitted with a non-return valve, or each exhaust valve may carry a light non-return valve on its spindle as shown. The level at which

expansion reaches atmospheric pressures is say *ff*, but this level having been reached by the water, its further movement draws in fresh combustible mixture till it occupies the space down to *cc*, and the liquid level has fallen to *gg*. The column of liquid now returns and drives the exhaust products through the valves *E* (which opened by their own weight) until these valves are shut by the water. The kinetic energy acquired by the column is now spent in compressing the fresh charge, which is ignited to start a new cycle. Thus each outstroke is a working stroke, and no locking gear is required on the valves.

The same cycle applies to Fig. 10a, but in this case there are a number of admission valves placed in a ring so as to allow the mixture to enter with a low velocity, in order to prevent eddies and mixing with the exhaust products.

The advantages of the cycle will appeal to the reader at once, as a higher compression pressure is obtained than with the simple pump, and consequently higher efficiencies with the same lift.

Before leaving the simple pump it is necessary to call attention to the fact that if a pump when working is stopped by switching off the ignition current, it will continue to complete its cycle up to the point of compressing the new charge, and will pull up, after a few oscillations of the water column, with the fresh charge remaining ready for ignition, to again start the pump when the current is switched on. In starting up from "all cold" a single charge of air is introduced against the head of water by a hand pump or small compressor, and the exhaust valve is opened by a hand lever to allow the air to escape. This starts the oscillation of the column which automatically shuts the exhaust valve, cushions, draws in a new charge, compresses and fires it, and so the pump gets away under load.

Coming now to the double-barrel pump, diagrammatically illustrated in Fig. 11, we have two combustion chambers, A and B, in which explosion occurs alternately. In each chamber we have




FIG. 11.

the usual cycle of compression, explosion, expansion, exhaust, and the taking in of the new charge, thus again involving four strokes of unequal length. In this case, as in that of Fig. 10a, the water column has only one outward and one inward movement per cycle, but the expression "two-stroke" would here be misleading, unless one remembers that it applies only to the water column, and does not refer to what occurs in the combustion chambers.

Let us follow through the cycle in this case, and we will assume that a compressed combustible charge exists in the top of chamber A, and that B is full of water. Explosion and expansion in A cause the outward propulsion of the water column, and when atmospheric pressure is reached the exhaust valve of A opens, water flows in to follow the column and to rise in A expelling burnt products, and there being insufficient pressure to maintain the water in B the level therein falls, causing an intake into B of a fresh combustible charge. All this takes place during the outward movement of the column of water, and then the column coming to rest commences to return towards the chambers. It finds that the remaining burnt products in A can be readily sent out through the still open exhaust valve, whereas the new charge in B cannot escape as the admission valve which admitted the charge is now shut under the action of its spring. Consequently the column rises at first in A until the exhaust valve is shut, and then in B compressing the new charge. Ignition in B starts a fresh cycle with the functions of A and B reversed.

There are important differences to be noted between the action of this pump and of the single-barrel pump first described. To begin with, the new charge is taken in merely by water falling

under the action of gravity, and does not depend upon the compression and expansion of an elastic cushion. The clearance spaces at the tops of the combustion chambers may therefore be reduced to the very small volume needed to bring easily to rest that portion only of the column which rises in the chamber; the main portion of the column being brought to rest by the compression of the new charge. Again, for a given height of lift the compression pressure attained is higher in the double-barrel pump, because the returning column gains speed while exhausting the last part of the burnt products, and has thus obtained a store of kinetic energy before starting the compression stroke proper.

The advantages of the two-barrel over the simplest of the single-barrel pumps may be briefly stated:—

1. Higher explosion pressure for the same water lift, due to (a) reduced clearance resulting in less contamination of the new charge by residual burnt products, and (b) higher compression pressure.
2. More cycles possible in unit time.
3. Greater output for a given total weight of pump and play pipe.

There are ways and means of making a single-barrel pump operate on a four-stroke gas and a two-stroke water cycle with many of the advantages pertaining to the two-barrel pump, and although interesting experiments have been made by running a single-barrel pump in such manner, yet it is impossible to deal with them in this paper, and indeed, it is necessary to omit all reference to very many other types of pumps which the author has designed.

So far we have considered only those pumps which have a drowned suction, and a limited lift of 40 ft. We will now take a brief glance at a few of the types of Humphrey pumps capable of working with a suction lift, and then we will come to high-lift pumps.

Fig. 12 is a diagram of one kind of suction lift pump, and the cycle is as follows:—

1. Explosion of compressed combustible charge in A driving water to high-level tank K, continuation of expansion stroke below atmosphere owing to the existence of non-return valve in exhaust pipe. Consequent lowering of pressure till water is raised from low-level tank H, past valve G, until water comes to rest and valve G shuts.
2. Return movement of water column towards chamber A giving exhaust and cushion stroke.
3. Cushion expansion, and inlet of a measured combustible charge into A, and expansion of this charge below atmosphere.
4. Second return of water column towards A giving compression stroke.

The measured charge involved in step 3 of the cycle may be obtained in many ways, one of the simplest being by the use of gas bags, the diaphragms of which are attached to valves, and on being drawn in actuate the valves to close the outlet. The use of a measuring device can, however, be obviated by employing the "rejected charge" device to be described in connection with air compressors.

Another suction pump is illustrated by diagram in Fig. 13. The combustion chambers of A and B of a two-barrel pump are connected to the play pipe D, but the water suction pipe is at the opposite end of the play pipe, and in addition there is an air vessel C, and valves N and M, as shown. The cycle will be readily surmised. On explosion in A the water column moves outwards from the chambers and compresses the air in C until the pressure is sufficient to lift valve




FIG. 12.

N and pass water into the high-level tank. On the column coming to rest valve N shuts and the compressed air in C expands again, imparting velocity to the column, and enabling the expansion




FIG. 13.




FIG. 14.

to pass below atmosphere, and so lift water from the low-level tank at the same time that exhaust in A and compression of the new charge in B take place. The cycle is then repeated.

A single-barrel pump will operate in a similar manner, but the arrangement of Fig. 14 necessitates two extra strokes, and the cycle is as follows:—

- (a) refers to what occurs at pump.
- (b) refers to what occurs at air vessel.

1st Outstroke (caused by explosion in 1).

- (a) Explosion in 1 followed by expansion to atmospheric pressure, then continued movement taking in scavenging air till column comes to rest.

- (b) Compression of air in 2 until delivery pressure is reached, then water is delivered through valve 9 until column comes to rest.

1st Instroke (caused by expansion in 2).

- (a) Exhaust until valve 6 is shut by the water, then compression of cushion which remains.

- (b) Expansion of air in 2 giving velocity to water column. When partial vacuum equal to suction lift is attained, water is sucked up past valve 10 to follow moving water.

2nd Outstroke (caused by expansion of cushion in 1).

- (a) Expansion of cushion in 1 and intake of combustible mixture in excess, the first portion being taken from 8

through valve 7, and the remainder through admission valve 5.

- (b) Compression of air in 2 but no delivery of water.

2nd Instroke (caused by expansion in 2).

- (a) Rejection of surplus charge past valve 7 until water shuts this valve. Compression of charge which remains.

- (b) Expansion of air in 2.

Note.—For clearness the usual scavenging valve on pump is not shown. Exhaust and scavenging valves are released (or locked shut) together. Admission and rejected-charge valves are released (or locked shut) together.

Yet another suction pump is shown in Fig. 15, the arrangement being suitable for pumping from a well. Explosion in A drives the water down one leg of the U pipe and up the other leg into the delivery tank. Expansion below atmosphere causes an intake of water through the suction valves in the well, then the first return movement occurs giving the exhaust and cushion stroke, followed

by the cushion expansion and gas suction stroke, and lastly the compression stroke. Many other varieties will probably suggest themselves to the reader, but it is only necessary to describe one more type, which is illustrated by Fig. 16, and is interesting as giving the same high efficiency with a low lift as can be obtained with a high lift.

In this case the energy of water falling to a lower level is used to cause the intake of fresh water, and the pump barrel is placed at a low level to render this possible. Thus in the figure we have a single combustion chamber A, and upon explosion water is forced outwardly, the whole column from the pump to the high-level tank partaking of the motion. The two parts of the column *a*, from pump to valve V, and *b* from valve V to high-level tank ET are so proportioned that the *a* portion loses its kinetic energy first, and is ready to return towards the pump before the *b* portion has come to rest. When the *a* portion flows back downhill fresh water is taken in at valve V between the two portions of the column, and the exhaust and cushion strokes occur in A. Expansion of the cushion in A gives the usual outstroke taking in gas and air, and the cycle is completed by a second instroke which compresses the combustible charge in A. In this last stroke either the *a* portion or the whole column may take part, depending on the proportions of *a* and *b* and the differences of levels. The chief point to observe is that while water is only raised from




FIG. 15.




FIG. 16.

tank ST to tank ET, yet the fall to the pump may be sufficient to give a good compression pressure, and thus secure high efficiency.

Coming now to high-lift pumps, any Humphrey pump, whether single or double barrel, may be converted into a high-lift pump by means of an air vessel fitted with valves and called an "intensifier." The idea is to first allow the water column to gain velocity and then to utilize its kinetic energy to (a) compress an elastic fluid, (b) deliver water under the pressure to which the elastic fluid has been compressed. Fig. 17 will serve to make the cycle clear.

A and B are the barrels of a two-barrel pump, and at the end of the play pipe D there are two air vessels E and F, the latter being large enough to give a continuous flow at outlet O, and to maintain a practically uniform pressure. The smaller air vessel E is fitted with a downwardly projecting pipe K, open to the atmosphere at the top and carrying a valve L at its lower extremity, arranged to close under the action of the rising water. The cycle starts with explosion, all valves except L being shut and the water level as shown. While the water level in E is rising to L, air is merely being discharged into the atmosphere, and as no work is being done by the column of water it gains speed until valve L is shut by impact. Imprisoned in E there is now a definite quantity of air, which suffers compression until its pressure reaches that at which the high-pressure water valves W can open and allow the remaining kinetic energy of the column to force water into F. Valves

W close when the column comes to rest, but there remains enough energy in the compressed air in E to give, by expansion, the return flow, which causes exhaust in A and compression of the fresh charge in B to start a fresh cycle. When the water level falls below valve L, this valve opens and air is admitted into E for the rest of the return stroke.

Now, it is easy to see that if the pipe K is made vertically adjustable with regard to E, the point of the cycle at which L shuts can be varied, and more or less air entrapped in E at will. But




FIG. 17.

the amount of energy stored in this air will also vary with its quantity, for we assume that the degree of compression remains constant, and is indeed fixed by the pressure maintained in F. Consequently the ratio of the total energy of the working stroke to the energy stored in the compressed air in E can be made anything desired, or, in other words, we can obtain any compression pressure of the new charge in B which we like, and this independent

of the water lift. The advantage is obvious for compression pressures equal to those in modern gas engines can be employed with a corresponding increase in thermal efficiency. Further, by manipulating the position of pipe K a given pump can be made to meet any conditions as to height of lift, for if the lift increases K can be raised so that the energy stored in the air in E remains the same, there being now less air but at a higher pressure.

A short digression may now be made to describe an important development of the arrangement shown in Fig. 17, and the reader's notice is directed to the fact that at each cycle air is drawn into and rejected from the vessel E. Let us suppose K is connected to a supply of combustible mixture instead of opening into the atmosphere, we shall then have an automatic pump for taking in mixture and discharging it under pressure. If the discharge is into a reservoir from which combustion chambers A and B can be supplied, we have at once a means of quickening the cycles and greatly increasing the output of a given size apparatus. It is convenient to replace vessel E by two vessels, one for air and one for gas, so as to maintain the combustible constituents separate until they enter the combustion chambers. If the first portion of the outstroke of the water column is allowed to reject the surplus air and gas back to the sources of supply, then the action throughout the cycle is precisely that described when using the single vessel E, except that a larger proportion of the total energy is absorbed in the compression of air and gas, but the excess is given out again during the expansion of the pre-compressed charge in either A or B. The chief advantage arises from the more rapid working, as there is no longer any need to wait for the water level in A or B to fall under the action of gravity when the charge is being taken in. In fact, the apparatus becomes practically independent of the water level on the supply side. The 1000 HP Humphrey pump now under construction in Germany will operate in the manner just described, the result being that the dimensions are very moderate, and the pump itself occupies no more space than a 1000 HP tandem gas engine.

The limits of this Appendix preclude any reference to single-barrel high-lift pumps, other than that shown in Fig. 14, or to other modifications of the double-barrel type to suit special conditions, as there still remains the important subject of air compressors to be considered.

If the column of water oscillating in the play pipe of a Humphrey pump is used as a water piston, and caused to rise and fall in an air vessel fitted with suitable valves for the inlet and outlet of air, the combination constitutes an air compressor of a very efficient type and promising many advantages. Let us take the case of a single-barrel pump and a single air vessel, as illustrated in Fig. 18. A is the ordinary pump chamber and C the air compressor chamber, and we may call them for convenience the "pump" and the "compressor" respectively. The inlet valve *i*, for gas and air, and the exhaust valve *e*, for burnt products, exist as before, but the exhaust pipe and valve are adjustable vertically so as to vary the cushion space in the top of A. There is another pipe *p*, fitted with a valve *r*, and also adjustable vertically. A reservoir X, such as an old boiler shell, is connected by a flexible pipe to *p*. Corresponding parts are fitted to the compressor; thus *f* is an air inlet valve, *g* an outlet valve for air which is shut by the water, and *h* a non-return valve for the compressed air. The dip pipe *q*, with its valve *s*, gives communication between the atmosphere

and the compressor. The outlet pipe and the dip pipe are vertically adjustable as in the pump. Lastly, suppose the play pipe D filled with water, then we have all the elements required for working under the most varied conditions.

The cycle can be explained by assuming the water level is well up in A and low in C, as shown in the figure, and that a compressed charge is ignited in A. Expansion occurs, driving down the water in A and up in C. At first air escapes from C through valve *s*, but when the water reaches this valve it is shut and the remaining air is trapped, and suffers compression until the pressure of discharge is reached, when *h* opens and compressed air is delivered. Next the water reaches valve *g* and shuts it so that no more air can escape, and the water column is brought to rest by the continued compression of the remaining air, which forms a cushion. Meanwhile in chamber A expansion to atmosphere allows the exhaust valve *e* to open, and the continued stroke draws in scavenging air (the scavenging valve being omitted from the figure for the sake of simplicity), but valves *i* and *r* remain locked. Now the column begins to return, due to the expansion of the compressed cushion in C, and this causes exhaust and cushion in A, and at the same time there is a fall of pressure in C to atmosphere, then valve *f* is opened against a light spring and a fresh supply of air enters.




FIG. 18.

So far we have had one outward and one return stroke, but the expansion of the cushion in A starts a second outstroke which results in drawing in a new combustible charge in A through valves *i* and *r*, which were released on the shutting of the exhaust valve *e*. As the second outstroke is nearly as long as the first, it follows that too much combustible mixture is drawn in, but the surplus is got rid of on the second return stroke by allowing it to escape into the receiver X, and to slightly raise the pressure therein. Valve *i* was shut by its spring, but *r* waits to be shut by the action of the water, and when this occurs chamber A contains a definite volume of combustible mixture, the size of charge being fixed by the height of *r*. Finally we have only to observe that the second outstroke towards C merely compressed the air in C without causing delivery to take place, but storing in the air the energy given out by the expansion of the cushion in A. The air in C now expanding gives the compression stroke in A, and the combustible charge is ready to be ignited to start the next cycle.

Perhaps the whole cycle, which may take two seconds to accomplish, sounds a little complicated, but if so, it is merely due to the length of the description. It may be easier to grasp the action if it is set out to show the simultaneous steps in A and C, thus:—

	A.	C.
1st Outstroke.	Expansion to atmosphere. Intake of scavenging air.	Expulsion of air till water shuts valve <i>s</i> . Compression and discharge of compressed air till water shuts valve <i>g</i> . Cushion till water comes to rest.
1st Instroke.	Exhaust till water shuts valve <i>e</i> . Cushion till water comes to rest.	Expansion of cushion to atmosphere. Intake of fresh air.
2nd Outstroke.	Expansion of cushion to atmosphere. Intake of combustible charge in excess.	Compression of air, but not sufficient for further delivery.
2nd Instroke.	Rejection of surplus charge till water shuts valve <i>r</i> . Compression of charge till water comes to rest.	Expansion of compressed air.

It will be evident that in the next cycle when admission of combustible charge occurs, the surplus last rejected into reservoir X will want to enter first, because it is under slight pressure, whereas inlet valve *i* has to be sucked open against its spring. Consequently X will empty to atmospheric pressure each time, and only the additional mixture required will be taken in through valve *i*. A slight modification may be made by transferring valve *i* from the pump to the reservoir X.

The flexibility of the air compressor can now be studied. To begin with the pump side, the level of the inlet valve *e*, and the rejected charge valve *r*, are assumed to be variable although Fig. 18, being merely a diagram, does not show how the pipes carrying these valves are moved vertically. As the level of these two valves controls the amount of charge ignited at each cycle, and the amount of the cushion space, their regulation is all that is required to increase or diminish the energy developed per working stroke. On the compressor side the position of the valves *g* and *s* controls the cycle of operations on this side of the apparatus, and renders it possible to compress a large volume of air to a low pressure, or a smaller volume of air to a high pressure, or to make any intermediate changes which may be desired.

Thus all the conditions of output, up to the full limit of the compressor, may be governed at will, and for all ranges the compression pressure of the new charge may be kept up to the required degree, so that the apparatus works at its maximum efficiency throughout the whole range. The amount of water which oscillates between the chambers should theoretically be altered along with the total capacity per working cycle, but the reason for this is merely to prevent the last portion of each down stroke from being wasted by taking in surplus combustible mixture in one chamber, or surplus air in the other chamber, to an undue extent. If the surplus of the combustible mixture is unnecessarily large, the extra amount rejected will increase the pressure in the reservoir X, and this

increase of pressure may be made to automatically govern a water supply, and so bring up the total volume of reciprocating water, or to allow part of the water already in the apparatus to escape, so as just to keep a small amount of excess charge for each cycle, no matter what may be the output of the pump.

To illustrate the importance of the air compressor, and at the same time bring to the reader's notice the use of the double-barrel pumps for this purpose, we may take a definite example, and Fig. 19 shows a compressor capable of dealing with 25,000 cubic feet of free air per minute, and compressing it to 25 lbs. per square inch. It is composed





FIG. 19.

of two units, as shown in elevation and plan, and the dimensions are given. The horse-power in the air delivered is about 1500. As the pressure of delivery increases the forces acting upon the water also increase, and the accelerations become greater. Consequently for a higher pressure of delivery the size of the apparatus becomes smaller for a given output.

Usually compressed air is required to be delivered at as low a temperature as possible, so as to free it from moisture, and it may be noted that where the maximum cooling is required vertical sheets of wire gauze may be fixed in the compressor, so that the gauze takes up water on each stroke and forms a very effective cooling medium in direct contact with the air, thus permitting the compression to be more nearly isothermal than in any other kind of compressor. The reciprocating water itself can be cooled either by cooling the play pipe externally, or by allowing water to be taken in and rejected at each cycle. The latter arrangement has been worked out, but for lack of space it cannot now be described.

One other type of compressor may, however, be briefly referred to, because it differs from the other air compressors in that the pump and the compressor alternate in their functions at each cycle. It has the advantage of giving a greater horse-power output for a given size of apparatus, but it has the disadvantage that the air and the exhaust products are mixed together and delivered under pressure. For power purposes, however, this is not a drawback, and in such a case there is some advantage in delivering the compressed mixture rather hot, so that during its expansion, while performing work in some kind of air motor, there is no chance of its freezing the moisture contained, as frequently happens when the air enters the motor at normal temperatures. The thermal efficiency of such an arrangement is exceedingly high, provided that the air can be utilized close to the compressor so as to make use of its sensible heat.



$$\text{Efficiency} = 1 - y \frac{T^1 - t}{T - t_c}$$

$$T^1 = t \left(\frac{T}{t_c} \right)^{\frac{1}{\gamma}}$$

$$t_c = t \left(\frac{P_c}{P} \right)^{\frac{\gamma-1}{\gamma}}$$

$$T = (\text{for curve at } 1000^\circ \text{ C.}) = 273^\circ + 1000^\circ \text{ C.} = 1273^\circ \text{ C. Abs.}$$

$$T = (\text{for curve at } 1600^\circ \text{ C.}) = 273^\circ + 1600^\circ \text{ C.} = 1873^\circ \text{ C. Abs.}$$

$$\gamma = 1.508.$$


$$t = \text{Suction temperature} = 17^\circ \text{ C.} = 290^\circ \text{ C. Abs.}$$

Adiabatic compression and expansion.

FIG. 20.

Turning now to the question of thermal efficiency, the curves shown in Figs. 20, 21, and 22 show the relative efficiency as between the Humphrey pump cycle and the ordinary Otto cycle

calculated upon the usual formula, and upon the assumptions stated on the diagrams. These calculations are based on the assumption of the constant specific heat, but Professor Dr. Eugen Meyer, of Charlottenburg, has made the very laborious calculations involved when taking the true specific heat of each constituent of the gas mixture, and allowing for the variations of the temperature involved at each point on the curve. The absolute results are affected, but the relative results remain approximately the same, and for present purposes it is sufficient to take the curves as here given.



$$\text{Efficiency} = 1 - \frac{t}{t_c}$$

$$t = 273^\circ + 17^\circ \text{ C.} = 290^\circ \text{ C. Abs.}$$

$$t_c = t \left(\frac{P_c}{P} \right)^{\frac{\gamma-1}{\gamma}}$$

$$\gamma = 1.408.$$

FIG. 21.

It may be mentioned, however, that with a compression pressure of eleven atmospheres absolute the theoretical thermal efficiency of the Humphrey cycle is 52.5%, whereas that of the Otto cycle is only 40% when all corrections for varying specific heats are allowed for. Such compression pressures have not yet been adopted by the author, but they will be employed in the 1000 HP German pump already referred to. In the meantime, when using only very moderate compression pressures of under 50 lbs. per square inch, an actual thermal efficiency of over 23% has been obtained on a four-cycle Humphrey pump. This corresponds to 0.95 lb. of anthracite coal per water HP hour, and was obtained on a lift of only 35 ft. It may be expected therefore that as the compression pressure increases the efficiency will also increase, and there is every reason to believe that when the compression pressure reaches that employed in ordinary gas engines, the best

efficiencies attained in gas engines will be reached and probably surpassed by the Humphrey pump.

A large scale experiment is to be tried in which a Humphrey pump will be used to drive a water turbine coupled to an electric generator. The advantages of such an arrangement over the ordinary gas engine arise chiefly from the simplicity of the working parts, the absence of all troubles arising from contraction and expansion due to heating and cooling, the freedom from cyclic irregularity, thus enabling alternators to be driven in parallel, and finally, the high efficiency and the low cost of upkeep. Also, the apparatus may be started and stopped immediately, and can indeed be entirely controlled from a switchboard. One has to face the loss due to conversion of water power into mechanical energy, but the efficiency of well-designed turbines can be guaranteed at over 80 % at full load, and in a central station there is no need to run any of the pumps at less than full load, since they can be so easily started and stopped. Moreover, if blast furnace gas or producer gas derived from cheap fuel is used, the loss of 20 % of the energy is not important, as compared with the advantages gained by the adoption of the gas-hydro-electric system, and the absence of the need for any lubrication would alone more than compensate.

In conclusion, a brief reference may be made to the application of the Humphrey pump for the purposes of marine propulsion. The theoretical efficiency of the jet propeller is well known and




FIG. 22.

admitted. The trouble has been to find a pump which would be at once pump and engine combined, and which would handle large quantities of water so that the area of the jet at the point of exit might be comparable with the area of the water acted upon by an ordinary screw propeller. The Humphrey pump fulfils the required conditions, and the diagram of Fig. 23 shows one possible arrangement in skeleton form. The double-barrel pump with cylinders A, B discharges simultaneously in two directions through equal lengths of pipe C, D leading to air vessels E, F. The suction occurs through the side of the ship and passages G, H as shown. The water from one air vessel E is brought back to air vessel F through a pipe J, and the common discharge is then through the pipe K which opens into the surrounding water at the stern of the ship. Means for diverting the jet as it leaves the vessel either to the right or to the left, or through a complete turn of 180° so as to drive the ship astern, are not shown, as they have been worked out by many experimenters.

The arrangement indicated in the figure prevents all vibration, since the stresses, due to the moving water, are equal and opposite, the pump being situated in the centre, between the air vessels. Also, the air vessels keep the discharge continuous, so that there are no jerks, the result being a system in which full power, either ahead or astern, is available instantly, and the ship so fitted has a radius of action, owing to the fuel economy, equal to at least twice that which can be obtained by any other system. Since jet propellers become more wasteful with increasing velocities of

propulsion, it may be found advisable to limit the application of the system now proposed to cargo steamers of moderate speed, but for such vessels requiring, say, 2000 to 3000 HP the scheme contains all the elements of success. It may eventually prove that a pump having pre-compression of its gas and air will be more suitable for the larger sizes, and, when one remembers the small space occupied by two or three 1000 HP pumps of this type, the outlook is distinctly promising.

The Metropolitan Water Board have to instal a very large pumping plant at their new reservoir at Chingford, and the chief engineer and a committee of the board have for some time past been studying most carefully several schemes submitted to them with the corresponding tenders for




FIG. 23.

different types of plant. As the result of a most thorough investigation the committee unanimously reported in favour of the adoption of the Humphrey pump, and at the meeting of the board on November 4, 1910, the committee's recommendation was approved. The report showed for these pumps a saving in first cost of £19,000 on the complete installation, including buildings and foundations, as compared with triple expansion steam engines running at 350 revolutions per minute and coupled to centrifugal pumps. Moreover, there is a great saving in fuel consumption and running expenses, since the coal consumed is only about half that of the steam plant. Gas engines and oil engines driving centrifugal pumps were also considered.

The quantity of water to be pumped is 180 million gallons per 24 hours, and the lift is 25 to 30 feet. For this duty there will be erected five Humphrey pumps, four of which will each have a capacity of 40,000,000 and one 20,000,000 gallons per day.

APPENDIX II.
USEFUL TABLES.

TABLE I.
STRENGTH AND WEIGHT OF METALS.

Metal.	Tearing Force in Lbs. per Sq. In.	Crushing Force in Lbs. per Sq. In.	Shearing Force in Lbs. per Sq. In.	Elastic Strength in Lbs. per Sq. In.	Weight of a Cubic Inch in Lbs.	Weight of a Cubic Foot in Lbs.
Cast iron	18,000 to 20,000	90,000	10,000	10,500	0.26	460
Steel castings	67,000	—	—	35,000	0.284	490
„ forgings	63,000	—	—	—	0.282	487
Iron „	45,000 to 50,000	—	—	—	0.28	485
Wrought iron bars, BBI.	58,000	50,000	40,000	29,000	0.28	485
Nickel steel (3 per cent. nickel)	112,000	—	—	62,700	—	—
Gun metal	27,000	—	—	6,500	0.315	545
Phosphor bronze (cast)	35,000	—	—	19,000	—	—
Manganese bronze (cast)	55,000	—	—	30,000	0.31	535

TABLE II.
BOLTS AND NUTS.

TABLE OF BRITISH STANDARD HEXAGONAL BRIGHT AND BLACK NUTS, AND BOLT-HEADS.*
(Abbreviated.)

Diameter of Bolt.	Nuts.				Lock Nuts.		Bolt-Heads.	
	Width across Flats.		Width across Corners.	Thickness.	Thickness.		Thickness.	
	Max.	Min.			Max.	Min.	Max.	Min.
Inch.	Inch.	Inch.	Inch.	Inch.	Inch.	Inch.	Inch.	Inch.
$\frac{1}{8}$ (0.375)	0.525	0.520	0.61	0.36 0.27	0.35	0.18 0.19	0.17	0.23 0.24
$\frac{1}{4}$ (0.625)	0.710	0.705	0.82	0.39 0.40	0.38	0.26 0.27	0.25	0.34 0.35
$\frac{3}{8}$ (0.875)	0.920	0.915	1.06	0.51 0.52	0.50	0.34 0.35	0.33	0.45 0.46
$\frac{1}{2}$ (1.125)	1.100	1.092	1.27	0.64 0.65	0.63	0.43 0.44	0.42	0.56 0.57
$\frac{5}{8}$ (1.562)	1.300	1.292	1.50	0.76 0.77	0.75	0.51 0.52	0.50	0.67 0.68
$\frac{3}{4}$ (1.875)	1.480	1.472	1.71	0.89 0.90	0.88	0.59 0.60	0.58	0.78 0.79
1	1.670	1.662	1.93	1.01 1.02	1.00	0.68 0.69	0.67	0.89 0.90
$1\frac{1}{8}$ (1.375)	2.050	2.040	2.37	1.27 1.28	1.25	0.85 0.86	0.83	1.11 1.12
$1\frac{1}{4}$ (1.625)	2.410	2.400	2.78	1.52 1.53	1.50	1.02 1.03	1.00	1.33 1.34
$1\frac{3}{8}$ (1.75)	2.760	2.750	3.19	1.77 1.78	1.75	1.19 1.20	1.17	1.55 1.56
2	3.150	3.140	3.64	2.02 2.03	2.00	1.35 1.36	1.33	1.77 1.78
$2\frac{1}{8}$ (2.375)	3.550	3.535	4.10	2.27 2.28	2.25	1.52 1.53	1.50	1.99 2.00
$2\frac{1}{4}$ (2.625)	3.890	3.875	4.49	2.52 2.53	2.50	1.69 1.70	1.67	2.21 2.22
$2\frac{3}{8}$ (2.75)	4.180	4.165	4.83	2.77 2.78	2.75	1.85 1.86	1.83	2.43 2.44
3	4.530	4.515	5.23	3.02 3.03	3.00	2.02 2.03	2.00	2.65 2.66
$3\frac{1}{8}$ (3.375)	4.850	4.830	5.60	3.27 3.28	3.25	2.19 2.20	2.17	2.86 2.88
$3\frac{1}{4}$ (3.625)	5.180	5.160	5.98	3.52 3.53	3.50	2.35 2.36	2.33	3.08 3.09
$3\frac{3}{8}$ (3.75)	5.550	5.530	6.41	3.77 3.78	3.75	2.52 2.53	2.50	3.30 3.31
4	5.950	5.930	6.87	4.02 4.03	4.00	2.69 2.70	2.67	3.52 3.53
$4\frac{1}{8}$ (4.5)	6.320	6.295	7.28	4.27 4.28	4.25	2.86 2.87	2.83	3.74 3.75
$4\frac{1}{4}$ (4.75)	6.690	6.665	7.75	4.52 4.53	4.50	3.03 3.04	3.00	3.97 3.98
$4\frac{3}{8}$ (5.0)	7.060	7.035	8.23	4.77 4.78	4.75	3.20 3.21	3.17	4.19 4.20
$4\frac{1}{2}$ (5.25)	7.430	7.405	8.70	5.02 5.03	5.00	3.37 3.38	3.33	4.41 4.42
$4\frac{3}{4}$ (5.5)	7.800	7.775	9.17	5.27 5.28	5.25	3.54 3.55	3.50	4.63 4.64
$5\frac{1}{8}$ (5.625)	8.170	8.145	9.64	5.52 5.53	5.50	3.71 3.72	3.67	4.85 4.86
$5\frac{1}{4}$ (5.875)	8.540	8.515	10.11	5.77 5.78	5.75	3.88 3.89	3.83	5.07 5.08
$5\frac{3}{8}$ (6.125)	8.910	8.885	10.58	6.02 6.03	6.00	4.05 4.06	4.00	5.29 5.30
$5\frac{1}{2}$ (6.375)	9.280	9.255	11.05	6.27 6.28	6.25	4.22 4.23	4.17	5.51 5.52

† The figures in this column represent the maximum width across the corners correct to two decimal places. The figures in italics are those for black nuts.

A chamfer of 30° from the face should be adopted on all Bright Nuts and Bolt-heads. The interior diameter of the chamfer circle should not be appreciably less than the width across the flats.

In the common locking arrangement, in which a thick and thin nut are employed, the thin nut should have a thickness approximately equal to two-thirds that of the standard nut.

Castle Nuts should be provided with pin slots as shown in Fig. A.




FIG. A.

$T = 1.25D$; $H = .75D$; $S = 0.4375D$; $C = \text{width across flats} - \frac{1}{16} \text{ in.}$; where $D = \text{full diameter of thread on bolt}$.

* Abstracted by permission of the Engineering Standards Committee from their Publication [No. 28, Revised November, 1908] Report on British Standard Nuts, Bolt-heads and Spanners.

TABLE III.

WHITWORTH STANDARD BOLTS AND NUTS. SAFE LOAD IN LBS.

Diameter of Bolt.	Threads per Inch.	Diam. at Bottom of Thread.	Area at Bottom of Thread.	APPROXIMATE SAFE LOAD IN LBS.					
				At 4000 lbs. per Sq. In.	At 5000 lbs. per Sq. In.	At 6000 lbs. per Sq. In.	At 7000 lbs. per Sq. In.	At 8000 lbs. per Sq. In.	At 9000 lbs. per Sq. In.
Inch.		Inch.	Sq. Inch.	Lbs.	Lbs.	Lbs.	Lbs.	Lbs.	Lbs.
$\frac{1}{8}$	24	0.184	0.014	56	70	84	98	112	126
$\frac{1}{4}$	20	0.186	0.027	108	135	162	189	216	243
$\frac{3}{8}$	18	0.241	0.046	184	230	276	322	378	414
$\frac{1}{2}$	16	0.295	0.068	272	340	408	478	546	614
$\frac{5}{8}$	14	0.346	0.094	376	470	564	658	752	846
$\frac{3}{4}$	12	0.398	0.121	484	605	726	850	970	1,090
$\frac{7}{8}$	12	0.455	0.155	620	775	930	1,085	1,240	1,395
$1\frac{1}{8}$	11	0.508	0.204	816	1,020	1,224	1,418	1,620	1,824
$1\frac{1}{4}$	11	0.571	0.256	1,024	1,280	1,536	1,792	2,048	2,304
$1\frac{3}{8}$	10	0.622	0.304	1,216	1,520	1,824	2,126	2,430	2,784
$1\frac{1}{2}$	10	0.684	0.367	1,468	1,835	2,202	2,569	2,986	3,403
$1\frac{3}{4}$	9	0.738	0.422	1,688	2,110	2,582	2,954	3,376	3,800
2	9	0.795	0.496	1,984	2,480	2,976	3,472	3,968	4,464
$2\frac{1}{8}$	8	0.840	0.554	2,216	2,770	3,324	3,880	4,480	4,990
$2\frac{1}{4}$	7	0.942	0.697	2,788	3,485	4,182	4,880	5,575	6,270
$2\frac{3}{8}$	7	1.067	0.894	3,576	4,470	5,364	6,250	7,145	8,085
$2\frac{1}{2}$	6	1.162	1.058	4,282	5,360	6,348	7,400	8,455	9,510
$2\frac{3}{4}$	6	1.287	1.299	5,196	6,495	7,794	9,080	10,320	11,610
3	5	1.369	1.472	5,888	7,360	8,832	10,290	11,760	13,230
$3\frac{1}{8}$	5	1.494	1.753	7,012	8,765	10,518	12,210	13,950	15,700
$3\frac{1}{4}$	4 $\frac{1}{2}$	1.590	1.986	7,944	9,980	11,916	13,900	15,890	17,875
$3\frac{3}{8}$	4 $\frac{1}{2}$	1.720	2.311	9,244	11,555	13,866	16,170	18,480	20,790
$3\frac{1}{2}$	4	1.980	2.926	11,704	14,630	17,556	20,475	23,400	26,325
$3\frac{3}{4}$	4	2.180	3.783	14,932	18,665	22,398	26,125	29,855	33,590
4	3 $\frac{1}{2}$	2.384	4.464	17,856	22,320	26,784	31,230	35,680	40,140
$4\frac{1}{8}$	3	2.634	5.450	21,800	27,250	32,700	38,080	43,520	48,960
$4\frac{1}{4}$	3 $\frac{1}{4}$	2.856	6.402	25,608	32,010	38,412	44,814	51,216	57,618
$4\frac{3}{8}$	3 $\frac{1}{4}$	3.105	7.568	30,252	37,815	45,378	52,940	60,504	68,065
$4\frac{1}{2}$	3	3.320	8.673	34,692	43,365	52,038	60,710	69,384	78,057
$4\frac{3}{4}$	2 $\frac{3}{4}$	3.573	10.027	40,108	50,135	60,162	70,180	80,216	90,240
5	2 $\frac{3}{4}$	3.804	11.365	45,480	56,825	68,190	79,575	90,960	102,305
$5\frac{1}{8}$	2 $\frac{1}{2}$	4.054	12.908	51,682	64,540	77,448	90,356	103,264	116,172
$5\frac{1}{4}$	2 $\frac{1}{2}$	4.284	14.404	57,616	72,020	86,424	100,830	115,232	129,636
$5\frac{3}{8}$	2 $\frac{1}{2}$	4.534	16.146	64,584	80,730	96,876	113,020	129,168	145,314
$5\frac{1}{2}$	2 $\frac{1}{2}$	5.012	19.720	78,880	98,600	118,320	138,040	157,760	177,480
6	2 $\frac{1}{2}$	5.487	23.640	94,560	118,200	141,840	165,300	189,120	212,760

(Reproduced by permission from the "Engineer's Year-Book.")

NOTE.—In order to allow for the twisting stress to which the bolt is subjected due to screwing up (which is, of course, in addition to the tension stress), the loads printed in heavy type should not be exceeded. Table IV. gives loads which may be safely applied to bolts for most parts of gas engines, but for the bolts coupling the flanges of breech ends and water jackets and frame the stress should never exceed 5000 lbs. per sq. in. of the area at the bottom of the thread.

TABLE IIIA.

BOLTS AND NUTS.

WHITWORTH STANDARD HEXAGON BOLTS AND NUTS.

According to the Whitworth system of standard sizes of bolts and nuts, the thickness of the bolt-head is seven-eighths of the diameter, and the nut is equal to the diameter.

Dimensions in Inches.									
Size of Bolt and Thickness of Nut.	Nut across Flats.	Nut across Corners.	Tapping Hole.	Thickness of Bolt-head.	Size of Bolt and Thickness of Nut.	Nut across Flats.	Nut across Corners.	Tapping Hole.	Thickness of Bolt-head.
$\frac{1}{8}$	.338	.390	.093	.1093	$\frac{1}{4}$	4.18	4.82	2.29	2.4062
$\frac{1}{4}$	.448	.517	.134	.164	$\frac{1}{2}$	4.34	5.02	2.5	2.5156
$\frac{3}{8}$	.525	.608	.186	.2187	$\frac{3}{4}$	4.53	5.23	2.63	2.628
$\frac{1}{2}$	.601	.694	.241	.2784	$\frac{7}{8}$	4.69	5.41	2.75	2.7343
$\frac{5}{8}$	.709	.819	.295	.3281	1	4.86	5.60	2.86	2.8256
$\frac{3}{4}$	.820	.947	.346	.3828	$1\frac{1}{8}$	5.01	5.78	2.98	2.9531
$\frac{7}{8}$	.920	1.06	.398	.4375	$1\frac{1}{4}$	5.17	5.98	3.1	3.0624
1	1.01	1.16	.455	.4921	$1\frac{3}{8}$	5.36	6.19	3.23	3.1718
$1\frac{1}{8}$	1.1	1.27	.508	.5468	$1\frac{1}{2}$	5.55	6.41	3.32	3.2812
$1\frac{1}{4}$	1.2	1.38	.571	.6016	$1\frac{3}{4}$	5.75	6.64	3.45	3.3906
$1\frac{3}{8}$	1.3	1.6	.622	.6562	2	5.95	6.87	3.57	3.5
$1\frac{1}{2}$	1.39	1.6	.684	.7084	$2\frac{1}{8}$	6.16	7.11	3.69	3.6094
$1\frac{3}{4}$	1.48	1.7	.732	.7656	$2\frac{1}{4}$	6.37	7.36	3.8	3.7046
2	1.57	1.82	.796	.8203	$2\frac{3}{8}$	6.60	7.63	3.93	3.8271
$2\frac{1}{8}$	1.67	1.95	.84	.875	$2\frac{1}{2}$	6.83	7.88	4.05	3.9374
$2\frac{1}{4}$	1.78	2.15	.942	.9843	$2\frac{5}{8}$	7.06	8.15	4.18	4.0469
$2\frac{3}{8}$	2.05	2.36	1.06	1.0987	3	7.3	8.43	4.28	4.1562
$2\frac{1}{2}$	2.21	2.55	1.16	1.2031	$3\frac{1}{8}$	7.55	8.72	4.4	4.2656
$2\frac{5}{8}$	2.41	2.78	1.28	1.3135	$3\frac{1}{4}$	7.8	9.01	4.53	4.375
$2\frac{3}{4}$	2.67	2.97	1.37	1.4128	$3\frac{3}{8}$	8.06	9.31	4.66	4.4844
3	2.75	3.18	1.49	1.5312	$3\frac{1}{2}$	8.35	9.64	4.76	4.5936
$3\frac{1}{8}$	3.02	3.48	1.59	1.6406	$3\frac{3}{4}$	8.6	9.98	4.88	4.7031
$3\frac{1}{4}$	3.15	3.63	1.71	1.75	4	8.88	10.23	5.01	4.8124
$3\frac{3}{8}$	3.34	3.85	1.84	1.8528	$4\frac{1}{8}$	9.15	10.47	5.13	4.9218
$3\frac{1}{2}$	3.54	4.09	1.93	1.9687	$4\frac{1}{4}$	9.45	10.91	5.24	5.0312
$3\frac{3}{4}$	3.75	4.33	2.05	2.0781	$4\frac{3}{8}$	9.75	11.26	5.36	5.1406
4	3.89	4.49	2.18	2.1875	5	10	11.55	5.48	5.25
$4\frac{1}{8}$	4.05	4.67	2.30	2.2968					

(Reproduced by permission from the "Engineer's Year-Book.")

TABLE IV.
SAFE LOADS ON STUDS AND BOLTS.

Diameter of Stud or Bolt.	Safe Load that one Stud or Bolt will carry in Lbs. (B.B.I. or Mild Steel).	Diameter of Stud or Bolt.	Safe Load that one Stud or Bolt will carry in Lbs. (B.B.I. or Mild Steel).
Ins.	Lbs.	Ins.	Lbs.
$\frac{1}{2}$	250	$2\frac{1}{2}$	26,100
$\frac{3}{4}$	500	$2\frac{3}{4}$	31,200
$\frac{1}{2}$	900	3	38,100
$\frac{3}{4}$	1,500	$3\frac{1}{4}$	44,800
1	2,150	$3\frac{1}{2}$	53,000
$1\frac{1}{4}$	3,000	$3\frac{3}{4}$	60,500
$1\frac{1}{2}$	4,250	4	70,100
$1\frac{3}{4}$	5,500	$4\frac{1}{4}$	79,500
$1\frac{1}{2}$	7,000	$4\frac{1}{2}$	90,800
$1\frac{3}{4}$	8,500	$4\frac{3}{4}$	100,800
$1\frac{1}{2}$	11,000	5	118,000
$1\frac{3}{4}$	13,000	$5\frac{1}{4}$	124,600
2	16,000	$5\frac{1}{2}$	138,000
$2\frac{1}{4}$	20,400		

TABLE V.
Pipe Threads.

WHITWORTH'S STANDARD THREADS FOR GAS AND WATER PIPES.

Dimensions in Inches.			Number of Threads per Inch.	Dimensions in Inches.			Number of Threads per Inch.
Internal Diameter of Pipe.	External Diameter of Pipe.	Diameter at Bottom of Thread.		Internal Diameter of Pipe.	External Diameter of Pipe.	Diameter at Bottom of Thread.	
$\frac{1}{8}$	.382	.336	28	$1\frac{1}{4}$	2.245	2.128	11
$\frac{1}{4}$	.518	.451	19	2	2.347	2.23	11
$\frac{3}{8}$	.656	.589	19	$2\frac{1}{4}$	2.467	2.351	11
$\frac{1}{2}$	.836	.734	14	$2\frac{1}{2}$	2.587	2.47	11
$\frac{5}{8}$	.902	.811	14	$2\frac{3}{4}$	2.794	2.678	11
$\frac{3}{4}$	1.04	.949	14	3	3	2.882	11
$\frac{7}{8}$	1.189	1.097	14	$3\frac{1}{4}$	3.124	3.009	11
1	1.309	1.192	11	$3\frac{1}{2}$	3.247	3.13	11
$1\frac{1}{4}$	1.492	1.375	11	$3\frac{3}{4}$	3.367	3.251	11
$1\frac{1}{2}$	1.65	1.533	11	4	3.485	3.368	11
$1\frac{3}{4}$	1.745	1.628	11	$4\frac{1}{4}$	3.698	3.581	11
$1\frac{1}{2}$	1.882	1.766	11	$4\frac{1}{2}$	3.912	3.795	11
$1\frac{3}{4}$	2.022	1.965	11	$4\frac{3}{4}$	4.125	4.008	11
$1\frac{1}{2}$	2.16	2.042	11	5	4.340	4.223	11

(Reproduced by permission from the "Engineer's Year-Book.")

FUELS.

The Heat developed by Fuels in burning, may be ascertained by calculation when their chemical composition is known. The chemical composition of various combustibles is given in the following Table.

TABLE VI.

CHEMICAL COMPOSITION OF COMBUSTIBLES.

Description.	Carbon.	Hydrogen.	Oxygen.	Ash.
Coke, average of 25 analyses	0.935	—	—	0.065
Charcoal, from wood, average	0.925	0.118	—	0.075
Oil of turpentine	0.882	0.106	—	—
Pine-wood oil	0.867	0.145	0.027	—
Paraffin, or petroleum oil	0.855	0.110	—	—
Petroleum, average	0.840	0.100	0.050	—
(Creosote, or tar-refuse)	0.825	0.075	0.075	—
Spermaceti	0.817	0.123	0.060	—
Beeswax	0.815	0.139	0.046	—
Coal, average	0.804	0.062	0.079	0.041
Schist oil	0.800	0.117	0.083	—
Resin	0.791	0.102	0.107	—
Asphalt	0.790	0.095	0.087	0.028
Tallow	0.788	0.118	0.094	—
Sperm oil	0.787	0.110	0.103	—
Olive oil	0.770	0.098	—	—
Lignite, bituminous	0.749	0.134	0.066	0.046
Lignite, perfect	0.690	0.060	0.130	0.058
Lignite, imperfect	0.602	0.075	0.202	0.058
Peat, perfectly dry	0.600	0.053	0.290	0.055
Peat, dry, average	0.600	0.060	0.300	0.040
Peat, dry, medium quality	0.570	0.060	0.320	0.050
Alcohol	0.460	0.050	0.437	0.053
Wood-pilms, or bundles of twigs, dry	0.520	0.135	0.345	—
Wood, perfectly dry, average	0.510	0.060	0.400	0.030
Wood-bark, dry	0.507	0.060	0.418	0.022
Wood, pine, dry	0.477	0.063	0.432	0.028
Wood, oak, dry	0.445	0.055	0.486	0.015
Sawdust, dry	0.430	0.053	0.498	0.021
Straw, barley, dry	0.410	0.043	0.531	0.016
Straw, wheat, dry	0.380	0.054	0.510	0.066
Straw, oat, dry	0.360	0.050	0.540	0.050
	0.318	0.060	0.567	0.045

Heating Power of Carbon.—One lb. of carbon burning to carbonic acid develops 14500 units of heat, according to Peckel, and 12900 units of heat according to Dulong.

One lb. of hydrogen develops 62535 units of heat; the heat developed by hydrogen is 62535 ÷ 14500 = 4.31 times as great as that of carbon.

One lb. of oxygen requires 8 lbs. of oxygen.

Atmospheric air contains 20 per cent. of oxygen.

The Heat developed by a Combustible, or its Calorific Power, may be calculated from its chemical constituents by this formula:—

$$\text{Units of heat} = (14500 \times \text{percentage of carbon}) + \left\{ \frac{62535 \times (\% \text{ hydrogen} - \% \text{ oxygen})}{8} \right\}.$$

(Reproduced by permission from Hutton's "Practical Engineer's Handbook," published by Crosby Lockwood and Son.)

FUELS—continued.

Gaseous Fuel.—The composition of average coal-gas is as follows:—

Hydrogen	...	...	...	...	...	51.00
Mari-gas	...	...	...	...	...	89.30
Carbon oxide	...	...	...	...	...	7.88
Oil-gas	...	...	...	...	...	3.86
Nitrogen	...	...	...	...	...	2.27
Oxygen	...	...	...	...	...	0.30
					100.00	

The Maximum Heating Power of Average Coal-Gas has been found by experiment to be 700 heat-units per cubic foot of gas. The heating power of ordinary 16-candle-power coal-gas is 630 units of heat per cubic foot. As 30 cubic feet of coal-gas at 63° Fahr. = 1 lb., the maximum heating power of 1 lb. of coal-gas is 700 × 30 = 21000 heat-units, or more than 80 per cent. greater than that of coal of average quality.

TABLE VII.

QUANTITY OF GAS IN CUBIC FEET OBTAINED FROM COAL.

Description of Coal.	Specific Gravity of Gas.	Cubic feet of Gas obtained per Ton of Coal.	Weight in lbs. of Gas per Ton of Coal.
Bighead	0.752	15000	866
Capella	0.577	14400	638
Leamington	0.618	13200	627
Armiton	0.626	12600	606
Newcastle	0.475	11648	423
Welsh	0.737	11424	645
Pelaw	0.444	11424	389
Pelton	0.437	11424	387
Bickersstaff, Liverpool	0.475	11424	415
Wigan	0.528	11400	461
Garsfield	0.398	10600	321
Powell	0.459	10165	357
Forest of Dean	0.360	10153	279
South Staffordshire	0.370	9600	235
Derby's Deep Main	0.424	9400	308
Derby's Soft Coal	0.528	7500	303
Leeds	0.530	6800	264

The volume of gas in cubic feet may be reduced to weight in lbs. by multiplying the volume by the specific gravity of the gas and by the constant number 0.076.

One Ton of Crude Petroleum will yield 21000 cubic feet of good gas.

(Reproduced by permission from Hutton's "Practical Engineer's Handbook," published by Crosby Lockwood and Son.)

TABLE VIII.

COMPOSITION AND CALORIFIC POWER OF DOWSON'S WATER-GAS, AND OF
ORDINARY 16 CANDLE-POWER COAL-GAS.

Composition of the Gas.	ORDINARY COAL-GAS, 16 CANDLE- POWER.			DOWSON'S GENERATOR-GAS, OR WATER-GAS.		
	Volume per Cent. at 0 deg. Cent. and 760 mm.	Weight in Grammes of 100 Litres.	Calorific Power of 100 Litres.	Volume per Cent. at 0 deg. Cent. and 760 mm.	Weight in Grammes of 100 Litres.	Calorific Power of 100 Litres.
Hydrogen	51.81	4.68	159,559	18.73	1.67	57,689
Marsh gas	35.25	25.20	829,187	0.81	0.22	2,899
Olefiant gas	8.58	4.41	52,664	0.81	0.38	4,638
Carbonic oxide	8.95	11.20	27,854	25.07	31.86	77,992
„ acid	—	—	—	6.57	12.91	—
Oxygen	0.08	0.11	—	0.08	0.04	—
Nitrogen	0.88	0.47	—	48.98	61.27	—
	100.00	46.02	569,264	100.00	107.85	148,218

(Reproduced by permission from Hutton's "Practical Engineer's Handbook," published by
Crosby Lockwood and Son.)

TABLE IX.

TABLE FOR THE CONVERSION OF DEGREES ON THE CENTIGRADE THERMOMETER INTO
THOSE OF FAHRENHEIT'S SCALE.

Cent.	Fahr.	Cent.	Fahr.	Cent.	Fahr.	Cent.	Fahr.	Cent.	Fahr.	Cent.	Fahr.
-100	-148.0	-55	-67.0	-10	14.0	35	95.0	80	176.0	125	257.0
-99	-146.2	-54	-65.2	-9	15.8	36	96.8	81	177.8	126	258.8
-98	-144.4	-53	-63.4	-8	17.6	37	98.6	82	179.6	127	260.6
-97	-142.6	-52	-61.6	-7	19.4	38	100.4	83	181.4	128	262.4
-96	-140.8	-51	-59.8	-6	21.2	39	102.2	84	183.2	129	264.2
-95	-139.0	-50	-58.0	-5	23.0	40	104.0	85	185.0	130	266.0
-94	-137.2	-49	-56.2	-4	24.8	41	105.8	86	186.8	131	267.8
-93	-135.4	-48	-54.4	-3	26.6	42	107.6	87	188.6	132	269.6
-92	-133.6	-47	-52.6	-2	28.4	43	109.4	88	190.4	133	271.4
-91	-131.8	-46	-50.8	-1	30.2	44	111.2	89	192.2	134	273.2
-90	-130.0	-45	-49.0	0	32.0	45	113.0	90	194.0	135	275.0
-89	-128.2	-44	-47.2	+ 1	33.8	46	114.8	91	195.8	136	276.8
-88	-126.4	-43	-45.4	2	35.6	47	116.6	92	197.6	137	278.6
-87	-124.6	-42	-43.6	3	37.4	48	118.4	93	199.4	138	280.4
-86	-122.8	-41	-41.8	4	39.2	49	120.2	94	201.2	139	282.2
-85	-121.0	-40	-40.0	5	41.0	50	122.0	95	203.0	140	284.0
-84	-119.2	-39	-38.2	6	42.8	51	123.8	96	204.8	141	285.8
-83	-117.4	-38	-36.4	7	44.6	52	125.6	97	206.6	142	287.6
-82	-115.6	-37	-34.6	8	46.4	53	127.4	98	208.4	143	289.4
-81	-113.8	-36	-32.8	9	48.2	54	129.2	99	210.2	144	291.2
-80	-112.0	-35	-31.0	10	50.0	55	131.0	100	212.0	145	293.0
-79	-110.2	-34	-29.2	11	51.8	56	132.8	101	213.8	146	294.8
-78	-108.4	-33	-27.4	12	53.6	57	134.6	102	215.6	147	296.6
-77	-106.6	-32	-25.6	13	55.4	58	136.4	103	217.4	148	298.4
-76	-104.8	-31	-23.8	14	57.2	59	138.2	104	219.2	149	300.2
-75	-103.0	-30	-22.0	15	59.0	60	140.0	105	221.0	150	302.0
-74	-101.2	-29	-20.2	16	60.8	61	141.8	106	222.8	151	303.8
-73	-99.4	-28	-18.4	17	62.6	62	143.6	107	224.6	152	305.6
-72	-97.6	-27	-16.6	18	64.4	63	145.4	108	226.4	153	307.4
-71	-95.8	-26	-14.8	19	66.2	64	147.2	109	228.2	154	309.2
-70	-94.0	-25	-13.0	20	68.0	65	149.0	110	230.0	155	311.0
-69	-92.2	-24	-11.2	21	69.8	66	150.8	111	231.8	156	312.8
-68	-90.4	-23	-9.4	22	71.6	67	152.6	112	233.6	157	314.6
-67	-88.6	-22	-7.6	23	73.4	68	154.4	113	235.4	158	316.4
-66	-86.8	-21	-5.8	24	75.2	69	156.2	114	237.2	159	318.2
-65	-85.0	-20	-4.0	25	77.0	70	158.0	115	239.0	160	320.0
-64	-83.2	-19	-2.2	26	78.8	71	159.8	116	240.8	161	321.8
-63	-81.4	-18	-0.4	27	80.6	72	161.6	117	242.6	162	323.6
-62	-79.6	-17	+ 1.4	28	82.4	73	163.4	118	244.4	163	325.4
-61	-77.8	-16	+ 3.2	29	84.2	74	165.2	119	246.2	164	327.2
-60	-76.0	-15	+ 5.0	30	86.0	75	167.0	120	248.0	165	329.0
-59	-74.2	-14	+ 6.8	31	87.8	76	168.8	121	249.8	166	330.8
-58	-72.4	-13	+ 8.6	32	89.6	77	170.6	122	251.6	167	332.6
-57	-70.6	-12	+ 10.4	33	91.4	78	172.4	123	253.4	168	334.4
-56	-68.8	-11	+ 12.2	34	93.2	79	174.2	124	255.2	169	336.2

TABLE FOR THE CONVERSION OF DEGREES (continued).

°Cent.	°Fahr.	°Cent.	°Fahr.	°Cent.	°Fahr.	°Cent.	°Fahr.	°Cent.	°Fahr.	°Cent.	°Fahr.
170	338.0	210	410.0	250	482.0	290	554.0	330	626.0	440	824
171	339.8	211	411.8	251	483.8	291	555.8	331	627.8	450	842
172	341.6	212	413.6	252	485.6	292	557.6	332	629.6	460	860
173	343.4	213	415.4	253	487.4	293	559.4	333	631.4	470	878
174	345.2	214	417.2	254	489.2	294	561.2	334	633.2	480	896
175	347.0	215	419.0	255	491.0	295	563.0	335	635.0	482	900
176	348.8	216	420.8	256	492.8	296	564.8	336	636.8	490	914
177	350.6	217	422.6	257	494.6	297	566.6	337	638.6	500	932
178	352.4	218	424.4	258	496.4	298	568.4	338	640.4	538	1000
179	354.2	219	426.2	259	498.2	299	570.2	339	642.2	593	1100
180	356.0	220	428.0	260	500.0	300	572.0	340	644.0	600	1112
181	357.8	221	429.8	261	501.8	301	573.8	341	645.8	649	1200
182	359.6	222	431.6	262	503.6	302	575.6	342	647.6	700	1292
183	361.4	223	433.4	263	505.4	303	577.4	343	649.4	704	1300
184	363.2	224	435.2	264	507.2	304	579.2	344	651.2	760	1400
185	365.0	225	437.0	265	509.0	305	581.0	345	653.0	800	1472
186	366.8	226	438.8	266	510.8	306	582.8	346	654.8	815	1500
187	368.6	227	440.6	267	512.6	307	584.6	347	656.6	871	1600
188	370.4	228	442.4	268	514.4	308	586.4	348	658.4	900	1652
189	372.2	229	444.2	269	516.2	309	588.2	349	660.2	928	1700
190	374.0	230	446.0	270	518.0	310	590.0	350	662.0	972	1800
191	375.8	231	447.8	271	519.8	311	591.8	351	663.8	1000	1832
192	377.6	232	449.6	272	521.6	312	593.6	352	665.6	1087	1900
193	379.4	233	451.4	273	523.4	313	595.4	353	667.4	1093	2000
194	381.2	234	453.2	274	525.2	314	597.2	354	669.2	1100	2012
195	383.0	235	455.0	275	527.0	315	599.0	355	671.0	1148	2100
196	384.8	236	456.8	276	528.8	316	600.8	356	672.8	1200	2192
197	386.6	237	458.6	277	530.6	317	602.6	357	674.6	1300	2372
198	388.4	238	460.4	278	532.4	318	604.4	358	676.4	1400	2552
199	390.2	239	462.2	279	534.2	319	606.2	359	678.2	1500	2732
200	392.0	240	464.0	280	536.0	320	608.0	360	680.0	1600	2912
201	393.8	241	465.8	281	537.8	321	609.8	370	698	1700	3092
202	395.6	242	467.6	282	539.6	322	611.6	371	700	1800	3272
203	397.4	243	469.4	283	541.4	323	613.4	380	716	1900	3452
204	399.2	244	471.2	284	543.2	324	615.2	390	732	2000	3632
205	401.0	245	473.0	285	545.0	325	617.0	400	748	2100	3812
206	402.8	246	474.8	286	546.8	326	618.8	410	764	2200	3992
207	404.6	247	476.6	287	548.6	327	620.6	420	780	2300	4172
208	406.4	248	478.4	288	550.4	328	622.4	430	796	2400	4352
209	408.2	249	480.2	289	552.2	329	624.2	440	812	2500	4532

(Reproduced by permission from the "Engineer's Pocket-Book.")

TABLE X.

TABLE FOR THE CONVERSION OF DEGREES ON THE FAHRENHEIT THERMOMETER INTO
THOSE OF THE CENTIGRADE SCALE.

°Fahr.	°Cent.	°Fahr.	°Cent.	°Fahr.	°Cent.	°Fahr.	°Cent.	°Fahr.	°Cent.	°Fahr.	°Cent.
212	100.0	193	89.4	174	78.8	155	68.2	136	57.7	117	47.2
211	99.4	192	88.8	173	78.2	154	67.7	135	57.2	116	46.6
210	98.8	191	88.2	172	77.7	153	67.2	134	56.6	115	46.1
209	98.3	190	87.7	171	77.2	152	66.6	133	56.1	114	45.5
208	97.7	189	87.2	170	76.6	151	66.1	132	55.5	113	45.0
207	97.2	188	86.6	169	76.1	150	65.5	131	55.0	112	44.4
206	96.6	187	86.1	168	75.5	149	65.0	130	54.4	111	43.8
205	96.1	186	85.5	167	75.0	148	64.4	129	53.8	110	43.3
204	95.5	185	85.0	166	74.4	147	63.8	128	53.3	109	42.7
203	95.0	184	84.4	165	73.8	146	63.3	127	52.7	108	42.2
202	94.4	183	83.8	164	73.3	145	62.7	126	52.2	107	41.6
201	93.8	182	83.3	163	72.7	144	62.2	125	51.6	106	41.1
200	93.2	181	82.7	162	72.2	143	61.6	124	51.1	105	40.5
199	92.7	180	82.2	161	71.6	142	61.1	123	50.5	104	40.0
198	92.2	179	81.6	160	71.1	141	60.5	122	50.0	103	39.4
197	91.6	178	81.1	159	70.5	140	60.0	121	49.4	102	38.8
196	91.1	177	80.5	158	70.0	139	59.4	120	48.8	101	38.3
195	90.6	176	80.0	157	69.4	138	58.8	119	48.3	100	37.7
194	90.4	175	79.4	156	68.8	137	58.3	118	47.7	99	37.2

(Reproduced by permission from the "Engineer's Year-Book.")

TABLE XI.

METRIC PRESSURES IN KILOGRAMMES PER SQUARE CENTIMETRE WITH
EQUIVALENTS IN POUNDS PER SQUARE INCH.

Kilos per Sq. Cm.	Lbs. per Sq. Inch.	Kilos per Sq. Cm.	Lbs. per Sq. Inch.	Kilos per Sq. Cm.	Lbs. per Sq. Inch.	Kilos per Sq. Cm.	Lbs. per Sq. Inch.
·1	1·422	3·1	44·091	6·1	86·761	9·1	129·431
·2	2·844	3·2	45·514	6·2	88·183	9·2	130·853
·3	4·266	3·3	46·936	6·3	89·606	9·3	132·275
·4	5·689	3·4	48·358	6·4	91·028	9·4	133·698
·5	7·111	3·5	49·781	6·5	92·450	9·5	135·120
·6	8·533	3·6	51·203	6·6	93·873	9·6	136·542
·7	9·956	3·7	52·625	6·7	95·295	9·7	137·965
·8	11·378	3·8	54·048	6·8	96·717	9·8	139·387
·9	12·800	3·9	55·470	6·9	98·140	9·9	140·809
1	14·223	4	56·892	7	99·562	10	142·232
1·1	15·645	4·1	58·315	7·1	100·984	10·5	149·343
1·2	17·067	4·2	59·737	7·2	102·407	11	156·455
1·3	18·490	4·3	61·159	7·3	103·829	11·5	163·566
1·4	19·912	4·4	62·582	7·4	105·251	12	170·678
1·5	21·334	4·5	64·004	7·5	106·674	12·5	177·790
1·6	22·757	4·6	65·426	7·6	108·096	13	184·901
1·7	24·179	4·7	66·849	7·7	109·518	13·5	192·013
1·8	25·601	4·8	68·271	7·8	110·940	14	199·124
1·9	27·024	4·9	69·693	7·9	112·363	14·5	206·236
2	28·445	5	71·116	8	113·785	15	213·348
2·1	29·868	5·1	72·538	8·1	115·207	15·5	220·459
2·2	31·291	5·2	73·960	8·2	116·630	16	227·571
2·3	32·713	5·3	75·382	8·3	118·052	16·5	234·682
2·4	34·135	5·4	76·805	8·4	119·474	17	241·794
2·5	35·558	5·5	78·227	8·5	120·897	17·5	248·906
2·6	36·980	5·6	79·649	8·6	122·319	18	256·017
2·7	38·402	5·7	81·072	8·7	123·741	18·5	263·129
2·8	39·824	5·8	82·494	8·8	125·164	19	270·240
2·9	41·247	5·9	83·916	8·9	126·586	19·5	277·352
3	42·669	6	85·339	9	128·008	20	284·464

(Reproduced by permission from the "Engineer's Year-Book.")

MOMENTS OF INERTIA, MODULI OF SECTIONS, BEAMS, AND BENDING MOMENTS.

TABLE XII.



TABLE OF MOMENTS OF INERTIA AND RESISTANCE OF VARIOUS SECTIONS.		
Form of Section	Moment of Inertia through Centre of Gravity	Modulus of Section = Z_b
 RECTANGLE.	$\frac{bh^3}{12}$	$\frac{bd^2}{6}$
 RECTANGLE.	$\frac{b}{12}(d^3 - d_1^3)$	$\left\{ \frac{b}{6}(d^2 - d_1^2) \right\}$
 TRIANGLE.	$\frac{bd^3}{36}$	$\frac{bd^2}{24}$

TABLE OF MOMENTS OF INERTIA, &c.— <i>cont.</i>		
Form of Section	Moment of Inertia through Centre of Gravity	Modulus of Section = Z_b
 SQUARE.	$\frac{d^4}{12}$	$\frac{d^3}{6}$
 SQUARE.	$\frac{d^4}{12}$	$\cdot 118d^3$
 HEXAGON.	$\frac{b}{16}b^4\sqrt{3}$ = $\cdot 5413b^4$	$\frac{b}{8}b^3$ = $\cdot 625b^3$
 HEXAGON.	$\frac{b}{16}b^4\sqrt{3}$ = $\cdot 5413b^4$	$\frac{b}{16}b^3\sqrt{3}$ = $\cdot 5413b^3$
 OCTAGON.	$\frac{1 + 2\sqrt{2}}{6}b^4$ = $\cdot 698b^4$	$\cdot 6906b^3$
Regular polygon with b = side. r = radius of circum- scribed circle. a = area = $\frac{nr^2}{2} \sin. \frac{2\pi}{n}$.	$\frac{a}{12}(3r^2 - \frac{b^2}{2})$	$\frac{ra}{4}$
 CIRCLE.	$\frac{\pi d^4}{64}$ = $\frac{\pi r^4}{4}$ = $\cdot 7854r^4$	$\frac{\pi d^3}{92}$ = $\cdot 7854r^3$



TABLE OF MOMENTS OF INERTIA, &c.— <i>cont.</i>		
Form of Section	Moment of Inertia through Centre of Gravity	Modulus of Section = Z_y
	$\frac{bd^3 + b_1d_1^3}{12}$	$\frac{bd^2 + b_1d_1^2}{6d}$
	<i>Note.</i>—The moment of inertia of a hollow section about any axis is equal to the moment of inertia of the whole section taken as solid about that axis and then deducting the moment of the hollow part from it about the same axis.	
	$\frac{bd^3 - b_1d_1^3}{12}$	$\left(\frac{bd^2 - b_1d_1^2}{6d} \right)$

TABLE OF MOMENTS OF INERTIA, &c.— <i>cont.</i>		
Form of Section	Moment of Inertia through Centre of Gravity	Modulus of Section = Z_y
	$\frac{\pi}{64} (d^4 - d_1^4)$	$\frac{\pi}{32} \left(\frac{d^4 - d_1^4}{d} \right)$
	$\frac{\pi}{4} (r^4 - r_1^4)$	$\frac{\pi}{4} \left(\frac{r^4 - r_1^4}{r} \right)$
	$.110d^4$	$.19r^3$
	$\frac{.110(r^4 - r_1^4)}{r + r_1}$	$\frac{I}{y}$
	$\frac{\pi bd^3}{64} = .0491bd^3$	$\frac{\pi bd^2}{32} = .0982bd^2$
	$\frac{d^4 - d_1^4}{12}$	$\frac{1}{6} \left(\frac{d^4 - d_1^4}{d} \right)$
	$\frac{d^4 - d_1^4}{12}$	$\left(\frac{d^4 - d_1^4}{12d}, \sqrt{2} \right)$ $= .1178 \left(\frac{d^4 - d_1^4}{d} \right)$

TABLE XIII.

TABLE OF MOMENTS OF INERTIA AND MODULI Z_0 FOR CIRCULAR SECTIONS.									
Diameter in Inches	Moment of Inertia	Modulus	Diameter in Inches	Moment of Inertia	Modulus	Diameter in Inches	Moment of Inertia	Modulus	Diameter in Inches
1	0.0491	0.0082	35	73623	4209	69	1112660	33251	
2	0.7854	0.7854	36	82148	4580	70	1178688	33674	
3	3.976	3.951	37	91908	4973	71	1247393	35138	
4	12.67	6.383	38	102354	5387	73	1319167	36644	
5	30.48	12.37	39	113561	5824	75	1393996	38198	
6	53.62	21.21	40	125664	6283	77	1471963	39783	
7	81.79	33.67	41	138709	6766	79	1553156	41417	
8	114.9	50.27	42	152745	7274	81	1637662	43096	
9	152.1	71.57	43	167830	7806	83	1725571	44830	
10	194.09	98.17	44	183984	8363	85	1816973	46589	
11	240.9	130.7	45	201289	8946	87	1911967	48404	
12	292.8	169.6	46	219787	9556	89	2010819	50286	
13	350.7	215.7	47	239331	10193	91	2113051	52174	
14	414.6	269.4	48	260076	10857	93	2219347	54130	
15	484.5	331.3	49	282979	11550	95	2339605	56135	
16	560.4	402.1	50	308796	12272	97	2474390	58189	
17	642.3	482.3	51	336866	13023	99	2623392	60293	
18	730.2	572.6	52	367233	13804	101	2786120	62446	
19	824.1	673.4	53	399988	14616	103	2963120	64648	
20	924.0	785.4	54	435233	15459	105	3154849	66933	
21	1030.0	909.2	55	473088	16334	107	3361657	69310	
22	1142.1	1045	56	513566	17241	109	3584165	71689	
23	1260.2	1191	57	556807	18181	111	3822833	73982	
24	1384.3	1357	58	602947	19155	113	4077992	76448	
25	1514.4	1534	59	652048	20163	115	4349992	78988	
26	1650.5	1724	60	704272	21206	117	4638492	81642	
27	1792.6	1927	61	759681	22284	119	4943092	84413	
28	1940.7	2145	62	818339	23398	121	5264392	86933	
29	2094.8	2379	63	879333	24548	123	5602092	89601	
30	2254.9	2627	64	942760	25736	125	5956892	92401	
31	2421.0	2895	65	1009637	26961	127	6329292	95259	
32	2593.1	3177	66	1079964	28226	129	6719892	98176	
33	2771.2	3473	67	1153841	29537				
34	2955.3	3783	68	1231368	30889				

(Reproduced by permission from Mackrow's "Naval Architects' Pocket-book.")

TABLE OF MOMENTS OF INERTIA, &C.— <i>cont.</i>		
Form of Section	Moment of Inertia through Centre of Gravity	Modulus of Section = Z_0
	$\frac{1}{3} \{ by_1^3 - b_1 y^3 \}$	$\frac{I}{y}$
	$\frac{1}{3} \{ b d_1^3 - (b - b_1)(d_1 - a_1)^3 + b_1 d_1^3 \}$ $- \frac{1}{3} \{ (b_1 - b)(d_1 - a_1)^3 \}$	

*General Expressions for applying the above Table.*Let M_0 = greatest bending moment. y = modulus of the section. f = distance of neutral axis from part under greatest stress.
 f = greatest tensile or compressive stress on unit of cross section. I = moment of inertia of cross section. E = modulus of elasticity of material. r = radius of curvature.

$$\frac{f}{r} = \frac{M}{I} = \frac{E}{r}$$

Then

$$M = \frac{f I}{y} = \frac{E I}{r}$$

$$f = \frac{M y}{I} = \frac{E y}{r}$$

$$E = \frac{f r}{y} = \frac{M r}{I}$$

$$r = \frac{E I}{M} = \frac{E y}{f}$$

Note.—All measurements to be taken in inches or pounds as required.

(Reproduced by permission from Mackrow's "Naval Architects' Pocket-book.")




FIG. A.

TABLE XIV.

External Diameter In Inches		Thickness in Inches:									
		1-3	1-5	1-8	2-0	2-3	2-5	2-8	3-0	3-5	
10	327.1 65.42	875.0 74.99	405.5 61.70	427.8 66.45							
11	405.3 81.06	517.5 84.11	571.5 105.9	605.8 115.8							
12	501.0 100.2	605.8 116.0	775.5 128.9	816.8 138.1	900.0 142.4	150.0					
13	792.8 158.5	911.1 146.3	1019 165.8	1080 168.1	1134 174.4	1201 184.8					
14	995.9 199.1	1107 187.4	1311 207.1	1395 219.8	1465 228.4	1564 239.9					
15	1248 250.5	1407 281.4	1655 305.5	1705 315.8	1865 345.8	1934 355.9					
16	1588 317.6	1615 325.9	2065 371.9	2139 381.1	2299 391.3	2408 403.8					
17	1989 397.8	2014 402.8	2571 411.9	2638 418.7	2838 445.6	2909 456.5					
18	2446 489.2	2468 495.4	3043 507.3	3097 511.9	3475 545.6	3503 556.8					
19	2980 596.0	3040 607.3	3695 620.0	3712 628.3	4108 702.3	4211 714.9					
20	3754 750.8	3808 761.4	4508 900.0	4577 910.4	5099 1024.4	5148 1037.7					
25											
35											
37.5											
40											
45											
50											
55											
60											
65											
70											
75											
80											
85											
90											
95											
100											

Note.—The first figures given are the moments of inertia, and the second the modulus.

(Reproduced by permission from Mackrow's "Naval Architects' Pocket-book.")

BEAMS.

GRAPHICAL METHOD OF DETERMINING THE BENDING MOMENTS AND SHEARING FORCES IN A BEAM.
Concentrated Loads acting at various Points.




FIG. 1.

In fig. 1 AB represents the beam supported at points A and B. Set off continuously along a line EF the forces w^1, w^2, w^3, w^4 — C', C', C', C' , the resultant of the forces. Take any point O, and join


$OC^1, OC^2, \dots, OC^4$, &c. Draw the parallel lines $AD^0, WD^1, \dots, BD^0$ through the lines of action of the forces. Take any point, D^0 in AD^0 , and draw D^0, D^1 parallel to OC^0, D^1, D^2 parallel to $OC^1, \dots, D^1, D^4$ parallel to OC^4 . Join D^0, D^4 , completing the funicular polygon D^0, D^1, D^2, D^3, D^4 . Draw a line OC parallel to D^0, D^4 , cutting EF in C ; then C^0C equals the supporting force at A , and OC^4 equals the supporting force at B . Also through O draw OH perpendicular to EF .

Through the points $C^0, C^1, \dots, C^4$ drop perpendiculars on to $AD^0, WD^1, \dots, BD^0$, and form the hatched figure $g^0ks^0qs^4$. Then the vertical ordinate of this diagram, measured at any point in the length of the beam, gives the shearing force at that point, measured on the same scale as used for setting off w^1, w^2 , &c. To obtain the bending moment at any point x make a scale as follows:—

If beam is drawn to a scale 1 foot = x inches, and loads are drawn to a scale 1 pound = z inches, then the ordinate ' y ' of the funicular polygon is the bending moment at the point x on a scale such that 1 foot-pound is $\frac{x \times y}{OH}$, in inches always; OH is measured on an inch scale.

Forces acting in different directions.

FIG. 2.



These diagrams are constructed in a similar manner to (fig. 1), the lengths of the forces being also set off in the direction

of their line of action. C^0O is the supporting force at A , and OC^4 the holding down force at B as it lies to the left of C —that is, it is measured in the opposite direction to C^0C^1 ; the bending moment at any point O' where the sides of the funicular polygon cross is zero, and the bending moments to the left of O' are in the opposite direction to those on the right of O' .

TABLE XV.

TABLE OF GRAPHICAL BENDING MOMENTS AND SHEARING FORCES OF BEAMS.

W = load. L = length of beam.
 w = uniform intensity of load.
 M = maximum bending moment.
 m = bending moment at any section.
 s_1 = maximum shearing force.
 s = shearing force at any section.


The diagrams are constructed by setting off to scale M , and s_1 , or s ; then the ordinate measured at any point represents the moment or shearing force at that section.

Bending Moment

Shearing Force

FIG. 3.

FIG. 4.



Set down $s = w$ parallel to AC .

Set down $M = WL$, and join BC .

TABLE OF GRAPHICAL BENDING MOMENTS, &C.— <i>cont.</i>		TABLE OF GRAPHICAL BENDING MOMENTS, &C.— <i>cont.</i>	
Bending Moments	Shearing Forces	Bending Moments	Shearing Forces
<i>Fixed at one end and loaded uniformly.</i> FIG. 6. Set off $M = \frac{wL^2}{2}$; draw the parabola BC, whose vertex is at B.		<i>Fixed at one end with several concentrated loads.</i> FIG. 12. Set off $s = W_1, s_1 = W_1, s_2 = W_1 + W_2$ and construct the rectangles ABDE, EFGH, and HKCJ.	
<i>Fixed at one end, uniformly loaded, with additional weight at one end.</i> FIG. 7. Set off $M = WL$, and $M_1 = \frac{wL^2}{2}$. Join DB, and construct the parabola BC whose vertex is at B.		<i>Supported at both ends, loaded at centre.</i> FIG. 11. Set off s and $s = \frac{W}{2}$, and construct the rectangles ACDE and BGFE.	
<i>Fixed at one end, partially uniformly loaded.</i> FIG. 9. Set off $M = wz(1 - \frac{s}{2})$. Join O to a point D at middle of load. Draw BE, a semiparabola, as for a beam uniformly loaded of a length s.		<i>Supported at both ends, uniformly loaded.</i> FIG. 16. Set off s_1 above and s_1 below $\frac{wL}{2}$, and join DC.	


TABLE OF GRAPHICAL BENDING MOMENTS, &C.—cont.

Bending Moments

Shearing Forces


Supported at both ends, load out of centre.

FIG. 17.



Set off $M = \frac{Wab}{L}$, and join AC and BC.


FIG. 18.



Set off $s = \frac{Wb}{L}$, and $s_1 = \frac{Wa}{L}$, and construct rectangles ACDE and EBGF.

Supported at both ends, unequally distributed loads.

FIG. 19.




The bending moment at any point is equal to the sum of the bending moments produced at that point by each of the weights separately. Set off

$$M = \frac{W_1 a_1 b_1}{L}, M_1 = \frac{W_1 a_1 b_1}{L}, M_2 = \frac{W_2 a_2 b_2}{L}$$

Then set up JH, KG, and NF, making the length for whole ordinates equal to the sum of the three ordinates at those points due to the several bending moments.

FIG. 20.



Set up

$$s = \frac{Wb + W_1 h_1 + W_2 h_2}{L}$$

$$s_1 = \frac{Wb + W_1 h_1 + W_2 h_2 - W_2 a_2}{L}$$

$$s_2 = \frac{Wb + W_1 h_1 + W_2 h_2 - W_2 a_1}{L}$$

$$s_3 = \frac{Wb + W_1 h_1 + W_2 h_2 - W_2 a_1 - W_1 a_2}{L}$$

$$= \frac{Wb + W_1 a_1 + W_2 a_2}{L}$$


TABLE OF GRAPHICAL BENDING MOMENTS, &C.—cont.

Bending Moments

Shearing Forces


Supported at both ends, and partial uniform load not extending to either support.

FIG. 21.



Set off OD at centre of load $= \frac{wz^2}{2L}$, and join AC and BC; at ends of z erect perpendiculars HF and EG, cutting AC and BC in H and E. Join D and E, then on z draw the parabola FEK, whose middle ordinate equals $\frac{wz^2}{8}$.

FIG. 22.




$$\text{Set up } s = \frac{wz}{2L} (2L - 2z - z),$$

$$\text{and } s_1 = \frac{wz}{2L} (2z + z),$$

and construct the diagram as in figure.


Supported at both ends, with partial uniform load extending to one support.

FIG. 23.



Set up $CD = \frac{wz(2L-z)}{2L}$; then draw underneath the parabola AED, whose ordinate at centre $= \frac{wz^2}{8}$.

FIG. 24.









$$\text{Set up } s \text{ at } A = \frac{wz(2L-z)}{2L},$$

$$\text{and set down } s_1 = \frac{wz^2}{2L},$$

and construct the diagram.

(Reproduced by permission from Mackenzie's "Naval Architects' Pocket-book.")

TABLE XVI.

TABLE OF BEAMS OF EQUAL STRENGTH THROUGHOUT THEIR LENGTH.	
<i>Note.</i> —The sections are in all cases supposed to be rectangular.	
FIG. A.	
	<i>Depth equal throughout.</i> Breadth proportional to distance from loaded end.
FIG. B.	
	<i>Depth equal throughout.</i> Breadth proportional to square of distance from unsupported end.
<i>Breadth equal throughout.</i> Depth proportional to square root of distance from loaded end.	FIG. C.
	
<i>Breadth equal throughout.</i> Depth proportional to distance from unsupported end.	FIG. D.
	
<i>Depth equal throughout.</i> Breadth proportional to distance from nearest point of support.	FIG. E.
	
<i>Depth equal throughout.</i> Breadth proportional to product of distance from both points of support.	FIG. F.
	
<i>Breadth equal throughout.</i> Depth proportional to the square root of the distance from the nearest point of support.	FIG. G.
	
<i>Breadth equal throughout.</i> Depth proportional to the square root of the product of distance from both points of support.	FIG. H.
	

(Reproduced by permission from Mackrow's "Naval Architects' Pocket-book.")

TABLE XVIII.

FRENCH MEASURES OF LENGTH.

	Metrs.	English Equivalents.
1 millimetre	= 0.001	= 0.08937 inch, or $\frac{1}{16}$ inch nearly.
10 millimetres	= 1 centimetre	= 0.01 = 0.3937 inch.
10 centimetres	= 1 decimetre	= 0.1 = 3.93704 inches, or 4 inches nearly.
10 decimetres	{	{
100 centimetres		
1000 millimetres		
	= 1 METRE	= 1 = { 39.3704 inches 3.2809 feet.

(Reproduced by permission from D. K. Clark's "Mechanical Engineer's Pocket-book.")

TABLE XVII.

LIQUID MEASURE.

	L'tres	
1 centilitre	(0.61025 cubic inch.	
10 cubic centi- metres	{ 0.01 { 0.0704 gill. 6.1025 cubic inches.	
... 1 décilitre	... 0.01 { 0.1761 pint.	
... { 1 LITRE	{ 61.02524 cubic ins.	
... { (1 cubic deci- metre)	{ 0.2201 gallon.	
10 litres	... 10 { 2.2009 gallons.	
10 décalitres	... 100 { 22.009 gallons.	

DRY MEASURE.

10 litres	... 1 décalitre	... 10 { 2.2009 gallons.
10 décalitres	... 1 hectolitre	... 100 { 22.009 gallons.
10 hectolitres	... { 1 kilolitre	{ 220.09 bushels.
	{ (1 cubic metre)	{ 1000 { 220.09 bushels.

The use of measures equal to a double-litre, a half-litre, a double-décilitre, a half-décilitre, is sanctioned by law.

(Reproduced by permission from D. K. Clark's "Mechanical Engineer's Pocket-book.")

TABLE XIX.

FRENCH MEASURES OF SURFACE.

	Square Metres.	English Equivalents.
1 square millimetre	0.000001	0.00155 square inch.
100 square millimetres	{ 1 square metre	{ 0.0001 { 0.155 square inch.
100 square centimetres	{ 1 square metre	{ 0.01 { 15.5008 square ins.
100 square decimetres	{ 1 square centiare	{ 10.7641 square feet.
10,000 square centimetres		{ 1.1960 square yards

(Reproduced by permission from D. K. Clark's "Mechanical Engineer's Pocket-book.")

TABLE XX.

FRENCH MEASURES OF WEIGHT.

	Grammes.	English Equivalents.
1 milligramme	0.001	0.0154 grain.
10 milligrammes	1 centigramme	0.01 { 0.1543 grain.
10 centigrammes	1 decigramme	0.1 { 1.5432 grains.
10 decigrammes	{ 1 GRAMME { (unit of weight)	{ 1 { 15.4323 grains.
10 grammes	1 décagramme	10 { 154.3235 grains.
10 dédagrammes	1 hectogramme	100 { 8.5274 ounce.
100 dédagrammes	1 KILOGRAMME	1000 { 1543.2349 grains.
100 hectogrammes	1 metric quintal	1000 { 22046 pounds.
10 quintals, or	1 millier, or	{ 2204.6212 pounds.
1000 kilogrammes	tonne	{ 19.6841 cwts. 0.9842 ton.

(Reproduced by permission from D. K. Clark's "Mechanical Engineer's Pocket-book.")

MILLIMETRES TO INCHES.

Milli- metres	Inches and Decimals of an Inch	Milli- metres	Inches and Decimals of an Inch	Milli- metres	Inches and Decimals of an Inch
117	4.606341	165	6.486121	213	8.385902
118	4.645711	166	6.535492	214	8.425272
119	4.685081	167	6.574862	215	8.464643
120	4.724452	168	6.614233	216	8.504013
121	4.763822	169	6.653603	217	8.543384
122	4.803193	170	6.692973	218	8.582754
123	4.842563	171	6.732344	219	8.622125
124	4.881934	172	6.771714	220	8.661495
125	4.921304	173	6.811085	221	8.700866
126	4.960674	174	6.850455	222	8.740236
127	5.000045	175	6.889826	223	8.779606
128	5.039415	176	6.929196	224	8.818977
129	5.078786	177	6.968567	225	8.858347
130	5.118156	178	7.007937	226	8.897718
131	5.157527	179	7.047307	227	8.937088
132	5.196897	180	7.086678	228	8.976459
133	5.236267	181	7.126048	229	9.015829
134	5.275638	182	7.165419	230	9.055199
135	5.315008	183	7.204789	231	9.094570
136	5.354379	184	7.244160	232	9.133940
137	5.393749	185	7.283530	233	9.173311
138	5.433120	186	7.322900	234	9.212681
139	5.472490	187	7.362271	235	9.252052
140	5.511861	188	7.401641	236	9.291422
141	5.551231	189	7.441012	237	9.330792
142	5.590601	190	7.480382	238	9.370163
143	5.629972	191	7.519753	239	9.409533
144	5.669342	192	7.559123	240	9.448904
145	5.708713	193	7.598493	241	9.488274
146	5.748083	194	7.637864	242	9.527645
147	5.787454	195	7.677234	243	9.567015
148	5.826824	196	7.716605	244	9.606385
149	5.866195	197	7.755975	245	9.645756
150	5.905565	198	7.795346	246	9.685126
151	5.944935	199	7.834716	247	9.724497
152	5.984306	200	7.874086	248	9.763867
153	6.023676	201	7.913457	249	9.803238
154	6.063047	202	7.952827	250	9.842608
155	6.102417	203	7.992198	251	9.881978
156	6.141787	204	8.031568	252	9.921349
157	6.181158	205	8.070939	253	9.960719
158	6.220528	206	8.110309	254	10.000090
159	6.259899	207	8.149679	255	10.039460
160	6.299269	208	8.189050	256	10.078831
161	6.338640	209	8.228420	257	10.118201
162	6.378010	210	8.267791	258	10.157571
163	6.417380	211	8.307161	259	10.196942
164	6.456751	212	8.346532	260	10.236312

TABLE XXI.
MILLIMETRES TO INCHES.

TABLES GIVING THE ENGLISH EQUIVALENTS OF 1 MILLI-METRE TO 1,000.					
Milli-metres	Inches and Decimals of an Inch	Milli-metres	Inches and Decimals of an Inch	Milli-metres	Inches and Decimals of an Inch
1	0.039370	39	1.535447	78	3.070894
2	0.078741	40	1.574817	79	3.110264
3	0.118111	41	1.614188	80	3.149635
4	0.157482	42	1.653558	81	3.189005
5	0.196852	43	1.692929	82	3.228375
6	0.236223	44	1.732299	83	3.267746
7	0.275593	45	1.771669	84	3.307116
8	0.314963	46	1.811040	85	3.346487
9	0.354334	47	1.850410	86	3.385857
10	0.393704	48	1.889781	87	3.425228
11	0.433075	49	1.929151	88	3.464598
12	0.472445	50	1.968522	89	3.503968
13	0.511816	51	2.007892	90	3.543339
14	0.551186	52	2.047262	91	3.582709
15	0.590556	53	2.086633	92	3.622080
16	0.629927	54	2.126003	93	3.661450
17	0.669297	55	2.165374	94	3.700821
18	0.708668	56	2.204744	95	3.740191
19	0.748038	57	2.244115	96	3.779561
20	0.787409	58	2.283485	97	3.818932
21	0.826779	59	2.322855	98	3.858302
22	0.866149	60	2.362226	99	3.897673
23	0.905520	61	2.401596	100	3.937043
24	0.944890	62	2.440967	101	3.976414
25	0.984261	63	2.480337	102	4.015784
26	1.023631	64	2.519708	103	4.055155
27	1.063002	65	2.559078	104	4.094525
28	1.102372	66	2.598448	105	4.133895
29	1.141742	67	2.637819	106	4.173266
30	1.181111	68	2.677189	107	4.212636
31	1.220483	69	2.716560	108	4.252007
32	1.259854	70	2.755930	109	4.291377
33	1.299224	71	2.795301	110	4.330748
34	1.338595	72	2.834671	111	4.370118
35	1.377965	73	2.874041	112	4.409488
36	1.417335	74	2.913412	113	4.448859
37	1.456706	75	2.952782	114	4.488229
38	1.496076	76	2.992153	115	4.527600
39	1.496076	77	3.031523	116	4.566970

MILLIMETRES TO INCHES.

Milli- metres	Inches and Decimals of an Inch	Milli- metres	Inches and Decimals of an Inch	Milli- metres	Inches and Decimals of an Inch
261	10-275683	309	12-165464	357	14-056244
262	10-315053	310	12-204434	358	14-094615
263	10-354434	311	12-244304	359	14-133985
264	10-393879	312	12-283575	360	14-173356
265	10-433165	313	12-322945	361	14-212726
266	10-472585	314	12-362316	362	14-252096
267	10-511905	315	12-401686	363	14-291467
268	10-551276	316	12-441057	364	14-330837
269	10-590646	317	12-480427	365	14-370208
270	10-630017	318	12-519797	366	14-409578
271	10-669387	319	12-559168	367	14-448949
272	10-708758	320	12-598538	368	14-488319
273	10-748128	321	12-637909	369	14-527689
274	10-787498	322	12-677279	370	14-567060
275	10-826869	323	12-716650	371	14-606430
276	10-866239	324	12-756020	372	14-645801
277	10-905610	325	12-795390	373	14-685171
278	10-944980	326	12-834761	374	14-724542
279	10-984351	327	12-874131	375	14-763912
280	11-023721	328	12-913502	376	14-803282
281	11-063091	329	12-952872	377	14-842653
282	11-102462	330	12-992243	378	14-882023
283	11-141832	331	13-031613	379	14-921394
284	11-181203	332	13-070983	380	14-960764
285	11-220573	333	13-110354	381	15-000135
286	11-259944	334	13-149724	382	15-039505
287	11-299314	335	13-189095	383	15-078875
288	11-338684	336	13-228465	384	15-118246
289	11-378055	337	13-267836	385	15-157616
290	11-417425	338	13-307206	386	15-196987
291	11-456796	339	13-346576	387	15-236357
292	11-496166	340	13-385947	388	15-275728
293	11-535537	341	13-425317	389	15-315098
294	11-574907	342	13-464688	390	15-354469
295	11-614277	343	13-504058	391	15-393839
296	11-653648	344	13-543429	392	15-433209
297	11-693018	345	13-582799	393	15-472580
298	11-732389	346	13-622170	394	15-511950
299	11-771759	347	13-661540	395	15-551321
300	11-811129	348	13-700910	396	15-590691
301	11-850500	349	13-740281	397	15-630062
302	11-889871	350	13-779651	398	15-669432
303	11-929241	351	13-819022	399	15-708802
304	11-968611	352	13-858392	400	15-748173
305	12-007982	353	13-897763	401	15-787543
306	12-047352	354	13-937133	402	15-826914
307	12-086723	355	13-976503	403	15-866284
308	12-126093	356	14-015874	404	15-905655

MILLIMETRES TO INCHES.

Milli- metres	Inches and Decimals of an Inch	Milli- metres	Inches and Decimals of an Inch	Milli- metres	Inches and Decimals of an Inch
405	15-945025	453	17-854806	501	19-724586
406	15-984395	454	17-874176	502	19-763957
407	16-023766	455	17-913547	503	19-803327
408	16-063136	456	17-952917	504	19-842698
409	16-102507	457	17-992287	505	19-882068
410	16-141877	458	18-031658	506	19-921439
411	16-181248	459	18-071028	507	19-960809
412	16-220618	460	18-110399	508	19-000179
413	16-259988	461	18-149769	509	20-039550
414	16-299359	462	18-189140	510	20-078920
415	16-338729	463	18-228510	511	20-118291
416	16-378100	464	18-267880	512	20-157661
417	16-417470	465	18-307251	513	20-197032
418	16-456841	466	18-346621	514	20-236402
419	16-496211	467	18-385992	515	20-275773
420	16-535581	468	18-425362	516	20-315143
421	16-574952	469	18-464733	517	20-354513
422	16-614322	470	18-504103	518	20-393884
423	16-653693	471	18-543474	519	20-433254
424	16-693063	472	18-582844	520	20-472625
425	16-732444	473	18-622214	521	20-511995
426	16-771804	474	18-661585	522	20-551366
427	16-811175	475	18-700955	523	20-590736
428	16-850545	476	18-740326	524	20-630106
429	16-889915	477	18-779696	525	20-669477
430	16-929286	478	18-819067	526	20-708847
431	16-968656	479	18-858437	527	20-748218
432	17-008027	480	18-897807	528	20-787588
433	17-047397	481	18-937178	529	20-826959
434	17-086768	482	18-976548	530	20-866329
435	17-126138	483	19-015919	531	20-905699
436	17-165508	484	19-055289	532	20-945070
437	17-204879	485	19-094660	533	20-984440
438	17-244249	486	19-134030	534	21-023811
439	17-283620	487	19-173400	535	21-063181
440	17-322990	488	19-212771	536	21-102552
441	17-362361	489	19-252141	537	21-141922
442	17-401731	490	19-291512	538	21-181292
443	17-441102	491	19-330882	539	21-220663
444	17-480472	492	19-370253	540	21-260033
445	17-519842	493	19-409623	541	21-299404
446	17-559213	494	19-448993	542	21-338774
447	17-598583	495	19-488364	543	21-378145
448	17-637954	496	19-527734	544	21-417515
449	17-677324	497	19-567105	545	21-456885
450	17-716694	498	19-606465	546	21-496256
451	17-756065	499	19-645836	547	21-535626
452	17-795435	500	19-685216	548	21-574997

MILLIMETRES TO INCHES.

Milli- metres	Inches and Decimals of an Inch	Milli- metres	Inches and Decimals of an Inch	Milli- metres	Inches and Decimals of an Inch
549	21-614867	597	23-504148	645	25-898929
550	21-638738	598	23-543518	646	25-943299
551	21-663108	599	23-582889	647	25-972670
552	21-732478	600	23-622259	648	25-512040
553	21-771849	601	23-661630	649	25-551410
554	21-811219	602	23-701000	650	25-590781
555	21-850590	603	23-740371	651	25-630151
556	21-889960	604	23-779741	652	25-669522
557	21-929331	605	23-819111	653	25-708892
558	21-968701	606	23-858482	654	25-748263
559	22-008072	607	23-897852	655	25-787633
560	22-047442	608	23-937223	656	25-827003
561	22-086812	609	23-976593	657	25-866374
562	22-126183	610	24-015964	658	25-905744
563	22-165553	611	24-055334	659	25-945115
564	22-204924	612	24-094704	660	25-984486
565	22-244294	613	24-134075	661	26-023856
566	22-283665	614	24-173445	662	26-063226
567	22-323035	615	24-212816	663	26-102596
568	22-362405	616	24-252186	664	26-141967
569	22-401776	617	24-291557	665	26-181337
570	22-441146	618	24-330927	666	26-220708
571	22-480517	619	24-370297	667	26-260078
572	22-519887	620	24-409668	668	26-299449
573	22-559258	621	24-449038	669	26-338819
574	22-598628	622	24-488409	670	26-378189
575	22-637998	623	24-527779	671	26-417560
576	22-677369	624	24-567150	672	26-456930
577	22-716739	625	24-606520	673	26-496301
578	22-756110	626	24-645890	674	26-535671
579	22-795480	627	24-685261	675	26-575042
580	22-834851	628	24-724631	676	26-614412
581	22-874221	629	24-764002	677	26-653782
582	22-913591	630	24-803372	678	26-693153
583	22-952962	631	24-842743	679	26-732523
584	22-992332	632	24-882113	680	26-771894
585	23-031703	633	24-921483	681	26-811264
586	23-071073	634	24-960854	682	26-850635
587	23-110444	635	25-000224	683	26-890005
588	23-149814	636	25-039595	684	26-929376
589	23-189184	637	25-078965	685	26-968746
590	23-228555	638	25-118336	686	27-008116
591	23-267925	639	25-157706	687	27-047487
592	23-307296	640	25-197077	688	27-086857
593	23-346666	641	25-236447	689	27-126228
594	23-386037	642	25-275817	690	27-165598
595	23-425407	643	25-315188	691	27-204969
596	23-464778	644	25-354558	692	27-244339

MILLIMETRES TO INCHES.

Milli- metres	Inches and Decimals of an Inch	Milli- metres	Inches and Decimals of an Inch	Milli- metres	Inches and Decimals of an Inch
693	27-283709	741	29-178490	789	31-038271
694	27-323080	742	29-217861	790	31-102641
695	27-362450	743	29-257231	791	31-142012
696	27-401821	744	29-296601	792	31-181382
697	27-441191	745	29-335972	793	31-220752
698	27-480562	746	29-375342	794	31-260123
699	27-519932	747	29-404713	795	31-299493
700	27-559303	748	29-444083	796	31-338864
701	27-598673	749	29-483454	797	31-378234
702	27-638043	750	29-522824	798	31-417604
703	27-677414	751	29-562194	799	31-456975
704	27-716784	752	29-601565	800	31-496346
705	27-756155	753	29-640935	801	31-535716
706	27-795525	754	29-680306	802	31-575086
707	27-834895	755	29-724676	803	31-614457
708	27-874266	756	29-764047	804	31-653827
709	27-913636	757	29-803417	805	31-693198
710	27-953007	758	29-842787	806	31-732568
711	27-992377	759	29-882158	807	31-771938
712	28-031748	760	29-921528	808	31-811309
713	28-071118	761	29-960899	809	31-850679
714	28-110488	762	30-000269	810	31-890050
715	28-149859	763	30-039640	811	31-929420
716	28-189229	764	30-079010	812	31-968791
717	28-228600	765	30-118380	813	32-008161
718	28-267970	766	30-157751	814	32-047532
719	28-307341	767	30-197121	815	32-086902
720	28-346711	768	30-236492	816	32-126272
721	28-386081	769	30-275862	817	32-165643
722	28-425452	770	30-315233	818	32-205013
723	28-464822	771	30-354603	819	32-244384
724	28-504193	772	30-393973	820	32-283754
725	28-543563	773	30-433344	821	32-323125
726	28-582934	774	30-472714	822	32-362495
727	28-622304	775	30-512085	823	32-401866
728	28-661675	776	30-551455	824	32-441236
729	28-701045	777	30-590825	825	32-480606
730	28-740415	778	30-630196	826	32-519977
731	28-779786	779	30-669566	827	32-559347
732	28-819156	780	30-708937	828	32-598718
733	28-858527	781	30-748307	829	32-638088
734	28-897897	782	30-787678	830	32-677459
735	28-937268	783	30-827048	831	32-716829
736	28-976638	784	30-866419	832	32-756199
737	29-016008	785	30-905789	833	32-795570
738	29-055379	786	30-945159	834	32-834940
739	29-094749	787	30-984530	835	32-874311
740	29-134120	788	31-023900	836	32-913681

Milli- metres	Inches and Decimals of an Inch	Milli- metres	Inches and Decimals of an Inch	Milli- metres	Inches and Decimals of an Inch
837	32.953052	885	34.842832	933	36.732613
838	32.962422	886	34.862203	934	36.771984
839	33.031792	887	34.921573	935	36.811354
840	33.071163	888	34.960944	936	36.850724
841	33.110533	889	35.000314	937	36.890095
842	33.149904	890	35.039684	938	36.929465
843	33.189274	891	35.079055	939	36.968836
844	33.228645	892	35.118425	940	37.008206
845	33.268015	893	35.157796	941	37.047576
846	33.307385	894	35.197166	942	37.086947
847	33.346756	895	35.236536	943	37.126317
848	33.386126	896	35.275907	944	37.165688
849	33.425497	897	35.315277	945	37.205058
850	33.464867	898	35.354648	946	37.244429
851	33.504238	899	35.394018	947	37.283799
852	33.543608	900	35.433389	948	37.323170
853	33.582979	901	35.472759	949	37.362540
854	33.622349	902	35.512130	950	37.401910
855	33.661719	903	35.551500	951	37.441281
856	33.701090	904	35.590871	952	37.480651
857	33.740460	905	35.630241	953	37.520022
858	33.779831	906	35.669611	954	37.559392
859	33.819201	907	35.708982	955	37.598765
860	33.858572	908	35.748352	956	37.638135
861	33.897942	909	35.787723	957	37.677503
862	33.937312	910	35.827093	958	37.716874
863	33.976683	911	35.866464	959	37.756244
864	34.016053	912	35.905834	960	37.795615
865	34.055424	913	35.945204	961	37.834985
866	34.094794	914	35.984575	962	37.874356
867	34.134165	915	36.023945	963	37.913726
868	34.173535	916	36.063316	964	37.953096
869	34.212905	917	36.102686	965	37.992467
870	34.252276	918	36.142057	966	38.031837
871	34.291646	919	36.181427	967	38.071208
872	34.331017	920	36.220797	968	38.110578
873	34.370387	921	36.260168	969	38.149949
874	34.409758	922	36.299538	970	38.189319
875	34.449128	923	36.338909	971	38.228689
876	34.488498	924	36.378279	972	38.268060
877	34.527869	925	36.417650	973	38.307430
878	34.567239	926	36.457020	974	38.346801
879	34.606610	927	36.496390	975	38.386171
880	34.645980	928	36.535761	976	38.425542
881	34.685351	929	36.575131	977	38.464912
882	34.724721	930	36.614502	978	38.504283
883	34.764091	931	36.653872	979	38.543653
884	34.803462	932	36.693243	980	38.583023

TABLE XXII.

TABLE GIVING THE ENGLISH EQUIVALENTS OF METRES IN INCHES AND DECIMALS OF AN INCH.

Metres	Inches and Decimals of an Inch	Metres	Inches and Decimals of an Inch	Metres	Inches and Decimals of an Inch
1	39.370432	84	3338.594687	67	2637.818941
2	78.740864	85	3377.965119	68	2677.189373
3	118.111296	86	3417.335551	69	2716.559805
4	157.481728	87	3456.705983	70	2755.930237
5	196.852160	88	3496.076415	71	2795.300669
6	236.222592	89	3535.446846	72	2834.671101
7	275.593024	90	3574.817278	73	2874.041533
8	314.963456	41	1614.187710	74	2913.411965
9	354.333888	42	1653.558142	75	2952.782397
10	393.704320	43	1692.928574	76	2992.152829
11	433.074752	44	1732.299006	77	3031.523261
12	472.445184	45	1771.669438	78	3070.893693
13	511.815616	46	1811.039870	79	3110.264125
14	551.186047	47	1850.410302	80	3149.634557
15	590.556479	48	1889.780734	81	3189.004989
16	629.926911	49	1929.151166	82	3228.375421
17	669.297343	50	1968.521598	83	3267.745853
18	708.667775	51	2007.892030	84	3307.116285
19	748.038207	52	2047.262462	85	3346.486717
20	787.408639	53	2086.632894	86	3385.857149
21	826.779071	54	2126.003326	87	3425.227581
22	866.149503	55	2165.373758	88	3464.598013
23	905.519935	56	2204.744190	89	3503.968444
24	944.890367	57	2244.114622	90	3543.338876
25	984.260799	58	2283.485054	91	3582.709308
26	1023.631231	59	2322.855486	92	3622.079740
27	1063.001663	60	2362.225918	93	3661.450172
28	1102.372095	61	2401.596350	94	3700.820604
29	1141.742527	62	2440.966782	95	3740.191036
30	1181.112959	63	2480.337214	96	3779.561468
31	1220.483391	64	2519.707645	97	3818.931900
32	1259.853823	65	2559.078077	98	3858.302332
33	1299.224255	66	2598.448509	99	3897.672764

(Reproduced by permission from Mackenzie's "Naval Architects' Pocket-book.")

TABLE GIVING THE EQUIVALENTS IN MILLIMETRES
OF THE DIVISIONS OF THE INCH.

TABLE GIVING THE EQUIVALENTS IN MILLIMETRES OF THE DIVISIONS OF THE INCH.			
Divisions of the Inch	Millimetres	Divisions of the Inch	Millimetres
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...
...	...	...	...

EQUIVALENTS OF ENGLISH AND METRICAL MEASURES.

Divisions of the Inch	Millimetres	Divisions of the Inch	Millimetres
...	...	...	...
$\frac{1}{16}$	16-867036	$\frac{1}{16}$	17-065472
...	...	...	...
$\frac{1}{8}$	17-065472	$\frac{1}{8}$	17-263908
...	...	...	...
$\frac{3}{16}$	17-462343	$\frac{3}{16}$	17-660779
...	...	...	...
$\frac{1}{2}$	17-859215	$\frac{1}{2}$	18-087650
...	...	...	...
$\frac{5}{8}$	18-256086	$\frac{5}{8}$	18-454522
...	...	...	...
$\frac{3}{4}$	18-454522	$\frac{3}{4}$	18-652958
...	...	...	...
$\frac{7}{8}$	18-851393	$\frac{7}{8}$	19-049829
...	...	...	...
1	19-049829	1	19-248265
...	...	...	...
$\frac{1}{16}$	19-446701	$\frac{1}{16}$	19-645136
...	...	...	...
$\frac{1}{8}$	19-645136	$\frac{1}{8}$	19-843572
...	...	...	...
$\frac{3}{16}$	20-042008	$\frac{3}{16}$	20-240443
...	...	...	...
$\frac{1}{2}$	20-438879	$\frac{1}{2}$	20-637315
...	...	...	...
$\frac{3}{4}$	20-637315	$\frac{3}{4}$	20-835751
...	...	...	...
1	20-835751	1	21-034186

TABLE XXIV.
TABLE GIVING THE EQUIVALENTS IN MILLIMETRES
OF THE DIVISIONS OF THE FOOT.

Millimetres		In.		Millimetres		In.		Millimetres		In.	
1	25.39977	10	253.99772	19	482.59567	28	711.19862				
2	50.79954	11	279.39749	20	507.99544	29	736.59939				
3	76.19932	12	304.79727	21	533.39521	30	761.99316				
4	101.59909	13	330.19704	22	558.79499	31	787.39294				
5	126.99886	14	355.59681	23	584.19476	32	812.79271				
6	152.39863	15	380.99858	24	609.59453	33	838.19248				
7	177.79840	16	406.39635	25	634.99430	34	863.59225				
8	203.19818	17	431.79613	26	660.39408	35	888.99202				
9	228.59795	18	457.19590	27	685.79385	36	914.39180				

(Reproduced by permission from Macerow's "Naval Architects' Pocket-book.")

Metres.	Feet.	Yards.	Metres.	Feet.	Yards.
1	3.2809	1.0936	44	144.3596	48.1193
2	6.5618	2.1872	45	147.6405	49.2129
3	9.8427	3.2809	46	150.9214	50.3065
4	13.1236	4.3745	47	154.2023	51.4001
5	16.4045	5.4681	48	157.4832	52.4938
6	19.6854	6.5617	49	160.7641	53.5874
7	22.9663	7.6553	50	164.0450	54.6810
8	26.2472	8.7490	51	167.3259	55.7746
9	29.5281	9.8426	52	170.6068	56.8682
10	32.8090	10.9362	53	173.8877	57.9619
11	36.0899	12.0298	54	177.1686	59.0555
12	39.3708	13.1234	55	180.4495	60.1491
13	42.6517	14.2171	56	183.7304	61.2427
14	45.9326	15.3107	57	187.0113	62.3363
15	49.2135	16.4043	58	190.2922	63.4300
16	52.4944	17.4979	59	193.5731	64.5236
17	55.7753	18.5915	60	196.8540	65.6172
18	59.0562	19.6852	61	200.1349	66.7108
19	62.3371	20.7788	62	203.4158	67.8044
20	65.6180	21.8724	63	206.6967	68.8981
21	68.8989	22.9660	64	209.9776	69.9917
22	72.1798	24.0596	65	213.2585	71.0853
23	75.4607	25.1533	66	216.5394	72.1789
24	78.7416	26.2469	67	219.8203	73.2725
25	82.0225	27.3405	68	223.1012	74.3662
26	85.3034	28.4341	69	226.3821	75.4598
27	88.5843	29.5277	70	229.6630	76.5534
28	91.8652	30.6214	71	232.9439	77.6470
29	95.1461	31.7150	72	236.2248	78.7406
30	98.4270	32.8086	73	239.5057	79.8342
31	101.7079	33.9022	74	242.7866	80.9279
32	104.9888	34.9958	75	246.0675	82.0215
33	108.2697	36.0895	76	249.3484	83.1151
34	111.5506	37.1831	77	252.6293	84.2087
35	114.8315	38.2767	78	255.9102	85.3024
36	118.1124	39.3703	79	259.1911	86.3960
37	121.3933	40.4639	80	262.4720	87.4896
38	124.6742	41.5576	81	265.7529	88.5832
39	127.9551	42.6512	82	269.0338	89.6768
40	131.2360	43.7448	83	272.3147	90.7705
41	134.5169	44.8384	84	275.5956	91.8641
42	137.7978	45.9320	85	278.8765	92.9577
43	141.0787	47.0257	86	282.1574	94.0513

(Reproduced by permission from D. K. Clark's "Mechanical Engineer's Pocket-book.")

TABLE XXV.—LINEAL FEET IN METRES.

Feet.	Metres.	Feet.	Metres.	Feet.	Metres.	Feet.	Metres.
1	.3048	26	7.9248	51	15.5448	76	23.1648
2	.6096	27	8.2296	52	15.8496	77	23.4696
3	.9144	28	8.5344	53	16.1544	78	23.7744
4	1.2192	29	8.8392	54	16.4592	79	24.0792
5	1.5240	30	9.1440	55	16.7640	80	24.3840
6	1.8288	31	9.4488	56	17.0688	81	24.6888
7	2.1336	32	9.7536	57	17.3736	82	24.9936
8	2.4384	33	10.0584	58	17.6784	83	25.2984
9	2.7432	34	10.3632	59	17.9832	84	25.6032
10	3.0480	35	10.6680	60	18.2880	85	25.9080
11	3.3528	36	10.9728	61	18.5928	86	26.2128
12	3.6576	37	11.2776	62	18.8976	87	26.5176
13	3.9624	38	11.5824	63	19.2024	88	26.8224
14	4.2672	39	11.8872	64	19.5072	89	27.1272
15	4.5720	40	12.1920	65	19.8120	90	27.4320
16	4.8768	41	12.4968	66	20.1168	91	27.7368
17	5.1816	42	12.8016	67	20.4216	92	28.0416
18	5.4864	43	13.1064	68	20.7264	93	28.3464
19	5.7912	44	13.4112	69	21.0312	94	28.6512
20	6.0960	45	13.7160	70	21.3360	95	28.9560
21	6.4008	46	14.0208	71	21.6408	96	29.2608
22	6.7056	47	14.3256	72	21.9456	97	29.5656
23	7.0104	48	14.6304	73	22.2504	98	29.8704
24	7.3152	49	14.9352	74	22.5552	99	30.1752
25	7.6200	50	15.2400	75	22.8600	100	30.4800

(Reproduced by permission from D. K. Clark's "Mechanical Engineer's Pocket-book.")

EQUIVALENTS OF ENGLISH AND METRICAL WEIGHTS.

TABLE XXVIII.

TABLE GIVING THE EQUIVALENTS OF AVOIR. OZ. IN
FRENCH KILOGRAMS.

Oz.	Kilograms	Oz.	Kilograms	Oz.	Kilograms	Oz.	Kilograms
1	0.028349541	5	0.141747704	9	0.255145867	13	0.368544030
2	0.056699082	6	0.170097245	10	0.283495408	14	0.396893571
3	0.085048622	7	0.198446785	11	0.311844948	15	0.425243112
4	0.113398163	8	0.226796326	12	0.340194489	16	0.453592652

TABLE XXIX.

TABLE GIVING THE EQUIVALENTS OF AVOIR. LBS. IN
FRENCH KILOGRAMS.

Lbs.	Kilograms	Lbs.	Kilograms	Lbs.	Kilograms	Lbs.	Kilograms
1	0.45359265	8	3.62874122	15	6.80388978	22	9.97903835
2	0.90718530	9	4.08233387	16	7.25748243	23	10.43263100
3	1.36077796	10	4.53592652	17	7.71107509	24	10.88622365
4	1.81437061	11	4.98951917	18	8.16466774	25	11.33981631
5	2.26796326	12	5.44311183	19	8.61826039	26	11.79340896
6	2.72155591	13	5.89670448	20	9.07185305	27	12.24700161
7	3.17514857	14	6.35029713	21	9.52544570	28	12.70059426

TABLE XXX.

TABLE GIVING THE EQUIVALENTS OF QUARTERS IN
FRENCH KILOGRAMS.

Qrs.	Kilograms	Qrs.	Kilograms	Qrs.	Kilograms	Qrs.	Kilograms
1	12.70059426	2	25.40118853	3	38.10178279	4	50.80237705

TABLE XXXI.

TABLE GIVING THE EQUIVALENTS OF CWTs. IN
FRENCH KILOGRAMS.

Cwt	Kilograms	Cwt	Kilograms	Cwt	Kilograms	Cwt	Kilograms
1	50.80237705	6	304.81426231	11	558.82614757	16	812.83803283
2	101.60475410	7	355.61669936	12	609.62852462	17	863.64040988
3	152.40718116	8	406.41901642	13	660.43090168	18	914.44278694
4	203.20950821	9	457.22189347	14	711.23327873	19	965.24516399
5	254.01188526	10	508.02377052	15	762.03565578	20	1016.0475411

TABLE XXXII.

TABLE GIVING THE EQUIVALENTS OF TONS IN
FRENCH KILOGRAMS.

Tons	Kilograms	Tons	Kilograms	Tons	Kilograms	Tons	Kilograms
1	1016.04754	20	20320.9508	300	304814.262	1300	1320861.80
2	2032.09508	30	30481.4262	400	406419.016	1400	1422466.56
3	3048.14262	40	40641.9016	500	508023.771	1500	1524071.31
4	4064.19016	50	50802.3771	600	609628.525	1600	1625676.07
5	5080.23771	60	60962.8525	700	711233.279	1700	1727280.82
6	6096.28525	70	71123.3279	800	812838.033	1800	1828885.57
7	7112.33279	80	81283.8033	900	914442.787	1900	1930490.33
8	8128.38033	90	91444.2787	1000	1016047.54	2000	2032095.08
9	9144.2787	100	101604.754	1100	1117652.30	3000	3048142.62
10	10160.4754	200	203209.508	1200	1219257.05	4000	4064190.16

(Reproduced by permission from Mackrow's "Naval Architects' Pocket-book.")

TABLE XXXIII.

TABLE GIVING THE EQUIVALENTS OF KILOGRAMS IN AVOIRDUPOIS POUNDS AND TONS.

Kilos.	Avoir. Lbs.	Ton	Kilos.	Avoir. Lbs.	Ton	Kilos.	Avoir. Lbs.	Ton	Kilos.	Avoir. Lbs.	Ton
1	2.20462	.00098421	26	57.32015	.02558935	51	112.43568	.05019450	76	167.55122	.07479965
2	4.40924	.00196841	27	59.52477	.02657356	52	114.64031	.05117871	77	169.75584	.07578886
3	6.61386	.00295282	28	61.72940	.02755777	53	116.84493	.05216291	78	171.96046	.07676806
4	8.81849	.00393682	29	63.93402	.02854197	54	119.04955	.05314712	79	174.16508	.07775227
5	11.02311	.00492103	30	66.13864	.02952618	55	121.25417	.05413133	80	176.36970	.07873647
6	13.22773	.00590524	31	68.34326	.03051038	56	123.45879	.05511553	81	178.57432	.07972068
7	15.43235	.00688944	32	70.54788	.03149459	57	125.66341	.05609974	82	180.77894	.08070489
8	17.63697	.00787365	33	72.75250	.03247880	58	127.86803	.05708394	83	182.98356	.08168909
9	19.84159	.00885785	34	74.95712	.03346300	59	130.07265	.05806815	84	185.18819	.08267330
10	22.04621	.00984206	35	77.16174	.03444721	60	132.27728	.05905235	85	187.39281	.08365750
11	24.25083	.01082627	36	79.36637	.03543141	61	134.48190	.06003656	86	189.59743	.08464171
12	26.45555	.01181047	37	81.57099	.03641562	62	136.68652	.06102077	87	191.80205	.08562591
13	28.66008	.01279468	38	83.77561	.03739982	63	138.89114	.06200497	88	194.00667	.08661012
14	30.86470	.01377888	39	85.98023	.03838403	64	141.09576	.06298918	89	196.21129	.08759433
15	33.06932	.01476309	40	88.18485	.03936824	65	143.30038	.06397338	90	198.41591	.08857853
16	35.27394	.01574729	41	90.38947	.04035244	66	145.50500	.06495759	91	200.62053	.08956274
17	37.47856	.01673150	42	92.59409	.04133665	67	147.70962	.06594180	92	202.82515	.09054694
18	39.68318	.01771571	43	94.79871	.04232085	68	149.91425	.06692600	93	205.02978	.09153115
19	41.88780	.01869991	44	97.00334	.04330506	69	152.11887	.06791021	94	207.23440	.09251536
20	44.09243	.01968412	45	99.20796	.04428927	70	154.32349	.06889441	95	209.43902	.09349956
21	46.29705	.02066832	46	101.41258	.04527347	71	156.52811	.06987862	96	211.64364	.09448377
22	48.50167	.02165253	47	103.61720	.04625768	72	158.73273	.07086283	97	213.84826	.09546797
23	50.70629	.02263674	48	105.82182	.04724188	73	160.93735	.07184703	98	216.05288	.09645218
24	52.91091	.02362094	49	108.02644	.04822609	74	163.14197	.07283124	99	218.25750	.09743639
25	55.11553	.02460515	50	110.23106	.04921030	75	165.34659	.07381544	100	220.46213	.09842059

TABLE GIVING THE EQUIVALENTS OF KILOGRAMS IN AVOIRDUPOIS POUNDS AND TONS (concluded).

Kilos.	Avoir. Lbs.	Ton	Kilos.	Avoir. Lbs.	Ton	Kilos.	Avoir. Lbs.	Ton	Kilos.	Avoir. Lbs.	Ton
101	222.66675	.09940480	126	277.78228	.12400995	151	332.89781	.14861509	176	388.01334	.17322024
102	224.87137	.10038900	127	279.98690	.12499415	152	335.10243	.14959930	177	390.21796	.17420445
103	227.07599	.10137321	128	282.29152	.12597836	153	337.30705	.15058351	178	392.42258	.17518865
104	229.28061	.10235742	129	284.49614	.12696256	154	339.51167	.15156771	179	394.62720	.17617286
105	231.48523	.10334162	130	286.60076	.12794677	155	341.71629	.15255192	180	396.83183	.17715706
106	233.68985	.10432583	131	288.80538	.12893097	156	343.92092	.15353612	181	399.03645	.17814127
107	235.89447	.10531003	132	291.01001	.12991518	157	346.12554	.15452033	182	401.24107	.17912548
108	238.09910	.10629424	133	293.21463	.13089939	158	348.33016	.15550453	183	403.44569	.18010968
109	240.30372	.10727844	134	295.41925	.13188359	159	350.53478	.15648874	184	405.65031	.18109389
110	242.50834	.10826265	135	297.62387	.13286780	160	352.73940	.15747295	185	407.85493	.18207809
111	244.71296	.10924686	136	299.82849	.13385200	161	354.94402	.15845715	186	410.05955	.18306230
112	246.91758	.11023106	137	302.03311	.13483621	162	357.14864	.15944136	187	412.26417	.18404651
113	249.12220	.11121527	138	304.23773	.13582042	163	359.35326	.16042556	188	414.46880	.18503071
114	251.32682	.11219947	139	306.44235	.13680462	164	361.55789	.16140977	189	416.67342	.18601492
115	253.53144	.11318368	140	308.64698	.13778883	165	363.76251	.16239398	190	418.87804	.18699912
116	255.73607	.11416789	141	310.85160	.13877303	166	365.96713	.16337818	191	421.08266	.18798333
117	257.94069	.11515209	142	313.05622	.13975724	167	368.17175	.16436239	192	423.28728	.18896754
118	260.14531	.11613630	143	315.26084	.14074145	168	370.37637	.16534659	193	425.49190	.18995174
119	262.34993	.11712050	144	317.46546	.14172565	169	372.58099	.16633080	194	427.69652	.19093595
120	264.55455	.11810471	145	319.67008	.14270986	170	374.78561	.16731501	195	429.90114	.19192015
121	266.75917	.11908892	146	321.87470	.14369406	171	376.99023	.16829921	196	432.10577	.19290436
122	268.96379	.12007312	147	324.07932	.14467827	172	379.19486	.16928342	197	434.31039	.19388857
123	271.16841	.12105733	148	326.28395	.14566248	173	381.39948	.17026762	198	436.51501	.19487277
124	273.37304	.12204153	149	328.48857	.14664668	174	383.60410	.17125183	199	438.71963	.19585698
125	275.57766	.12302574	150	330.69319	.14763089	175	385.80872	.17223604	200	440.92425	.19684118

(Reproduced by permission from Mackrow's "Naval Architects' Pocket-book.")

TABLE XXXIV.
BELT VELOCITY OR CIRCUMFERENTIAL SPEED OF PULLEYS.

Pulley Diam. in Inches.	Revolutions per Minute.												
	50	60	70	80	90	100	110	120	130	140	150	160	170
	Velocity in Feet per Minute.												
6	78.5	94.2	110	126	141	157	173	188	204	220	235	251	267
7	91.7	110	128	146	165	183	201	220	238	256	275	293	312
8	105	126	146	167	188	210	230	251	272	293	314	335	356
9	118	141	165	188	212	236	259	282	306	330	353	377	400
10	131	157	183	209	235	262	288	314	340	366	392	419	445
12	157	188	220	252	282	314	346	377	408	440	471	502	534
14	183	220	256	298	330	366	403	440	476	513	550	586	623
16	209	251	293	335	377	419	460	502	544	586	628	670	712
18	230	282	330	377	424	471	518	565	612	659	707	754	801
20	262	314	366	419	471	524	576	628	681	733	785	838	890
22	288	345	403	460	518	576	634	691	749	806	864	921	979
24	314	377	440	502	565	628	691	754	817	880	942	1005	1068
26	340	408	476	545	622	681	749	817	885	953	1021	1089	1157
28	380	440	513	586	659	733	806	880	953	1026	1100	1173	1246
30	393	471	550	628	706	785	864	942	1022	1100	1178	1256	1335
32	419	502	586	670	754	838	921	1005	1089	1173	1257	1340	1424
34	445	534	623	712	801	890	979	1068	1157	1246	1335	1424	1513
36	471	565	659	754	848	942	1037	1131	1225	1319	1414	1508	1602
40	523	628	733	837	942	1047	1152	1256	1361	1466	1571	1675	1780
48	628	754	879	1005	1131	1257	1382	1508	1633	1759	1885	2010	2136
54	707	848	989	1131	1272	1414	1555	1696	1838	1979	2120	2262	2403
60	785	942	1099	1256	1414	1571	1728	1885	2042	2199	2356	2513	2670
66	864	1036	1209	1382	1550	1728	1900	2073	2246	2419	2592	2764	2937
72	942	1131	1319	1508	1696	1885	2073	2262	2450	2639	2827	3016	3204
78	1021	1225	1429	1633	1838	2042	2245	2450	2655	2859	3063	3267	3472
84	1099	1319	1539	1754	1978	2199	2419	2639	2859	3079	3298	3518	3738

Pulley Diam. in Inches.	Revolutions per Minute.												
	180	190	200	210	220	230	240	250	260	270	280	290	300
	Velocity in Feet per Minute.												
6	282	298	314	330	346	361	377	392	408	424	440	455	471
7	330	348	367	385	403	421	440	458	477	495	513	531	550
8	377	398	419	440	461	481	503	523	545	565	586	607	628
9	424	447	471	495	518	542	565	588	613	630	660	683	707
10	471	497	524	549	576	602	628	654	681	707	733	759	785
12	560	597	628	659	691	722	754	785	817	848	880	911	942
14	659	696	733	769	806	843	880	916	953	989	1026	1063	1100
16	754	796	838	879	921	963	1005	1046	1089	1131	1173	1214	1257
18	848	895	942	989	1037	1084	1131	1178	1225	1272	1319	1366	1414
20	942	995	1047	1099	1152	1204	1256	1309	1361	1414	1466	1518	1571
22	1037	1094	1152	1209	1267	1325	1382	1440	1497	1555	1612	1670	1728
24	1131	1194	1257	1319	1382	1445	1508	1571	1633	1696	1759	1822	1885
26	1225	1293	1361	1429	1497	1565	1633	1701	1770	1838	1906	1974	2042
28	1319	1393	1466	1539	1613	1686	1759	1832	1906	1979	2052	2126	2199
30	1413	1492	1571	1649	1728	1806	1885	1963	2042	2120	2199	2277	2356
32	1508	1592	1675	1759	1843	1927	2010	2094	2178	2252	2345	2429	2513
34	1602	1691	1780	1869	1958	2047	2136	2225	2314	2403	2492	2581	2670
36	1696	1791	1885	1978	2073	2168	2262	2356	2450	2545	2639	2733	2827
40	1885	1989	2094	2199	2304	2413	2518	2623	2728	2832	2937	3041	3145
48	2262	2387	2513	2639	2765	2890	3016	3142	3267	3393	3518	3644	3769
54	2545	2686	2827	2969	3110	3251	3393	3534	3675	3817	3958	4100	4240
60	2827	2984	3141	3298	3454	3613	3770	3927	4084	4241	4398	4555	4712
66	3110	3283	3455	3628	3801	3974	4147	4319	4492	4665	4838	5010	5183
72	3392	3581	3770	3958	4147	4335	4524	4713	4900	5089	5278	5466	5654
78	3675	3880	4084	4288	4492	4696	4900	5099	5309	5518	5717	5921	6125
84	3958	4178	4398	4618	4838	5058	5277	5497	5717	5937	6157	6377	6597

(Reproduced by permission from the "Mechanical World Pocket Diary.")

NOTE.—The speeds printed in heavy type are the best for Main Driving Belts.

TABLE XXXV.

HORSE-POWER OF LEATHER BELTS PER INCH OF WIDTH.

Velocity of Belt in Feet per Minute.	Best Oak-tanned Belts.			Best Link or Chain Belts.					
	Single Belts.	Light Double Belts.	Heavy Double Belts.	in. 1	in. 1	in. 1	in. 1	in. 1	in. 1
100	0.15	0.21	0.27	0.18	0.15	0.17	0.20	0.24	0.27
200	0.30	0.42	0.55	0.25	0.29	0.35	0.40	0.47	0.55
300	0.45	0.64	0.82	0.38	0.44	0.52	0.60	0.71	0.82
400	0.61	0.85	1.09	0.51	0.58	0.69	0.80	0.95	1.09
500	0.76	1.06	1.36	0.64	0.73	0.86	1.00	1.18	1.36
600	0.91	1.27	1.64	0.76	0.87	1.04	1.20	1.42	1.64
700	1.06	1.49	1.91	0.89	1.02	1.21	1.40	1.65	1.91
800	1.21	1.70	2.18	0.92	1.16	1.38	1.60	1.89	2.18
900	1.36	1.91	2.45	1.05	1.31	1.55	1.80	2.18	2.45
1000	1.51	2.12	2.73	1.27	1.45	1.73	2.00	2.36	2.73
1100	1.67	2.33	3.00	1.40	1.60	1.90	2.20	2.60	3.00
1200	1.82	2.55	3.27	1.53	1.75	2.07	2.40	2.84	3.27
1300	1.97	2.76	3.55	1.65	1.89	2.25	2.60	3.07	3.55
1400	2.12	2.97	3.82	1.78	2.04	2.42	2.80	3.31	3.82
1500	2.27	3.18	4.09	1.91	2.18	2.59	3.00	3.55	4.09
1600	2.42	3.39	4.36	2.04	2.33	2.76	3.20	3.78	4.36
1700	2.58	3.61	4.64	2.16	2.47	2.94	3.40	4.02	4.64
1800	2.73	3.82	4.91	2.29	2.62	3.11	3.60	4.25	4.91
1900	2.88	4.03	5.18	2.42	2.76	3.28	3.80	4.49	5.18
2000	3.03	4.24	5.45	2.55	2.91	3.45	4.00	4.73	5.45
2100	3.18	4.45	5.73	2.67	3.05	3.63	4.20	4.96	5.73
2200	3.33	4.67	6.00	2.80	3.20	3.80	4.40	5.20	6.00
2300	3.49	4.88	6.27	2.93	3.35	3.97	4.60	5.44	6.27
2400	3.64	5.09	6.55	3.05	3.49	4.15	4.80	5.67	6.55
2500	3.79	5.30	6.82	3.18	3.64	4.32	5.00	5.91	6.82
2600	3.94	5.52	7.09	3.31	3.78	4.49	5.20	6.15	7.09
2700	4.09	5.73	7.36	3.44	3.93	4.66	5.40	6.38	7.36
2800	4.24	5.94	7.64	3.57	4.07	4.83	5.60	6.62	7.64
2900	4.39	6.15	7.91	3.70	4.21	5.00	5.80	6.85	7.91
3000	4.50	6.36	8.18	3.83	4.35	5.17	6.00	7.09	8.18
3100	4.60	6.58	8.45	3.96	4.49	5.34	6.20	7.33	8.45
3200	4.69	6.79	8.70	4.09	4.63	5.51	6.40	7.57	8.70
3300	4.77	7.00	8.96	4.22	4.77	5.68	6.60	7.81	8.96
3400	4.84	7.21	9.21	4.35	4.91	5.85	6.80	8.05	9.21
3500	4.90	7.41	9.46	4.48	5.05	6.02	7.00	8.29	9.46
3600	4.95	7.60	9.70	4.61	5.19	6.19	7.20	8.53	9.70
3700	4.99	7.78	9.94	4.74	5.33	6.36	7.40	8.77	9.94
3800	5.03	7.95	10.17	4.87	5.47	6.53	7.60	9.01	10.17
3900	5.06	8.12	10.40	4.99	5.61	6.70	7.80	9.25	10.40
4000	5.08	8.28	10.62	5.12	5.75	6.87	8.00	9.49	10.62
4200	5.10	8.53	11.07	5.37	5.99	7.11	8.24	9.73	11.07
4400	5.07	8.77	11.51	5.61	6.23	7.35	8.48	10.00	11.51
4600	5.07	8.99	11.93	5.85	6.47	7.59	8.72	10.24	11.93
4800	5.07	9.21	12.35	6.09	6.71	7.83	8.96	10.48	12.35
5000	5.07	9.42	12.76	6.33	6.95	8.07	9.20	10.72	12.76

(Reproduced by permission from the "Mechanical World Pocket Diary.")

NOTE.—The speeds printed in heavy type are the best for Main Driving Belts.
For Table of Belt Velocities, see Table XXXIV., p. 271.

ROPE DRIVING.*

Undoubtedly every rope has its most suitable groove angle, but as the providing of a range of templates to agree with every advance in size would, perhaps, prove more inconvenient than advantageous, two leading angles have been fixed upon for all driving-ropes—viz. 40 deg. for those above 1½ in. in diameter, and 30 deg. below that size; excepting, however, the small bands used for driving cotton machinery—say ¼ in. in diameter and even less, when angles as sharp as 15 deg. are brought into requisition. In setting out a groove it should always be borne in mind that a rope is to all intents and purposes an elastic wedge, and reaches its highest driving capabilities when it is compressed to the shape of the groove itself. This uniform ought, therefore, always to be anticipated, for if the sides of the groove are merely shown as tangents to the circle representing a given diameter of rope, there is always the danger of making the groove too shallow, so that when compression takes place the rope is liable to find its way to the bottom, or, what is almost as detrimental, work upon the semi-circle with which grooves generally terminate, when grip is considerably




FIG. 1.—How to Set Out a Groove of 40 degrees.

weakened and slipping supervenes, the true indication of which is heated pulley-rims.

How to Set Out a Groove of 40 Deg.—Without appealing to the protractor, a 40-deg. groove may be set out as per illustration (Fig. 1).

First let a centre of equal diameter represent the rope, draw the vertical and horizontal centre lines, the chord AB of the arc. AB then is the position measured downwards from the centre of the rope of the centre for rounding the bottom of the groove, and when doubled along the vertical line points the apex of the inverted angle, the arms of which cut through

the circle at BB, and also through the upper horizontal line at CC. These two points mark the centres for the radii of the flange terminals, if such are required, and also indicate the thickness of the metal.

Flangeless Grooves.—Finding that superposed flanges do not contribute in any way to better transmission, but rather prevent the rope falling direct into its working position if the driving is at all unsteady, besides crippling any extension in the direction of a larger diameter, many engineers are now adopting flangeless grooves, which are set out in precisely the same manner, only that the angles are extended and simply rounded off at the terminals, as shown in the section (Fig. 2).

The pitch is gained by measuring from centre to centre of mid-feathers along the horizontal line passing through the circle, and this multiplied by the number of ropes, adding the thickness of two splices to represent the extra metal required for outside flanges, will give the total width of the pulley.

Setting Out a 30-Deg. Groove (Fig. 3).—The only alteration in the above method when drawing a 30-deg. groove is the length of the measuring line, which, instead of being represented by the chord AB, is extended to a point where a line resting at 45 deg. from the centre of the rope (Fig. 2) intersects the circle at C (Fig. 3). The line (BC) measures the depth of the groove, and, repeated, points the inverted apex of the angle.

Grooves for Carrier Pulleys.—

Grooves having no power to transmit, but which are merely used to bear up or conduct ropes out of the straight driving path, should be so constructed that they (the ropes) may rest easily at the bottom, while the mid-feathers open outwards. The pitch of these grooves should, of course, correspond with the transmitters to which they are tributary.

Plaster Casts of Grooves.—When templates of existing grooves are required, the quickest and surest way is to take plaster casts, the grooves being previously well greased. These give more readily measured definitions than may be secured by attempting to cut pieces of timber, tin, or other available material to the desired shape, which serve rather to perplex than to guide the judgment in the selection of suitable ropes, particularly when the pairs do not agree, although respectively intended to represent the grooves of driving and driven pulleys.




FIG. 3.—Setting Out a 30-degree Groove.

* Abstract of a paper read before the South Wales Institute of Engineers by Mr. Edwin Kenyon, of Messrs. William Kenyon & Sons, Ltd., Dukinfield, near Manchester, inserted by kind permission of the author.

TABLE XXXVIII.*

To be used in estimating the size and number of ropes for Main Driving Pulleys on shafts of—

Single-cylinder single-acting (Otto cycle) gas engines or

Vis-à-vis " " " "

Twin " " " "

Table of Horse-Powers which good "Three-Strand Cotton Driving Ropes will transmit (allowing a good margin of safety), running upon Pulleys not less than Thirty Times their Respective Diameters.

Diameter of Rope.	1"	1½"	1¾"	1⅞"	2"	2½"	3"	3½"	4"
Velocity in ft. per min.									
1000	1.6	2.0	2.5	3.0	3.7	4.3	5.0	5.7	6.5
1100	1.8	2.2	2.8	3.3	4.0	4.7	5.5	6.3	7.1
1200	1.9	2.4	3.0	3.6	4.4	5.1	6.0	6.9	7.8
1300	2.1	2.6	3.3	4.0	4.8	5.6	6.5	7.4	8.4
1400	2.3	2.8	3.5	4.3	5.2	6.0	7.0	8.0	9.1
1500	2.4	3.0	3.8	4.6	5.5	6.4	7.5	8.6	9.8
1600	2.6	3.3	4.0	4.9	5.9	6.9	8.0	9.2	10.4
1700	2.7	3.5	4.3	5.2	6.3	7.3	8.5	9.7	11.1
1800	2.9	3.7	4.5	5.5	6.7	7.7	9.0	10.3	11.7
1900	3.1	3.9	4.8	5.8	7.0	8.1	9.5	10.9	12.4
2000	3.2	4.1	5.1	6.1	7.4	8.6	10.0	11.4	13.0
2100	3.4	4.3	5.3	6.4	7.8	9.0	10.5	12.0	13.7
2200	3.5	4.5	5.6	6.7	8.1	9.4	11.0	12.6	14.3
2300	3.7	4.7	5.8	7.0	8.5	9.9	11.5	13.2	15.0
2400	3.9	4.9	6.1	7.3	8.9	10.3	12.0	13.8	15.6
2500	4.0	5.1	6.3	7.6	9.2	10.7	12.5	14.3	16.3
2600	4.2	5.3	6.6	7.8	9.6	11.2	13.0	14.9	16.9
2700	4.3	5.5	6.8	8.3	10.0	11.6	13.5	15.5	17.6
2800	4.5	5.7	7.1	8.5	10.4	12.0	14.0	16.1	18.2
2900	4.7	5.9	7.3	8.8	10.7	12.5	14.5	16.6	18.9
3000	4.8	6.1	7.6	9.1	11.1	12.9	15.0	17.2	19.5
3100	5.0	6.3	7.9	9.4	11.5	13.3	15.5	17.8	20.2
3200	5.2	6.6	8.1	9.8	11.9	13.8	16.0	18.4	20.9
3300	5.3	6.8	8.4	10.1	12.3	14.2	16.5	18.9	21.5
3400	5.5	7.0	8.6	10.4	12.6	14.6	17.0	19.5	22.2
3500	5.6	7.2	8.9	10.7	13.0	15.0	17.5	20.1	22.8
3600	5.8	7.4	9.1	11.0	13.4	15.5	18.0	20.7	23.5
3700	6.0	7.6	9.4	11.3	13.7	15.9	18.5	21.2	24.1
3800	6.1	7.8	9.6	11.6	14.1	16.3	19.0	21.8	24.8
3900	6.3	8.0	9.9	11.9	14.5	16.8	19.5	22.4	25.4
4000	6.5	8.2	10.2	12.2	14.8	17.2	20.0	23.0	26.1
4100	6.6	8.4	10.4	12.5	15.2	17.6	20.5	23.5	26.7
4200	6.8	8.6	10.7	12.8	15.6	18.1	21.0	24.1	27.4
4300	6.9	8.8	10.9	13.1	15.9	18.5	21.5	24.7	28.0
4400	7.1	9.0	11.2	13.4	16.4	18.9	22.0	25.3	28.7
4500	7.3	9.2	11.4	13.7	16.7	19.4	22.5	25.8	29.3
4600	7.4	9.4	11.7	14.0	17.1	19.8	23.0	26.4	30.0
4700	7.6	9.6	11.9	14.3	17.4	20.2	23.5	27.0	30.6
4800	7.8	9.9	12.2	14.7	17.8	20.7	24.0	27.6	31.3
4900	7.9	10.1	12.4	15.0	18.2	21.1	24.5	28.1	32.0
5000	8.1	10.3	12.7	15.3	18.5	21.5	25.0	28.7	32.7

For circumferential speed of pulleys, see Table XXXIV., p. 271.

NOTE.—The most economical velocities for rope drives of this class are from 3000 to 4500 feet per minute. In no case should the velocity exceed 5000 feet per minute.

In Table XXXVIII. a very ample margin of safety has been allowed in order to secure a long life of the ropes; the power may be increased by 15 per cent. with safety.

* This table has been specially prepared by Messrs. William Kenyon & Sons, Ltd., Dukinfield, near Manchester, for this class of drive.

TABLE XXXIX.

TABLE OF THE CIRCUMFERENCES AND AREAS OF CIRCLES, ADVANCING BY 8THS.

Diamr.	0		$\frac{1}{8}$		$\frac{1}{4}$		$\frac{3}{8}$		$\frac{1}{2}$		$\frac{5}{8}$		$\frac{3}{4}$		$\frac{7}{8}$		Diamr.
	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	
0	—	—	·3927	·0123	·7854	·0491	1·178	·1104	1·571	·1963	1·964	·3068	2·356	·4418	2·749	·6013	0
1	3·142	·7854	3·534	·9940	3·927	1·227	4·320	1·485	4·712	1·767	5·105	2·074	5·498	2·405	5·891	2·761	1
2	6·283	3·142	6·676	3·547	7·069	3·976	7·461	4·430	7·854	4·909	8·247	5·412	8·639	5·940	9·032	6·492	2
3	9·425	7·069	9·818	7·670	10·21	8·296	10·60	8·946	11·00	9·621	11·39	10·32	11·78	11·04	12·17	11·79	3
4	12·57	12·57	12·96	13·36	13·35	14·19	13·74	15·03	14·14	15·90	14·53	16·80	14·92	17·72	15·32	18·67	4
5	15·71	19·64	16·10	20·63	16·49	21·65	16·89	22·69	17·28	23·76	17·67	24·85	18·06	25·97	18·46	27·11	5
6	18·85	28·27	19·24	29·46	19·64	30·68	20·03	31·92	20·42	33·18	20·81	34·47	21·21	35·78	21·60	37·12	6
7	21·99	38·48	22·38	39·87	22·78	41·28	23·17	42·72	23·56	44·18	23·95	45·66	24·35	47·17	24·74	48·71	7
8	25·13	50·27	25·53	51·85	25·92	53·46	26·31	55·09	26·70	56·75	27·10	58·43	27·49	60·13	27·88	61·86	8
9	28·27	63·62	28·67	65·40	29·06	67·20	29·45	69·03	29·85	70·88	30·24	72·76	30·63	74·66	31·02	76·59	9
10	31·42	78·54	31·81	80·52	32·20	82·52	32·59	84·54	32·99	86·59	33·38	88·66	33·77	90·76	34·16	92·89	10
11	34·56	95·03	34·95	97·21	35·34	99·40	35·74	101·6	36·13	103·9	36·52	106·1	36·91	108·4	37·31	110·8	11
12	37·70	113·1	38·09	115·5	38·48	117·9	38·88	120·3	39·27	122·7	39·67	125·2	40·06	127·7	40·45	130·2	12
13	40·84	132·7	41·23	135·3	41·63	137·9	42·02	140·5	42·41	143·1	42·80	145·8	43·20	148·5	43·59	151·2	13
14	43·98	153·9	44·38	156·7	44·77	159·5	45·16	162·3	45·55	165·1	45·95	168·0	46·34	170·9	46·73	173·8	14
15	47·12	176·7	47·52	179·7	47·91	182·7	48·30	185·7	48·69	188·7	49·09	191·7	49·48	194·8	49·87	197·9	15
16	50·27	201·1	50·66	204·2	51·05	207·4	51·44	210·6	51·84	213·8	52·23	217·1	52·62	220·4	53·01	223·7	16
17	53·41	227·0	53·80	230·3	54·19	233·7	54·59	237·1	54·98	240·5	55·37	244·0	55·76	247·4	56·16	250·9	17
18	56·55	254·5	56·94	258·0	57·33	261·6	57·73	265·2	58·12	268·8	58·51	272·4	58·90	276·1	59·30	279·8	18
19	59·69	283·5	60·08	287·3	60·48	291·1	60·87	294·8	61·26	298·6	61·65	302·5	62·05	306·4	62·44	310·2	19
Diamr.	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Diamr.
0			$\frac{1}{8}$		$\frac{1}{4}$		$\frac{3}{8}$		$\frac{1}{2}$		$\frac{5}{8}$		$\frac{3}{4}$		$\frac{7}{8}$		

TABLE OF THE CIRCUMFERENCES AND AREAS OF CIRCLES, ADVANCING BY 8THS (continued).

Diamr.	0		$\frac{1}{8}$		$\frac{1}{4}$		$\frac{3}{8}$		$\frac{1}{2}$		$\frac{5}{8}$		$\frac{3}{4}$		$\frac{7}{8}$		Diamr.
	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	
20	62·83	314·2	63·22	318·1	63·62	322·1	64·01	326·1	64·40	330·1	64·80	334·1	65·19	338·2	65·58	342·3	20
21	65·97	346·4	66·37	350·5	66·76	354·7	67·15	358·8	67·54	363·1	67·94	367·3	68·33	371·5	68·72	375·8	21
22	69·12	380·1	69·51	384·5	69·90	388·8	70·29	393·2	70·69	397·6	71·08	402·0	71·47	406·5	71·86	411·0	22
23	72·26	415·5	72·65	420·0	73·04	424·6	73·43	429·1	73·83	433·7	74·22	438·4	74·61	443·0	75·01	447·7	23
24	75·40	452·4	75·79	457·1	76·18	461·9	76·58	466·6	76·97	471·4	77·36	476·3	77·75	481·1	78·15	486·0	24
25	78·54	490·9	78·93	495·8	79·33	500·7	79·72	505·7	80·11	510·7	80·50	515·7	80·90	520·8	81·29	525·8	25
26	81·68	530·9	82·07	536·0	82·47	541·2	82·86	546·4	83·25	551·5	83·64	556·8	84·04	562·0	84·43	567·3	26
27	84·82	572·6	85·22	577·9	85·61	583·2	86·00	588·6	86·39	594·0	86·79	599·4	87·18	604·8	87·57	610·3	27
28	87·96	615·8	88·36	621·3	88·75	626·8	89·14	632·4	89·54	637·9	89·93	643·5	90·32	649·2	90·71	654·8	28
29	91·11	660·5	91·50	666·2	91·89	672·0	92·28	677·7	92·68	683·5	93·07	689·3	93·46	695·1	93·86	701·0	29
30	94·25	706·9	94·64	712·8	95·03	718·7	95·43	724·6	95·82	730·6	96·21	736·6	96·60	742·6	97·00	748·7	30
31	97·39	754·8	97·78	760·9	98·17	767·0	98·57	773·1	98·96	779·3	99·35	785·5	99·75	791·7	100·1	798·0	31
32	100·5	804·2	100·9	810·5	101·3	816·9	101·7	823·2	102·1	829·6	102·5	836·0	102·9	842·4	103·3	848·8	32
33	103·7	855·3	104·1	861·8	104·5	868·3	104·9	874·8	105·2	881·4	105·6	888·0	106·0	894·6	106·4	901·3	33
34	106·8	907·9	107·2	914·6	107·6	921·3	108·0	928·1	108·4	934·8	108·8	941·6	109·2	948·4	109·6	955·3	34
35	110·0	962·1	110·3	969·0	110·7	975·9	111·1	982·8	111·5	989·8	111·9	996·8	112·3	1003·8	112·7	1010·8	35
36	113·1	1017·9	113·5	1025·0	113·9	1032·1	114·3	1039·2	114·7	1046·3	115·1	1053·5	115·5	1060·7	115·8	1068·0	36
37	116·2	1075·2	116·6	1082·5	117·0	1089·8	117·4	1097·1	117·8	1104·5	118·2	1111·8	118·6	1119·2	119·0	1126·7	37
38	119·4	1134·1	119·8	1141·6	120·2	1149·1	120·6	1156·6	121·0	1164·2	121·3	1171·7	121·7	1179·3	122·1	1186·9	38
39	122·5	1194·6	122·9	1202·3	123·3	1210·0	123·7	1217·7	124·1	1225·4	124·5	1233·2	124·9	1241·0	125·3	1248·8	39
Diamr.	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Diamr.
0			$\frac{1}{8}$		$\frac{1}{4}$		$\frac{3}{8}$		$\frac{1}{2}$		$\frac{5}{8}$		$\frac{3}{4}$		$\frac{7}{8}$		

TABLE XXXIX. (continued).

Diamr.	0		$\frac{1}{8}$		$\frac{1}{4}$		$\frac{3}{8}$		$\frac{1}{2}$		$\frac{5}{8}$		$\frac{3}{4}$		$\frac{7}{8}$		Diamr.
	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	
40	125·7	1256·6	126·1	1264·5	126·4	1272·4	126·8	1280·3	127·2	1288·2	127·6	1296·2	128·0	1304·2	128·4	1312·2	40
41	128·8	1320·3	129·2	1328·3	129·6	1336·4	130·0	1344·5	130·4	1352·7	130·8	1360·8	131·2	1369·0	131·6	1377·2	41
42	131·9	1385·4	132·3	1393·7	132·7	1402·0	133·1	1410·3	133·5	1418·6	133·9	1427·0	134·3	1435·4	134·7	1443·8	42
43	135·1	1452·2	135·5	1460·7	135·9	1469·1	136·3	1477·6	136·7	1486·2	137·1	1494·7	137·4	1503·3	137·8	1511·9	43
44	138·2	1520·5	138·6	1529·2	139·0	1537·9	139·4	1546·6	139·8	1555·3	140·2	1564·0	140·6	1572·8	141·0	1581·6	44
45	141·4	1590·4	141·8	1599·3	142·2	1608·2	142·5	1617·0	142·9	1626·0	143·3	1634·9	143·7	1643·9	144·1	1652·9	45
46	144·5	1661·9	144·9	1671·0	145·3	1680·0	145·7	1689·1	146·1	1698·2	146·5	1707·4	146·9	1716·6	147·3	1725·7	46
47	147·7	1734·9	148·0	1744·2	148·4	1753·5	148·8	1762·7	149·2	1772·1	149·6	1781·4	150·0	1790·8	150·4	1800·1	47
48	150·8	1809·6	151·2	1819·0	151·6	1828·5	152·0	1837·9	152·4	1847·5	152·8	1857·0	153·2	1866·6	153·6	1876·1	48
49	153·9	1885·7	154·3	1895·4	154·7	1905·0	155·1	1914·7	155·5	1924·4	155·9	1934·2	156·3	1943·9	156·7	1953·7	49
50	157·1	1963·8	157·5	1973·3	157·9	1983·2	158·3	1993·1	158·7	2003·0	159·0	2012·9	159·4	2022·8	159·8	2032·8	50
51	160·2	2042·8	160·6	2052·8	161·0	2062·9	161·4	2073·0	161·8	2083·1	162·2	2093·2	162·6	2103·4	163·0	2113·5	51
52	163·4	2123·7	163·8	2133·9	164·1	2144·2	164·5	2154·5	164·9	2164·8	165·3	2175·1	165·7	2185·4	166·1	2195·8	52
53	166·5	2206·2	166·9	2216·6	167·3	2227·0	167·7	2237·5	168·1	2248·0	168·5	2258·5	168·9	2269·1	169·3	2279·6	53
54	169·6	2290·2	170·0	2300·8	170·4	2311·5	170·8	2322·1	171·2	2332·8	171·6	2343·5	172·0	2354·3	172·4	2365·0	54
55	172·8	2375·8	173·2	2386·6	173·6	2397·5	174·0	2408·3	174·4	2419·2	174·8	2430·1	175·1	2441·1	175·5	2452·0	55
56	175·9	2463·0	176·3	2474·0	176·7	2485·0	177·1	2496·1	177·5	2507·2	177·9	2518·3	178·3	2529·4	178·7	2540·6	56
57	179·1	2551·8	179·5	2563·0	179·9	2574·2	180·2	2585·4	180·6	2596·7	181·0	2608·0	181·4	2619·4	181·8	2630·7	57
58	182·2	2642·1	182·6	2653·5	183·0	2664·9	183·4	2676·4	183·8	2687·8	184·2	2699·3	184·6	2710·9	185·0	2722·4	58
59	185·4	2734·0	185·7	2745·6	186·1	2757·2	186·5	2768·8	186·9	2780·5	187·3	2792·2	187·7	2803·9	188·1	2815·7	59

Diamr.	0		$\frac{1}{8}$		$\frac{1}{4}$		$\frac{3}{8}$		$\frac{1}{2}$		$\frac{5}{8}$		$\frac{3}{4}$		$\frac{7}{8}$		Diamr.
	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	
60	188-5	2827-4	188-9	2839-2	189-3	2851-0	189-7	2862-9	190-1	2874-8	190-5	2886-6	190-9	2898-6	191-2	2910-5	60
61	191-6	2922-5	192-0	2934-5	192-4	2946-5	192-8	2958-5	193-2	2970-6	193-6	2982-7	194-0	2994-8	194-4	3006-9	61
62	194-8	3019-1	195-2	3031-3	195-6	3043-5	196-0	3055-7	196-3	3068-0	196-7	3080-2	197-1	3092-6	197-5	3104-9	62
63	197-9	3117-2	198-3	3129-6	198-7	3142-0	199-1	3154-5	199-5	3166-9	199-9	3179-4	200-3	3191-9	200-7	3204-4	63
64	201-1	3217-0	201-5	3229-6	201-8	3242-2	202-2	3254-8	202-6	3267-5	203-0	3280-1	203-4	3292-8	203-8	3305-6	64
65	204-2	3318-3	204-6	3331-1	205-0	3343-9	205-4	3356-7	205-8	3369-6	206-2	3382-4	206-6	3395-3	207-0	3408-3	65
66	207-3	3421-2	207-7	3434-2	208-1	3447-2	208-5	3460-2	208-9	3473-2	209-3	3486-3	209-7	3499-4	210-1	3512-5	66
67	210-6	3525-7	210-9	3538-8	211-3	3552-0	211-7	3565-2	212-1	3578-5	212-5	3591-7	212-8	3605-0	213-2	3618-4	67
68	213-6	3631-7	214-0	3645-1	214-4	3658-4	214-8	3671-8	215-2	3685-3	215-6	3698-7	216-0	3712-2	216-4	3725-7	68
69	216-8	3739-3	217-2	3752-8	217-6	3766-4	217-9	3780-0	218-3	3793-7	218-7	3807-3	219-1	3821-0	219-5	3834-7	69
70	219-9	3848-5	220-3	3862-2	220-7	3876-0	221-1	3889-8	221-5	3903-6	221-9	3917-5	222-3	3931-4	222-7	3945-3	70
71	223-1	3959-2	223-4	3937-2	223-8	3937-1	224-2	4001-1	224-6	4015-2	225-0	4029-2	225-4	4043-3	225-8	4057-4	71
72	226-2	4071-5	226-6	4085-7	227-0	4099-8	227-4	4114-0	227-8	4128-2	228-2	4142-5	228-6	4156-8	228-9	4171-2	72
73	229-3	4185-4	229-7	4199-7	230-1	4214-1	230-5	4228-5	230-9	4242-9	231-3	4257-4	231-7	4271-8	232-1	4286-3	73
74	232-5	4300-9	232-9	4315-4	233-3	4330-0	233-7	4344-6	234-0	4359-2	234-4	4373-8	234-8	4388-5	235-2	4403-2	74
75	235-6	4417-9	236-0	4432-6	236-4	4447-4	236-8	4462-2	237-2	4477-0	237-6	4491-8	238-0	4506-7	238-4	4521-5	75
76	238-8	4536-5	239-2	4551-4	239-5	4566-4	240-0	4581-3	240-3	4596-3	240-7	4611-4	241-1	4626-4	241-5	4641-5	76
77	241-9	4656-6	242-3	4671-8	242-7	4686-9	243-1	4702-1	243-5	4717-3	243-9	4732-5	244-3	4747-8	244-7	4763-1	77
78	245-0	4778-4	245-4	4793-7	245-8	4809-0	246-2	4824-4	246-6	4839-8	247-0	4855-2	247-4	4870-7	247-8	4886-2	78
79	248-2	4901-7	248-6	4917-2	249-0	4932-7	249-4	4948-3	249-8	4963-9	250-1	4979-5	250-5	4995-2	250-9	5010-9	79

TABLE XXXIX. (continued).

TABLE OF THE CIRCUMFERENCES AND AREAS OF CIRCLES, ADVANCING BY 8THS (concluded).																	
Diamr.	0		$\frac{1}{8}$		$\frac{1}{4}$		$\frac{3}{8}$		$\frac{1}{2}$		$\frac{5}{8}$		$\frac{3}{4}$		$\frac{7}{8}$		Diamr.
	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	
80	251.3	5026.5	251.7	5042.3	252.1	5058.0	252.5	5073.8	252.9	5089.6	253.3	5105.4	253.7	5121.2	254.1	5137.1	80
81	254.5	5153.0	254.9	5168.9	255.3	5184.9	255.6	5200.8	256.0	5216.8	256.4	5232.8	256.8	5248.9	257.2	5264.9	81
82	257.6	5281.0	258.0	5297.1	258.4	5313.3	258.8	5329.4	259.2	5345.6	259.6	5361.8	260.0	5378.1	260.4	5394.3	82
83	260.8	5410.6	261.1	5426.9	261.5	5443.3	261.9	5459.6	262.3	5476.0	262.7	5492.4	263.1	5508.8	263.5	5525.3	83
84	263.9	5541.8	264.3	5558.3	264.7	5574.8	265.1	5591.4	265.5	5607.9	265.9	5624.5	266.3	5641.2	266.6	5657.8	84
85	267.0	5674.5	267.4	5691.2	267.8	5707.9	268.2	5724.7	268.6	5741.5	269.0	5758.3	269.4	5775.1	269.8	5791.9	85
86	270.2	5808.8	270.6	5825.7	271.0	5842.6	271.4	5859.6	271.7	5876.5	272.1	5893.5	272.5	5910.6	272.9	5927.6	86
87	273.3	5944.7	273.7	5961.8	274.1	5978.9	274.5	5996.0	274.9	6013.2	275.3	6030.4	275.7	6047.6	276.1	6064.9	87
88	276.5	6082.1	276.9	6099.4	277.2	6116.7	277.6	6134.1	278.0	6151.4	278.4	6168.8	278.8	6186.2	279.2	6203.7	88
89	279.6	6221.2	280.0	6238.6	280.4	6256.1	280.8	6273.7	281.2	6291.2	281.6	6308.8	282.0	6326.4	282.4	6344.1	89
90	282.7	6361.7	283.1	6379.4	283.5	6397.1	283.9	6414.8	284.3	6432.6	284.7	6450.4	285.1	6468.2	285.5	6486.0	90
91	285.9	6503.9	286.3	6521.8	286.7	6539.7	287.1	6557.6	287.5	6575.5	287.8	6593.5	288.2	6611.5	288.6	6629.6	91
92	289.0	6647.6	289.4	6665.7	289.8	6683.8	290.2	6701.9	290.6	6720.1	291.0	6738.2	291.4	6756.4	291.8	6774.7	92
93	292.2	6793.0	292.6	6811.2	293.0	6829.5	293.3	6847.8	293.7	6866.1	294.1	6884.5	294.5	6902.9	294.9	6921.3	93
94	295.3	6939.8	295.7	6958.2	296.1	6976.7	296.5	6995.3	296.9	7013.8	297.3	7032.4	297.7	7051.0	298.1	7069.6	94
95	298.5	7088.2	298.8	7106.9	299.2	7125.6	299.6	7144.3	300.0	7163.0	300.4	7181.8	300.8	7200.6	301.2	7219.4	95
96	301.6	7238.2	302.0	7257.1	302.4	7276.0	302.8	7294.9	303.2	7313.8	303.6	7332.8	303.9	7351.8	304.3	7370.8	96
97	304.7	7389.8	305.1	7408.9	305.5	7428.0	305.9	7447.1	306.3	7466.2	306.7	7485.3	307.1	7504.5	307.5	7523.7	97
98	307.9	7543.0	308.3	7562.2	308.7	7581.5	309.1	7600.8	309.4	7620.1	309.8	7639.5	310.2	7658.9	310.6	7678.3	98
99	311.0	7697.7	311.4	7717.2	311.8	7736.6	312.2	7756.1	312.6	7775.6	313.0	7795.2	313.4	7814.8	313.8	7834.4	99
Diamr.	0		$\frac{1}{8}$		$\frac{1}{4}$		$\frac{3}{8}$		$\frac{1}{2}$		$\frac{5}{8}$		$\frac{3}{4}$		$\frac{7}{8}$		Diamr.
	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	Circum.	Area	

(Reproduced by permission from Mackrow's "Naval Architects' Pocket-book.")

TABLE XL.

TABLE OF THE CIRCUMFERENCES OF CIRCLES, ADVANCING BY 10THS.											
Diamr.	Circumferences										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	
0	·0000	·3142	·6283	·9425	1·2566	1·5708	1·8850	2·1991	2·5133	2·8274	0
1	3·1416	3·4557	3·7699	4·0840	4·3982	4·7124	5·0265	5·3407	5·6548	5·9690	1
2	6·2832	6·5973	6·9115	7·2256	7·5398	7·8540	8·1681	8·4823	8·7964	9·1106	2
3	9·4248	9·7389	10·0531	10·3672	10·6814	10·9956	11·3097	11·6239	11·9380	12·2522	3
4	12·5664	12·8805	13·1947	13·5088	13·8230	14·1372	14·4513	14·7655	15·0796	15·3938	4
5	15·7080	16·0221	16·3363	16·6504	16·9646	17·2788	17·5929	17·9071	18·2212	18·5354	5
6	18·8496	19·1637	19·4779	19·7920	20·1062	20·4204	20·7345	21·0487	21·3628	21·6770	6
7	21·9912	22·3053	22·6195	22·9336	23·2478	23·5620	23·8761	24·1903	24·5044	24·8186	7
8	25·1328	25·4469	25·7611	26·0752	26·3894	26·7036	27·0177	27·3319	27·6460	27·9602	8
9	28·2744	28·5885	28·9027	29·2168	29·5310	29·8452	30·1593	30·4735	30·7876	31·1018	9
10	31·4160	31·7301	32·0443	32·3585	32·6726	32·9868	33·3009	33·6150	33·9292	34·2434	10
11	34·5576	34·8717	35·1859	35·5010	35·8142	36·1284	36·4425	36·7567	37·0708	37·3840	11
12	37·6992	38·0133	38·3275	38·6416	38·9558	39·2700	39·5841	39·8983	40·2124	40·5266	12
13	40·8408	41·1549	41·4691	41·7832	42·0974	42·4116	42·7257	43·0399	43·3540	43·6682	13
14	43·9824	44·2965	44·6107	44·9248	45·2390	45·5532	45·8673	46·1815	46·4956	46·8098	14
15	47·1240	47·4381	47·7523	48·0664	48·3806	48·6948	49·0089	49·3231	49·6372	49·9514	15
16	50·2656	50·5797	50·8939	51·2080	51·5224	51·8364	52·1505	52·4647	52·7788	53·0930	16
17	53·4072	53·7213	54·0355	54·3496	54·6638	54·9780	55·2921	55·6063	55·9204	56·2346	17
18	56·5488	56·8629	57·1771	57·4912	57·8054	58·1196	58·4337	58·7479	59·0620	59·3762	18
19	59·6904	60·0045	60·3187	60·6328	60·9470	61·2612	61·5753	61·8895	62·2036	62·5178	19
Diamr.	Circumferences										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	

TABLE XL. (continued).

280

Diamr.	Circumferences										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	
20	62·8320	63·1461	63·4603	63·7744	64·0886	64·4028	64·7161	65·0311	65·3452	65·6594	20
21	65·9736	66·2870	66·6012	66·7916	67·2930	67·5444	67·8585	68·1727	68·4868	68·8010	21
22	69·1152	69·4293	69·7435	70·0576	70·3718	70·6860	71·0001	71·3143	71·6284	71·9426	22
23	72·2568	72·5709	72·8851	73·1992	73·5134	73·8276	74·1417	74·4559	74·7680	75·0882	23
24	75·3984	75·7125	76·0267	76·3408	76·6523	76·9692	77·2833	77·5975	77·9116	78·2258	24
25	78·5400	78·8541	79·1683	79·4824	79·7966	80·1108	80·4249	80·7391	81·0532	81·3674	25
26	81·6816	82·3099	82·6240	82·6240	82·9382	83·2524	83·5665	83·8807	84·1948	84·5090	26
27	84·8232	85·1373	85·4515	85·7656	86·0798	86·3940	86·7081	87·0223	87·3364	87·6506	27
28	87·9648	88·2789	88·5931	88·9072	89·2214	89·5315	89·8497	90·1639	90·4780	90·7922	28
29	91·1064	91·4205	91·7347	92·0488	92·3630	92·6772	92·9913	93·3055	93·6196	93·9338	29
30	94·2480	94·5621	94·8763	95·1904	95·5046	95·8188	96·1329	96·4471	96·7612	97·0754	30
31	97·3896	97·7037	98·0179	98·3320	98·6452	98·9604	99·2745	99·5887	99·9028	100·217	31
32	100·531	100·845	101·160	101·474	101·748	102·102	102·416	102·730	103·044	103·359	32
33	103·673	103·987	104·301	104·615	104·929	105·244	105·558	105·872	106·186	106·500	33
34	106·814	107·129	107·427	107·757	108·071	108·385	108·699	109·035	109·308	109·642	34
35	109·956	110·270	110·584	110·898	112·213	111·527	111·841	112·155	112·469	112·783	35
36	113·098	113·412	113·726	114·040	114·354	114·668	114·983	115·297	115·611	115·925	36
37	116·239	116·553	116·868	117·182	117·496	117·810	118·124	118·438	118·752	119·067	37
38	119·381	119·695	120·009	120·323	120·637	120·952	121·266	121·580	121·894	122·208	38
39	122·522	122·837	123·151	123·465	123·779	124·093	124·407	124·722	125·036	125·350	39
Diamr.	Circumferences										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	

Diamr.	Circumferences										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	
40	125·664	125·978	126·292	126·606	126·921	127·235	127·549	127·863	128·177	128·491	40
41	128·806	129·120	129·432	129·748	130·062	130·376	130·691	131·005	131·319	131·632	41
42	131·947	132·261	132·576	132·890	133·204	133·518	133·832	134·146	134·460	134·775	42
43	135·089	135·403	135·717	136·033	136·345	136·660	136·974	137·288	137·602	137·916	43
44	138·230	138·545	138·859	139·173	139·487	139·801	140·115	140·430	140·744	141·058	44
45	141·372	141·686	142·000	142·314	142·629	142·943	143·257	143·571	143·885	144·199	45
46	144·514	144·828	145·142	145·456	145·770	146·084	146·399	146·713	147·027	147·341	46
47	147·655	147·969	148·284	148·598	148·912	149·226	149·536	149·854	150·168	150·483	47
48	150·797	151·111	151·425	151·739	152·053	152·368	152·682	152·996	153·310	153·624	48
49	153·938	154·253	154·567	154·881	155·195	155·509	155·823	156·138	156·452	156·766	49
50	157·080	157·394	157·708	158·022	158·337	158·651	158·965	159·279	159·593	159·907	50
51	160·222	160·536	160·850	161·164	161·478	161·792	162·107	162·421	162·734	163·049	51
52	163·363	163·677	163·994	164·306	164·620	164·934	165·248	165·562	165·876	166·191	52
53	166·506	166·819	167·133	167·447	167·761	168·076	168·390	168·705	169·018	169·332	53
54	169·646	169·961	170·275	170·589	170·903	171·217	171·531	171·846	172·160	172·474	54
55	172·788	173·102	173·416	173·730	174·045	174·359	174·673	174·977	175·309	175·615	55
56	175·930	176·244	176·558	176·872	177·186	177·500	177·815	178·129	178·443	178·757	56
57	179·071	179·385	179·700	180·014	180·328	180·642	180·956	181·280	181·584	181·899	57
58	182·213	182·527	182·841	183·155	183·469	183·784	184·098	184·412	184·726	185·040	58
59	185·354	185·669	185·983	186·270	186·611	186·925	187·239	187·554	187·868	188·182	59
Diamr.	Circumferences										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	

TABLE XL. (continued).

TABLE OF THE CIRCUMFERENCES OF CIRCLES, ADVANCING BY 10THS (continued).											
Diamr.	Circumferences										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	
60	188.496	188.510	189.124	189.438	189.753	190.067	190.381	190.695	191.009	191.323	60
61	191.638	191.952	192.266	192.580	192.894	193.208	193.523	193.837	194.151	194.465	61
62	194.779	195.093	195.408	195.722	196.036	196.350	196.664	196.978	197.292	197.607	62
63	197.921	198.235	198.549	198.863	199.177	199.492	199.806	200.120	200.434	200.748	63
64	201.062	201.377	201.691	202.005	202.319	202.633	202.947	203.262	203.576	203.890	64
65	204.204	204.518	204.832	205.146	205.461	205.775	206.089	206.403	206.717	207.031	65
66	207.346	207.660	207.974	208.288	208.602	208.916	209.231	209.545	209.859	210.173	66
67	210.487	210.801	211.116	211.430	211.744	212.058	212.372	212.686	213.000	213.315	67
68	213.629	213.943	214.257	214.571	214.885	215.200	215.514	215.828	216.142	216.456	68
69	216.770	217.085	217.399	217.713	218.027	218.341	218.655	218.970	219.284	219.598	69
70	219.912	220.226	220.540	220.854	221.169	221.483	221.797	222.111	222.425	222.739	70
71	223.054	223.368	223.682	223.996	224.310	224.624	224.939	225.253	225.567	225.881	71
72	226.195	226.509	226.824	227.138	227.452	227.766	228.080	228.394	228.708	229.023	72
73	229.337	229.651	229.965	230.279	230.593	230.908	231.222	231.536	231.850	232.164	73
74	232.478	232.793	233.107	233.421	233.735	234.049	234.363	234.678	234.992	235.306	74
75	235.620	235.934	236.248	236.562	236.877	237.191	237.505	237.819	238.133	238.447	75
76	238.762	239.076	239.390	239.704	240.018	240.332	240.647	240.961	241.275	241.599	76
77	241.903	242.217	242.532	242.846	243.160	243.474	243.788	244.102	244.416	244.731	77
78	245.045	245.359	245.673	245.987	246.301	246.616	246.930	247.244	247.548	247.872	78
79	248.186	248.501	248.815	249.129	249.443	249.757	250.071	250.386	250.700	251.014	79
Diamr.	Circumferences										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	

(Reproduced by permission from Mackrow's "Naval Architects' Pocket-book.")

TABLE OF THE CIRCUMFERENCES OF CIRCLES, ADVANCING BY 10THS (concluded).											
Diamr.	Circumferences										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	
80	251.328	251.624	251.956	252.270	252.585	252.899	253.213	253.527	253.841	254.155	80
81	254.470	254.784	255.098	255.412	255.726	256.040	256.355	256.669	256.983	257.297	81
82	257.611	257.925	258.240	258.554	258.865	259.182	259.496	259.810	260.124	260.439	82
83	260.753	261.067	261.381	261.695	262.009	262.324	262.638	262.952	263.264	263.580	83
84	263.894	264.209	264.523	264.837	265.151	265.465	265.779	266.094	266.408	266.722	84
85	267.036	267.350	267.664	267.978	268.293	268.607	268.921	269.235	269.549	269.863	85
86	270.178	270.492	270.806	271.120	271.434	271.748	272.067	272.377	272.691	273.005	86
87	273.319	273.633	273.988	274.262	274.576	274.890	275.204	275.518	275.832	276.147	87
88	276.461	276.775	277.089	277.403	277.717	278.032	278.346	278.660	278.975	279.288	88
89	279.602	279.917	280.231	280.545	280.859	281.173	281.487	281.833	282.116	282.430	89
90	282.744	283.058	283.372	283.686	284.001	284.315	284.629	284.943	285.257	285.571	90
91	285.886	286.200	286.514	286.829	287.142	287.456	287.771	288.085	288.399	288.713	91
92	289.027	289.341	289.656	289.970	290.284	290.598	290.912	291.226	291.540	291.855	92
93	292.169	292.483	292.797	293.111	293.425	293.740	294.054	294.368	294.682	294.996	93
94	295.310	295.625	295.939	296.244	296.567	296.881	297.195	297.510	297.824	298.138	94
95	298.452	298.766	299.072	299.394	299.709	300.023	300.337	300.651	300.965	301.279	95
96	301.594	301.908	302.222	302.536	302.850	303.164	303.479	303.793	304.107	304.421	96
97	304.735	305.049	305.364	305.678	305.992	306.306	306.620	306.936	307.248	307.563	97
98	307.877	308.191	308.505	308.819	309.133	309.448	309.762	310.076	310.396	310.704	98
99	311.018	311.333	311.647	311.961	312.275	312.589	312.903	313.218	313.512	313.846	99
Diamr.	Circumferences										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	

(Reproduced by permission from Mackrow's "Naval Architects' Pocket-book.")

TABLE XLI.

TABLE OF THE AREAS OF CIRCLES, ADVANCING BY 10THS.

Diamr.	Areas										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	
0	·0000	·0078	·0314	·0706	·1256	·1963	·2827	·3848	·5026	·6361	0
1	·7854	·9503	1·1309	1·3273	1·5393	1·7671	2·0106	2·2698	2·5446	2·8352	1
2	3·1416	3·4636	3·8013	4·1547	4·5239	4·9087	5·3093	5·7255	6·1575	6·6052	2
3	7·0686	7·5476	8·0424	8·5530	9·0792	9·6211	10·1787	10·7521	11·3411	11·9459	3
4	12·5664	13·2025	13·8544	14·5220	15·2053	15·9043	16·6190	17·3494	18·0956	18·8574	4
5	19·6350	20·4282	21·2372	22·0618	22·9022	23·7583	24·6301	25·5176	26·4208	27·3397	5
6	28·2744	29·2247	30·1907	31·1725	32·1699	33·1831	34·2120	35·2566	36·3168	37·3928	6
7	38·4846	39·5920	40·7151	41·8539	43·0085	44·1787	45·3647	46·5663	47·7837	49·0168	7
8	50·2656	51·5300	52·8102	54·1062	55·4178	56·7451	58·0881	59·4469	60·8213	62·2115	8
9	63·6174	65·0389	66·4762	67·9292	69·3979	70·8823	72·3824	73·8982	75·4298	76·9770	9
10	78·5400	80·1186	81·7130	83·2920	84·9488	86·5903	88·2475	89·9204	91·6090	93·3133	10
11	95·0334	96·7691	98·5205	100·2877	102·0705	103·8691	105·6834	107·5134	109·3590	111·2204	11
12	113·0976	114·9904	116·8989	118·8231	120·7631	122·7187	124·6901	126·6771	128·6799	130·6984	12
13	132·7326	134·7824	136·8480	138·9294	141·0264	143·1391	145·2675	147·4117	149·5715	151·7471	13
14	153·9384	156·1453	158·3680	160·6064	162·8605	165·1303	167·4158	169·7170	172·0340	174·3666	14
15	176·7150	179·0790	181·4588	183·8542	186·2654	188·6923	191·1349	193·5932	196·0672	198·5569	15
16	201·0624	203·5835	206·1209	208·6723	211·1411	213·8251	216·4248	219·0402	221·6712	224·3189	16
17	226·9086	229·5888	232·3527	235·0623	237·7877	240·5287	243·2855	246·0679	248·8461	251·6500	17
18	254·4696	257·3048	260·1558	263·0226	265·9050	268·8031	271·7169	274·6465	277·5917	280·5527	18
19	283·5294	286·5217	289·5298	292·5536	295·5931	298·6483	301·7192	304·8060	307·9082	311·0252	19
Diamr.	Areas										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	

TABLE OF THE AREAS OF CIRCLES, ADVANCING BY 10THS (continued).

Diamr.	Areas										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	
20	314·1600	317·3094	320·4746	323·6554	326·8520	330·0643	333·2923	336·3360	339·7954	343·0705	20
21	346·3614	349·6679	352·9901	356·3281	359·6817	363·0511	366·4362	369·8370	373·2534	376·6856	21
22	380·1336	383·5972	387·0765	390·5751	394·0823	397·6087	401·1509	404·7087	408·2823	411·8716	22
23	415·4766	419·0972	422·7336	426·3858	430·0536	433·7371	437·4363	441·1511	444·8819	448·6283	23
24	452·3904	456·1681	459·9616	463·7708	467·5957	471·4363	475·2926	479·1646	483·0524	486·9558	24
25	490·8750	494·8098	498·7604	502·7266	506·7086	510·7063	514·7196	518·7488	522·7936	526·8541	25
26	530·9304	535·0223	539·1299	543·2533	547·3923	551·5471	555·7176	559·9038	564·1056	568·3232	26
27	572·5566	576·8056	581·0703	585·3507	589·6469	593·9587	598·2863	602·6295	606·9885	611·3632	27
28	615·7536	620·1596	624·5814	629·0190	633·4722	637·9411	642·4257	646·9261	651·4421	655·9739	28
29	660·5214	665·0845	669·6634	674·2580	678·8683	683·4943	688·1360	692·7934	697·4666	702·1554	29
30	706·8600	711·5802	716·3162	721·0678	725·8352	730·6183	735·4171	740·2316	745·0618	749·9077	30
31	754·7694	759·6467	764·5397	769·4485	774·3729	779·3131	784·2689	789·2406	794·2278	799·2308	31
32	804·2496	809·2840	814·3341	819·3999	824·4815	829·5787	834·6917	839·8203	844·9647	850·1248	32
33	855·3006	860·4920	865·6992	870·9222	876·1608	881·4151	886·6851	891·9709	897·2723	902·5895	33
34	907·9224	913·2709	918·6352	924·0115	929·4109	934·8223	940·2494	945·6922	951·1508	956·6250	34
35	962·1150	967·6206	973·1420	978·6790	984·2318	989·8003	995·3845	1000·984	1006·600	1012·231	35
36	1017·878	1023·541	1029·220	1034·913	1040·624	1046·349	1052·090	1057·8474	1063·620	1069·408	36
37	1075·213	1081·032	1086·868	1092·719	1098·586	1104·469	1110·367	1116·281	1122·211	1128·156	37
38	1134·118	1140·095	1146·087	1152·095	1158·119	1164·159	1170·215	1176·286	1182·373	1188·465	38
39	1194·539	1200·727	1206·877	1213·042	1219·224	1225·420	1231·633	1237·861	1244·121	1250·365	39
Diamr.	Areas										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	

TABLE XLI. (continued).

TABLE OF THE AREAS OF CIRCLES, ADVANCING BY 10THS (continued).

Diamr.	Areas										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	
40	1256·640	1262·931	1269·239	1275·560	1281·898	1288·252	1294·622	1301·007	1307·408	1313·825	40
41	1320·257	1326·706	1333·169	1339·649	1346·144	1352·655	1359·182	1365·724	1372·282	1378·856	41
42	1385·446	1392·051	1398·672	1405·308	1411·961	1418·629	1425·313	1432·012	1438·727	1445·458	42
43	1452·205	1458·967	1465·745	1472·539	1479·348	1486·173	1493·014	1499·871	1506·743	1513·629	43
44	1520·534	1527·454	1534·389	1541·340	1548·306	1555·288	1562·286	1569·300	1576·329	1583·374	44
45	1590·435	1597·511	1604·604	1611·711	1618·835	1625·974	1633·129	1640·302	1647·486	1654·689	45
46	1661·906	1669·140	1676·389	1683·654	1690·935	1698·231	1705·543	1712·871	1720·214	1727·574	46
47	1734·949	1742·339	1749·746	1757·168	1764·605	1772·059	1779·528	1787·013	1794·513	1802·030	47
48	1809·562	1817·109	1824·673	1832·252	1839·847	1847·457	1855·083	1862·725	1870·383	1878·056	48
49	1885·745	1893·450	1901·171	1908·907	1916·659	1924·426	1932·210	1940·009	1947·823	1955·654	49
50	1963·500	1971·362	1979·239	1987·133	1995·042	2002·966	2010·907	2018·863	2026·835	2034·877	50
51	2042·825	2050·844	2058·878	2066·929	2074·995	2083·077	2091·175	2099·288	2107·417	2115·561	51
52	2123·722	2131·898	2140·089	2148·297	2156·520	2164·759	2173·013	2181·284	2189·570	2197·871	52
53	2206·189	2214·522	2222·870	2231·235	2239·615	2248·011	2256·423	2264·870	2273·293	2281·752	53
54	2290·226	2298·717	2307·222	2315·744	2324·281	2332·834	2341·403	2349·987	2358·588	2367·203	54
55	2375·835	2384·482	2393·145	2401·824	2410·518	2419·228	2427·954	2436·696	2445·453	2454·226	55
56	2463·014	2471·819	2480·639	2489·475	2498·326	2507·193	2516·076	2524·974	2533·889	2542·819	56
57	2551·765	2560·726	2569·703	2578·696	2587·705	2596·729	2605·769	2614·824	2623·896	2632·983	57
58	2642·086	2651·205	2660·338	2669·488	2678·654	2687·835	2697·032	2706·245	2715·473	2724·718	58
59	2733·977	2743·253	2752·544	2761·851	2771·174	2780·512	2789·866	2799·236	2808·622	2818·023	59
Diamr.	Areas										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	

TABLE OF THE AREAS OF CIRCLES, ADVANCING BY 10THS (continued).

Diamr.	Areas										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	
60	2827·440	2836·873	2846·321	2855·785	2865·265	2874·760	2884·262	2893·798	2903·341	2912·899	60
61	2922·473	2932·063	2941·669	2951·290	2960·927	2970·579	2980·247	2989·931	2999·630	3009·346	61
62	3019·078	3028·824	3038·587	3048·365	3058·159	3067·969	3077·794	3087·634	3097·492	3107·364	62
63	3117·253	3127·156	3137·076	3147·011	3156·966	3166·929	3176·912	3186·910	3196·924	3206·953	63
64	3216·998	3227·059	3237·136	3247·228	3257·337	3267·460	3277·600	3287·755	3297·926	3308·113	64
65	3318·315	3328·534	3338·767	3349·016	3359·281	3369·562	3379·859	3390·171	3400·499	3410·843	65
66	3421·202	3431·578	3441·963	3452·375	3462·797	3473·235	3483·689	3494·164	3504·643	3515·143	66
67	3525·661	3536·193	3546·741	3557·304	3567·884	3578·479	3589·090	3599·716	3610·358	3621·016	67
68	3631·690	3642·379	3653·084	3663·804	3674·541	3685·293	3696·066	3706·845	3717·644	3728·459	68
69	3739·289	3750·136	3760·998	3771·876	3782·769	3793·678	3804·603	3815·544	3826·500	3837·472	69
70	3848·460	3859·495	3870·483	3881·517	3892·568	3903·634	3914·716	3925·814	3936·927	3948·057	70
71	3959·201	3970·362	3981·538	3992·730	4003·937	4015·161	4026·400	4037·655	4048·925	4060·212	71
72	4071·514	4082·833	4094·165	4105·513	4116·879	4128·259	4139·652	4151·067	4162·494	4173·938	72
73	4185·397	4196·871	4208·361	4219·868	4231·390	4242·927	4254·480	4266·049	4277·631	4289·234	73
74	4300·850	4312·482	4324·130	4335·793	4347·472	4359·166	4370·877	4382·603	4394·345	4406·102	74
75	4417·875	4429·664	4441·468	4453·289	4465·125	4476·976	4488·844	4500·727	4512·626	4524·540	75
76	4536·470	4548·416	4560·379	4572·355	4584·358	4596·357	4608·382	4620·422	4632·478	4644·549	76
77	4656·637	4668·740	4680·858	4692·993	4705·143	4717·309	4729·490	4741·688	4753·961	4766·129	77
78	4778·374	4790·634	4802·909	4815·201	4827·508	4839·831	4852·170	4864·524	4876·897	4889·280	78
79	4901·681	4914·099	4926·531	4938·982	4951·444	4963·924	4976·484	4988·931	5001·459	5014·001	79
Diamr.	Areas										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	

TABLE XLI. (continued).

TABLE OF THE AREAS OF CIRCLES, ADVANCING BY 10THS (concluded).											
Diamr.	Areas										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	
80	5026-560	5039-134	5051-724	5064-330	5076-955	5089-588	5102-241	5114-910	5127-594	5140-294	80
81	5153-009	5165-741	5178-488	5191-251	5204-029	5216-823	5229-633	5242-459	5255-300	5268-157	81
82	5281-030	5293-918	5306-822	5319-744	5332-678	5345-629	5358-596	5371-598	5384-576	5397-591	82
83	5410-621	5423-666	5436-727	5449-804	5462-897	5476-005	5489-129	5502-269	5515-424	5528-596	83
84	5541-702	5554-985	5568-203	5581-437	5594-687	5607-952	5621-233	5634-568	5647-843	5661-171	84
85	5674-515	5687-875	5701-250	5714-641	5728-048	5741-470	5754-909	5768-362	5781-832	5795-317	85
86	5808-818	5822-335	5835-868	5849-416	5862-980	5876-559	5890-154	5903-765	5917-392	5931-034	86
87	5944-693	5958-364	5972-056	5985-769	5999-482	6013-219	6026-971	6040-739	6054-515	6068-322	87
88	6082-138	6095-968	6109-815	6123-677	6137-555	6151-449	6165-359	6179-284	6193-225	6207-181	88
89	6221-153	6235-141	6249-145	6263-164	6277-200	6291-204	6305-317	6319-399	6333-497	6347-681	89
90	6361-740	6375-885	6390-046	6404-222	6418-414	6432-622	6446-844	6461-085	6475-340	6489-611	90
91	6503-897	6518-200	6532-517	6546-891	6561-208	6575-565	6589-946	6604-322	6618-764	6633-182	91
92	6647-626	6662-085	6676-560	6691-016	6705-557	6720-079	6734-617	6749-170	6763-739	6778-324	92
93	6792-925	6807-541	6822-173	6836-821	6851-484	6866-163	6880-858	6895-569	6910-295	6925-037	93
94	6939-794	6954-568	6969-357	6984-161	6998-982	7013-818	7028-670	7043-503	7058-418	7073-320	94
95	7088-235	7103-165	7118-112	7133-073	7148-051	7163-044	7178-053	7193-078	7208-118	7223-175	95
96	7238-246	7253-334	7268-437	7283-556	7298-691	7313-841	7329-007	7344-189	7359-386	7374-600	96
97	7389-829	7405-073	7420-334	7435-610	7450-901	7466-209	7481-532	7496-871	7512-225	7527-596	97
98	7542-982	7558-383	7573-801	7589-234	7604-683	7620-147	7635-627	7651-193	7666-635	7682-162	98
99	7697-705	7713-264	7728-839	7744-429	7760-035	7775-656	7791-294	7806-947	7822-615	7838-300	99
Diamr.	Areas										Diamr.
	·0	·1	·2	·3	·4	·5	·6	·7	·8	·9	

(Reproduced by permission from Mackrow's "Naval Architects' Pocket-book.")

TABLE XLII.

TABLE OF THE CIRCUMFERENCES OF CIRCLES, ADVANCING BY 12THS.													
Diamr.	Circumferences												Diamr.
	0	$\frac{1}{12}$	$\frac{2}{12}$	$\frac{3}{12}$	$\frac{4}{12}$	$\frac{5}{12}$	$\frac{6}{12}$	$\frac{7}{12}$	$\frac{8}{12}$	$\frac{9}{12}$	$\frac{10}{12}$	$\frac{11}{12}$	
0	·00000	·26180	·52360	·78540	1-0472	1-3090	1-5708	1-8326	2-0944	2-3562	2-6180	2-8798	0
1	3-1416	3-4034	3-6652	3-9270	4-1888	4-4506	4-7124	4-9742	5-2360	5-4978	5-7596	6-0214	1
2	6-2832	6-5450	6-8068	7-0686	7-3304	7-5922	7-8540	8-1158	8-3776	8-6394	8-9012	9-1630	2
3	9-4248	9-6866	9-9484	10-2102	10-4720	10-7338	10-9956	11-2574	11-5192	11-7810	12-0428	12-3046	3
4	12-5664	12-8282	13-0900	13-3518	13-6136	13-8754	14-1372	14-3990	14-6608	14-9226	15-1844	15-4462	4
5	15-7080	15-9698	16-2316	16-4934	16-7552	17-0170	17-2788	17-5406	17-8024	18-0642	18-3260	18-5878	5
6	18-8496	19-1114	19-3732	19-6350	19-8968	20-1586	20-4204	20-6822	20-9440	21-2058	21-4676	21-7294	6
7	21-9912	22-2530	22-5148	22-7766	23-0384	23-3002	23-5620	23-8238	24-0856	24-3474	24-6092	24-8710	7
8	25-1328	25-3946	25-6564	25-9182	26-1800	26-4418	26-7036	26-9654	27-2272	27-4890	27-7508	28-0126	8
9	28-2744	28-5362	28-7980	29-0598	29-3216	29-5834	29-8452	30-1070	30-3688	30-6306	30-8924	31-1542	9
10	31-4160	31-6778	31-9396	32-2014	32-4632	32-7250	32-9868	32-2486	33-5104	33-7722	34-0340	34-2958	10
11	34-5576	34-8194	35-0812	35-3430	35-6048	35-8666	36-1284	36-3902	36-6520	36-9138	37-1756	34-4374	11
12	37-6992	37-9610	38-2228	38-4846	38-7464	39-0082	39-2700	39-5318	39-7936	40-0554	40-3172	40-5790	12
13	40-8408	41-1026	41-3644	41-6262	41-8880	42-1498	42-4116	42-6734	42-9352	43-1970	43-4588	43-7206	13
14	43-9824	44-2442	44-5060	44-7678	45-0296	45-2914	45-5532	45-8150	46-0678	46-3386	46-6004	46-8622	14
15	47-1240	47-3858	47-6476	47-9094	48-1712	48-4330	48-6948	48-9566	49-2184	49-4802	49-7420	50-0038	15
16	50-2656	50-5274	50-7892	51-0510	51-3128	51-5746	51-8364	52-0982	52-3600	52-6218	52-8836	53-1454	16
17	53-4072	53-6690	53-9308	54-1926	54-4544	54-7162	54-9780	55-2398	55-5016	55-7634	56-0252	56-2870	17
18	56-5488	56-8106	57-0724	57-3342	57-5960	57-8578	58-1196	58-3814	58-6432	58-9050	59-1668	59-4286	18
19	59-6904	59-9522	60-2140	60-4758	60-7376	60-9994	61-2612	61-5230	61-7848	62-0466	62-3084	62-5702	19
Diamr.	Circumferences												Diamr.
	0	$\frac{1}{12}$	$\frac{2}{12}$	$\frac{3}{12}$	$\frac{4}{12}$	$\frac{5}{12}$	$\frac{6}{12}$	$\frac{7}{12}$	$\frac{8}{12}$	$\frac{9}{12}$	$\frac{10}{12}$	$\frac{11}{12}$	

TABLE XLII. (continued).

TABLE OF THE CIRCUMFERENCES OF CIRCLES, ADVANCING BY 12THS (concluded).													
Diamr.	Circumferences												Diamr.
	0	$\frac{1}{12}$	$\frac{2}{12}$	$\frac{3}{12}$	$\frac{4}{12}$	$\frac{5}{12}$	$\frac{6}{12}$	$\frac{7}{12}$	$\frac{8}{12}$	$\frac{9}{12}$	$\frac{10}{12}$	$\frac{11}{12}$	
20	62.8320	63.0938	63.3556	63.6174	63.8792	64.1410	64.4028	64.6646	64.9264	65.1882	65.4500	65.7118	20
21	65.9736	66.2354	66.4972	66.7590	67.0208	67.2826	67.5444	67.8062	68.0680	68.3298	68.5916	68.8534	21
22	69.1152	69.3770	69.6388	69.9006	70.1624	70.4242	70.6860	70.9478	71.2096	71.4714	71.7332	71.9950	22
23	72.2568	72.5186	72.7804	73.0422	73.3040	73.5658	73.8276	74.0894	74.3512	74.6130	74.8748	75.1366	23
24	75.3984	75.6602	75.9220	76.1838	76.4456	76.7074	76.9692	77.2310	77.4928	77.7546	78.0164	78.2782	24
25	78.5400	78.8018	79.0636	79.3254	79.5872	79.8490	80.1108	80.3726	80.6344	80.8962	81.1580	81.4198	25
26	81.6816	81.9434	82.2052	82.4670	82.7288	82.9906	83.2524	83.5142	83.7760	84.0378	84.2996	84.5614	26
27	84.8232	85.0850	85.3468	85.6086	85.8704	86.1322	86.3940	86.6558	86.9176	87.1794	87.4412	87.7030	27
28	87.9648	88.2266	88.4884	88.7502	89.0120	89.2738	89.5356	89.7974	90.0592	90.3210	90.5828	90.8446	28
29	91.1064	91.3682	91.6300	91.8918	92.1536	92.4154	92.6772	92.9390	93.2008	93.4626	93.7244	93.9862	29
30	94.2480	94.5098	94.7716	95.0334	95.2952	95.5570	95.8188	96.0806	96.3424	96.6042	96.8660	97.1278	30
31	97.3896	97.6514	97.9132	98.1750	98.4368	98.6986	98.9604	99.2222	99.4840	99.7458	100.0076	100.2694	31
32	100.531	100.793	101.055	101.317	101.578	101.840	102.102	102.364	102.626	102.887	103.149	103.411	32
33	103.673	103.935	104.196	104.458	104.720	104.982	105.244	105.505	105.767	106.029	106.291	106.553	33
34	106.814	107.076	107.338	107.600	107.862	108.123	108.385	108.647	108.909	109.171	109.432	109.694	34
35	109.956	110.218	110.480	110.741	111.003	111.265	111.527	111.789	112.050	112.312	112.574	112.836	35
36	113.098	113.359	113.621	113.883	114.145	114.407	114.668	114.930	115.192	115.454	115.716	115.977	36
37	116.239	116.501	116.763	117.025	117.286	117.548	117.810	118.072	118.334	118.595	118.857	119.119	37
38	119.381	119.643	119.904	120.166	120.428	120.690	120.952	121.213	121.475	121.737	121.999	122.261	38
39	122.522	122.784	123.046	123.308	123.570	123.831	124.093	124.355	124.617	124.879	125.140	125.402	39
Diamr.	Circumferences												Diamr.
	0	$\frac{1}{12}$	$\frac{2}{12}$	$\frac{3}{12}$	$\frac{4}{12}$	$\frac{5}{12}$	$\frac{6}{12}$	$\frac{7}{12}$	$\frac{8}{12}$	$\frac{9}{12}$	$\frac{10}{12}$	$\frac{11}{12}$	

(Reproduced by permission from Muckrow's "Naval Architects' Pocket-book.")

TABLE XLIII.

TABLE OF THE AREAS OF CIRCLES, ADVANCING BY 12THS.													
Diamr.	Areas												Diamr.
	0	$\frac{1}{12}$	$\frac{2}{12}$	$\frac{3}{12}$	$\frac{4}{12}$	$\frac{5}{12}$	$\frac{6}{12}$	$\frac{7}{12}$	$\frac{8}{12}$	$\frac{9}{12}$	$\frac{10}{12}$	$\frac{11}{12}$	
0	.0000	.0055	.0218	.0491	.0873	.1364	.1963	.2673	.3491	.4418	.5454	.6600	0
1	.7854	.9218	1.0690	1.2272	1.3963	1.5763	1.7671	1.9689	2.1817	2.4053	2.6398	2.8852	1
2	3.1416	3.4088	3.6870	3.9761	4.2761	4.5869	4.9087	5.2414	5.5851	5.9396	6.3050	6.6813	2
3	7.0686	7.4667	7.8758	8.2958	8.7266	9.1684	9.6211	10.0847	10.5592	11.0447	11.5410	12.0482	3
4	12.5664	13.0954	13.6354	14.1863	14.7480	15.3207	15.9043	16.4988	17.1042	17.7205	18.3478	18.9859	4
5	19.6350	20.2949	20.9658	21.6475	22.3402	23.0438	23.7583	24.4837	25.2200	25.9672	26.7254	27.4944	5
6	28.2743	29.0652	29.8669	30.6796	31.5032	32.3377	33.1831	34.0394	34.9066	35.7847	36.6737	37.5737	6
7	38.4846	39.4063	40.3389	41.2825	42.2370	43.2024	44.1786	45.1658	46.1640	47.1730	48.1929	49.2237	7
8	50.2655	51.3181	52.3817	53.4562	54.5415	55.6378	56.7450	57.8631	58.9921	60.1320	61.2829	62.4446	8
9	63.6173	64.8008	65.9953	67.2006	68.4169	69.6441	70.8822	72.1312	73.3911	74.6619	75.9436	77.2363	9
10	78.5398	79.8543	81.1796	82.5159	83.8631	85.2212	86.5901	87.9700	89.3609	90.7626	92.1752	93.5987	10
11	95.0332	96.4785	97.9348	99.4020	100.880	102.369	103.869	105.380	106.901	108.434	109.978	111.532	11
12	113.097	114.674	116.261	117.859	119.468	121.088	122.719	124.360	126.013	127.676	129.351	131.036	12
13	132.732	134.439	136.158	137.887	139.626	141.377	143.139	144.911	146.695	148.489	150.295	152.111	13
14	153.938	155.776	157.625	159.485	161.356	163.237	165.130	167.034	168.948	170.873	172.809	174.757	14
15	176.715	178.684	180.663	182.654	184.656	186.663	188.692	190.726	192.772	194.828	196.895	198.973	15
16	201.062	203.162	205.273	207.394	209.527	211.670	213.825	215.990	218.166	220.353	222.551	224.760	16
17	226.980	229.211	231.453	233.705	235.969	238.243	240.528	242.824	245.132	247.450	249.778	252.118	17
18	254.469	256.831	259.203	261.587	263.981	266.386	268.803	271.230	273.668	276.117	278.576	281.047	18
19	283.529	286.021	288.525	291.039	293.564	296.111	298.648	301.206	303.775	306.354	308.945	311.547	19
Diamr.	Areas												Diamr.
	0	$\frac{1}{12}$	$\frac{2}{12}$	$\frac{3}{12}$	$\frac{4}{12}$	$\frac{5}{12}$	$\frac{6}{12}$	$\frac{7}{12}$	$\frac{8}{12}$	$\frac{9}{12}$	$\frac{10}{12}$	$\frac{11}{12}$	

TABLE XLIII. (continued).

TABLE OF THE AREAS OF CIRCLES, ADVANCING BY 12THS (concluded).													
Diamr.	Areas												Diamr.
	0	$\frac{1}{12}$	$\frac{2}{12}$	$\frac{3}{12}$	$\frac{4}{12}$	$\frac{5}{12}$	$\frac{6}{12}$	$\frac{7}{12}$	$\frac{8}{12}$	$\frac{9}{12}$	$\frac{10}{12}$	$\frac{11}{12}$	
20	314.159	316.783	319.417	322.062	324.719	327.386	330.064	332.753	335.452	338.163	340.885	343.617	20
21	346.361	349.115	351.880	354.656	357.443	360.241	363.050	365.870	368.701	371.542	374.395	377.258	21
22	380.133	383.018	385.914	388.821	391.739	394.668	397.608	400.559	403.520	406.493	409.476	412.470	22
23	415.476	418.492	421.519	424.557	427.606	430.665	433.736	436.818	439.910	443.014	446.128	449.253	23
24	452.389	455.536	458.694	461.863	465.043	468.234	471.435	474.648	477.871	481.106	484.351	487.607	24
25	490.874	494.152	497.441	500.740	504.051	507.373	510.705	514.049	517.403	520.768	524.144	527.531	25
26	530.929	534.338	537.758	541.188	544.630	548.083	551.546	555.020	558.505	562.002	565.509	569.026	26
27	572.555	576.095	579.646	583.207	586.780	590.363	593.957	597.563	601.179	604.806	608.444	612.092	27
28	615.752	619.423	623.104	626.797	630.500	634.215	637.940	641.676	645.423	649.181	652.950	656.729	28
29	660.520	664.321	668.134	671.957	675.792	679.637	683.493	687.360	691.238	695.127	699.026	702.937	29
30	706.858	710.791	714.734	718.688	722.654	726.630	730.617	734.615	738.623	742.643	746.674	750.715	30
31	754.768	758.831	762.905	766.990	771.087	775.193	779.311	783.440	787.580	791.730	795.892	800.064	31
32	804.248	808.442	812.647	816.863	821.090	825.328	829.577	833.837	838.107	842.389	846.681	850.984	32
33	855.299	859.624	863.960	868.307	872.665	877.033	881.413	885.804	890.205	894.618	899.041	903.475	33
34	907.920	912.376	916.843	921.321	925.810	930.310	934.820	939.342	943.874	948.417	952.972	957.537	34
35	962.113	966.700	971.298	975.906	980.526	985.157	989.798	994.450	999.114	1003.79	1008.47	1013.17	35
36	1017.88	1022.59	1027.33	1032.06	1036.81	1041.57	1046.35	1051.13	1055.92	1060.73	1065.55	1070.37	36
37	1075.21	1080.06	1084.92	1089.79	1094.67	1099.56	1104.47	1109.38	1114.31	1119.24	1124.19	1129.15	37
38	1134.11	1139.09	1144.09	1149.09	1154.10	1159.12	1164.16	1169.20	1174.26	1179.32	1184.40	1189.49	38
39	1194.59	1199.70	1204.82	1209.96	1215.10	1220.25	1225.42	1230.59	1235.78	1240.98	1246.19	1251.41	39
Diamr.	Areas												Diamr.
	0	$\frac{1}{12}$	$\frac{2}{12}$	$\frac{3}{12}$	$\frac{4}{12}$	$\frac{5}{12}$	$\frac{6}{12}$	$\frac{7}{12}$	$\frac{8}{12}$	$\frac{9}{12}$	$\frac{10}{12}$	$\frac{11}{12}$	

(Reproduced by permission from Mackrow's "Naval Architects' Pocket-book.")

TABLE XLIV.

TABLE OF THE AREAS OF THE SEGMENTS OF A CIRCLE, THE DIAMETER BEING UNITY.									
<i>To find the area of the segment of any circle from the following tables.</i>									
RULE.—Divide the height of the segment by the diameter, take out the corresponding tabular area, which multiply by the square of the diameter for the result.									
$\frac{H}{D}$	Area	$\frac{H}{D}$	Area	$\frac{H}{D}$	Area	$\frac{H}{D}$	Area	$\frac{H}{D}$	Area
.001	.000042	.038	.009763	.075	.026761	.112	.048262	.148	.072450
.002	.000119	.039	.010148	.076	.027289	.113	.048894	.149	.073082
.003	.000219	.040	.010537	.077	.027821	.114	.049528	.150	.073714
.004	.000337	.041	.010931	.078	.028356	.115	.050165	.151	.074346
.005	.000470	.042	.011330	.079	.028894	.116	.050804	.152	.074978
.006	.000618	.043	.011734	.080	.029435	.117	.051446	.153	.075610
.007	.000779	.044	.012142	.081	.029979	.118	.052090	.154	.076242
.008	.000951	.045	.012554	.082	.030526	.119	.052736	.155	.076874
.009	.001135	.046	.012971	.083	.031076	.120	.053385	.156	.077506
.010	.001329	.047	.013392	.084	.031629	.121	.054036	.157	.078138
.011	.001533	.048	.013818	.085	.032186	.122	.054689	.158	.078770
.012	.001746	.049	.014247	.086	.032745	.123	.055345	.159	.079402
.013	.001968	.050	.014681	.087	.033307	.124	.056003	.160	.080034
.014	.002199	.051	.015119	.088	.033872	.125	.056663	.161	.080666
.015	.002438	.052	.015561	.089	.034441	.126	.057326	.162	.081298
.016	.002685	.053	.016007	.090	.035011	.127	.057991	.163	.081930
.017	.002940	.054	.016457	.091	.035585	.128	.058658	.164	.082562
.018	.003202	.055	.016911	.092	.036162	.129	.059327	.165	.083194
.019	.003471	.056	.017369	.093	.036741	.130	.059999	.166	.083826
.020	.003748	.057	.017831	.094	.037323	.131	.060672	.167	.084458
.021	.004031	.058	.018296	.095	.037909	.132	.061348	.168	.085090
.022	.004322	.059	.018766	.096	.038496	.133	.062026	.169	.085722
.023	.004618	.060	.019239	.097	.039087	.134	.062707	.170	.086354
.024	.004921	.061	.019716	.098	.039680	.135	.063389	.171	.086986
.025	.005230	.062	.020196	.099	.040276	.136	.064074	.172	.087618
.026	.005546	.063	.020680	.100	.040875	.137	.064760	.173	.088250
.027	.005867	.064	.021168	.101	.041476	.138	.065449	.174	.088882
.028	.006194	.065	.021659	.102	.042080	.139	.066140	.175	.089514
.029	.006527	.066	.022154	.103	.042687	.140	.066833	.176	.090146
.030	.006865	.067	.022652	.104	.043296	.141	.067528	.177	.090778
.031	.007209	.068	.023154	.105	.043908	.142	.068225	.178	.091410
.032	.007558	.069	.023659	.106	.044522	.143	.068924	.179	.092042
.033	.007913	.070	.024168	.107	.045139	.144	.069625	.180	.092674
.034	.008273	.071	.024680	.108	.045759	.145	.070328	.181	.093306
.035	.008638	.072	.025195	.109	.046381	.146	.071033	.182	.093938
.036	.009008	.073	.025714	.110	.047005	.147	.071741	.183	.094570
.037	.009383	.074	.026236	.111	.047632	.148	.072450	.184	.095202

TABLE XLIV. (continued).

TABLE OF THE AREAS OF THE SEGMENTS OF A CIRCLE, THE DIAMETER BEING UNITY (continued).									
$\frac{H}{D}$	Area	$\frac{H}{D}$	Area	$\frac{H}{D}$	Area	$\frac{H}{D}$	Area	$\frac{H}{D}$	Area
.149	.073161	.193	.106261	.237	.142387	.281	.180918		
.150	.073874	.194	.107051	.238	.143238	.282	.181817		
.151	.074586	.195	.107842	.239	.144091	.283	.182718		
.152	.075306	.196	.108636	.240	.144944	.284	.183619		
.153	.076026	.197	.109430	.241	.145799	.285	.184521		
.154	.076747	.198	.110226	.242	.146655	.286	.185425		
.155	.077469	.199	.111024	.243	.147512	.287	.186329		
.156	.078194	.200	.111823	.244	.148371	.288	.187234		
.157	.078921	.201	.112624	.245	.149230	.289	.188140		
.158	.079649	.202	.113426	.246	.150091	.290	.189047		
.159	.080380	.203	.114230	.247	.150953	.291	.189955		
.160	.081112	.204	.115035	.248	.151816	.292	.190864		
.161	.081846	.205	.115842	.249	.152680	.293	.191775		
.162	.082582	.206	.116650	.250	.153546	.294	.192684		
.163	.083320	.207	.117460	.251	.154412	.295	.193596		
.164	.084059	.208	.118271	.252	.155280	.296	.194509		
.165	.084801	.209	.119083	.253	.156149	.297	.195422		
.166	.085544	.210	.119897	.254	.157019	.298	.196337		
.167	.086289	.211	.120712	.255	.157890	.299	.197252		
.168	.087036	.212	.121529	.256	.158762	.300	.198168		
.169	.087785	.213	.122347	.257	.159636	.301	.199085		
.170	.088535	.214	.123167	.258	.160510	.302	.200003		
.171	.089287	.215	.123988	.259	.161386	.303	.200923		
.172	.090041	.216	.124810	.260	.162263	.304	.201841		
.173	.090797	.217	.125634	.261	.163140	.305	.202761		
.174	.091554	.218	.126459	.262	.164019	.306	.203683		
.175	.092313	.219	.127285	.263	.164899	.307	.204605		
.176	.093074	.220	.128113	.264	.165780	.308	.205527		
.177	.093836	.221	.128942	.265	.166663	.309	.206451		
.178	.094601	.222	.129773	.266	.167546	.310	.207376		
.179	.095366	.223	.130605	.267	.168430	.311	.208301		
.180	.096134	.224	.131438	.268	.169315	.312	.209227		
.181	.096903	.225	.132272	.269	.170202	.313	.210154		
.182	.097674	.226	.133108	.270	.171089	.314	.211082		
.183	.098447	.227	.133945	.271	.171978	.315	.212011		
.184	.099221	.228	.134784	.272	.172867	.316	.212940		
.185	.099997	.229	.135624	.273	.173758	.317	.213871		
.186	.100774	.230	.136465	.274	.174649	.318	.214802		
.187	.101553	.231	.137307	.275	.175542	.319	.215733		
.188	.102334	.232	.138150	.276	.176435	.320	.216666		
.189	.103116	.233	.138995	.277	.177330	.321	.217599		
.190	.103900	.234	.139841	.278	.178225	.322	.218533		
.191	.104685	.235	.140688	.279	.179122	.323	.219468		
.192	.105472	.236	.141537	.280	.180019	.324	.220404		

TABLE OF THE AREAS OF THE SEGMENTS OF A CIRCLE,
THE DIAMETER BEING UNITY (concluded).

$\frac{H}{D}$	Area	$\frac{H}{D}$	Area	$\frac{H}{D}$	Area	$\frac{H}{D}$	Area	$\frac{H}{D}$	Area
.325	.221340	.369	.263213	.413	.306140	.457	.349752		
.326	.222277	.370	.264178	.414	.307125	.458	.350748		
.327	.223215	.371	.265144	.415	.308110	.459	.351745		
.328	.224154	.372	.266111	.416	.309095	.460	.352742		
.329	.225093	.373	.267078	.417	.310081	.461	.353739		
.330	.226033	.374	.268045	.418	.311068	.462	.354736		
.331	.226974	.375	.269013	.419	.312054	.463	.355732		
.332	.227915	.376	.269982	.420	.313041	.464	.356730		
.333	.228858	.377	.270951	.421	.314029	.465	.357727		
.334	.229800	.378	.271920	.422	.315016	.466	.358725		
.335	.230745	.379	.272890	.423	.316004	.467	.359723		
.336	.231689	.380	.273861	.424	.316992	.468	.360721		
.337	.232634	.381	.274832	.425	.317981	.469	.361719		
.338	.233580	.382	.275803	.426	.318970	.470	.362717		
.339	.234526	.383	.276775	.427	.319959	.471	.363715		
.340	.235473	.384	.277748	.428	.320948	.472	.364713		
.341	.236421	.385	.278721	.429	.321938	.473	.365712		
.342	.237369	.386	.279694	.430	.322928	.474	.366710		
.343	.238318	.387	.280668	.431	.323918	.475	.367709		
.344	.239268	.388	.281642	.432	.324909	.476	.368708		
.345	.240218	.389	.282617	.433	.325900	.477	.369707		
.346	.241169	.390	.283592	.434	.326892	.478	.370706		
.347	.242121	.391	.284568	.435	.327882	.479	.371705		
.348	.243074	.392	.285544	.436	.328874	.480	.372704		
.349	.244026	.393	.286521	.437	.329866	.481	.373703		
.350	.244980	.394	.287498	.438	.330858	.482	.374702		
.351	.245934	.395	.288476	.439	.331850	.483	.375702		
.352	.246889	.396	.289453	.440	.332843	.484	.376702		
.353	.247845	.397	.290432	.441	.333836	.485	.377701		
.354	.248801	.398	.291411	.442	.334829	.486	.378701		
.355	.249757	.399	.292390	.443	.335822	.487	.379700		
.356	.250715	.400	.293369	.444	.336816	.488	.380700		
.357	.251673	.401	.294349	.445	.337810	.489	.381699		
.358	.252631	.402	.295330	.446	.338804	.490	.382699		
.359	.253590	.403	.296311	.447	.339798	.491	.383699		
.360	.254550	.404	.297292	.448	.340793	.492	.384699		
.361	.255510	.405	.298273	.449	.341787	.493	.385699		
.362	.256471	.406	.299255	.450	.342782	.494	.386699		
.363	.257433	.407	.300238	.451	.343777	.495	.387699		
.364	.258395	.408	.301220	.452	.344772	.496	.388699		
.365	.259357	.409	.302203	.453	.345768	.497	.389699		
.366	.260320	.410	.303187	.454	.346764	.498	.390699		
.367	.261284	.411	.304171	.455	.347759	.499	.391699		
.368	.262248	.412	.305155	.456	.348755	.500	.392699		

(Reproduced by permission from Macrow's "Naval Architects' Pocket-book.")

TABLE XLV.

TABLE OF SQUARES, CUBES, SQUARE ROOTS, CUBE ROOTS, AND RECIPROALS OF ALL INTEGER NUMBERS FROM 1 TO 2200.					
No.	Square	Cube	Square Root	Cube Root	Reciprocal
1	1	1	1.0000000	1.0000000	1.0000000000
2	4	8	1.4142136	1.2599210	.5000000000
3	9	27	1.7320508	1.4422486	.3333333333
4	16	64	2.0000000	1.5874011	.2500000000
5	25	125	2.2360680	1.7099759	.2000000000
6	36	216	2.4494897	1.8171206	.1666666667
7	49	343	2.6457518	1.9129312	.142857143
8	64	512	2.8284271	2.0000000	.1250000000
9	81	729	3.0000000	2.0800837	.1111111111
10	100	1000	3.1622777	2.1544347	.1000000000
11	121	1331	3.3166248	2.2239801	.0909090909
12	144	1728	3.4641016	2.2894296	.0833333333
13	169	2197	3.6055513	2.3513347	.076923077
14	196	2744	3.7416574	2.4101422	.071428571
15	225	3375	3.8729833	2.4662121	.0666666667
16	256	4096	4.0000000	2.5198421	.0625000000
17	289	4913	4.1231036	2.6271216	.058823529
18	324	5832	4.2426407	2.6207414	.055555556
19	361	6859	4.3588989	2.6684016	.052631579
20	400	8000	4.4721360	2.7144177	.0500000000
21	441	9261	4.5825757	2.7589243	.047619048
22	484	10648	4.6904158	2.8020393	.045454545
23	529	12167	4.7958615	2.8438670	.043478261
24	576	13824	4.8989795	2.8844991	.041666667
25	625	15625	5.0000000	2.9240177	.040000000
26	676	17713	5.0990195	2.9623460	.038461538
27	729	19683	5.1961524	3.0000000	.037037037
28	784	21952	5.2915026	3.0365889	.035714286
29	841	24389	5.3851648	3.0726168	.034482759
30	900	27000	5.4772258	3.1072325	.033333333
31	961	29791	5.5677644	3.1413808	.032258065
32	1024	32768	5.6568642	3.1744021	.031250000
33	1089	35937	5.7445626	3.2075343	.030303030
34	1156	39304	5.8309519	3.2396118	.029411765
35	1225	42875	5.9160798	3.2710663	.028571429
36	1296	46656	6.0000000	3.3019272	.027777778
37	1369	50653	6.0827625	3.3322218	.027027027
38	1444	54872	6.1644140	3.3619754	.026315789
39	1521	59319	6.2444990	3.3912114	.025641026
40	1600	64000	6.3245558	3.4199519	.025000000
41	1681	68921	6.4031242	3.4482172	.024390244
42	1764	74088	6.4807407	3.4769266	.023809524
43	1849	79507	6.5574886	3.5068981	.023225814
44	1936	85184	6.6332496	3.5369483	.022727273
45	2025	91125	6.7082089	3.5668993	.022222222

No.	Square	Cube	Square Root	Cube Root	Reciprocal
46	2116	97336	6.7823300	3.5880479	.021739130
47	2209	103833	6.8565546	3.6089261	.021327680
48	2304	110592	6.9282082	3.6342411	.020938383
49	2401	117649	7.0000000	3.6598067	.020440816
50	2500	125000	7.0710678	3.6840814	.020000000
51	2601	132651	7.1414284	3.7084298	.019577848
52	2704	140608	7.2111026	3.7325111	.019170769
53	2809	148877	7.2801069	3.7562858	.018779225
54	2916	157464	7.3484692	3.7797681	.018391861
55	3025	166375	7.4161985	3.8023925	.018018181
56	3136	175616	7.4833148	3.8258624	.017657148
57	3249	185199	7.5498944	3.8485011	.017307445
58	3364	195119	7.6157731	3.8714979	.016968448
59	3481	205376	7.6811457	3.8929965	.016640667
60	3600	216000	7.7459667	3.9148676	.016323445
61	3721	226981	7.8102497	3.9364972	.016016962
62	3844	238312	7.8740079	3.9578015	.015720052
63	3969	250000	7.9372539	3.9790571	.015432860
64	4096	262048	8.0000000	4.0000000	.015151515
65	4225	274465	8.0622577	4.0207256	.014875714
66	4356	287266	8.1240884	4.0412401	.014604507
67	4489	290468	8.1850528	4.0615480	.014337853
68	4624	294083	8.2462113	4.0816551	.014075754
69	4761	298109	8.3066239	4.1015661	.013818285
70	4900	302650	8.3666003	4.1212853	.013564507
71	5041	307711	8.4261498	4.1408178	.013314507
72	5184	313296	8.4852814	4.1601676	.013068089
73	5329	319409	8.5444087	4.1793892	.012824830
74	5476	326054	8.6028258	4.1984964	.012584151
75	5625	333235	8.6602540	4.2174633	.012346000
76	5776	340956	8.7177979	4.2362826	.012110385
77	5929	349219	8.7749644	4.2549210	.011877018
78	6084	358030	8.8317609	4.2734586	.011645828
79	6241	367399	8.8881944	4.2918404	.011416628
80	6400	377328	8.9442719	4.3099695	.011189300
81	6561	387811	9.0000000	4.3267487	.010963679
82	6724	398851	9.0558851	4.3444815	.010739522
83	6889	410449	9.1104396	4.3620707	.010516762
84	7056	422608	9.1651514	4.3795191	.010295391
85	7225	435335	9.2195445	4.3968296	.010075406
86	7396	448636	9.2736185	4.4140049	.009856707
87	7569	462509	9.3273791	4.4310478	.009639253
88	7744	476956	9.3808315	4.4479602	.009423000
89	7921	491989	9.4339811	4.4647451	.009207911
90	8100	507610	9.4868380	4.4814047	.008994011
91	8281	523829	9.5393920	4.4979414	.008781254
92	8464	540648	9.5916630	4.5143574	.008569565
93	8649	558069	9.6436508	4.5306549	.008358859
94	8836	576094	9.6953597	4.5468359	.008149129

TABLE XLV. (continued).

No.	Square	Cube	Square Root	Cube Root	Reciprocal
95	90 25	857 875	9-7467948	4-5629026	-0-10526316
96	92 16	884 786	9-7979590	4-5788570	-0-10416667
97	94 09	913 678	9-8486578	4-5947009	-0-108092718
98	96 04	941 192	9-8994949	4-6104363	-0-10204082
99	98 01	970 399	9-9498744	4-6260650	-0-10101010
100	1 00 00	1 000 000	10-0000000	4-6415888	-0-00000000
101	1 02 01	1 030 801	10-0498756	4-6570095	-0-00909990
102	1 04 04	1 061 208	10-0995049	4-6729287	-0-00808922
103	1 06 09	1 092 727	10-1488016	4-6875482	-0-00708788
104	1 08 16	1 124 864	10-1980590	4-7026694	-0-00615885
105	1 10 26	1 157 935	10-2469508	4-7176940	-0-00523810
106	1 12 36	1 191 016	10-2956501	4-7326256	-0-00438962
107	1 14 49	1 225 048	10-3444804	4-7474594	-0-00357394
108	1 16 64	1 259 712	10-3923048	4-7622082	-0-00279259
109	1 18 81	1 295 029	10-4403065	4-7768662	-0-00214312
110	1 21 00	1 331 000	10-4880885	4-7914199	-0-00160909
111	1 23 21	1 367 631	10-5356538	4-8058956	-0-00109009
112	1 25 44	1 404 928	10-5830052	4-8202845	-0-000628571
113	1 27 69	1 443 897	10-6301458	4-8345881	-0-00019558
114	1 30 06	1 481 644	10-6770783	4-8488076	-0-00171980
115	1 32 25	1 520 875	10-7238053	4-8629442	-0-00136652
116	1 34 56	1 560 896	10-7708296	4-8769990	-0-00092690
117	1 36 89	1 601 618	10-8166538	4-8909782	-0-00047009
118	1 38 24	1 643 083	10-8627805	4-9048681	-0-00474576
119	1 41 61	1 685 159	10-9087121	4-9186847	-0-00403861
120	1 44 00	1 728 000	10-9544512	4-9324242	-0-00333333
121	1 46 41	1 771 561	11-0000000	4-9460974	-0-00264463
122	1 48 84	1 815 848	11-0458610	4-9596757	-0-00196721
123	1 51 30	1 860 867	11-0905865	4-9731898	-0-00130081
124	1 53 76	1 906 624	11-1355987	4-9866310	-0-00064516
125	1 56 25	1 953 125	11-1803399	5-0000000	-0-00000000
126	1 58 76	2 000 876	11-2249722	5-0132979	-0-007986508
127	1 61 29	2 048 983	11-2694277	5-0265257	-0-0074016
128	1 63 84	2 097 153	11-3137085	5-0396842	-0-07812500
129	1 66 41	2 146 689	11-3578167	5-0527743	-0-0751938
130	1 69 00	2 197 000	11-4017548	5-0657970	-0-07692308
131	1 71 61	2 248 091	11-4455231	5-0787781	-0-07635688
132	1 74 24	2 300 968	11-4891253	5-0916484	-0-07575768
133	1 76 89	2 353 087	11-5325626	5-1044687	-0-07518737
134	1 79 56	2 406 104	11-5758869	5-1179299	-0-07462687
135	1 82 25	2 460 875	11-6189500	5-1298278	-0-07407407
136	1 84 96	2 515 456	11-6619088	5-1425682	-0-07352931
137	1 87 69	2 571 963	11-7046999	5-1551367	-0-07299270
138	1 90 44	2 628 073	11-7473401	5-1676498	-0-07246377
139	1 93 21	2 685 619	11-7898261	5-1801015	-0-07194245
140	1 96 00	2 744 000	11-8321596	5-1924941	-0-07149857
141	1 98 81	2 803 921	11-8748422	5-2048279	-0-07092199
142	2 01 64	2 863 858	11-9168753	5-2171084	-0-07042254
143	2 04 49	2 924 307	11-9562607	5-2296215	-0-06993900

No.	Square	Cube	Square Root	Cube Root	Reciprocal
144	2 07 36	2 985 984	12-0000000	5-2414828	-0-06944444
145	2 10 25	3 048 825	12-0415946	5-2585879	-0-06896552
146	2 13 16	3 112 186	12-0830460	5-2765874	-0-06848915
147	2 16 09	3 176 653	12-1248557	5-2954721	-0-06797271
148	2 19 04	3 241 793	12-1652551	5-2895725	-0-06756757
149	2 22 01	3 307 949	12-2065556	5-3014592	-0-06711409
150	2 25 00	3 375 000	12-2474487	5-3182928	-0-06666667
151	2 28 01	3 443 951	12-2882057	5-3250740	-0-06622517
152	2 31 04	3 511 808	12-3288280	5-3368038	-0-06578937
153	2 34 09	3 581 577	12-3693169	5-3484812	-0-06535948
154	2 37 16	3 653 364	12-4096786	5-3601084	-0-06493506
155	2 40 25	3 728 875	12-4498996	5-3716854	-0-06451613
156	2 43 36	3 806 808	12-4899960	5-3832126	-0-06410256
157	2 46 49	3 886 961	12-5299641	5-3946907	-0-06369427
158	2 49 64	3 944 813	12-5698951	5-4061202	-0-06328114
159	2 52 81	4 019 879	12-6095202	5-4175015	-0-06286908
160	2 56 00	4 096 000	12-6491106	5-4288852	-0-06245000
161	2 59 21	4 178 281	12-6885775	5-4401218	-0-06211180
162	2 62 44	4 251 588	12-7279221	5-4513618	-0-06179840
163	2 65 69	4 326 747	12-7671453	5-4625556	-0-06148969
164	2 68 96	4 403 944	12-8062485	5-4737087	-0-06097087
165	2 72 25	4 483 126	12-8452826	5-4848066	-0-06060606
166	2 75 56	4 574 396	12-8840987	5-4958647	-0-06021096
167	2 78 89	4 657 463	12-9223480	5-5068784	-0-05980924
168	2 82 24	4 741 682	12-9614814	5-5178484	-0-05939281
169	2 85 61	4 826 809	13-0000000	5-5287743	-0-05917160
170	2 89 00	4 913 000	13-0384048	5-5396588	-0-05892358
171	2 92 41	5 000 311	13-0768968	5-5504991	-0-05864786
172	2 95 84	5 088 448	13-1148770	5-5612978	-0-05831893
173	2 99 29	5 177 717	13-1529464	5-5720546	-0-057970347
174	3 02 76	5 268 084	13-1909060	5-5827702	-0-057647126
175	3 06 25	5 359 875	13-2287566	5-5934447	-0-05734286
176	3 09 76	5 453 776	13-2664992	5-6040787	-0-056981818
177	3 13 29	5 545 383	13-3041347	5-6146724	-0-056649718
178	3 16 84	5 639 753	13-3416641	5-6252263	-0-05617978
179	3 20 41	5 735 889	13-3790882	5-6357408	-0-05565992
180	3 24 00	5 833 000	13-4164079	5-6462162	-0-05515556
181	3 27 61	5 932 741	13-4536240	5-6566628	-0-05464481
182	3 31 24	6 033 568	13-4907876	5-6670511	-0-05414505
183	3 34 89	6 136 497	13-5277498	5-6774114	-0-05364788
184	3 38 56	6 241 930	13-5646600	5-6877840	-0-05314948
185	3 42 25	6 349 585	13-6014705	5-6980192	-0-05264805
186	3 45 96	6 460 868	13-6381817	5-7082676	-0-05214284
187	3 49 69	6 574 908	13-6747948	5-7184791	-0-05164594
188	3 53 44	6 691 308	13-7118092	5-7286648	-0-05114919
189	3 57 21	6 810 473	13-7497271	5-7387986	-0-05064891
190	3 61 00	6 932 000	13-7840488	5-7488971	-0-05014906
191	3 64 81	7 057 871	13-8202750	5-7589652	-0-04964862
192	3 68 64	7 177 888	13-8564065	5-7689962	-0-04914885

TABLE XLV. (continued).

No.	Square	Cube	Square Root	Cube Root	Reciprocal
198	8 72 49	7 189 087	18-8924440	5-7789966	-005181347
199	8 76 06	7 801 384	18-9286863	5-7889604	-005154689
200	8 80 25	7 414 875	18-9642400	5-7989890	-005128201
201	8 84 16	7 539 586	14-0000000	5-8087857	-005102041
202	8 88 09	7 645 879	14-0356688	5-8186479	-005076142
203	8 92 04	7 763 892	14-0712473	5-8284787	-005050606
204	8 96 01	7 880 899	14-1067360	5-8382725	-005025126
205	9 00 00	8 000 000	14-1421356	5-8480355	-005000000
206	9 04 01	8 130 601	14-1774669	5-8577560	-004975124
207	9 08 04	8 264 408	14-2126704	5-8674643	-004950495
208	9 12 09	8 395 427	14-2478068	5-8771307	-004926108
209	9 16 16	8 480 664	14-2828569	5-8867653	-004901961
210	9 20 25	8 616 135	14-3178211	5-8963685	-004878049
211	9 24 36	8 741 816	14-3527001	5-9069406	-004854369
212	9 28 49	8 866 748	14-3874946	5-9154817	-004830918
213	9 32 64	8 993 913	14-4222051	5-9249921	-004807692
214	9 36 81	9 120 899	14-4568823	5-9344721	-004784689
215	9 40 96	9 251 000	14-4913767	5-9439220	-004761905
216	9 45 21	9 376 981	14-5258330	5-9535418	-004739886
217	9 49 44	9 508 138	14-5602198	5-9632730	-004717681
218	9 53 69	9 636 297	14-5945195	5-9720926	-004694886
219	9 57 96	9 760 844	14-6287388	5-9814240	-004672897
220	9 62 25	9 888 875	14 6628743	5-9907264	-004651168
221	9 66 56	10 017 696	14 6969385	6-0000000	-004629560
222	9 70 89	10 318 818	14-7309199	6-0092450	-004608295
223	9 74 81	10 860 283	14-7648281	6-0184617	-004587156
224	9 78 81	10 508 459	14-7986486	6-0276502	-004566210
225	9 82 81	10 648 000	14-8328970	6-0368107	-004545456
226	9 86 81	10 798 881	14-8660687	6-0459435	-004524887
227	9 90 84	10 941 048	14-8996644	6-0550489	-004504505
228	9 94 89	11 089 567	14-9331845	6-0641270	-004484303
229	9 98 94	11 239 434	14-9666295	6-0731779	-004464286
230	10 02 96	11 389 625	15-0000000	6-0822020	-004444444
231	10 07 06	11 543 176	15-0382964	6-0911194	-004424779
232	10 11 16	11 697 088	15-0665192	6-1001702	-004404266
233	10 15 24	11 853 853	15-0950689	6-1091147	-004383965
234	10 19 34	12 008 989	15-1237609	6-1180382	-004363681
235	10 23 41	12 167 000	15-1527509	6-1269257	-004343426
236	10 27 46	12 326 891	15-1826842	6-1357924	-004323904
237	10 31 53	12 487 168	15-2125462	6-1446387	-004304385
238	10 35 59	12 649 887	15-2424875	6-1534486	-004284845
239	10 39 66	12 813 904	15-2720585	6-1622401	-004265319
240	10 43 71	12 979 875	15-3027097	6-1710058	-004245819
241	10 47 78	13 144 256	15-3322915	6-1797466	-004226288
242	10 51 83	13 313 058	15-3628048	6-1884628	-004206909
243	10 55 89	13 481 972	15-3932486	6-1971544	-004187681
244	10 59 94	13 651 919	15-4237246	6-2058218	-004168410
245	10 63 96	13 824 000	15-4536248	6-2144650	-004149354
246	10 67 96	13 997 531	15-5241747	6-2230843	-004130378
247	10 71 96	14 172 488	15-5558492	6-2316797	-004111328
248	10 75 96	14 348 907	15-5884573	6-2402515	-004092361
249	10 79 96	14 526 784	15-6224994	6-2488248	-004073398
250	10 83 96	14 706 125	15-65521758	6-2574054	-004054431
251	10 87 96	14 886 086	15-6884871	6-2659866	-004035464
252	10 91 96	15 067 686	15-7218286	6-2745854	-004016498
253	10 95 96	15 249 928	15-7552936	6-2831928	-003997531
254	10 99 96	15 433 809	15-7888646	6-2918000	-003978564
255	11 03 96	15 619 329	15-8225496	6-3004172	-003959597
256	11 07 96	15 806 566	15-8563246	6-3090344	-003940630
257	11 11 96	15 994 428	15-8901996	6-3176516	-003921663
258	11 15 96	16 183 009	15-9241748	6-3262688	-003902696
259	11 19 96	16 372 256	15-9582500	6-3348860	-003883729
260	11 23 96	16 562 169	15-9924252	6-3435032	-003864762
261	11 27 96	16 752 750	16-0266004	6-3521204	-003845795
262	11 31 96	16 943 999	16-0608756	6-3607376	-003826828
263	11 35 96	17 135 808	16-0952508	6-3693548	-003807861
264	11 39 96	17 328 277	16-1297260	6-3779720	-003788894
265	11 43 96	17 521 306	16-1643012	6-3865892	-003769927
266	11 47 96	17 714 895	16-1989764	6-3952064	-003750960
267	11 51 96	17 908 544	16-2337516	6-4038236	-003731993
268	11 55 96	18 103 253	16-2688268	6-4124408	-003713026
269	11 59 96	18 298 012	16-3039020	6-4210580	-003694059
270	12 03 96	18 492 821	16-3390772	6-4296752	-003675092
271	12 07 96	18 687 680	16-3742524	6-4382924	-003656125
272	12 11 96	18 882 489	16-4094276	6-4469096	-003637158
273	12 15 96	19 077 248	16-4446028	6-4555268	-003618191
274	12 19 96	19 272 057	16-4797780	6-4641440	-003599224
275	12 23 96	19 466 816	16-5149532	6-4727612	-003580257
276	12 27 96	19 661 525	16-5501284	6-4813784	-003561290
277	12 31 96	19 856 284	16-5853036	6-4900000	-003542323
278	12 35 96	20 051 093	16-6204788	6-4986272	-003523356
279	12 39 96	20 245 852	16-6556540	6-5072544	-003504389
280	12 43 96	20 440 661	16-6908292	6-5158816	-003485422
281	12 47 96	20 635 420	16-7260044	6-5245088	-003466455
282	12 51 96	20 830 129	16-7611796	6-5331360	-003447488
283	12 55 96	21 024 888	16-7963548	6-5417632	-003428521
284	12 59 96	21 219 697	16-8315300	6-5503904	-003409554
285	13 03 96	21 414 456	16-8667052	6-5590176	-003390587
286	13 07 96	21 609 265	16-9018804	6-5676448	-003371620
287	13 11 96	21 804 024	16-9370556	6-5762720	-003352653
288	13 15 96	22 000 733	16-9722308	6-5848992	-003333686
289	13 19 96	22 196 442	17-0074060	6-5935264	-003314719
290	13 23 96	22 392 151	17-0425812	6-6021536	-003295752
291	13 27 96	22 587 860	17-0777564	6-6107808	-003276785
292	13 31 96	22 783 569	17-1129296	6-6194080	-003257818
293	13 35 96	22 979 278	17-1481028	6-6280352	-003238851
294	13 39 96	23 174 987	17-1832760	6-6366624	-003219884
295	13 43 96	23 370 696	17-2184492	6-6452896	-003200917
296	13 47 96	23 566 405	17-2536224	6-6539168	-003181950
297	13 51 96	23 762 114	17-2887956	6-6625440	-003162983
298	13 55 96	23 957 823	17-3239688	6-6711712	-003144016
299	13 59 96	24 153 532	17-3591420	6-6797984	-003125049
300	14 03 96	24 349 241	17-3943152	6-6884256	-003106082

No.	Square	Cube	Square Root	Cube Root	Reciprocal
242	5 85 64	14 172 488	15-5658492	6-2316797	-004182281
243	5 90 49	14 348 907	15-5984573	6-2402515	-004153226
244	5 95 86	14 526 784	15 626 2494	6-2488248	-004124269
245	6 00 25	14 706 125	15-6590758	6-2574054	-004095311
246	6 05 16	14 886 086	15-6916871	6-2659866	-004066354
247	6 10 09	15 067 686	15-7242986	6-2745854	-004037398
248	6 15 04	15 249 928	15-7569101	6-2831928	-004018431
249	6 20 01	15 433 809	15-7895216	6-2918000	-003999464
250	6 25 00	15 619 329	15-8221331	6-3004172	-003980497
251	6 30 01	15 806 566	15-8547446	6-3090344	-003961530
252	6 35 04	16 000 000	15-8873561	6-3176516	-003942563
253	6 40 09	16 192 977	15-9200000	6-3262688	-003923596
254	6 45 16	16 386 408	15-9526544	6-3348860	-003904629
255	6 50 25	16 581 375	15-9853088	6-3435032	-003885662
256	6 55 36	16 777 316	16-0179632	6-3521204	-003866695
257	6 60 49	16 974 289	16-0506176	6-3607376	-003847728
258	6 65 64	17 172 319	16-0832720	6-3693548	-003828761
259	6 70 81	17 370 400	16-1159264	6-3779720	-003809794
260	6 76 00	17 568 529	16-1485808	6-3865892	-003790827
261	6 81 21	17 766 680	16-1812352	6-3952064	-003771860
262	6 86 44	17 964 798	16-2138896	6-4038236	-003752893
263	6 91 69	18 162 875	16-2465440	6-4124408	-003733926
264	6 96 96	18 360 912	16-2791984	6-4210580	-003714959
265	7 02 25	18 558 999	16-3118528	6-4296752	-003695992
266	7 07 56	18 757 136	16-3445072	6-4382924	-003677025
267	7 13 89	18 955 223	16-3771616	6-4469096	-003658058
268	7 19 24	19 153 270	16-4098160	6-4555268	-003639091
269	7 24 61	19 351 367	16-4424704	6-4641440	-003620124
270	7 29 00	19 549 424	16-4751248	6-4727612	-003601157
271	7 34 41	19 747 441	16-5077792	6-4813784	-003582190
272	7 39 84	19 945 518	16-5404336	6-4900000	-003563223
273	7 45 29	20 143 545	16-5730880	6-4986272	-003544256
274	7 50 76	20 341 632	16-6057424	6-5072544	-003525289
275	7 56 25	20 539 669	16-6383968	6-5158816	-003506322
276	7 61 76	20 737 756	16-6710512	6-5245088	-003487355
277	7 67 29	20 935 843	16-7037056	6-5331360	-003468388
278	7 72 84	21 133 930	16-7363600	6-5417632	-003449421
279	7 78 41	21 332 017	16-7690144	6-5503904	-003430454
280	7 84 00	21 530 104	16-8016688	6-5590176	-003411487
281	7 89 61	21 728 191	16-8343232	6-5676448	-003392520
282	7 95 24	21 926 278	16-8669776	6-5762720	-003373553
283	8 00 89	22 124 365	16-8996320	6-5848992	-003354586
284	8 06 56	22 322 452	16-9322864	6-5935264	-0033

TABLE XLV. (continued).

No.	Square	Onbe	Square Root	Cube Root	Reciprocal
391	8 46 81	34 643 171	17-0567221	6-6267054	-008456426
392	8 53 64	34 897 088	17-0680075	6-6842874	-008412968
393	8 58 49	35 151 757	17-1172428	6-64118522	-008412968
394	8 64 36	35 413 184	17-1464282	6-6498998	-008401861
395	8 70 25	35 673 875	17-1755640	6-6569802	-008389881
396	8 76 16	35 934 836	17-2046605	6-6644487	-008378778
397	8 82 09	36 198 078	17-2336879	6-6719408	-008367005
398	8 88 04	36 463 593	17-2626765	6-6794200	-008355270
399	8 94 01	36 730 999	17-2916165	6-6868681	-008344482
400	9 00 00	37 000 000	17-3205081	6-6943295	-008333383
401	9 06 01	37 270 901	17-3498516	6-7017588	-008322559
402	9 12 04	37 543 608	17-37871472	6-7091729	-008311268
403	9 18 09	37 818 137	17-4068952	6-7165700	-008300690
404	9 24 15	38 094 464	17-4355958	6-7239508	-008289474
405	9 30 25	38 373 825	17-4642492	6-7318155	-008278689
406	9 36 36	38 655 316	17-4928557	6-7396641	-008267974
407	9 42 40	38 940 448	17-5214155	6-7475967	-008257329
408	9 48 44	39 228 113	17-5499288	6-7556134	-008246758
409	9 54 51	39 518 413	17-5788958	6-7636148	-008236246
410	9 61 00	39 810 000	17-6068169	6-7716895	-008225690
411	9 67 21	40 103 931	17-6351921	6-7797229	-008215434
412	9 73 44	40 397 837	17-6636917	6-7878242	-008205128
413	9 79 69	40 694 397	17-6918060	6-7959613	-008194888
414	9 85 56	40 995 144	17-7200451	6-8040921	-008184718
415	9 92 25	41 298 875	17-7482893	6-8122847	-008174608
416	9 98 56	41 554 496	17-7768868	6-8204200	-008164557
417	10 04 89	41 855 018	17-8044938	6-8285942	-008154574
418	10 11 24	42 157 433	17-8325545	6-8367214	-008144654
419	10 17 61	42 461 759	17-8605711	6-8448947	-008134796
420	10 24 00	42 768 000	17-8885438	6-8530937	-008125000
421	10 30 41	43 076 161	17-9164729	6-8613213	-008115265
422	10 36 84	43 386 948	17-9443584	6-8695841	-008105590
423	10 43 29	43 698 867	17-9722008	6-8778120	-008095927
424	10 49 76	44 013 324	18-0000000	6-8860255	-008086420
425	10 56 25	44 330 135	18-0277564	6-8942844	-008076928
426	10 62 76	44 648 976	18-0554701	6-9025888	-008067485
427	10 69 30	44 969 783	18-0834113	6-9109188	-008058104
428	10 75 84	45 292 552	18-1107703	6-9192445	-008048780
429	10 82 41	45 617 289	18-1385571	6-9275859	-008039514
430	10 89 00	45 943 000	18-1659021	6-9359422	-008030808
431	10 95 61	46 269 691	18-1934054	6-9443054	-008022148
432	11 02 24	46 598 968	18-2208072	6-9526856	-008013656
433	11 08 50	46 930 837	18-2482876	6-9610808	-008004800
434	11 15 56	47 265 704	18-2758669	6-9695196	-007996012
435	11 22 35	47 603 575	18-3036052	6-9779709	-007987507
436	11 29 06	47 943 056	18-3316028	6-9864484	-007979190
437	11 35 69	48 284 753	18-3596984	6-9949858	-007970859
438	11 42 44	48 631 473	18-3884763	6-99358198	-007962580
439	11 49 31	48 983 319	18-4175226	6-99216826	-007954353

No.	Square	Onbe	Square Root	Cube Root	Reciprocal
840	11 56 00	39 304 000	18-4390889	6-9795821	-002941176
841	11 63 81	39 661 831	18-4661858	6-9863681	-002932651
842	11 71 64	40 000 000	18-4932430	6-9931906	-002923977
843	11 79 49	40 333 607	18-5202592	7-0000000	-002915452
844	11 88 36	40 707 584	18-5472370	7-0067962	-002906977
845	11 97 25	41 083 635	18-5741756	7-0135791	-002898651
846	12 06 16	41 461 786	18-6010752	7-0203490	-002890178
847	12 15 09	41 841 938	18-6279960	7-0271058	-002881844
848	12 24 04	42 224 193	18-6548761	7-0338497	-002873563
849	12 33 01	42 608 549	18-6818147	7-0405806	-002865380
850	12 42 00	42 994 000	18-7087869	7-0472987	-002857143
851	12 51 01	43 380 551	18-7358940	7-0540041	-002848908
852	12 60 04	43 768 208	18-7630460	7-0606967	-002840690
853	12 69 09	44 157 977	18-7902432	7-0673767	-002832461
854	12 78 16	44 549 864	18-8173942	7-0740440	-002824285
855	12 87 25	44 943 875	18-8444487	7-0807898	-002816160
856	12 96 36	45 339 016	18-8715162	7-0875411	-002808089
857	13 05 49	45 736 289	18-8985866	7-0942979	-002800090
858	13 14 64	46 134 604	18-9256689	7-1010585	-002792120
859	13 23 81	46 533 579	18-9527589	7-1078263	-002784256
860	13 33 00	46 934 100	18-9798560	7-1146087	-002776481
861	13 42 21	47 336 281	19-0069600	7-1214063	-002768778
862	13 51 44	47 739 016	19-0340726	7-1282193	-002761123
863	13 60 69	48 142 809	19-0611942	7-1350491	-002753528
864	13 70 00	48 547 664	19-0883261	7-1419040	-002745983
865	13 79 36	48 953 576	19-1154695	7-1487840	-002738515
866	13 88 73	49 360 549	19-1425841	7-1556890	-002731047
867	13 98 16	49 768 688	19-1697041	7-1626193	-002723674
868	14 07 64	50 177 991	19-1968301	7-1695657	-002716391
869	14 17 16	50 588 409	19-2239627	7-1765289	-002709197
870	14 26 73	50 999 944	19-2510968	7-1835044	-002702003
871	14 36 36	51 412 601	19-2782324	7-1904918	-002694818
872	14 46 04	51 826 376	19-3053701	7-1974803	-002687643
873	14 55 76	52 241 281	19-3324196	7-2044708	-002680468
874	15 05 53	52 656 416	19-3594801	7-2114633	-002673293
875	15 15 36	53 072 681	19-3865426	7-2184578	-002666118
876	15 25 25	53 489 986	19-4136071	7-2254543	-002658943
877	15 35 16	53 908 331	19-4406736	7-2324528	-002651768
878	15 45 11	54 327 721	19-4677421	7-2394533	-002644593
879	15 55 11	54 748 156	19-4948126	7-2464558	-002637418
880	15 65 16	55 169 641	19-5218851	7-2534593	-002630243
881	15 75 26	55 591 176	19-5489576	7-2604638	-002623068
882	15 85 41	56 013 761	19-5760301	7-2674693	-002615893
883	15 95 61	56 436 406	19-6031026	7-2744758	-002608718
884	16 05 86	56 860 111	19-6301751	7-2814833	-002601543
885	16 16 16	57 284 866	19-6572476	7-2884918	-002594368
886	16 26 51	57 710 681	19-6843201	7-2954993	-002587193
887	16 37 00	58 137 546	19-7113926	7-3025078	-002580018
888	16 47 24	58 565 681	19-7384651	7-3095173	-002572843

TABLE XLV. (continued).

No.	Square	Cube	Square Root	Cube Root	Reciprocal
889	15 13 31	58 863 869	19-7230829	7-9998956	-0-02570694
890	15 21 00	59 319 000	19-7484177	7-3061436	-0-02564109
891	15 28 51	59 776 471	19-7737199	7-3128618	-0-02557545
892	15 36 54	60 336 988	19-7989899	7-3186114	-0-02551020
893	15 44 49	60 938 487	19-8242276	7-3248295	-0-02544529
894	15 52 36	61 521 884	19-8494332	7-3310369	-0-02538071
895	15 60 35	62 139 875	19-8746069	7-3372839	-0-02531646
896	15 68 16	62 699 186	19-8997487	7-3434205	-0-02525253
897	15 75 09	63 370 778	19-9248688	7-3495966	-0-02518892
898	15 82 01	63 944 703	19-9499373	7-3557624	-0-02512533
899	15 88 54	64 531 109	19-9749844	7-3619178	-0-02506266
900	16 00 00	65 140 000	20-0000000	7-3680630	-0-02500000
901	16 08 01	65 761 901	20-0249841	7-3741979	-0-02493766
902	16 16 04	66 404 808	20-0499377	7-3803227	-0-02487562
903	16 24 09	67 069 837	20-0748399	7-3864378	-0-02481390
904	16 32 16	67 756 940	20-0997512	7-3925418	-0-02475248
905	16 40 25	68 466 135	20-1246118	7-3986363	-0-02469136
906	16 48 36	69 198 416	20-1494417	7-4047206	-0-02463054
907	16 56 49	69 952 889	20-1742410	7-4107930	-0-02456972
908	16 64 64	70 729 813	20-1990999	7-4168695	-0-02450980
909	16 72 81	71 529 989	20-2239142	7-4229142	-0-02444988
910	16 81 00	72 352 000	20-2484567	7-4289589	-0-02438920
911	16 89 31	73 196 631	20-2731349	7-4349938	-0-02432864
912	16 97 44	74 062 638	20-2977631	7-4410189	-0-02426814
913	17 05 69	74 950 997	20-3224014	7-4470342	-0-02420780
914	17 13 96	75 862 000	20-3469899	7-4530399	-0-02414745
915	17 22 25	76 795 875	20-3715488	7-4590359	-0-02408746
916	17 30 56	77 750 608	20-3960781	7-4650223	-0-02402744
917	17 38 80	78 727 392	20-4205779	7-4709991	-0-02396782
918	17 47 04	79 726 032	20-4450483	7-4769664	-0-02390846
919	17 55 51	80 746 608	20-4694895	7-4829242	-0-02384924
920	17 64 41	81 788 000	20-4939015	7-4888724	-0-02379025
921	17 73 31	82 850 271	20-5182845	7-4948113	-0-02373127
922	17 82 24	83 933 808	20-5426386	7-5007406	-0-02367268
923	17 91 16	85 038 607	20-5669638	7-5066707	-0-02361436
924	17 99 78	86 164 864	20-5912608	7-5125715	-0-02355621
925	18 08 35	87 312 635	20-6155281	7-5184730	-0-02349824
926	18 16 76	88 482 000	20-6397674	7-5243745	-0-02344041
927	18 25 23	89 672 983	20-6639783	7-5302742	-0-02338268
928	18 33 84	90 885 504	20-6881609	7-5361721	-0-02332504
929	18 42 41	92 119 681	20-7123152	7-5420667	-0-02326749
930	18 50 96	93 375 504	20-7364414	7-5479543	-0-02321002
931	18 59 51	94 653 271	20-7605395	7-5538468	-0-02315261
932	19 08 56	95 953 000	20-7846097	7-5597443	-0-02309524
933	19 17 59	97 274 808	20-8086520	7-5656468	-0-02303787
934	19 26 56	98 618 607	20-8326967	7-5715443	-0-02298049
935	19 35 56	100 000 000	20-8566586	7-5774468	-0-02292311
936	19 44 56	101 404 808	20-8806130	7-5833493	-0-02286572
937	19 53 56	102 830 000	20-9045450	7-5892518	-0-02280833
938	20 02 56	104 276 808			
939	20 11 56	105 744 808			
940	20 20 56	107 224 808			
941	20 29 56	108 724 808			
942	20 38 56	110 234 808			
943	20 47 56	111 754 808			
944	20 56 56	113 284 808			
945	20 65 56	114 824 808			
946	20 74 56	116 374 808			
947	20 83 56	117 934 808			
948	20 92 56	119 504 808			
949	21 01 56	121 084 808			
950	21 10 56	122 684 808			
951	21 19 56	124 294 808			
952	21 28 56	125 914 808			
953	21 37 56	127 544 808			
954	21 46 56	129 184 808			
955	21 55 56	130 834 808			
956	21 64 56	132 494 808			
957	21 73 56	134 164 808			
958	21 82 56	135 844 808			
959	21 91 56	137 534 808			
960	22 00 56	139 244 808			
961	22 09 56	140 964 808			
962	22 18 56	142 694 808			
963	22 27 56	144 434 808			
964	22 36 56	146 184 808			
965	22 45 56	147 944 808			
966	22 54 56	149 714 808			
967	23 03 56	151 494 808			
968	23 12 56	153 284 808			
969	23 21 56	155 084 808			
970	23 30 56	156 894 808			
971	23 39 56	158 714 808			
972	23 48 56	160 544 808			
973	23 57 56	162 384 808			
974	24 06 56	164 234 808			
975	24 15 56	166 094 808			
976	24 24 56	167 964 808			
977	24 33 56	169 844 808			
978	24 42 56	171 734 808			
979	24 51 56	173 634 808			
980	25 00 56	175 544 808			
981	25 09 56	177 464 808			
982	25 18 56	179 394 808			
983	25 27 56	181 334 808			
984	25 36 56	183 284 808			
985	25 45 56	185 244 808			
986	25 54 56	187 214 808			
987	26 03 56	189 194 808			
988	26 12 56	191 184 808			
989	26 21 56	193 184 808			
990	26 30 56	195 194 808			
991	26 39 56	197 214 808			
992	26 48 56	199 244 808			
993	26 57 56	201 284 808			
994	27 06 56	203 334 808			
995	27 15 56	205 394 808			
996	27 24 56	207 464 808			
997	27 33 56	209 544 808			
998	27 42 56	211 634 808			
999	27 51 56	213 734 808			
1000	28 00 56	215 844 808			

TABLE XLV. (continued).

No.	Square	Cube	Square Root	Cube Root	Reciprocal
487	23 71 69	115 501 808	22-0680765	7-8676180	-002053888
488	23 81 44	116 514 972	22-0907220	7-8729944	-002049180
489	23 91 21	116 980 169	22-1135444	7-8789684	-002044900
490	24 01 00	117 649 000	22-1359486	7-8837352	-002040816
491	24 10 81	118 370 771	22-1585198	7-8890946	-002036660
492	24 20 64	119 095 488	22-1810780	7-8944468	-002032520
493	24 30 49	119 823 157	22-2036003	7-8997917	-002028398
494	24 40 36	120 558 784	22-2261108	7-9051294	-002024291
495	24 50 25	121 287 875	22-2485965	7-9104599	-002020202
496	24 60 16	122 023 986	22-2710575	7-9157832	-002016129
497	24 70 09	122 768 478	22-2934968	7-9210994	-002012072
498	24 80 04	123 505 994	22-3159136	7-9264085	-002008032
499	24 90 01	124 241 499	22-3383079	7-9317104	-002004008
500	25 00 00	125 000 000	22-3606798	7-9370058	-002000000
501	25 10 01	125 751 501	22-3830298	7-9422981	-001996008
502	25 20 04	126 506 008	22-4053565	7-9475789	-001992032
503	25 30 09	127 263 637	22-4276615	7-9528477	-001988072
504	25 40 16	128 024 064	22-4499448	7-9581144	-001984127
505	25 50 25	128 787 925	22-4722051	7-9633748	-001980198
506	25 60 36	129 554 816	22-4944488	7-9686271	-001976285
507	25 70 49	130 323 948	22-5166605	7-9738781	-001972387
508	25 80 64	131 096 613	22-5388568	7-9791122	-001968504
509	25 90 81	131 872 929	22-5611028	7-9843444	-001964697
510	26 01 00	132 651 000	22-5831796	7-9895697	-001960784
511	26 11 21	133 433 831	22-6053891	7-9947883	-001956947
512	26 21 44	134 217 728	22-6274170	8-0000000	-001953125
513	26 31 69	135 005 697	22-6493068	8-0052049	-001949318
514	26 41 96	135 798 744	22-6715681	8-0104082	-001945525
515	26 52 25	136 596 875	22-6936114	8-0155946	-001941748
516	26 62 56	137 398 096	22-7156394	8-0207794	-001937984
517	26 73 89	138 198 418	22-7376340	8-0259574	-001934266
518	26 84 34	139 001 983	22-7596184	8-0311287	-001930502
519	26 95 11	139 798 869	22-7815713	8-0362985	-001926782
520	27 04 00	140 606 000	22-8035085	8-0414515	-001923077
521	27 14 41	141 420 761	22-8254244	8-0466080	-001919386
522	27 24 84	142 238 648	22-8473198	8-0517479	-001915709
523	27 35 39	143 065 067	22-8691983	8-0568862	-001912046
524	27 45 76	143 877 924	22-8910463	8-0620180	-001908397
525	27 56 25	144 708 125	22-9128785	8-0671432	-001904762
526	27 66 76	145 531 876	22-9346899	8-0722620	-001901141
527	27 77 29	146 368 188	22-9564806	8-0773748	-001897583
528	27 87 84	147 197 863	22-9782506	8-0824800	-001893989
529	27 98 41	148 028 889	23-0000000	8-0875794	-001890359
530	28 09 00	148 877 000	23-0217289	8-0926792	-001886792
531	28 19 61	149 731 391	23-0434372	8-0977589	-001883299
532	28 30 24	150 588 768	23-0651252	8-1028390	-001879699
533	28 40 89	151 451 437	23-0867928	8-1079128	-001876173
534	28 51 56	152 318 804	23-1084400	8-1129808	-001872659
535	28 62 25	153 180 875	23-1300670	8-1180414	-001869199

No.	Square	Cube	Square Root	Cube Root	Reciprocal
536	28 73 06	153 990 656	23-1516798	8-1230962	-001865672
537	28 83 69	154 864 158	23-1732605	8-1281447	-001862197
538	28 94 44	155 730 872	23-1948270	8-1331870	-001858786
539	29 05 31	156 590 819	23-2163755	8-1382280	-001855398
540	29 16 00	157 464 000	23-2379001	8-1432529	-001851852
541	29 26 81	158 340 431	23-2594067	8-1482765	-001848429
542	29 37 64	159 220 008	23-2808935	8-1532989	-001845018
543	29 48 49	160 108 007	23-3023604	8-1583031	-001841621
544	29 59 36	160 989 184	23-3238076	8-1633102	-001838235
545	29 70 31	161 871 695	23-3452351	8-1683092	-001834862
546	29 81 16	162 774 886	23-3666429	8-1733020	-001831502
547	29 92 09	163 687 828	23-3880311	8-1782988	-001828154
548	30 03 04	164 566 598	23-4093998	8-1832695	-001824818
549	30 14 01	165 489 149	23-4307490	8-1882441	-001821494
550	30 25 00	166 375 000	23-4520788	8-1932127	-001818182
551	30 36 01	167 284 151	23-4733892	8-1981753	-001814882
552	30 47 04	168 196 608	23-4946802	8-2031319	-001811594
553	30 58 09	169 113 877	23-5159520	8-2080825	-001808318
554	30 69 16	170 031 464	23-5372046	8-2130271	-001805054
555	30 80 25	170 958 676	23-5584380	8-2179657	-001801802
556	30 91 36	171 879 616	23-5796522	8-2228986	-001798561
557	31 02 49	172 806 698	23-6008474	8-2278254	-001795332
558	31 13 64	173 741 118	23-6220286	8-2327463	-001792115
559	31 24 81	174 676 879	23-6431808	8-2376614	-001788909
560	31 36 00	175 618 000	23-6643191	8-2425706	-001785714
561	31 47 31	176 568 481	23-6854886	8-2474740	-001782531
562	31 58 44	177 504 698	23-7065392	8-2523715	-001779359
563	31 69 69	178 458 547	23-7276210	8-2572633	-001776199
564	31 80 96	179 408 144	23-7486842	8-2621492	-001773050
565	31 92 25	180 369 125	23-7697286	8-2670294	-001769912
566	32 03 56	181 331 496	23-7907545	8-2719039	-001766784
567	32 14 89	182 295 263	23-8117618	8-2767726	-001763668
568	32 26 34	183 260 433	23-8327506	8-2816355	-001760566
569	32 37 81	184 226 009	23-8537209	8-2864928	-001757469
570	32 49 00	185 198 000	23-8746728	8-2913444	-001754386
571	32 60 41	186 169 411	23-8956063	8-2961908	-001751318
572	32 71 84	187 149 248	23-9165215	8-3009861	-001748252
573	32 83 39	188 133 511	23-9374184	8-3058231	-001745201
574	32 94 96	189 119 294	23-9582971	8-3106941	-001742160
575	33 06 56	190 109 875	23-9791576	8-3155175	-001739180
576	33 17 76	191 102 976	24-0000000	8-3203853	-001736111
577	33 29 39	192 100 068	24-0208243	8-3252475	-001733102
578	33 40 84	193 100 553	24-0416306	8-3301004	-001730104
579	33 52 41	194 104 539	24-0624188	8-3349558	-001727116
580	33 64 00	195 113 000	24-0831891	8-3398109	-001724188
581	33 75 61	196 123 941	24-1039416	8-3446410	-001721170
582	33 87 34	197 137 868	24-1246762	8-3494256	-001718213
583	33 99 09	198 156 267	24-1453929	8-3542047	-001715266
584	34 10 56	199 176 704	24-1660919	8-35896784	-001712329

No.	Square	Cube	Square Root	Cube Root	Reciprocal
585	84 23 25	300 301 685	24-1867732	8-3634466	-001709402
586	84 33 96	301 330 056	24-2074869	8-3682095	-001706485
587	84 45 60	302 363 078	24-2280829	8-3729668	-001703577
588	84 57 44	303 397 473	24-2487113	8-3777188	-001699680
589	84 69 21	304 386 460	24-2698222	8-3824653	-001697798
590	84 81 00	305 379 000	24-2899156	8-3872065	-001694915
591	84 94 81	306 425 071	24-3104916	8-3919423	-001692047
592	85 01 64	307 474 688	24-3310501	8-3966729	-001689189
593	85 16 49	308 537 857	24-3515913	8-4018981	-001686341
594	85 32 36	309 614 584	24-3721152	8-4061180	-001683502
595	85 48 25	310 614 875	24-3926218	8-4108826	-001680672
596	85 63 16	311 708 786	24-4131112	8-4156412	-001677852
597	85 64 09	312 776 178	24-4335384	8-4202460	-001675042
598	85 84 19	313 847 193	24-4540385	8-4249448	-001672241
599	85 98 01	314 931 799	24-4744765	8-4296383	-001669449
600	86 00 00	316 000 000	24-4949674	8-4343267	-001666567
601	86 12 01	317 081 801	24-5153013	8-4390098	-001663894
602	86 24 04	318 167 308	24-5356883	8-4436877	-001661180
603	86 36 09	319 256 327	24-5560583	8-4483605	-001658375
604	86 48 16	320 348 864	24-5764115	8-4530281	-001655629
605	86 60 25	321 445 195	24-5967478	8-4576906	-001652893
606	86 72 36	322 545 016	24-6170678	8-4623479	-001650165
607	86 84 49	323 648 648	24-6373700	8-4670000	-001647446
608	86 96 64	324 755 713	24-6576560	8-4716471	-001644787
609	87 08 81	325 866 539	24-6779254	8-4762892	-001642036
610	87 21 00	326 981 000	24-6981781	8-4809261	-001639344
611	87 33 21	328 099 131	24-7184142	8-4855579	-001636661
612	87 45 44	329 230 939	24-7386338	8-4901848	-001633987
613	87 57 69	330 346 397	24-7588368	8-4948065	-001631321
614	87 69 96	331 475 544	24-7790284	8-4994233	-001628664
615	87 82 25	332 608 875	24-7991985	8-5040350	-001626016
616	87 94 56	333 744 896	24-8193478	8-5086417	-001623377
617	88 06 89	334 885 113	24-8394847	8-5132435	-001620746
618	88 19 24	336 030 093	24-8596058	8-5178403	-001618123
619	88 31 61	337 176 659	24-8797106	8-5224321	-001615509
620	88 44 00	338 328 000	24-8997992	8-5270189	-001612903
621	88 56 41	339 483 061	24-9198716	8-5316609	-001610306
622	88 68 84	340 641 846	24-9399278	8-5363170	-001607717
623	88 81 29	341 804 867	24-9599679	8-5409751	-001605186
624	88 93 76	342 970 634	24-9799920	8-5456173	-001602564
625	89 06 25	344 140 635	25-0000000	8-5498797	-001600000
626	89 18 76	345 314 876	25-0199920	8-5544372	-001597486
627	89 31 29	346 491 683	25-0399681	8-5589899	-001594896
628	89 43 84	347 673 193	25-0599282	8-5635377	-001592357
629	89 56 41	348 868 189	25-0798724	8-5680807	-001589825
630	89 69 00	350 047 000	25-0996008	8-5726189	-001587302
631	89 81 24	351 239 561	25-1197184	8-5771528	-001584786
632	89 94 56	352 435 968	25-1396102	8-5816809	-001582278
633	40 06 89	353 636 137	25-1594913	8-5862047	-001579779
634	40 19 56	354 840 104	25-1793566	8-5907238	-001577287
635	40 32 25	356 047 875	25-1992063	8-5952380	-001574803
636	40 45 06	357 259 476	25-2190404	8-5997476	-001572327
637	40 57 60	358 474 853	25-2388389	8-6042525	-001569859
638	40 70 44	359 694 073	25-2586619	8-6087526	-001567398
639	40 83 21	360 917 119	25-2784493	8-6132480	-001564945
640	40 96 00	362 144 000	25-2982218	8-6177888	-001562500
641	41 08 81	363 374 731	25-3179778	8-6222248	-001560062
642	41 21 64	364 609 288	25-3377189	8-6267063	-001557632
643	41 34 49	365 847 707	25-3574447	8-6311880	-001555210
644	41 47 36	367 089 984	25-3771551	8-6356551	-001552795
645	41 60 25	368 338 125	25-3968502	8-6401226	-001550388
646	41 73 16	369 593 186	25-4165301	8-6446855	-001547988
647	41 86 09	370 840 093	25-4361947	8-6490437	-001545595
648	41 99 04	372 089 799	25-4558441	8-6534974	-001543210
649	42 12 01	373 339 448	25-4754784	8-6579465	-001540832
650	42 25 00	374 588 000	25-4950976	8-6623911	-001538462
651	42 38 01	375 834 451	25-5147016	8-6668310	-001536098
652	42 51 04	377 107 808	25-5342907	8-6712665	-001533742
653	42 64 09	378 384 077	25-5538647	8-6756974	-001531384
654	42 77 16	379 664 364	25-5734287	8-6801287	-001529032
655	42 90 25	381 011 875	25-5929678	8-6845456	-001526718
656	43 03 36	382 300 416	25-6124969	8-6889630	-001524390
657	43 16 49	383 589 398	25-6320112	8-6933759	-001522070
658	43 29 64	384 890 313	25-6515107	8-6977843	-001519757
659	43 42 81	386 191 170	25-6709953	8-7021882	-001517451
660	43 56 00	387 494 000	25-6904652	8-7065877	-001515152
661	43 69 21	388 808 781	25-7099208	8-7109827	-001512859
662	43 82 44	390 117 538	25-7293607	8-7153784	-001510574
663	43 95 69	391 434 247	25-7487864	8-7197596	-001508296
664	44 08 96	393 754 944	25-7681975	8-7241414	-001506024
665	44 22 25	394 079 635	25-7875989	8-7285187	-001503759
666	44 35 56	395 408 398	25-8069758	8-7328918	-001501502
667	44 48 89	396 740 968	25-8263431	8-7372604	-001499250
668	44 61 81	398 077 633	25-8456960	8-7416246	-001497006
669	44 75 64	399 413 809	25-8650343	8-7459846	-001494768
670	44 89 50	400 768 000	25-8843582	8-7503401	-001492587
671	45 03 41	402 111 711	25-9036677	8-7546913	-001490318
672	45 17 36	403 464 448	25-9229628	8-7590383	-001488095
673	45 31 31	404 831 917	25-9422435	8-7633809	-001485884
674	45 45 26	406 193 024	25-9615100	8-7677192	-001483680
675	45 59 25	407 546 875	25-9807621	8-7720532	-001481481
676	45 73 25	408 918 776	26-0000000	8-7763890	-001479290
677	45 87 29	410 288 733	26-0192237	8-7807084	-001477105
678	46 01 34	411 665 768	26-0384331	8-7850296	-001474926
679	46 15 41	413 048 889	26-0576284	8-7893466	-001472754
680	46 29 40	414 433 000	26-0768096	8-7936698	-001470588
681	46 43 41	415 813 341	26-0959577	8-7979679	-001468429
682	46 57 44	417 194 568	26-1151297	8-8022721	-001466276

TABLE XLV. (continued).

No.	Square	Cube	Square Root	Cube Root	Reciprocal
683	46 64 89	318 611 987	26-1342687	8-8065722	-001464129
684	46 78 56	320 013 504	26-1533937	8-8106081	-001461988
685	46 92 25	321 419 135	26-1725047	8-8151598	-001459854
686	47 05 96	323 998 866	26-1916017	8-8194474	-001457726
687	47 19 69	324 943 708	26-2106848	8-8237307	-001455604
688	47 33 44	325 680 673	26-2297541	8-8280099	-001453488
689	47 47 21	327 093 769	26-2488095	8-8322850	-001451379
690	47 61 00	328 500 000	26-2678511	8-8365559	-001449275
691	47 74 81	329 939 871	26-2868789	8-8408227	-001447178
692	47 88 64	331 873 868	26-3058929	8-8450854	-001445087
693	48 02 49	333 812 587	26-3248982	8-8493440	-001443001
694	48 16 36	334 355 884	26-3438797	8-8535985	-001440922
695	48 30 25	335 793 876	26-3628527	8-8578489	-001438848
696	48 44 16	337 153 578	26-3818119	8-8620952	-001436782
697	48 58 09	338 608 873	26-4007576	8-8663375	-001434720
698	48 72 04	340 068 803	26-4196896	8-8705757	-001432665
699	48 86 01	341 533 090	26-4386081	8-8748099	-001430615
700	49 00 00	343 000 000	26-4575131	8-8790400	-001428571
701	49 14 01	344 473 101	26-4764046	8-8832661	-001426534
702	49 28 04	345 948 403	26-4952826	8-8874882	-001424501
703	49 42 09	347 428 937	26-5141472	8-8917063	-001422476
704	49 56 16	348 913 684	26-5329983	8-8959204	-001420455
705	49 70 25	350 403 635	26-5518361	8-8901304	-001418440
706	49 84 36	351 895 816	26-5706605	8-8943365	-001416431
707	49 98 40	353 393 243	26-5894716	8-8985387	-001414427
708	50 12 46	354 894 913	26-6082594	8-9027369	-001412429
709	50 26 51	356 400 859	26-6270539	8-9069311	-001410437
710	50 41 00	357 911 000	26-6458252	8-9111214	-001408451
711	50 55 21	359 426 431	26-6645833	8-9153078	-001406470
712	50 69 44	360 944 138	26-6833281	8-9194902	-001404494
713	50 83 69	362 467 097	26-7020598	8-9236687	-001402525
714	50 97 96	363 994 844	26-7207784	8-9278438	-001400560
715	51 12 25	365 525 875	26-7394889	8-9320140	-001398601
716	51 26 56	367 061 696	26-7581763	8-9361809	-001396648
717	51 40 89	368 601 813	26-7768557	8-9403438	-001394700
718	51 55 24	369 146 959	26-7955220	8-9445029	-001392758
719	51 69 61	371 694 959	26-8141754	8-9486581	-001390821
720	51 84 00	373 248 000	26-8328157	8-9528095	-001388889
721	51 98 41	374 805 861	26-8514492	8-9569570	-001386963
722	52 12 84	376 367 048	26-8700577	8-9611007	-001385042
723	52 27 29	377 933 067	26-8886593	8-9652406	-001383126
724	52 41 76	379 503 434	26-9072481	8-9693766	-001381215
725	52 56 25	381 078 195	26-9258240	8-9735089	-001379310
726	52 70 76	382 657 176	26-9443872	8-9776378	-001377410
727	52 85 29	384 240 853	26-9629375	8-9817520	-001375516
728	52 99 84	385 828 858	26-9814751	8-9858829	-001373626
729	53 14 41	387 421 450	27-0000000	9-0000000	-001371742
730	53 28 00	389 017 000	27-0185122	9-0041134	-001369863
731	53 42 61	390 617 891	27-0370117	9-0082229	-001367989

No.	Square	Cube	Square Root	Cube Root	Reciprocal
732	53 58 24	392 223 169	27-0554985	9-0122988	-001366120
733	53 72 59	393 832 837	27-0739727	9-0164399	-001364256
734	53 87 36	395 446 904	27-0924311	9-0205293	-001362398
735	53 02 35	397 065 875	27-1108431	9-0246239	-001360544
736	53 16 96	398 688 256	27-1293199	9-0287149	-001358696
737	53 31 49	400 315 558	27-1477439	9-0328021	-001356852
738	53 46 44	401 947 272	27-1661554	9-0368857	-001355014
739	53 61 31	403 578 419	27-1845544	9-0409655	-001353180
740	53 76 00	405 209 000	27-2029410	9-0450417	-001351351
741	53 90 51	406 839 981	27-2213152	9-0491142	-001349528
742	53 05 64	408 470 484	27-2396769	9-0531831	-001347709
743	53 20 49	410 101 407	27-2580263	9-0572482	-001345895
744	53 35 36	411 732 684	27-2763634	9-0613098	-001344086
745	53 50 25	413 364 795	27-2946981	9-0653677	-001342282
746	53 65 16	415 000 986	27-3130006	9-0694220	-001340483
747	53 80 09	416 632 728	27-3313007	9-0734726	-001338688
748	53 95 04	418 265 992	27-3495987	9-0775197	-001336898
749	54 10 01	420 899 749	27-3678644	9-0815631	-001335118
750	54 25 00	422 534 000	27-3861279	9-0856030	-001333333
751	54 40 01	424 168 751	27-4043792	9-0896392	-001331558
752	54 55 04	425 803 008	27-4226184	9-0936719	-001329787
753	54 70 09	427 437 777	27-4408455	9-0977010	-001328021
754	54 85 16	429 072 048	27-4590604	9-1017265	-001326260
755	55 00 25	430 706 876	27-4772693	9-1057485	-001324508
756	55 15 36	432 341 216	27-4954512	9-1097669	-001322751
757	55 30 49	433 976 098	27-5136330	9-1137818	-001321004
758	55 45 64	435 611 519	27-5317998	9-1177931	-001319261
759	55 60 81	437 246 479	27-5499546	9-1218010	-001317523
760	55 76 00	438 881 000	27-5680975	9-1258058	-001315789
761	55 91 21	440 516 081	27-5862284	9-1298064	-001314060
762	56 06 44	442 151 798	27-6043475	9-1338084	-001312386
763	56 21 69	443 787 444	27-6224546	9-1377971	-001310616
764	56 36 96	445 423 244	27-6405499	9-1417874	-001308901
765	56 52 25	447 058 195	27-6586384	9-1457742	-001307190
766	56 67 56	448 693 296	27-6767050	9-1497576	-001305483
767	56 83 09	450 328 048	27-6947648	9-1537375	-001303781
768	56 98 34	451 962 889	27-7128129	9-1577189	-001302083
769	57 13 61	453 597 824	27-7308492	9-1616969	-001300390
770	57 28 90	455 232 865	27-7488789	9-1656565	-001298701
771	57 44 21	456 868 011	27-7668968	9-1696225	-001297017
772	57 59 54	458 503 268	27-7848980	9-1735852	-001295337
773	57 75 29	460 138 739	27-8028775	9-1775445	-001293661
774	57 90 76	461 773 524	27-8208355	9-1815008	-001291990
775	58 06 25	463 408 824	27-8388218	9-1854527	-001290323
776	58 21 76	465 044 875	27-8568218	9-1894018	-001288660
777	58 37 29	466 681 688	27-8747197	9-1933474	-001287000
778	58 52 84	468 319 265	27-8926514	9-1972897	-001285347
779	58 68 41	470 957 189	27-9105715	9-2012286	-001283697
780	58 84 00	472 595 000	27-9284801	9-2051641	-001282051

TABLE XLV. (continued).

No.	Square	Cube	Square Root	Cube Root	Reciprocal
781	60 90 61	476 879 541	27-9453772	9-2090862	-001280410
782	61 10 34	478 311 768	27-9642629	9-2130250	-001278772
783	61 30 59	480 048 687	27-98521872	9-2169850	-001277189
784	61 46 56	481 880 804	27-9990726	9-2208726	-001275510
785	61 63 25	483 756 935	28-0178515	9-2247914	-001273885
786	61 77 96	485 587 656	28-0356915	9-2287068	-001272325
787	61 93 69	487 448 408	28-0535203	9-2326189	-001270648
788	62 09 44	489 808 873	28-0713677	9-2365327	-001268906
789	62 25 21	491 169 069	28-0891438	9-2404838	-001267427
790	62 41 00	493 039 000	28-1069386	9-2444855	-001265828
791	62 56 81	494 918 671	28-1247292	9-2484254	-001264223
792	62 73 64	496 798 088	28-1424946	9-2523180	-001262626
793	62 89 49	498 677 257	28-1602557	9-2562024	-001261034
794	63 04 36	500 556 184	28-1780066	9-2599114	-001259448
795	63 20 25	502 459 816	28-1957444	9-2637978	-001257862
796	63 36 16	504 386 896	28-2134720	9-2676798	-001256281
797	63 53 09	506 361 578	28-2311884	9-2715592	-001254705
798	63 68 04	508 369 892	28-2488988	9-2754352	-001253183
799	63 84 01	510 393 899	28-2666881	9-2793081	-001251564
800	64 00 00	512 000 000	28-2842712	9-2831777	-001250000
801	64 16 01	513 923 401	28-3019484	9-2870440	-001248489
802	64 32 04	515 849 708	28-3196045	9-2909072	-001246888
803	64 48 09	517 781 697	28-3372546	9-2947671	-001245330
804	64 64 16	519 718 404	28-3548938	9-2986299	-001243781
805	64 80 23	521 660 137	28-3725219	9-3024775	-001242236
806	64 96 36	523 606 616	28-3901891	9-3063278	-001240695
807	65 13 49	525 557 948	28-4077454	9-3101750	-001239157
808	65 29 64	527 514 113	28-4253408	9-3140190	-001237624
809	65 44 81	529 475 129	28-4429253	9-3178599	-001236094
810	65 61 00	531 441 060	28-4604969	9-3216975	-001234568
811	65 77 21	533 411 781	28-4780617	9-3255320	-001233048
812	65 93 44	535 387 898	28-4956137	9-3293634	-001231527
813	66 09 69	537 367 797	28-5131849	9-3331916	-001230012
814	66 25 96	539 353 144	28-5308852	9-3370167	-001228500
815	66 42 25	541 343 876	28-5482048	9-3408386	-001226984
816	66 58 56	543 338 496	28-5657187	9-3446575	-001225490
817	66 75 29	545 338 518	28-5832119	9-3484781	-001223990
818	66 91 94	547 343 493	28-6006998	9-3522857	-001222494
819	67 07 61	549 353 959	28-6181760	9-3560952	-001221001
820	67 24 00	551 368 000	28-6356431	9-3599016	-001219512
821	67 40 41	553 387 661	28-6530976	9-3637049	-001218027
822	67 56 84	555 412 948	28-6705424	9-3675061	-001216545
823	67 73 39	557 441 767	28-6879766	9-3713022	-001215067
824	67 89 76	559 476 934	28-7054002	9-3750963	-001213592
825	68 06 25	561 515 695	28-7228132	9-3788873	-001212121
826	68 23 06	563 559 976	28-7402157	9-3826752	-001210654
827	68 39 39	565 609 283	28-7576077	9-3864600	-001209190
828	68 55 84	567 663 558	28-7749891	9-3902419	-001207729
829	68 72 41	569 723 789	28-7923601	9-3940206	-001206273

No.	Square	Cube	Square Root	Cube Root	Reciprocal
830	68 89 00	571 787 000	28-8097906	9-3977964	-001204819
831	69 06 61	573 866 191	28-8270706	9-4015691	-001203369
832	69 23 34	575 980 868	28-8444102	9-4053887	-001201923
833	69 39 59	578 009 537	28-8617394	9-4091054	-001200480
834	69 55 56	580 088 875	28-8790582	9-4128690	-001199041
835	69 72 35	582 193 870	28-8963666	9-4166297	-001197605
836	69 88 96	584 277 056	28-9136646	9-4203873	-001196172
837	70 05 69	586 376 258	28-9309523	9-4241420	-001194748
838	70 22 44	588 480 472	28-9482927	9-4278986	-001193317
839	70 39 31	590 589 719	28-9654967	9-4316423	-001191895
840	70 56 00	592 704 000	28-9827585	9-4353880	-001190476
841	70 72 81	594 833 821	29-0000000	9-4391307	-001189061
842	70 89 64	596 947 686	29-0172363	9-4428704	-001187648
843	71 06 49	599 077 107	29-0344623	9-4466072	-001186234
844	71 23 36	601 211 584	29-0516781	9-4503410	-001184834
845	71 40 35	603 351 195	29-0688837	9-4540719	-001183432
846	71 57 16	605 495 736	29-0860791	9-4577959	-001182033
847	71 74 09	607 645 423	29-1032644	9-4615249	-001180638
848	71 91 04	609 800 192	29-1204396	9-4652470	-001179245
849	72 08 01	611 960 049	29-1376046	9-4689661	-001177856
850	72 25 00	614 126 000	29-1547595	9-4726824	-001176471
851	72 42 01	616 296 051	29-1719043	9-4763957	-001175088
852	72 59 04	618 470 206	29-1890390	9-4801061	-001173709
853	72 76 09	620 650 477	29-2061637	9-4838186	-001172333
854	72 93 16	622 835 864	29-2232784	9-4875182	-001170960
855	73 10 35	625 026 875	29-2403880	9-4912191	-001169591
856	73 27 38	627 223 016	29-2574777	9-4949188	-001168224
857	73 44 49	629 425 798	29-2745623	9-4986147	-001166861
858	73 61 64	631 633 718	29-2916370	9-5023078	-001165501
859	73 78 81	633 848 779	29-3087018	9-5059980	-001164144
860	73 96 00	636 066 000	29-3257566	9-5096854	-001162791
861	74 13 31	638 277 381	29-3428015	9-5133699	-001161440
862	74 30 44	640 508 998	29-3598365	9-5170515	-001160098
863	74 47 69	642 785 647	29-3768616	9-5207303	-001158749
864	74 64 96	645 072 544	29-3938769	9-5244063	-001157407
865	74 82 35	647 314 635	29-4108823	9-5280794	-001156069
866	74 99 56	649 561 886	29-4278779	9-5317497	-001154734
867	75 16 89	651 714 863	29-4448637	9-5354172	-001153403
868	75 34 24	653 973 033	29-4618397	9-5390818	-001152074
869	75 51 61	656 238 009	29-4788059	9-5427487	-001150748
870	75 69 00	658 503 000	29-4957624	9-5464027	-001149425
871	75 86 41	660 776 611	29-5127091	9-5500539	-001148106
872	76 03 84	663 064 848	29-5296461	9-5537123	-001146789
873	76 21 39	665 368 817	29-5465734	9-5573630	-001145475
874	76 38 76	667 687 634	29-5634910	9-5610108	-001144165
875	76 56 35	669 991 876	29-5803989	9-5646559	-001142867
876	76 73 76	672 323 876	29-5972972	9-5682982	-001141568
877	76 91 29	674 626 133	29-6141858	9-5719377	-001140271
878	77 08 84	676 886 153	29-6310648	9-5755745	-001138952

TABLE XLV. (continued).

No.	Square	Cube	Square Root	Cube Root	Reciprocal
879	77 36 41	679 151 439	29-6479842	9-5792085	-001183656
880	77 44 00	681 473 000	29-6647939	9-5828397	-001186364
881	77 51 41	683 797 841	29-6816442	9-5864682	-001189074
882	77 59 34	686 198 983	29-6984848	9-5900989	-001191787
883	77 66 89	688 485 887	29-7153159	9-5937169	-001194503
884	78 14 56	690 807 104	29-7321675	9-5973873	-001197222
885	78 23 25	693 164 135	29-7489496	9-6009548	-001200000
886	78 31 46	695 506 456	29-7657521	9-6045696	-001202844
887	78 39 69	697 864 103	29-7825452	9-6081817	-001205688
888	78 48 44	700 397 073	29-7993289	9-6117911	-001208532
889	79 03 21	703 585 869	29-8161030	9-6153977	-001211376
890	79 31 00	704 969 000	29-8328678	9-6190017	-001214220
891	79 38 81	707 347 971	29-8496281	9-6226036	-001217064
892	79 46 64	709 753 398	29-8663890	9-6262016	-001219908
893	79 54 49	712 131 987	29-8831056	9-6297975	-001222752
894	79 59 86	714 516 984	29-8998328	9-6333907	-001225596
895	80 10 25	716 917 875	29-9165506	9-6369812	-001228440
896	80 20 16	719 333 136	29-9332591	9-6402690	-001231284
897	80 29 09	721 784 373	29-9499583	9-6441542	-001234128
898	80 38 04	724 150 793	29-9666481	9-6477867	-001236972
899	80 46 01	726 573 699	29-9833287	9-6513166	-001239816
900	81 00 00	729 000 000	30-0000000	9-6548938	-001242660
901	81 18 01	731 433 701	30-0166620	9-6584084	-001245504
902	81 36 04	733 870 805	30-0333148	9-6620408	-001248348
903	81 54 09	736 313 837	30-0499584	9-6656096	-001251192
904	81 73 16	738 763 264	30-0665928	9-6691762	-001254036
905	81 90 25	741 217 685	30-0832179	9-6727408	-001256880
906	82 08 36	743 677 416	30-0998389	9-6763017	-001259724
907	82 26 49	746 143 648	30-1164407	9-6798604	-001262568
908	82 44 54	748 613 813	30-1330383	9-6834166	-001265412
909	82 63 01	751 089 439	30-1496269	9-6869701	-001268256
910	82 81 00	753 571 000	30-1662063	9-6905211	-001271100
911	82 99 21	756 058 031	30-1827765	9-6940694	-001273944
912	83 17 44	758 550 538	30-1993377	9-6976151	-001276788
913	83 35 69	761 048 497	30-2158929	9-7011583	-001279632
914	83 53 96	763 551 944	30-2324329	9-7046989	-001282476
915	83 73 25	766 060 875	30-2489669	9-7082869	-001285320
916	83 90 56	768 575 396	30-2654919	9-7117723	-001288164
917	84 08 89	771 096 213	30-2820079	9-7153051	-001291008
918	84 27 24	773 630 693	30-2985148	9-7188354	-001293852
919	84 45 61	776 151 559	30-3150128	9-7223631	-001296696
920	84 64 00	778 688 000	30-3315018	9-7258883	-001299540
921	84 83 41	781 339 981	30-3479818	9-7294109	-001302384
922	85 00 84	783 777 443	30-3644529	9-7329309	-001305228
923	85 19 29	786 880 487	30-3809151	9-7364484	-001308072
924	85 37 76	788 889 034	30-3973683	9-7399634	-001310916
925	85 56 25	791 453 135	30-4138127	9-7434768	-001313760
926	85 74 76	794 032 776	30-4302481	9-7469857	-001316604
927	85 93 29	796 597 938	30-4466747	9-7504930	-001319448

No.	Square	Onbe	Square Root	Cube Root	Reciprocal
928	86 11 84	799 178 753	30-4630924	9-7539979	-001077586
929	86 30 41	801 765 089	30-4795013	9-7575002	-001076426
930	86 49 00	804 387 000	30-4959504	9-7610001	-001075269
931	86 67 61	807 954 491	30-5123996	9-7644974	-001074114
932	86 86 34	809 557 568	30-5288750	9-7679922	-001072961
933	87 04 59	812 166 237	30-5454048	9-7714845	-001071811
934	87 23 36	814 780 504	30-5619136	9-7749748	-001070664
935	87 42 15	817 400 875	30-5777697	9-7784616	-001069519
936	87 60 56	820 025 858	30-5941171	9-7819466	-001068376
937	87 79 39	822 656 953	30-6104557	9-7854288	-001067236
938	87 98 24	825 288 673	30-6267837	9-7889087	-001066098
939	88 17 11	827 926 004	30-6431069	9-7923861	-001064963
940	88 36 00	830 584 536	30-6594194	9-7958611	-001063830
941	88 54 51	833 237 631	30-6757233	9-7993336	-001062699
942	88 73 44	835 896 888	30-6920185	9-8028036	-001061571
943	88 92 39	838 561 807	30-7083051	9-8062711	-001060445
944	89 11 36	841 233 384	30-7245830	9-8097362	-001059322
945	89 30 35	843 908 625	30-7408523	9-8131989	-001058201
946	89 49 36	846 580 536	30-7571180	9-8166591	-001057082
947	89 68 39	849 278 133	30-7733651	9-8201169	-001055966
948	89 87 44	851 971 893	30-7896086	9-8235723	-001054852
949	90 06 51	854 670 849	30-8058486	9-8270252	-001053741
950	90 25 50	857 376 000	30-8220700	9-8304757	-001052632
951	90 44 51	860 086 351	30-8382879	9-8339238	-001051525
952	90 63 54	862 801 408	30-8544972	9-8373695	-001050420
953	90 83 09	865 523 177	30-8706981	9-8408127	-001049318
954	91 02 16	868 250 664	30-8868904	9-8442556	-001048218
955	91 21 25	870 983 875	30-9030743	9-8476920	-001047120
956	91 40 36	873 733 816	30-9192437	9-8511280	-001046025
957	91 59 49	876 487 498	30-9354166	9-8545617	-001044932
958	91 78 64	879 217 913	30-9516751	9-8579929	-001043841
959	91 97 81	881 974 079	30-9677251	9-8614218	-001042758
960	92 16 00	884 738 000	30-9838668	9-8648488	-001041667
961	92 35 21	887 503 631	31-0000000	9-8682724	-001040588
962	92 54 44	890 277 138	31-0161248	9-8716941	-001039509
963	92 73 69	893 063 847	31-0322413	9-8751185	-001038432
964	92 93 06	895 861 344	31-0483494	9-8785905	-001037344
965	93 12 35	898 633 125	31-0644491	9-8819451	-001036269
966	93 31 56	901 438 696	31-0805405	9-8853574	-001035197
967	93 50 89	904 231 053	31-0966236	9-8887673	-001034126
968	93 70 34	907 089 263	31-1126984	9-8921749	-001033058
969	93 89 61	909 833 200	31-1287648	9-8956801	-001031992
970	94 09 00	912 673 000	31-1448230	9-8989880	-001030928
971	94 28 41	915 498 611	31-1608729	9-9023885	-001029866
972	94 47 84	918 330 043	31-1769145	9-9057817	-001028807
973	94 67 39	921 167 817	31-1929479	9-9091776	-001027742
974	94 86 76	924 010 434	31-2089731	9-9125712	-001026694
975	95 06 35	926 859 875	31-2249900	9-9159624	-001025641
976	95 25 76	929 714 176	31-2409987	9-9193613	-001024590

TABLE XLV. (continued).

No.	Square	Cube	Square Root	Cube Root	Reciprocal
977	95 45 30	932 574 833	31-2569992	9-9227379	-001023541
978	95 64 34	935 441 353	31-2729915	9-9261222	-001022495
979	95 84 41	938 813 739	31-2869757	9-9295042	-001021450
980	96 04 00	941 198 000	31-3019517	9-9328839	-001020408
981	96 23 61	944 076 141	31-3209195	9-9362618	-001019368
982	96 43 34	946 968 168	31-3368792	9-9396363	-001018330
983	96 63 30	949 863 087	31-3528308	9-9430092	-001017294
984	96 83 35	952 768 904	31-3687743	9-9463797	-001016250
985	97 03 35	955 671 625	31-3847097	9-9497479	-001015228
986	97 21 96	958 586 253	31-4006369	9-9531198	-001014199
987	97 41 69	961 504 803	31-4165561	9-9564775	-001013171
988	97 61 44	964 430 373	31-4324773	9-9598388	-001012146
989	97 81 31	967 361 669	31-4483704	9-9631981	-001011122
990	98 01 00	970 298 000	31-4642654	9-9665549	-001010101
991	98 20 81	973 243 371	31-4801625	9-9699095	-001009082
992	98 40 64	976 191 488	31-4960815	9-9732619	-001008065
993	98 60 49	979 146 667	31-5119025	9-9766120	-001007049
994	98 80 36	982 107 785	31-5277655	9-9799599	-001006036
995	99 00 25	985 074 873	31-5436206	9-9833055	-001005025
996	99 20 15	988 047 936	31-5594677	9-9866488	-001004016
997	99 40 04	991 026 973	31-5753068	9-9899300	-001003009
998	99 60 04	994 011 993	31-5911380	9-9932289	-001002004
999	99 80 01	997 003 999	31-6069613	9-9965656	-001001001
1000	1 00 00 00	1 000 000 000	31-6227766	10-0000000	-001000000
1001	1 00 20 01	1 003 008 001	31-6385840	10-0033922	-000999010
1002	1 00 40 04	1 006 019 008	31-6543886	10-0066322	-000998040
1003	1 00 60 09	1 009 037 027	31-6701752	10-0099899	-000997090
1004	1 00 80 18	1 012 048 064	31-6859590	10-0133155	-0009960159
1005	1 01 00 25	1 015 075 135	31-7017849	10-0166389	-0009950249
1006	1 01 20 36	1 018 108 216	31-7176080	10-0199601	-0009940858
1007	1 01 40 49	1 021 147 848	31-7332638	10-0232791	-0009930487
1008	1 01 60 64	1 024 192 513	31-7490157	10-0265058	-0009920686
1009	1 01 80 81	1 027 243 739	31-7647608	10-0299104	-0009910860
1010	1 02 00 01	1 030 301 000	31-7804972	10-0332228	-0009900990
1011	1 02 21 31	1 033 364 833	31-7962262	10-0365830	-0009891197
1012	1 02 41 44	1 036 433 726	31-8119474	10-0398410	-0009881423
1013	1 02 61 60	1 039 509 197	31-8276609	10-0431469	-0009871668
1014	1 02 81 96	1 043 590 744	31-8433666	10-0464066	-0009861933
1015	1 03 02 35	1 047 678 875	31-8590646	10-0497621	-0009852217
1016	1 03 23 55	1 051 773 993	31-8747549	10-0530514	-0009842520
1017	1 03 44 80	1 055 884 016	31-8904374	10-0563485	-0009832842
1018	1 03 65 34	1 060 000 889	31-9061123	10-0596435	-0009823183
1019	1 03 86 01	1 064 088 859	31-9217794	10-0629364	-0009813543
1020	1 04 06 41	1 068 181 906	31-9374388	10-0662271	-0009803922
1021	1 04 27 41	1 072 283 261	31-9530806	10-0695156	-0009794319
1022	1 04 48 44	1 076 386 648	31-9687847	10-0728020	-0009784786
1023	1 04 69 50	1 080 493 167	31-9843712	10-0760863	-0009775171
1024	1 04 90 70	1 084 604 821	32-0000000	10-0793684	-0009765623
1025	1 05 11 36	1 088 721 825	32-0156212	10-0826484	-0009756098

No.	Square	Cube	Square Root	Cube Root	Reciprocal
1026	1 05 32 76	1 090 045 576	32-0312348	10-0859262	-0009746589
1027	1 05 53 29	1 093 906 688	32-0468407	10-0892019	-0009737098
1028	1 05 57 84	1 096 878 053	32-0624391	10-0924755	-0009727626
1029	1 05 58 41	1 099 847 889	32-0780298	10-0957469	-0009718173
1030	1 05 59 00	1 102 827 000	32-0936181	10-0990163	-0009708738
1031	1 05 59 31	1 105 816 703	32-1091887	10-1022835	-0009699321
1032	1 05 59 64	1 108 816 988	32-1247568	10-1055487	-0009690922
1033	1 05 60 01	1 111 828 804	32-1408173	10-1088117	-0009682542
1034	1 05 60 35	1 114 842 875	32-1568704	10-1120726	-0009674180
1035	1 05 60 70	1 117 859 666	32-1731159	10-1153314	-0009665866
1036	1 05 61 06	1 120 876 666	32-1893539	10-1185882	-0009657510
1037	1 05 61 43	1 123 893 873	32-2056181	10-1218428	-0009649202
1038	1 05 61 81	1 126 911 981	32-2218674	10-1251053	-0009640891
1039	1 05 62 20	1 129 930 819	32-2381229	10-1283457	-0009632589
1040	1 05 62 59	1 132 950 000	32-2543810	10-1315941	-0009624385
1041	1 05 63 00	1 135 969 888	32-2706316	10-1348403	-0009616188
1042	1 05 63 41	1 138 989 666	32-2868848	10-1380845	-0009607929
1043	1 05 64 22	1 141 999 666	32-3031316	10-1413266	-0009599699
1044	1 05 65 03	1 144 999 666	32-3193816	10-1445667	-0009591484
1045	1 05 65 44	1 147 999 666	32-3356316	10-1478047	-0009583278
1046	1 05 66 25	1 150 999 666	32-3518816	10-1510406	-0009575072
1047	1 05 67 06	1 153 999 666	32-3681316	10-1542744	-0009566866
1048	1 05 67 47	1 156 999 666	32-3843816	10-1575062	-0009558660
1049	1 05 68 28	1 159 999 666	32-4006316	10-1607359	-0009550454
1050	1 05 69 09	1 162 999 666	32-4168816	10-1639636	-0009542248
1051	1 05 69 50	1 165 999 666	32-4331316	10-1671893	-0009534042
1052	1 05 70 31	1 168 999 666	32-4493816	10-1704129	-0009525836
1053	1 05 71 12	1 171 999 666	32-4656316	10-1736344	-0009517630
1054	1 05 71 53	1 174 999 666	32-4818816	10-1768539	-0009509424
1055	1 05 72 34	1 177 999 666	32-4981316	10-1800714	-0009501218
1056	1 05 73 15	1 180 999 666	32-5143816	10-1832868	-0009493012
1057	1 05 73 56	1 183 999 666	32-5306316	10-1865002	-0009484806
1058	1 05 74 37	1 186 999 666	32-5468816	10-1897116	-0009476600
1059	1 05 75 18	1 189 999 666	32-5631316	10-1929209	-0009468394
1060	1 05 75 59	1 192 999 666	32-5793816	10-1961283	-0009460188
1061	1 05 76 40	1 195 999 666	32-5956316	10-1993336	-0009451982
1062	1 05 77 21	1 198 999 666	32-6118816	10-2025369	-0009443776
1063	1 05 78 02	1 201 999 666	32-6281316	10-2057382	-0009435570
1064	1 05 78 43	1 204 999 666	32-6443816	10-2089395	-0009427364
1065	1 05 79 24	1 207 999 666	32-6606316	10-2121347	-0009419158
1066	1 05 80 05	1 210 999 666	32-6768816	10-2153300	-0009410952
1067	1 05 80 46	1 213 999 666	32-6931316	10-2185233	-0009402746
1068	1 05 81 27	1 216 999 666	32-7093816	10-2217146	-0009394540
1069	1 05 82 08	1 219 999 666	32-7256316	10-2249039	-0009386334
1070	1 05 82 49	1 222 999 666	32-7418816	10-2280912	-0009378128
1071	1 05 83 30	1 225 999 666	32-7581316	10-2312766	-0009369922
1072	1 05 84 11	1 228 999 666	32-7743816	10-2344659	-0009361716
1073	1 05 84 52	1 231 999 666	32-7906316	10-2376413	-0009353510
1074	1 05 85 33	1 234 999 666	32-8068816	10-2408207	-0009345304

TABLE XLV. (continued).

No.	Square	Cube	Square Root	Cube Root	Reciprocal
1075	1 15 56 35	1 243 206 875	32-7871926	10-2439981	-0009802926
1076	1 15 56 76	1 245 766 976	32-8024389	10-2471735	-0009296080
1077	1 15 57 10	1 249 243 583	32-8176782	10-2508470	-0009285051
1078	1 15 57 41	1 253 726 553	32-8329103	10-2535186	-0009276438
1079	1 15 57 72	1 258 213 089	32-8481354	10-2566881	-0009267841
1080	1 15 58 04	1 263 713 000	32-8638335	10-2598557	-0009259259
1081	1 15 58 35	1 269 214 641	32-8795644	10-2630213	-0009250694
1082	1 15 58 66	1 274 726 868	32-8952784	10-2661850	-0009242144
1083	1 15 58 97	1 280 243 665	32-9110033	10-2693467	-0009233610
1084	1 15 59 28	1 285 767 704	32-9267564	10-2725065	-0009225092
1085	1 15 59 59	1 291 291 825	32-9424247	10-2756644	-0009216590
1086	1 15 60 30	1 296 816 000	32-9580982	10-2788208	-0009208032
1087	1 15 60 61	1 302 340 271	32-9737607	10-2819763	-0009199453
1088	1 15 60 92	1 307 864 542	32-9894350	10-2851324	-0009190876
1089	1 15 61 23	1 313 388 813	32-1001000	10-2882885	-0009182278
1090	1 15 61 54	1 318 913 084	32-1007624	10-2914447	-0009173681
1091	1 15 62 25	1 324 437 355	32-1014048	10-2945709	-0009165083
1092	1 15 62 56	1 330 961 626	32-1020673	10-2977153	-0009156486
1093	1 15 63 27	1 336 485 897	32-1027298	10-3008577	-0009147889
1094	1 15 63 58	1 342 010 168	32-1033922	10-3039982	-0009139292
1095	1 15 64 29	1 347 534 439	32-1040547	10-3071386	-0009130695
1096	1 15 64 60	1 353 058 710	32-1047171	10-3102735	-0009122098
1097	1 15 64 91	1 358 582 981	32-1053796	10-3134088	-0009113501
1098	1 15 65 22	1 364 107 252	32-1060421	10-3165411	-0009104904
1099	1 15 65 53	1 369 631 523	32-1067046	10-3196721	-0009096307
1100	1 15 66 24	1 375 155 794	32-1073671	10-3228012	-0009087710
1101	1 15 66 55	1 380 680 065	32-1080296	10-3259284	-0009079113
1102	1 15 67 26	1 386 204 336	32-1086921	10-3290537	-0009070516
1103	1 15 67 57	1 391 728 607	32-1093546	10-3321770	-0009061919
1104	1 15 68 28	1 397 252 878	32-1100171	10-3353003	-0009053322
1105	1 15 68 59	1 402 777 149	32-1106796	10-3384236	-0009044725
1106	1 15 69 30	1 408 301 420	32-1113421	10-3415468	-0009036128
1107	1 15 69 61	1 413 825 691	32-1120046	10-3446701	-0009027531
1108	1 15 70 32	1 419 349 962	32-1126671	10-3477934	-0009018934
1109	1 15 70 63	1 424 874 233	32-1133296	10-3509167	-0009010337
1110	1 15 70 94	1 430 398 504	32-1139896	10-3540400	-0009001740
1111	1 15 71 25	1 435 922 775	32-1146496	10-3571633	-0008993143
1112	1 15 71 56	1 441 447 046	32-1153096	10-3602866	-0008984546
1113	1 15 72 27	1 446 971 317	32-1159696	10-3634099	-0008975949
1114	1 15 72 58	1 452 495 588	32-1166296	10-3665332	-0008967352
1115	1 15 73 29	1 458 019 859	32-1172896	10-3696565	-0008958755
1116	1 15 73 60	1 463 544 130	32-1179496	10-3727798	-0008950158
1117	1 15 73 91	1 469 068 401	32-1186096	10-3759031	-0008941561
1118	1 15 74 22	1 474 592 672	32-1192696	10-3790264	-0008932964
1119	1 15 74 53	1 480 116 943	32-1199296	10-3821497	-0008924367
1120	1 15 74 84	1 485 641 214	32-1205896	10-3852730	-0008915770
1121	1 15 75 15	1 491 165 485	32-1212496	10-3883963	-0008907173
1122	1 15 75 46	1 496 689 756	32-1219096	10-3915196	-0008898576
1123	1 15 75 77	1 502 214 027	32-1225696	10-3946429	-0008890000
1124	1 15 76 08	1 507 738 298	32-1232296	10-3977662	-0008881403
1125	1 15 76 39	1 513 262 569	32-1238896	10-4008895	-0008872806
1126	1 15 76 70	1 518 786 840	32-1245496	10-4040128	-0008864209
1127	1 15 77 01	1 524 311 111	32-1252096	10-4071361	-0008855612
1128	1 15 77 32	1 529 835 382	32-1258696	10-4102594	-0008847015
1129	1 15 77 63	1 535 359 653	32-1265296	10-4133827	-0008838418
1130	1 15 77 94	1 540 883 924	32-1271896	10-4165060	-0008829821
1131	1 15 78 25	1 546 408 195	32-1278496	10-4196293	-0008821224
1132	1 15 78 56	1 551 932 466	32-1285096	10-4227526	-0008812627
1133	1 15 78 87	1 557 456 737	32-1291696	10-4258759	-0008804030
1134	1 15 79 18	1 562 981 008	32-1298296	10-4289992	-0008795433
1135	1 15 79 49	1 568 505 279	32-1304896	10-4321225	-0008786836
1136	1 15 79 80	1 574 029 550	32-1311496	10-4352458	-0008778239
1137	1 15 80 11	1 579 553 821	32-1318096	10-4383691	-0008769642
1138	1 15 80 42	1 585 078 092	32-1324696	10-4414924	-0008761045
1139	1 15 80 73	1 590 602 363	32-1331296	10-4446157	-0008752448
1140	1 15 81 04	1 596 126 634	32-1337896	10-4477390	-0008743851
1141	1 15 81 35	1 601 650 905	32-1344496	10-4508623	-0008735254
1142	1 15 81 66	1 607 175 176	32-1351096	10-4539856	-0008726657
1143	1 15 81 97	1 612 699 447	32-1357696	10-4571089	-0008718060
1144	1 15 82 28	1 618 223 718	32-1364296	10-4602322	-0008709463
1145	1 15 82 59	1 623 747 989	32-1370896	10-4633555	-0008700866
1146	1 15 83 30	1 629 272 260	32-1377496	10-4664788	-0008692269
1147	1 15 83 61	1 634 796 531	32-1384096	10-4696021	-0008683672
1148	1 15 83 92	1 640 320 802	32-1390696	10-4727254	-0008675075
1149	1 15 84 23	1 645 845 073	32-1397296	10-4758487	-0008666478
1150	1 15 84 54	1 651 369 344	32-1403896	10-4789720	-0008657881
1151	1 15 84 85	1 656 893 615	32-1410496	10-4820953	-0008649284
1152	1 15 85 16	1 662 417 886	32-1417096	10-4852186	-0008640687
1153	1 15 85 47	1 667 942 157	32-1423696	10-4883419	-0008632090
1154	1 15 85 78	1 673 466 428	32-1430296	10-4914652	-0008623493
1155	1 15 86 09	1 678 990 699	32-1436896	10-4945885	-0008614896
1156	1 15 86 40	1 684 514 970	32-1443496	10-4977118	-0008606299
1157	1 15 86 71	1 690 039 241	32-1450096	10-5008351	-0008597702
1158	1 15 87 02	1 695 563 512	32-1456696	10-5039584	-0008589105
1159	1 15 87 33	1 701 087 783	32-1463296	10-5070817	-0008580508
1160	1 15 87 64	1 706 612 054	32-1469896	10-5102050	-0008571911
1161	1 15 87 95	1 712 136 325	32-1476496	10-5133283	-0008563314
1162	1 15 88 26	1 717 660 596	32-1483096	10-5164516	-0008554717
1163	1 15 88 57	1 723 184 867	32-1489696	10-5195749	-0008546120
1164	1 15 88 88	1 728 709 138	32-1496296	10-5226982	-0008537523
1165	1 15 89 19	1 734 233 409	32-1502896	10-5258215	-0008528926
1166	1 15 89 50	1 739 757 680	32-1509496	10-5289448	-0008520329
1167	1 15 89 81	1 745 281 951	32-1516096	10-5320681	-0008511732
1168	1 15 90 12	1 750 806 222	32-1522696	10-5351914	-0008503135
1169	1 15 90 43	1 756 330 493	32-1529296	10-5383147	-0008494538
1170	1 15 90 74	1 761 854 764	32-1535896	10-5414380	-0008485941
1171	1 15 91 05	1 767 379 035	32-1542496	10-5445613	-0008477344
1172	1 15 91 36	1 772 903 306	32-1549096	10-5476846	-0008468747
1173	1 15 91 67	1 778 427 577	32-1555696	10-5508079	-0008460150
1174	1 15 91 98	1 783 951 848	32-1562296	10-5539312	-0008451553
1175	1 15 92 29	1 789 476 119	32-1568896	10-5570545	-0008442956
1176	1 15 92 60	1 795 000 390	32-1575496	10-5601778	-0008434359
1177	1 15 92 91	1 800 524 661	32-1582096	10-5633011	-0008425762
1178	1 15 93 22	1 806 048 932	32-1588696	10-5664244	-0008417165
1179	1 15 93 53	1 811 573 203	32-1595296	10-5695477	-0008408568
1180	1 15 93 84	1 817 097 474	32-1601896	10-5726710	-0008400000
1181	1 15 94 15	1 822 621 745	32-1608496	10-5757943	-0008391403
1182	1 15 94 46	1 828 146 016	32-1615096	10-5789176	-0008382806
1183	1 15 94 77	1 833 670 287	32-1621696	10-5820409	-0008374209
1184	1 15 95 08	1 839 194 558	32-1628296	10-5851642	-0008365612
1185	1 15 95 39	1 844 718 829	32-1634896	10-5882875	-0008357015
1186	1 15 95 70	1 850 243 100	32-1641496	10-5914108	-0008348418
1187	1 15 96 01	1 855 767 371	32-1648096	10-5945341	-0008339821
1188	1 15 96 32	1 861 291 642	32-1654696	10-5976574	-0008331224
1189	1 15 96 63	1 866 815 913	32-1661296	10-6007807	-0008322627
1190	1 15 96 94	1 872 340 184	32-1667896	10-6039040	-0008314030
1191	1 15 97 25	1 877 864 455	32-1674496	10-6070273	-0008305433
1192	1 15 97 56	1 883 388 726	32-1681096	10-6101506	-0008296836
1193	1 15 97 87	1 888 913 000	32-1687696	10-6132739	-0008288239
1194	1 15 98 18	1 894 437 271	32-1694296	10-6163972	-0008279642
1195	1 15 98 49	1 900 961 542	32-1700896	10-6195205	-0008271045
1196	1 15 98 80	1 906 485 813	32-1707496	10-6226438	-0008262448
1197	1 15 99 11	1 912 010 084	32-1714096	10-6257671	-0008253851
1198	1 15 99 42	1 917 534 355	32-1720696	10-6288904	-0008245254
1199	1 15 99 73	1 923 058 626	32-1727296	10-6320137	-0008236657
1200	1 16 00 04	1 928 582 897	32-1733896	10-6351370	-0008228060
1201	1 16 00 35	1 934 107 168	32-1740496	10-6382603	-0008219463
1202	1 16 00 66	1 939 631 439	32-1747096	10-6413836	-0008210866
1203	1 16 00 97	1 945 155 710	32-1753696	10-6445069	-0008202269
1204	1 16 01 28	1 950 680 000	32-1760296	10-6476302	-0008193672
1205	1 16 01 59	1 956 204 271	32-1766896	10-6507535	-0008185075
1206	1 16 02 30	1 961 728 542	32-1773496	10-6538768	-0008176478
1207	1 16 02 61	1 967 252 813	32-1780096	10-6570001	-0008167881
12					

TABLE XLV. (continued).

No.	Square	Cube	Square Root	Cube Root	Reciprocal
1271	1 61 54 41	2 053 235 511	35-6510869	10-8321629	-0007867821
1272	1 61 79 84	2 058 075 648	35-6651090	10-8350080	-0007861685
1273	1 62 05 80	2 063 988 417	35-6791255	10-8378416	-0007855460
1274	1 62 30 76	2 069 798 824	35-6931868	10-8406788	-0007849294
1275	1 62 56 36	2 075 671 876	35-7071421	10-8435144	-0007843197
1276	1 63 11 76	2 081 523 578	35-7211422	10-8463485	-0007836991
1277	1 63 37 39	2 088 440 993	35-7351367	10-8491812	-0007830804
1278	1 63 53 84	2 095 326 938	35-7491258	10-8520125	-0007824726
1279	1 64 10 30	2 099 240 680	35-7631095	10-8548422	-0007818608
1280	1 64 38 04	2 097 152 000	35-7771087	10-8576704	-0007812500
1281	1 64 09 61	2 103 071 041	35-7911060	10-8604972	-0007806401
1282	1 64 35 34	2 106 997 768	35-8050276	10-8633225	-0007800312
1283	1 64 60 59	2 111 938 187	35-8189894	10-8661464	-0007794232
1284	1 64 86 56	2 116 874 804	35-8329457	10-8689687	-0007788162
1285	1 65 12 35	2 121 894 135	35-8468965	10-8717897	-0007782101
1286	1 65 37 96	2 126 781 656	35-8608421	10-8746091	-0007776090
1287	1 65 63 69	2 131 748 993	35-8747822	10-8774271	-0007770080
1288	1 65 89 44	2 136 719 873	35-8887169	10-8802436	-0007763975
1289	1 66 15 31	2 141 700 569	35-9026461	10-8830587	-0007757952
1290	1 66 41 00	2 146 689 000	35-9165609	10-8858728	-0007751938
1291	1 66 66 81	2 151 685 171	35-9304884	10-8886845	-0007745983
1292	1 66 92 64	2 156 689 098	35-9444015	10-8914952	-0007740000
1293	1 67 18 49	2 161 700 787	35-9583092	10-8944044	-0007733952
1294	1 67 44 36	2 166 730 184	35-9722115	10-8971128	-0007727975
1295	1 67 70 25	2 171 747 875	35-9861084	10-8999186	-0007722008
1296	1 67 96 16	2 176 758 838	36-0000000	10-9027285	-0007716019
1297	1 68 22 09	2 181 835 073	36-0138862	10-9055269	-0007710160
1298	1 68 48 04	2 186 875 593	36-0277671	10-9083290	-0007704160
1299	1 68 74 01	2 191 938 899	36-0416426	10-9111296	-0007698229
1300	1 69 00 00	2 197 000 000	36-0555128	10-9139287	-0007692308
1301	1 69 26 01	2 202 073 901	36-0693776	10-9167265	-0007686395
1302	1 69 52 04	2 207 155 608	36-0832931	10-9195228	-0007680492
1303	1 69 78 09	2 212 245 197	36-0970913	10-9223177	-0007674597
1304	1 70 04 16	2 217 343 464	36-1109402	10-9251111	-0007668712
1305	1 70 30 35	2 222 447 635	36-1247837	10-9279031	-0007662885
1306	1 70 56 56	2 227 560 616	36-1386220	10-9306987	-0007656968
1307	1 71 23 19	2 232 681 495	36-1524506	10-9334829	-0007651109
1308	1 71 49 44	2 237 810 113	36-1662826	10-9362706	-0007645260
1309	1 71 75 81	2 243 946 680	36-1801050	10-9390569	-0007639419
1310	1 72 02 30	2 249 091 000	36-1939221	10-9418418	-0007633588
1311	1 72 28 81	2 254 243 381	36-2077240	10-9446258	-0007627765
1312	1 72 55 36	2 259 403 927	36-2215406	10-9474074	-0007621961
1313	1 73 22 00	2 264 574 144	36-2353119	10-9501880	-0007616146
1314	1 73 48 56	2 269 747 144	36-2491879	10-9529673	-0007610350
1315	1 73 75 35	2 274 930 876	36-2629287	10-9557451	-0007604568
1316	1 74 02 16	2 280 123 406	36-2767143	10-9585215	-0007598754
1317	1 74 29 00	2 285 328 033	36-2904946	10-9612965	-0007592904
1318	1 74 55 49	2 290 543 493	36-3042697	10-9640701	-0007587258
1319	1 75 22 01	2 295 764 759	36-3180896	10-9668423	-0007581501

No.	Square	Cube	Square Root	Cube Root	Reciprocal
1320	1 75 48 56	2 300 997 000	36-3319113	10-9696181	-0007575758
1321	1 75 75 56	2 306 166 161	36-3457385	10-9723925	-0007569923
1322	1 76 02 56	2 311 340 243	36-3595719	10-9751505	-0007564097
1323	1 76 29 56	2 316 519 367	36-3734067	10-9779171	-0007558279
1324	1 76 56 56	2 321 703 544	36-3872439	10-9806828	-0007552460
1325	1 77 23 56	2 326 892 784	36-4010825	10-9834486	-0007546642
1326	1 77 50 56	2 332 087 088	36-4149225	10-9862136	-0007540824
1327	1 78 17 56	2 337 286 456	36-4287637	10-9889789	-0007535006
1328	1 78 44 56	2 342 490 888	36-4426051	10-9917444	-0007529188
1329	1 78 71 56	2 347 699 384	36-4564466	10-9945099	-0007523370
1330	1 78 98 56	2 352 912 944	36-4702881	10-9972754	-0007517552
1331	1 79 25 56	2 358 131 568	36-4841296	10-1000408	-0007511734
1332	1 79 52 56	2 363 356 256	36-4979711	10-1000000	-0007505916
1333	1 80 19 56	2 368 586 008	36-5118126	10-1000000	-0007499098
1334	1 80 46 56	2 373 820 824	36-5256541	10-1000000	-0007493280
1335	1 80 73 56	2 379 060 704	36-5394956	10-1000000	-0007487462
1336	1 81 00 56	2 384 305 648	36-5533371	10-1000000	-0007481644
1337	1 81 27 56	2 389 555 656	36-5671786	10-1000000	-0007475826
1338	1 81 54 56	2 394 810 728	36-5810201	10-1000000	-0007470008
1339	1 82 21 56	2 400 070 864	36-5948616	10-1000000	-0007464190
1340	1 82 48 56	2 405 336 064	36-6087031	10-1000000	-0007458372
1341	1 82 75 56	2 410 601 328	36-6225446	10-1000000	-0007452554
1342	1 83 02 56	2 415 866 656	36-6363861	10-1000000	-0007446736
1343	1 83 29 56	2 421 137 056	36-6502276	10-1000000	-0007440918
1344	1 83 56 56	2 426 412 528	36-6640691	10-1000000	-0007435100
1345	1 84 23 56	2 431 693 072	36-6779106	10-1000000	-0007429282
1346	1 84 50 56	2 436 978 688	36-6917521	10-1000000	-0007423464
1347	1 85 17 56	2 442 269 272	36-7055936	10-1000000	-0007417646
1348	1 85 44 56	2 447 564 832	36-7194351	10-1000000	-0007411828
1349	1 86 11 56	2 452 865 368	36-7332766	10-1000000	-0007406010
1350	1 86 38 56	2 458 170 880	36-7471181	10-1000000	-0007400192
1351	1 86 65 56	2 463 481 376	36-7609596	10-1000000	-0007394374
1352	1 86 92 56	2 468 796 856	36-7748011	10-1000000	-0007388556
1353	1 87 19 56	2 474 117 328	36-7886426	10-1000000	-0007382738
1354	1 87 46 56	2 479 442 784	36-8024841	10-1000000	-0007376920
1355	1 87 73 56	2 484 768 224	36-8163256	10-1000000	-0007371102
1356	1 88 00 56	2 490 093 648	36-8301671	10-1000000	-0007365284
1357	1 88 27 56	2 495 419 056	36-8440086	10-1000000	-0007359466
1358	1 88 54 56	2 500 744 464	36-8578501	10-1000000	-0007353648
1359	1 89 21 56	2 506 069 872	36-8716916	10-1000000	-0007347830
1360	1 89 48 56	2 511 395 280	36-8855331	10-1000000	-0007342012
1361	1 89 75 56	2 516 720 688	36-8993746	10-1000000	-0007336194
1362	1 90 02 56	2 522 046 096	36-9132161	10-1000000	-0007330376
1363	1 90 29 56	2 527 371 504	36-9270576	10-1000000	-0007324558
1364	1 90 56 56	2 532 696 912	36-9408991	10-1000000	-0007318740
1365	1 91 23 56	2 538 022 320	36-9547406	10-1000000	-0007312922
1366	1 91 50 56	2 543 347 728	36-9685821	10-1000000	-0007307104
1367	1 92 17 56	2 548 673 136	36-9824236	10-1000000	-0007301286
1368	1 92 44 56	2 554 000 544	36-9962651	10-1000000	-0007295468
1369	1 92 71 56	2 559 326 952	37-0101066	10-1000000	-0007289650
1370	1 92 98 56	2 564 653 360	37-0239481	10-1000000	-0007283832
1371	1 93 25 56	2 570 000 768	37-0377896	10-1000000	-0007278014
1372	1 93 52 56	2 575 348 176	37-0516311	10-1000000	-0007272196
1373	1 94 19 56	2 580 696 584	37-0654726	10-1000000	-0007266378
1374	1 94 46 56	2 586 044 992	37-0793141	10-1000000	-0007260560
1375	1 94 73 56	2 591 393 400	37-0931556	10-1000000	-0007254742
1376	1 95 00 56	2 596 741 808	37-1069971	10-1000000	-0007248924
1377	1 95 27 56	2 602 090 216	37-1208386	10-1000000	-0007243106
1378	1 95 54 56	2 607 438 624	37-1346801	10-1000000	-0007237288
1379	1 96 21 56	2 612 787 032	37-1485216	10-1000000	-0007231470
1380	1 96 48 56	2 618 135 440	37-1623631	10-1000000	-0007225652
1381	1 96 75 56	2 623 483 848	37-1762046	10-1000000	-0007219834
1382	1 97 02 56	2 628 832 256	37-1900461	10-1000000	-0007214016
1383	1 97 29 56	2 634 180 664	37-2038876	10-1000000	-0007208198
1384	1 97 56 56	2 639 529 072	37-2177291	10-1000000	-0007202380
1385	1 98 23 56	2 644 877 480	37-2315706	10-1000000	-0007196562
1386	1 98 50 56	2 650 225 888	37-2454121	10-1000000	-0007190744
1387	1 99 17 56	2 655 574 296	37-2592536	10-1000000	-0007184926
1388	1 99 44 56	2 660 922 704	37-2730951	10-1000000	-0007179108
1389	1 99 71 56	2 666 271 112	37-2869366	10-1000000	-0007173290
1390	2 00 00 00	2 671 619 520	37-3007781	10-1000000	-0007167472

TABLE XLV. (continued).

No.	Square	Cube	Square Root	Cube Root	Reciprocal
1369	1 87 41 61	3 565 736 409	37-0000000	11-1087025	-0007804602
1370	1 87 69 00	3 571 853 000	37-0185110	11-1064054	-0007299270
1371	1 87 96 41	3 578 987 811	37-0270172	11-1064054	-0007299270
1372	1 88 23 84	3 586 122 622	37-0405184	11-1118078	-0007298696
1373	1 88 51 25	3 593 257 433	37-0540196	11-1145064	-0007298321
1374	1 88 78 66	3 599 392 244	37-0675208	11-1172041	-0007297927
1375	1 89 06 07	3 605 527 055	37-0810220	11-1199004	-0007297573
1376	1 89 33 48	3 611 661 866	37-0945232	11-1225955	-0007297219
1377	1 89 60 89	3 617 796 677	37-1080244	11-1252906	-0007296864
1378	1 89 88 30	3 623 931 488	37-1215256	11-1279817	-0007296510
1379	1 90 15 71	3 630 066 299	37-1350268	11-1306729	-0007296156
1380	1 90 43 12	3 636 201 110	37-1485280	11-1333641	-0007295802
1381	1 90 70 53	3 642 335 921	37-1620292	11-1360553	-0007295448
1382	1 90 97 94	3 648 470 732	37-1755304	11-1387465	-0007295094
1383	1 91 25 35	3 654 605 543	37-1890316	11-1414377	-0007294740
1384	1 91 52 76	3 660 740 354	37-2025328	11-1441289	-0007294386
1385	1 92 20 17	3 666 875 165	37-2160340	11-1468201	-0007294032
1386	1 92 47 58	3 673 009 976	37-2295352	11-1495113	-0007293678
1387	1 92 75 39	3 679 144 787	37-2430364	11-1522025	-0007293324
1388	1 93 02 80	3 685 279 598	37-2565376	11-1548937	-0007292970
1389	1 93 30 21	3 691 414 409	37-2700388	11-1575849	-0007292616
1390	1 93 57 62	3 697 549 220	37-2835400	11-1602761	-0007292262
1391	1 94 25 03	3 703 684 031	37-2970412	11-1629673	-0007291908
1392	1 94 52 44	3 709 818 842	37-3105424	11-1656585	-0007291554
1393	1 95 19 85	3 715 953 653	37-3240436	11-1683497	-0007291200
1394	1 95 47 26	3 722 088 464	37-3375448	11-1710409	-0007290846
1395	1 95 74 67	3 728 223 275	37-3510460	11-1737321	-0007290492
1396	1 96 02 08	3 734 358 086	37-3645472	11-1764233	-0007290138
1397	1 96 29 49	3 740 492 897	37-3780484	11-1791145	-0007289784
1398	1 96 56 90	3 746 627 708	37-3915496	11-1818057	-0007289430
1399	1 97 24 31	3 752 762 519	37-4050508	11-1844969	-0007289076
1400	1 97 51 72	3 758 897 330	37-4185520	11-1871881	-0007288722
1401	1 98 19 13	3 765 032 141	37-4320532	11-1898793	-0007288368
1402	1 98 46 54	3 771 166 952	37-4455544	11-1925705	-0007288014
1403	1 98 73 95	3 777 301 763	37-4590556	11-1952617	-0007287660
1404	1 99 01 36	3 783 436 574	37-4725568	11-1979529	-0007287306
1405	1 99 28 77	3 789 571 385	37-4860580	11-2006441	-0007286952
1406	1 99 56 18	3 795 706 196	37-4995592	11-2033353	-0007286598
1407	1 99 83 59	3 801 841 007	37-5130604	11-2060265	-0007286244
1408	1 99 10 99	3 807 975 818	37-5265616	11-2087177	-0007285890
1409	1 99 38 40	3 814 110 629	37-5400628	11-2114089	-0007285536
1410	1 99 65 81	3 820 245 440	37-5535640	11-2141001	-0007285182
1411	1 99 93 22	3 826 380 251	37-5670652	11-2167913	-0007284828
1412	1 99 20 63	3 832 515 062	37-5805664	11-2194825	-0007284474
1413	1 99 48 04	3 838 649 873	37-5940676	11-2221737	-0007284120
1414	1 99 75 45	3 844 784 684	37-6075688	11-2248649	-0007283766
1415	2 00 02 86	3 850 919 495	37-6210700	11-2275561	-0007283412
1416	2 00 30 27	3 857 054 306	37-6345712	11-2302473	-0007283058
1417	2 00 57 68	3 863 189 117	37-6480724	11-2329385	-0007282704

No.	Square	Cube	Square Root	Cube Root	Reciprocal
1418	2 01 25 09	3 869 324 128	37-6615736	11-2356297	-0007282350
1419	2 01 52 50	3 875 458 939	37-6750748	11-2383209	-0007281996
1420	2 02 20 31	3 881 593 750	37-6885760	11-2410121	-0007281642
1421	2 02 48 12	3 887 728 561	37-7020772	11-2437033	-0007281288
1422	2 03 15 53	3 893 863 372	37-7155784	11-2463945	-0007280934
1423	2 03 43 34	3 899 998 183	37-7290796	11-2490857	-0007280580
1424	2 04 11 15	3 906 132 994	37-7425808	11-2517769	-0007280226
1425	2 04 38 96	3 912 267 805	37-7560820	11-2544681	-0007279872
1426	2 05 06 77	3 918 402 616	37-7695832	11-2571593	-0007279518
1427	2 05 34 58	3 924 537 427	37-7830844	11-2598505	-0007279164
1428	2 06 02 39	3 930 672 238	37-7965856	11-2625417	-0007278810
1429	2 06 30 20	3 936 807 049	37-8100868	11-2652329	-0007278456
1430	2 06 58 01	3 942 941 860	37-8235880	11-2679241	-0007278102
1431	2 07 25 82	3 949 076 671	37-8370892	11-2706153	-0007277748
1432	2 07 53 63	3 955 211 482	37-8505904	11-2733065	-0007277394
1433	2 08 21 44	3 961 346 293	37-8640916	11-2760000	-0007277040
1434	2 08 49 25	3 967 481 104	37-8775928	11-2786912	-0007276686
1435	2 09 17 06	3 973 615 915	37-8910940	11-2813824	-0007276332
1436	2 09 44 87	3 979 750 726	37-9045952	11-2840736	-0007275978
1437	2 10 12 68	3 985 885 537	37-9180964	11-2867648	-0007275624
1438	2 10 40 49	3 992 020 348	37-9315976	11-2894560	-0007275270
1439	2 11 08 30	3 998 155 159	37-9450988	11-2921472	-0007274916
1440	2 11 36 11	4 004 290 000	37-9585999	11-2948384	-0007274562
1441	2 12 03 92	4 010 424 811	37-9721011	11-2975296	-0007274208
1442	2 12 31 73	4 016 559 622	37-9856023	11-3002208	-0007273854
1443	2 12 59 54	4 022 694 433	37-9991035	11-3029120	-0007273500
1444	2 13 27 35	4 028 829 244	38-0026047	11-3056032	-0007273146
1445	2 13 55 16	4 034 964 055	38-0161059	11-3082944	-0007272792
1446	2 14 22 97	4 041 098 866	38-0296071	11-3109856	-0007272438
1447	2 14 50 78	4 047 233 677	38-0431083	11-3136768	-0007272084
1448	2 15 18 59	4 053 368 488	38-0566095	11-3163680	-0007271730
1449	2 15 46 40	4 059 503 299	38-0701107	11-3190592	-0007271376
1450	2 16 14 21	4 065 638 110	38-0836119	11-3217504	-0007271022
1451	2 16 42 02	4 071 772 921	38-0971131	11-3244416	-0007270668
1452	2 17 09 83	4 077 907 732	38-1106143	11-3271328	-0007270314
1453	2 17 37 64	4 084 042 543	38-1241155	11-3298240	-0007269960
1454	2 18 05 45	4 090 177 354	38-1376167	11-3325152	-0007269606
1455	2 18 33 26	4 096 312 165	38-1511179	11-3352064	-0007269252
1456	2 19 01 07	4 102 446 976	38-1646191	11-3378976	-0007268898
1457	2 19 28 88	4 108 581 787	38-1781203	11-3405888	-0007268544
1458	2 20 00 69	4 114 716 598	38-1916215	11-3432800	-0007268190
1459	2 20 28 50	4 120 851 409	38-2051227	11-3459712	-0007267836
1460	2 20 56 31	4 126 986 220	38-2186239	11-3486624	-0007267482
1461	2 21 24 12	4 133 121 031	38-2321251	11-3513536	-0007267128
1462	2 21 51 93	4 139 255 842	38-2456263	11-3540448	-0007266774
1463	2 22 19 74	4 145 390 653	38-2591275	11-3567360	-0007266420
1464	2 22 47 55	4 151 525 464	38-2726287	11-3594272	-0007266066
1465	2 23 15 36	4 157 660 275	38-2861299	11-3621184	-0007265712
1466	2 23 43 17	4 163 795 086	38-2996311	11-3648096	-0007265358
1467	2 24 10 98	4 169 929 897	38-3131323	11-3675008	-0007265004

TABLE XIV. (continued)

No.	Square	Cube	Square Root	Cube Root	Reciprocal
1467	3 15 20 80	8 187 114 563	38-9014860	11-3625785	-0006816688
1468	3 15 50 34	8 188 578 293	38-8144881	11-3651547	-0006811989
1469	3 15 79 61	8 170 044 709	38-9275358	11-3677847	-0006807352
1470	3 16 09 00	8 176 538 000	38-8405790	11-3703186	-0006802721
1471	3 16 38 41	8 168 010 111	38-3536178	11-3728914	-0006799097
1472	3 16 67 84	8 189 508 048	38-8665522	11-3754679	-0006793478
1473	3 16 97 39	8 169 010 817	38-3796821	11-3780438	-0006788666
1474	3 17 26 76	8 303 534 424	38-3927287	11-3806195	-0006784261
1475	3 17 56 35	8 309 046 875	38-4057277	11-3831806	-0006779661
1476	3 18 25 76	8 315 875 768	38-4187454	11-3857625	-0006775068
1477	3 18 55 90	8 393 118 838	38-4317577	11-3883382	-0006770481
1478	3 19 24 84	8 398 667 853	38-4447656	11-3909028	-0006765900
1479	3 19 54 41	8 335 336 289	38-4777691	11-3934712	-0006761325
1480	3 20 23 86	8 341 798 000	38-4877681	11-3960384	-0006756757
1481	3 20 53 61	8 248 387 641	38-4837627	11-3986045	-0006752194
1482	3 21 23 81	8 254 953 168	38-4967530	11-4011695	-0006747638
1483	3 21 53 66	8 261 545 587	38-5097890	11-4037382	-0006743088
1484	3 22 23 86	8 268 147 904	38-5227206	11-4063059	-0006738544
1485	3 22 53 36	8 374 769 195	38-5356977	11-4088574	-0006734007
1486	3 23 23 01	8 381 379 256	38-5486705	11-4114177	-0006729475
1487	3 23 52 61	8 268 008 808	38-5616389	11-4139769	-0006724950
1488	3 24 22 44	8 304 648 273	38-5746080	11-4165349	-0006720480
1489	3 24 52 01	8 301 298 169	38-5875627	11-4190918	-0006715917
1490	3 25 21 81	8 307 949 000	38-6005181	11-4216476	-0006711409
1491	3 25 51 61	8 314 613 771	38-6134691	11-4242022	-0006706908
1492	3 26 21 04	8 331 337 468	38-6264158	11-4267566	-0006702418
1493	3 26 50 36	8 337 970 157	38-6393592	11-4293079	-0006697924
1494	3 27 20 16	8 348 071 986	38-6781598	11-4318591	-0006693440
1495	3 27 50 35	8 341 833 876	38-6652299	11-4344092	-0006688963
1496	3 28 20 16	8 388 518 008	38-6781598	11-4369561	-0006684492
1497	3 28 50 36	8 384 790 473	38-6910843	11-4395059	-0006680027
1498	3 29 20 16	8 395 930 577	38-7040050	11-4420525	-0006675567
1499	3 29 50 36	8 386 354 499	38-7169214	11-4445980	-0006671114
1500	3 30 20 16	8 375 000 000	38-7298335	11-4471424	-0006666667
1501	3 30 50 36	8 381 764 501	38-7427412	11-4496857	-0006662220
1502	3 31 20 49	8 398 518 008	38-7556447	11-4522278	-0006657790
1503	3 31 50 36	8 395 930 577	38-7684489	11-4547688	-0006653360
1504	3 32 20 16	8 403 073 064	38-7814889	11-4573087	-0006648986
1505	3 32 50 36	8 408 863 625	38-7948294	11-4598474	-0006644518
1506	3 33 20 16	8 415 663 216	38-8072158	11-4623850	-0006640106
1507	3 33 50 36	8 432 470 848	38-8200978	11-4649215	-0006635700
1508	3 34 20 49	8 439 988 513	38-8329757	11-4674668	-0006631300
1509	3 34 50 36	8 436 115 238	38-8458491	11-4699911	-0006626895
1510	3 35 20 16	8 443 951 901	38-8587184	11-4725242	-0006622451
1511	3 35 50 36	8 449 795 831	38-8715834	11-4750562	-0006618134
1512	3 36 20 49	8 456 649 793	38-8844442	11-4775871	-0006613757
1513	3 36 50 36	8 463 513 697	38-8973006	11-4801169	-0006609386
1514	3 37 20 16	8 470 384 744	38-9101529	11-4826455	-0006605020
1515	3 37 50 36	8 477 265 875	38-9230009	11-4851781	-0006600660

No.	Square	Cube	Square Root	Cube Root	Reciprocal
1516	3 38 20 49	8 484 156 096	38-9358447	11-4876995	-0006596806
1517	3 38 50 36	8 491 055 413	38-9449684	11-4902249	-0006591958
1518	3 39 20 16	8 497 963 883	38-9615194	11-4927491	-0006587615
1519	3 39 50 36	8 504 881 359	38-9743505	11-4952722	-0006583278
1520	3 40 20 49	8 511 808 000	38-9871774	11-4977942	-0006578947
1521	3 40 50 36	8 518 748 761	38-9940000	11-5003151	-0006574622
1522	3 41 20 16	8 525 698 648	38-9912814	11-5028348	-0006570302
1523	3 41 50 36	8 532 648 627	38-9956326	11-5053535	-0006565988
1524	3 42 20 49	8 539 605 834	39-0084426	11-5078711	-0006561680
1525	3 42 50 36	8 546 578 125	39-0161483	11-5103876	-0006557377
1526	3 43 20 16	8 553 559 876	39-0240499	11-5129020	-0006553080
1527	3 43 50 36	8 560 550 188	39-0788473	11-5154173	-0006548788
1528	3 44 20 49	8 567 549 963	39-0869496	11-5179305	-0006544505
1529	3 44 50 36	8 574 558 889	39-0921296	11-5204425	-0006540222
1530	3 45 20 16	8 581 577 000	39-1152144	11-5229585	-0006535948
1531	3 45 50 36	8 588 604 301	39-1279851	11-5254684	-0006531679
1532	3 46 20 49	8 595 640 768	39-1407716	11-5279722	-0006527415
1533	3 46 50 36	8 602 686 487	39-1535439	11-5304739	-0006523157
1534	3 47 20 16	8 609 741 804	39-1663120	11-5329865	-0006518905
1535	3 47 50 36	8 616 805 875	39-1790760	11-5354920	-0006514658
1536	3 48 20 49	8 623 878 656	39-1918659	11-5379965	-0006510417
1537	3 48 50 36	8 630 961 153	39-2045915	11-5404998	-0006506181
1538	3 49 20 16	8 638 053 879	39-2173431	11-5430021	-0006501951
1539	3 49 50 36	8 645 153 819	39-2300995	11-5455033	-0006497726
1540	3 50 20 49	8 652 264 000	39-2428837	11-5480034	-0006493506
1541	3 50 50 36	8 659 383 431	39-2556728	11-5505025	-0006489293
1542	3 51 20 16	8 666 513 058	39-2685078	11-5530004	-0006485084
1543	3 51 50 36	8 673 650 007	39-2810387	11-5554978	-0006480881
1544	3 52 20 49	8 680 797 184	39-2937654	11-5579931	-0006476684
1545	3 52 50 36	8 687 953 635	39-3064980	11-5604878	-0006472492
1546	3 53 20 16	8 695 119 886	39-3192065	11-5629815	-0006468305
1547	3 53 50 36	8 702 294 893	39-3319208	11-5654740	-0006464124
1548	3 54 20 49	8 709 478 898	39-3446311	11-5679655	-0006459948
1549	3 54 50 36	8 716 672 149	39-3573773	11-5704519	-0006455778
1550	3 55 20 16	8 723 875 875	39-3700934	11-5729453	-0006451618
1551	3 55 50 36	8 731 087 151	39-3827373	11-5754386	-0006447453
1552	3 56 20 49	8 738 306 006	39-3954312	11-5779208	-0006443299
1553	3 56 50 36	8 745 539 877	39-4081210	11-5804069	-0006439150
1554	3 57 20 16	8 752 779 464	39-4208067	11-5828919	-0006435006
1555	3 57 50 36	8 760 038 875	39-4334888	11-5853759	-0006430868
1556	3 58 20 49	8 767 307 151	39-4461658	11-5878598	-0006426785
1557	3 58 50 36	8 774 585 693	39-4588933	11-5903407	-0006422608
1558	3 59 20 16	8 781 883 118	39-4715087	11-5928215	-0006418465
1559	3 59 50 36	8 789 119 879	39-4841740	11-5953018	-0006414368
1560	3 60 20 49	8 796 416 000	39-4968853	11-5977798	-0006410266
1561	3 60 50 36	8 803 731 431	39-5094925	11-6002576	-0006406160
1562	3 61 20 16	8 811 086 398	39-5221457	11-6027842	-0006402049
1563	3 61 50 36	8 818 364 547	39-5348748	11-6052097	-0006397953
1564	3 62 20 49	8 825 694 144	39-5474399	11-6076841	-0006393862

TABLE XLV. (continued).

No.	Square	Cube	Square Root	Cube Root	Reciprocal
1565	2 44 92 35	8 888 087 135	39-5600809	11-6101575	-00063889776
1566	2 45 23 56	8 840 389 496	39-5727179	11-6120299	-00063885696
1567	2 45 55 17	8 847 751 263	39-5853508	11-6151012	-00063881621
1568	2 46 00 38	8 855 128 432	39-5979797	11-6175715	-00063877551
1569	2 46 17 61	8 862 508 009	39-6106046	11-6200407	-00063873486
1570	2 46 40 00	8 869 898 000	39-6232255	11-6225088	-00063869427
1571	2 46 49 41	8 877 289 411	39-6358424	11-6249759	-00063865372
1572	2 47 01 34	8 884 701 248	39-6484552	11-6274407	-00063861325
1573	2 47 17 84	8 892 115 517	39-6610640	11-6299070	-00063857279
1574	2 47 34 78	8 899 547 924	39-6736688	11-6323210	-00063853240
1575	2 48 00 35	8 906 984 378	39-6862696	11-6348339	-00063849206
1576	2 48 37 76	8 914 430 875	39-6988665	11-6372857	-00063845176
1577	2 48 69 38	8 921 887 038	39-7114598	11-6397566	-00063841154
1578	2 49 00 84	8 929 335 553	39-7240481	11-6422161	-00063837136
1579	2 49 32 41	8 936 783 539	39-7366329	11-6446751	-00063833122
1580	2 49 64 00	8 944 231 000	39-7492183	11-6471829	-00063829114
1581	2 49 56 61	8 951 685 941	39-7617907	11-6495895	-00063825111
1582	2 50 27 34	8 959 139 368	39-7743636	11-6520452	-00063821118
1583	2 50 58 98	8 966 593 387	39-7869325	11-6544998	-00063817119
1584	2 51 30 56	8 974 044 704	39-7994975	11-6569534	-00063813131
1585	2 51 52 38	8 981 496 625	39-8120585	11-6594059	-00063809148
1586	2 52 23 96	8 988 948 086	39-8246155	11-6618574	-00063805170
1587	2 52 55 69	8 996 399 008	39-8371686	11-6643079	-00063801197
1588	2 53 17 44	8 004 850 473	39-8497177	11-6667574	-00063797229
1589	2 53 49 31	8 012 301 469	39-8622628	11-6692058	-00063793266
1590	2 53 81 00	8 019 752 000	39-8748040	11-6716532	-00063789308
1591	2 53 12 81	8 027 203 071	39-8873418	11-6740996	-00063785355
1592	2 53 44 64	8 034 654 088	39-8998747	11-6765449	-00063781407
1593	2 53 76 49	8 042 105 157	39-9124041	11-6789892	-00063777464
1594	2 54 08 36	8 049 556 285	39-9249255	11-6814325	-00063773526
1595	2 54 40 25	8 057 007 375	39-9374511	11-6838748	-00063769592
1596	2 54 72 16	8 064 458 428	39-9499587	11-6863161	-00063765664
1597	2 55 04 04	8 071 909 478	39-9624824	11-6887563	-00063761741
1598	2 55 35 04	8 079 360 173	39-9749922	11-6911955	-00063757822
1599	2 55 66 01	8 086 811 799	39-9874980	11-6936397	-00063753909
1600	2 55 97 00	8 094 263 000	40-0000000	11-6960709	-00063750000
1601	2 56 28 01	8 101 714 801	40-0124980	11-6985071	-00063746096
1602	2 56 59 04	8 109 166 808	40-0249922	11-7009422	-00063742197
1603	2 56 50 09	8 116 618 307	40-0374824	11-7033764	-00063738303
1604	2 57 20 16	8 124 070 824	40-0499688	11-7058095	-00063734414
1605	2 57 50 35	8 131 523 195	40-0624512	11-7082417	-00063730530
1606	2 58 20 54	8 138 975 616	40-0749298	11-7106738	-00063726650
1607	2 58 51 13	8 146 428 016	40-0874045	11-7131029	-00063722775
1608	2 58 56 64	8 153 880 548	40-0998753	11-7155320	-00063718905
1609	2 59 26 81	8 161 333 539	40-1123423	11-7179601	-00063715040
1610	2 59 57 00	8 168 786 000	40-1248053	11-7203872	-00063711180
1611	2 59 59 31	8 176 238 926	40-1372645	11-7228133	-00063707325
1612	2 59 55 44	8 183 691 928	40-1497198	11-7252384	-00063703474
1613	2 59 17 60	8 191 145 897	40-1621713	11-7276625	-00063700028

No.	Square	Cube	Square Root	Cube Root	Reciprocal
1614	2 60 49 36	4 304 488 544	40-1746188	11-7300855	-0006195787
1615	2 60 88 25	4 312 938 875	40-1870626	11-7325076	-0006191950
1616	2 61 14 56	4 320 389 198	40-1995025	11-7349286	-0006188119
1617	2 61 40 89	4 327 839 513	40-2119385	11-7373487	-0006184292
1618	2 61 79 34	4 335 289 828	40-2243707	11-7397677	-0006180470
1619	2 62 11 61	4 342 739 869	40-2367990	11-7421858	-0006176652
1620	2 62 44 00	4 350 189 900	40-2492286	11-7446029	-0006172840
1621	2 63 06 84	4 357 639 931	40-2616643	11-7470190	-0006169081
1622	2 63 49 36	4 365 089 962	40-2741101	11-7494341	-0006165228
1623	2 63 41 29	4 372 539 993	40-2865472	11-7518482	-0006161428
1624	2 63 73 76	4 380 989 964	40-2989884	11-7542613	-0006157685
1625	2 64 06 35	4 389 439 935	40-3114296	11-7566734	-0006153946
1626	2 64 38 84	4 396 889 906	40-3238903	11-7590846	-0006150207
1627	2 64 71 33	4 404 339 877	40-3363510	11-7614947	-0006146468
1628	2 65 03 84	4 411 789 848	40-3488117	11-7639039	-0006142729
1629	2 65 36 35	4 419 239 819	40-3612724	11-7663121	-0006139035
1630	2 65 68 86	4 426 689 790	40-3737331	11-7687193	-0006135296
1631	2 66 01 37	4 434 139 761	40-3861938	11-7711255	-0006131508
1632	2 66 33 88	4 441 589 732	40-3986545	11-7735306	-0006127745
1633	2 66 66 39	4 449 039 703	40-4111152	11-7759357	-0006123982
1634	2 66 98 90	4 456 489 674	40-4235759	11-7783408	-0006120219
1635	2 67 31 41	4 463 939 645	40-4360366	11-7807459	-0006116456
1636	2 67 63 92	4 471 389 616	40-4484973	11-7831510	-0006112693
1637	2 67 96 43	4 478 839 587	40-4609580	11-7855561	-0006108930
1638	2 68 28 94	4 486 289 558	40-4734187	11-7879612	-0006105167
1639	2 68 61 45	4 493 739 529	40-4858794	11-7903663	-0006101404
1640	2 68 93 96	4 501 189 500	40-4983401	11-7927714	-0006097641
1641	2 69 26 47	4 508 639 471	40-5107908	11-7951765	-0006093878
1642	2 69 58 98	4 516 089 442	40-5232515	11-7975816	-0006090115
1643	2 70 31 49	4 523 539 413	40-5357122	11-7999867	-0006086352
1644	2 70 63 99	4 530 989 384	40-5481729	11-8023918	-0006082589
1645	2 70 96 50	4 538 439 355	40-5606336	11-8047969	-0006078826
1646	2 71 29 01	4 545 889 326	40-5730943	11-8072020	-0006075063
1647	2 71 61 52	4 553 339 297	40-5855550	11-8096071	-0006071300
1648	2 71 94 03	4 560 789 268	40-5980157	11-8119622	-0006067537
1649	2 72 26 54	4 568 239 239	40-6104764	11-8143673	-0006063774
1650	2 72 59 05	4 575 689 210	40-6229371	11-8167724	-0006059911
1651	2 73 31 56	4 583 139 181	40-6353978	11-8191775	-0006056148
1652	2 73 64 07	4 590 589 152	40-6478585	11-8215826	-0006052385
1653	2 73 96 58	4 598 039 123	40-6603192	11-8239877	-0006048622
1654	2 74 29 09	4 605 489 094	40-6727799	11-8263928	-0006044859
1655	2 74 61 60	4 612 939 065	40-6851806	11-8287979	-0006041096
1656	2 74 94 11	4 620 389 036	40-6975813	11-8312030	-0006037333
1657	2 75 26 62	4 627 839 007	40-7099820	11-8336081	-0006033570
1658	2 75 59 13	4 635 289 000	40-7223827	11-8360132	-0006029807
1659	2 75 91 64	4 642 739 000	40-7347834	11-8384183	-0006026044
1660	2 76 24 15	4 650 189 000	40-7471841	11-8408234	-0006022281
1661	2 76 56 66	4 657 639 000	40-7595848	11-8432285	-0006018518
1662	2 77 29 17	4 665 089 000	40-7719855	11-8456336	-0006014755

TABLE XLV. (continued).

No.	Square	Cube	Square Root	Cube Root	Reciprocal
1663	2 76 55 63	4 599 141 247	40-7798970	11-8176100	-0006018229
1664	2 76 56 36	4 607 442 934	40-7921561	11-8199848	-0006009615
1665	2 76 57 25	4 615 752 295	40-8044163	11-8223576	-0006006006
1666	2 77 55 56	4 634 076 296	40-8166633	11-8247299	-0006007201
1667	2 77 56 59	4 632 407 968	40-8289113	11-8271014	-0005999800
1668	2 78 52 24	4 640 749 632	40-8411557	11-8294719	-0005995204
1669	2 78 53 61	4 649 101 309	40-8538964	11-8618414	-0005991612
1670	2 78 55 00	4 657 465 000	40-8656335	11-8642100	-0005988074
1671	2 79 29 41	4 665 834 711	40-8778689	11-8665776	-0005984440
1672	2 79 30 54	4 674 216 443	40-8900966	11-8689443	-0005980861
1673	2 79 32 39	4 683 608 337	40-9029227	11-8713100	-0005977286
1674	2 80 23 76	4 691 010 994	40-9145451	11-8736748	-0005973716
1675	2 80 25 25	4 699 431 875	40-9267698	11-8760387	-0005970149
1676	2 80 26 76	4 707 848 778	40-9389790	11-8784016	-0005966587
1677	2 81 23 20	4 716 275 738	40-9511905	11-8807636	-0005963029
1678	2 81 24 54	4 724 717 758	40-9633968	11-8831246	-0005959476
1679	2 81 26 31	4 733 169 839	40-9756025	11-8854847	-0005955926
1680	2 82 34 00	4 741 633 000	40-9878031	11-8878439	-0005952381
1681	2 82 35 61	4 750 104 241	41-0000000	11-8902022	-0005948840
1682	2 82 37 24	4 758 596 568	41-0121933	11-8925595	-0005945303
1683	2 83 24 89	4 767 078 967	41-0248880	11-8949159	-0005941771
1684	2 83 26 56	4 775 591 504	41-0376591	11-8972718	-0005938242
1685	2 83 28 25	4 784 094 136	41-0487515	11-8996258	-0005934718
1686	2 84 26 96	4 792 616 856	41-0609303	11-9019793	-0005931198
1687	2 84 28 69	4 801 149 708	41-0731055	11-9043319	-0005927682
1688	2 84 30 44	4 809 692 673	41-0852772	11-9066836	-0005924171
1689	2 85 37 21	4 818 245 769	41-0974462	11-9090344	-0005920653
1690	2 85 39 01	4 826 809 000	41-1096096	11-9113843	-0005917160
1691	2 85 40 84	4 835 393 871	41-1217704	11-9137332	-0005913661
1692	2 85 42 64	4 843 965 886	41-1339276	11-9160812	-0005910165
1693	2 86 39 49	4 852 559 587	41-1460812	11-9184283	-0005906675
1694	2 86 41 36	4 861 163 834	41-1582313	11-9207744	-0005903188
1695	2 87 30 26	4 869 777 875	41-1703777	11-9231196	-0005899705
1696	2 87 32 16	4 878 401 536	41-1825206	11-9254639	-0005896226
1697	2 87 34 00	4 887 035 978	41-1946599	11-9278078	-0005892752
1698	2 88 33 04	4 895 680 393	41-2067956	11-9301497	-0005889282
1699	2 88 35 01	4 904 335 099	41-2189277	11-9324913	-0005885815
1700	2 89 30 00	4 913 000 000	41-2310563	11-9348319	-0005882353
1701	2 89 32 04	4 921 675 101	41-2431812	11-9371716	-0005878896
1702	2 89 34 00	4 930 360 408	41-2553037	11-9395104	-0005875441
1703	2 90 33 16	4 939 055 937	41-2674205	11-9418482	-0005871991
1704	2 90 35 16	4 947 761 664	41-2795849	11-9441852	-0005868545
1705	2 90 37 25	4 956 477 635	41-2916456	11-9465218	-0005865108
1706	2 91 34 86	4 965 203 816	41-3037529	11-9488564	-0005861666
1707	2 91 36 49	4 973 940 248	41-3158565	11-9511906	-0005858231
1708	2 91 39 64	4 982 686 913	41-3279566	11-9535239	-0005854801
1709	2 92 43 81	4 991 443 893	41-3400532	11-9558563	-0005851375
1710	2 92 47 00	5 000 211 000	41-3521463	11-9581878	-0005847953
1711	2 92 50 21	5 008 998 431	41-3642358	11-9605184	-0005844585

No.	Square	Cube	Square Root	Cube Root	Reciprocal
1712	2 93 05 44	5 017 776 138	41-3763217	11-9628481	-0005841121
1713	2 93 08 69	5 026 574 027	41-3884042	11-9651768	-0005837719
1714	2 93 11 96	5 035 862 844	41-4004831	11-9675047	-0005834306
1715	2 94 07 35	5 044 900 875	41-4125585	11-9698317	-0005830904
1716	2 94 10 56	5 053 920 698	41-4246304	11-9721577	-0005827506
1717	2 94 13 80	5 063 068 618	41-4366987	11-9744629	-0005824112
1718	2 94 16 24	5 072 577 593	41-4487636	11-9768071	-0005820722
1719	2 95 09 41	5 077 577 593	41-4608249	11-9791304	-0005817386
1720	2 95 12 64	5 086 448 000	41-4728827	11-9814528	-0005813958
1721	2 96 15 41	5 095 398 361	41-4849370	11-9837744	-0005810575
1722	2 96 18 64	5 104 330 048	41-4969878	11-9860950	-0005807201
1723	2 97 01 37	5 113 330 067	41-5090351	11-9884148	-0005803831
1724	2 97 04 60	5 122 381 424	41-5210790	11-9907336	-0005800464
1725	2 97 07 85	5 131 868 135	41-5331193	11-9930516	-0005797101
1726	2 97 11 10	5 141 866 176	41-5451561	11-9953686	-0005793748
1727	2 97 14 33	5 151 897 638	41-5571895	11-9976848	-0005790388
1728	2 98 07 84	5 161 780 863	41-5692191	12-0000000	-0005787037
1729	2 98 11 07	5 170 743 489	41-5812457	12-0023144	-0005783690
1730	2 99 04 30	5 179 717 000	41-5932686	12-0046278	-0005780347
1731	2 99 07 53	5 188 700 821	41-6052881	12-0069404	-0005777002
1732	2 99 10 76	5 197 696 163	41-6173041	12-0092521	-0005773657
1733	2 99 14 00	5 206 699 687	41-6293166	12-0115629	-0005770304
1734	2 99 17 23	5 215 714 004	41-6413256	12-0138728	-0005766951
1735	2 99 20 46	5 224 740 875	41-6533312	12-0161818	-0005763698
1736	2 99 23 69	5 233 776 265	41-6653333	12-0184900	-0005760439
1737	2 99 26 92	5 242 822 558	41-6773319	12-0207978	-0005757182
1738	2 99 30 15	5 251 869 873	41-6893271	12-0231037	-0005753924
1739	2 99 33 38	5 260 927 273	41-7013189	12-0254092	-0005750671
1740	2 99 36 61	5 269 994 000	41-7133072	12-0277188	-0005747416
1741	2 99 39 84	5 279 113 081	41-7252921	12-0300175	-0005744161
1742	2 99 43 07	5 288 180 488	41-7372785	12-0323204	-0005740908
1743	2 99 46 30	5 297 247 904	41-7492515	12-0346223	-0005737655
1744	2 99 49 53	5 306 315 407	41-7612260	12-0369283	-0005734402
1745	2 99 52 76	5 315 382 824	41-7731971	12-0392325	-0005731149
1746	2 99 56 00	5 324 450 241	41-7851648	12-0415329	-0005727896
1747	2 99 59 23	5 333 517 658	41-7971201	12-0438313	-0005724643
1748	2 99 62 46	5 342 585 075	41-8090869	12-0461318	-0005721390
1749	2 99 65 69	5 351 652 492	41-8210473	12-0484316	-0005718137
1750	2 99 68 92	5 360 719 909	41-8330018	12-0507314	-0005714884
1751	2 99 72 15	5 369 787 326	41-8449510	12-0530306	-0005711631
1752	2 99 75 38	5 378 854 743	41-8569002	12-0553303	-0005708378
1753	2 99 78 61	5 387 922 160	41-8688498	12-0576300	-0005705125
1754	2 99 81 84	5 396 989 577	41-8807982	12-0599297	-0005701872
1755	2 99 85 07	5 406 056 994	41-8927467	12-0622294	-0005698619
1756	2 99 88 30	5 415 124 411	41-9046951	12-0645291	-0005695366
1757	2 99 91 53	5 424 191 828	41-9166435	12-0668288	-0005692113
1758	2 99 94 76	5 433 259 245	41-9285919	12-0691285	-0005688860
1759	2 99 98 00	5 442 326 662	41-9405403	12-0714282	-0005685607
1760	2 99 101 23	5 451 394 079	41-9524887	12-0737279	-0005682354

TABLE XLV. (continued).

No.	Square	Cube	Square Root	Cube Root	Reciprocal
1761	8 10 11 91	5 461 074 061	41-9642705	12-0759077	-0005678592
1762	8 10 46 44	5 470 898 728	41-9761837	12-0781930	-0005675869
1763	8 10 81 69	5 479 701 947	41-9880935	12-0804775	-0005672150
1764	8 11 16 98	5 489 031 744	42-0000000	12-0827612	-0005668934
1765	8 11 52 25	5 498 879 135	42-0119031	12-0850439	-0005665722
1766	8 11 87 53	5 508 725 096	42-0238028	12-0873258	-0005662514
1767	8 12 33 89	5 517 084 608	42-0356991	12-0896069	-0005659310
1768	8 12 33 89	5 526 456 593	42-0475921	12-0918870	-0005656109
1769	8 12 98 61	5 535 839 000	42-0594817	12-0941664	-0005652911
1770	8 12 93 00	5 545 939 000	42-0713679	12-0964449	-0005649718
1771	8 13 64 41	5 554 637 011	42-0832508	12-0987226	-0005646527
1772	8 13 98 84	5 563 615 648	42-0951304	12-1009993	-0005643341
1773	8 13 85 80	5 573 476 917	42-1070065	12-1032753	-0005640158
1774	8 14 70 76	5 583 913 894	42-1188794	12-1055503	-0005636979
1775	8 15 06 25	5 593 859 875	42-1307488	12-1078245	-0005633803
1776	8 15 41 78	5 603 813 878	42-1426150	12-1100979	-0005630631
1777	8 15 77 29	5 613 294 458	42-1544778	12-1123704	-0005627462
1778	8 16 13 84	5 623 793 953	42-1663373	12-1146420	-0005624297
1779	8 16 48 41	5 633 953 000	42-1781931	12-1169128	-0005621185
1780	8 16 84 00	5 643 753 000	42-1900462	12-1191827	-0005617978
1781	8 17 19 61	5 653 263 541	42-2018957	12-1214518	-0005614823
1782	8 17 55 24	5 663 788 788	42-2137418	12-1237200	-0005611672
1783	8 17 90 80	5 673 953 000	42-2256346	12-1259874	-0005608525
1784	8 18 26 56	5 683 858 904	42-2374242	12-1282539	-0005605381
1785	8 18 63 25	5 693 859 000	42-2492608	12-1305197	-0005602241
1786	8 18 97 95	5 703 859 000	42-2610982	12-1327845	-0005599104
1787	8 19 33 69	5 713 859 000	42-2729227	12-1350485	-0005595971
1788	8 19 63 44	5 723 859 000	42-2847490	12-1373117	-0005592841
1789	8 20 00 31	5 733 859 000	42-2965719	12-1395740	-0005589715
1790	8 20 30 00	5 743 859 000	42-3083916	12-1418355	-0005586592
1791	8 20 76 81	5 753 859 000	42-3202079	12-1440961	-0005583473
1792	8 21 13 64	5 763 859 000	42-3320210	12-1463559	-0005580357
1793	8 21 43 49	5 773 859 000	42-3438307	12-1486148	-0005577245
1794	8 21 84 86	5 783 859 000	42-3556371	12-1508729	-0005574136
1795	8 22 20 35	5 793 859 000	42-3674408	12-1531302	-0005571031
1796	8 22 56 19	5 803 859 000	42-3792402	12-1553866	-0005567929
1797	8 23 03 09	5 813 859 000	42-3910368	12-1576432	-0005564830
1798	8 23 28 04	5 823 859 000	42-4028301	12-1598970	-0005561735
1799	8 23 64 01	5 833 859 000	42-4146201	12-1621509	-0005558644
1800	8 24 00 00	5 843 859 000	42-4264069	12-1644040	-0005555556
1801	8 24 36 01	5 853 859 000	42-4381903	12-1666562	-0005552471
1802	8 24 72 04	5 863 859 000	42-4499705	12-1689076	-0005549380
1803	8 25 08 09	5 873 859 000	42-4617475	12-1711582	-0005546312
1804	8 25 44 18	5 883 859 000	42-4735212	12-1734079	-0005543237
1805	8 25 80 25	5 893 859 000	42-4852916	12-1756569	-0005540166
1806	8 26 16 36	5 903 859 000	42-4970387	12-1779050	-0005537099
1807	8 26 52 49	5 913 859 000	42-5087826	12-1801522	-0005534034
1808	8 26 88 64	5 923 859 000	42-5205833	12-1823987	-0005530973
1809	8 27 24 81	5 933 859 000	42-5323406	12-1846443	-0005527916

No.	Square	Cube	Square Root	Cube Root	Reciprocal
1810	8 27 61 00	5 943 859 000	42-5440948	12-1868891	-0005524862
1811	8 27 97 31	5 953 859 000	42-5558456	12-1891331	-0005521811
1812	8 28 33 44	5 963 859 000	42-5675938	12-1913762	-0005518764
1813	8 28 69 69	5 973 859 000	42-5793377	12-1936185	-0005515720
1814	8 29 06 96	5 983 859 000	42-5910789	12-1958609	-0005512679
1815	8 29 43 25	5 993 859 000	42-6028168	12-1981006	-0005509642
1816	8 29 79 56	6 003 859 000	42-6145515	12-2003404	-0005506608
1817	8 30 15 88	6 013 859 000	42-6262829	12-2025794	-0005503577
1818	8 30 52 21	6 023 859 000	42-6380122	12-2048176	-0005500550
1819	8 30 88 56	6 033 859 000	42-6497362	12-2070549	-0005497526
1820	8 31 24 61	6 043 859 000	42-6614580	12-2092915	-0005494505
1821	8 31 60 41	6 053 859 000	42-6731766	12-2115272	-0005491488
1822	8 31 96 84	6 063 859 000	42-6848919	12-2137621	-0005488474
1823	8 32 33 29	6 073 859 000	42-6966040	12-2159962	-0005485464
1824	8 32 69 76	6 083 859 000	42-7083180	12-2182295	-0005482456
1825	8 33 06 25	6 093 859 000	42-7200387	12-2204620	-0005479452
1826	8 33 42 76	6 103 859 000	42-7317512	12-2226986	-0005476451
1827	8 33 79 30	6 113 859 000	42-7434206	12-2249244	-0005473454
1828	8 34 15 84	6 123 859 000	42-7551167	12-2271544	-0005470460
1829	8 34 52 41	6 133 859 000	42-7668095	12-2293866	-0005467469
1830	8 35 29 00	6 143 859 000	42-7784992	12-2316120	-0005464481
1831	8 35 65 61	6 153 859 000	42-7901858	12-2338396	-0005461496
1832	8 36 02 24	6 163 859 000	42-8018691	12-2360668	-0005458515
1833	8 36 38 89	6 173 859 000	42-8135492	12-2382923	-0005455537
1834	8 36 75 56	6 183 859 000	42-8252262	12-2405174	-0005452563
1835	8 37 12 25	6 193 859 000	42-8369099	12-2427418	-0005449591
1836	8 37 48 96	6 203 859 000	42-8485706	12-2449653	-0005446628
1837	8 37 85 69	6 213 859 000	42-8602280	12-2471880	-0005443668
1838	8 38 22 44	6 223 859 000	42-8718922	12-2494099	-0005440696
1839	8 38 59 21	6 233 859 000	42-8835633	12-2516310	-0005437738
1840	8 39 36 00	6 243 859 000	42-8952312	12-2538513	-0005434783
1841	8 39 72 81	6 253 859 000	42-9068979	12-2560708	-0005431831
1842	8 40 09 64	6 263 859 000	42-9185625	12-2582895	-0005428882
1843	8 40 46 49	6 273 859 000	42-9302251	12-2605074	-0005425936
1844	8 40 83 26	6 283 859 000	42-9418911	12-2627245	-0005422993
1845	8 41 20 05	6 293 859 000	42-9535532	12-2649408	-0005420054
1846	8 41 56 86	6 303 859 000	42-9652121	12-2671563	-0005417118
1847	8 42 33 69	6 313 859 000	42-9768739	12-2693710	-0005414185
1848	8 43 10 54	6 323 859 000	42-9885305	12-2715849	-0005411255
1849	8 43 47 41	6 333 859 000	42-1001900	12-2737980	-0005408329
1850	8 43 84 30	6 343 859 000	42-1017951	12-2760108	-0005405405
1851	8 44 21 21	6 353 859 000	42-1033996	12-2782218	-0005402485
1852	8 44 58 14	6 363 859 000	42-1050035	12-2804325	-0005399568
1853	8 45 35 09	6 373 859 000	42-1066069	12-2826424	-0005396654
1854	8 45 72 06	6 383 859 000	42-1082098	12-2848515	-0005393743
1855	8 46 09 05	6 393 859 000	42-1098122	12-2870598	-0005390836
1856	8 46 46 06	6 403 859 000	42-1114141	12-2892673	-0005387931
1857	8 46 83 09	6 413 859 000	42-1130155	12-2914740	-0005385030
1858	8 47 20 14	6 423 859 000	42-1146164	12-2936800	-0005382131

TABLE XLV. (continued).

No.	Square	Onbe	Square Root	Cube Root	Reciprocal
1869	8 45 58 81	6 494 493 779	43-1161228	12-2953851	-0005379236
1870	8 45 58 81	6 494 493 779	43-1277173	12-2980895	-0005376344
1881	8 46 38 21	6 445 940 981	43-1393992	12-3002930	-0005373455
1882	8 46 38 21	6 455 695 988	43-1508980	12-3024958	-0005370569
1883	8 46 38 21	6 465 695 988	43-1624937	12-3046978	-0005367687
1884	8 47 07 69	6 476 040 644	43-1740663	12-3068990	-0005364807
1885	8 47 07 69	6 486 040 644	43-1856458	12-3090994	-0005361930
1886	8 47 07 69	6 496 839 695	43-1972221	12-3112991	-0005359057
1887	8 47 07 69	6 497 839 695	43-2087954	12-3134979	-0005356186
1888	8 48 04 24	6 518 944 093	43-2203656	12-3156959	-0005353319
1889	8 48 04 24	6 538 717 909	43-2319326	12-3178932	-0005350455
1890	8 49 01 61	6 559 303 000	43-2434966	12-3200897	-0005347594
1891	8 49 01 61	6 549 809 811	43-2550575	12-3222854	-0005344735
1892	8 50 06 41	6 569 306 849	43-2666153	12-3244803	-0005341880
1893	8 50 06 41	6 579 795 617	43-2781700	12-3266744	-0005339028
1894	8 51 18 76	6 581 955 694	43-2897216	12-3288678	-0005336179
1895	8 51 18 76	6 591 798 875	43-3012702	12-3310604	-0005333333
1896	8 51 18 76	6 601 849 876	43-3128157	12-3332522	-0005330490
1897	8 52 01 29	6 613 913 193	43-3243580	12-3354432	-0005327651
1898	8 52 01 29	6 623 498 193	43-3358973	12-3376334	-0005324814
1899	8 53 06 41	6 634 074 489	43-3474336	12-3398229	-0005321980
1900	8 53 06 41	6 644 672 000	43-3589688	12-3420116	-0005319149
1901	8 53 06 41	6 655 360 841	43-3704969	12-3441993	-0005316321
1902	8 54 04 56	6 665 900 987	43-3820289	12-3463866	-0005313496
1903	8 54 04 56	6 676 533 897	43-3935479	12-3485730	-0005310674
1904	8 54 04 56	6 687 175 104	43-4050684	12-3507586	-0005307856
1905	8 55 03 25	6 697 839 135	43-4165867	12-3529434	-0005305040
1906	8 55 03 25	6 708 494 456	43-4281015	12-3551274	-0005302227
1907	8 56 07 69	6 719 171 108	43-4396132	12-3573107	-0005299417
1908	8 56 07 69	6 729 859 073	43-4511220	12-3594932	-0005296610
1909	8 56 07 69	6 740 558 869	43-4626276	12-3616749	-0005293806
1910	8 57 01 31	6 751 269 000	43-4741302	12-3638559	-0005291005
1911	8 57 01 31	6 761 990 871	43-4856298	12-3660361	-0005288207
1912	8 57 01 31	6 772 724 988	43-4971263	12-3682155	-0005285412
1913	8 57 01 31	6 783 468 934	43-5086198	12-3703931	-0005282620
1914	8 57 01 31	6 794 213 984	43-5201103	12-3725711	-0005279831
1915	8 58 01 35	6 804 969 875	43-5315977	12-3747492	-0005277045
1916	8 58 01 35	6 815 721 156	43-5430821	12-3769255	-0005274262
1917	8 58 01 35	6 826 478 934	43-5545635	12-3791011	-0005271481
1918	8 59 06 09	6 837 237 958	43-5660404	12-3812759	-0005268704
1919	8 59 06 09	6 847 999 879	43-5775171	12-3834500	-0005265928
1920	8 60 03 01	6 858 765 000	43-5889894	12-3856238	-0005263158
1921	8 61 03 01	6 869 530 701	43-6004697	12-3877959	-0005260389
1922	8 61 03 01	6 880 296 908	43-6119529	12-3899676	-0005257624
1923	8 62 04 09	6 891 064 837	43-6234382	12-3921386	-0005254861
1924	8 63 03 16	6 901 833 161	43-6349186	12-3943098	-0005252101
1925	8 63 03 16	6 912 602 935	43-6463987	12-3964784	-0005249344
1926	8 63 03 16	6 923 373 161	43-6578759	12-3986471	-0005246590
1927	8 63 03 16	6 934 144 416	43-6693511	12-4008151	-0005243838
1928	8 63 03 16	6 944 915 671	43-6808263	12-4029831	-0005241086
1929	8 63 03 16	6 955 686 926	43-6923015	12-4051511	-0005238334
1930	8 64 00 41	6 966 458 181	43-7037767	12-4073191	-0005235582
1931	8 64 00 41	6 977 229 436	43-7152519	12-4094871	-0005232830
1932	8 64 00 41	6 987 999 691	43-7267271	12-4116551	-0005230078
1933	8 64 00 41	6 998 769 946	43-7382023	12-4138231	-0005227326
1934	8 64 00 41	7 009 539 201	43-7496775	12-4159911	-0005224574
1935	8 64 00 41	7 020 309 456	43-7611527	12-4181591	-0005221822
1936	8 64 00 41	7 031 079 711	43-7726279	12-4203271	-0005219070
1937	8 64 00 41	7 041 849 966	43-7841031	12-4224951	-0005216318
1938	8 64 00 41	7 052 619 221	43-7955783	12-4246631	-0005213566
1939	8 64 00 41	7 063 389 476	43-8070535	12-4268311	-0005210814
1940	8 64 00 41	7 074 159 731	43-8185287	12-4289991	-0005208062
1941	8 64 00 41	7 084 929 986	43-8300039	12-4311671	-0005205310
1942	8 64 00 41	7 095 699 241	43-8414791	12-4333351	-0005202558
1943	8 64 00 41	7 106 469 496	43-8529543	12-4355031	-0005200806
1944	8 64 00 41	7 117 239 751	43-8644295	12-4376711	-0005198054
1945	8 64 00 41	7 128 009 506	43-8759047	12-4398391	-0005195302
1946	8 64 00 41	7 138 779 761	43-8873799	12-4419971	-0005192550
1947	8 64 00 41	7 149 549 516	43-8988551	12-4441551	-0005189798
1948	8 64 00 41	7 160 319 771	43-9103303	12-4463131	-0005187046
1949	8 64 00 41	7 171 089 526	43-9218055	12-4484711	-0005184294
1950	8 64 00 41	7 181 859 781	43-9332807	12-4506291	-0005181542
1951	8 64 00 41	7 192 629 536	43-9447559	12-4527871	-0005178790
1952	8 64 00 41	7 203 399 791	43-9562311	12-4549451	-0005176038
1953	8 64 00 41	7 214 169 546	43-9677063	12-4571031	-0005173286
1954	8 64 00 41	7 224 939 801	43-9791815	12-4592611	-0005170534
1955	8 64 00 41	7 235 709 556	43-9906567	12-4614191	-0005167782
1956	8 64 00 41	7 246 479 811	43-1001319	12-4635771	-0005165030
1957	8 64 00 41	7 257 249 566	43-1016071	12-4657351	-0005162278
1958	8 64 00 41	7 268 019 821	43-1030823	12-4678931	-0005159526
1959	8 64 00 41	7 278 789 576	43-1045575	12-4700511	-0005156774
1960	8 64 00 41	7 289 559 831	43-1060327	12-4722091	-0005154022
1961	8 64 00 41	7 299 329 586	43-1075079	12-4743671	-0005151270
1962	8 64 00 41	7 309 099 841	43-1089831	12-4765251	-0005148518
1963	8 64 00 41	7 319 869 596	43-1104583	12-4786831	-0005145766
1964	8 64 00 41	7 329 639 351	43-1119335	12-4808411	-0005143014
1965	8 64 00 41	7 339 409 606	43-1134087	12-4829991	-0005140262
1966	8 64 00 41	7 349 179 861	43-1148839	12-4851571	-0005137510
1967	8 64 00 41	7 359 949 616	43-1163591	12-4873151	-0005134758
1968	8 64 00 41	7 369 719 871	43-1178343	12-4894731	-0005132006
1969	8 64 00 41	7 379 489 626	43-1193095	12-4916311	-0005129254
1970	8 64 00 41	7 389 259 381	43-1207847	12-4937891	-0005126502
1971	8 64 00 41	7 399 029 636	43-1222599	12-4959471	-0005123750
1972	8 64 00 41	7 408 799 391	43-1237351	12-4981051	-0005121008
1973	8 64 00 41	7 418 569 646	43-1252103	12-5002631	-0005118256
1974	8 64 00 41	7 428 339 901	43-1266855	12-5024211	-0005115504
1975	8 64 00 41	7 438 109 656	43-1281607	12-5045791	-0005112752
1976	8 64 00 41	7 447 879 911	43-1296359	12-5067371	-0005110000
1977	8 64 00 41	7 457 649 666	43-1311111	12-5088951	-0005107248
1978	8 64 00 41	7 467 419 921	43-1325863	12-5110531	-0005104496
1979	8 64 00 41	7 477 189 676	43-1340615	12-5132111	-0005101744
1980	8 64 00 41	7 486 959 931	43-1355367	12-5153691	-0005100000
1981	8 64 00 41	7 496 729 686	43-1370119	12-5175271	-0005097248
1982	8 64 00 41	7 506 499 441	43-1384871	12-5196851	-0005094496
1983	8 64 00 41	7 516 269 196	43-1399623	12-5218431	-0005091744
1984	8 64 00 41	7 526 039 451	43-1414375	12-5239951	-0005088992
1985	8 64 00 41	7 535 809 706	43-1429127	12-5261531	-0005086240
1986	8 64 00 41	7 545 579 461	43-1443879	12-5283111	-0005083488
1987	8 64 00 41	7 555 349 716	43-1458631	12-5304691	-0005080736
1988	8 64 00 41	7 565 119 471	43-1473383	12-5326271	-0005077984
1989	8 64 00 41	7 574 889 726	43-1488135	12-5347851	-0005075232
1990	8 64 00 41	7 584 659 481	43-1502887	12-5369431	-0005072480
1991	8 64 00 41	7 594 429 236	43-1517639	12-5390951	-0005069728
1992	8 64 00 41	7 604 199 491	43-1532391	12-5412531	-0005066976
1993	8 64 00 41	7 613 969 746	43-1547143	12-5434111	-0005064224
1994	8 64 00 41	7 623 739 501	43-1561895	12-5455691	-0005061472
1995	8 64 00 41	7 633 509 756	43-1576647	12-5477271	-0005058720
1996	8 64 00 41	7 643 279 511	43-1591399	12-5498851	-0005055968
1997	8 64 00 41	7 653 049 766	43-1606151	12-5520431	-0005053216
1998	8 64 00 41	7 662 819 521	43-1620903	12-5542011	-0005050464
1999	8 64 00 41	7 672 589 776	43-1635655	12-5563591	-0005047712
2000	8 64 00 41	7 682 359 531	43-1650407	12-5585171	-0005044960
2001	8 64 00 41	7 692 129 786	43-1665159	12-5606751	-0005042208
2002	8 64 00 41	7 701 899 541	43-1679911	12-5628331	-0005039456
2003	8 64 00 41	7 711 669 796	43-1694663	12-5649911	-0005036704
2004	8 64 00 41	7 721 439 551	43-1709415	12-5671491	-0005033952
2005	8 64 00 41	7 731 209 806	43-1724167	12-5693071	-0005031200
2006	8 64 00 41	7 740 979 561	43-1738919	12-5714651	-0005028448
2007	8 64 00 41	7 750 749 816	43-1753671	12-5736231	-0005025696
2008	8 64 00 41	7 760 519 571	43-1768423	12-5757811	-0005022944
2009	8 64 00 41	7 770 289 326	43-1783175	12-5779391	-0005020192
2010	8 64 00 41	7 780 059 581	43-1797927	12-5800971	-0005017440
2011	8 64 00 41	7 789 829 336	43-1812679	12-5822551	-0005014688
201					

TABLE XLV. (continued).

No.	Square	Cube	Square Root	Cube Root	Reciprocal
1957	8 89 98 49	7 495 014 498	44-2379997	12-5082612	-0005109862
1958	8 89 97 64	7 508 809 919	44-2402988	12-5108914	-0005107252
1959	8 89 96 81	7 518 017 079	44-2426519	12-5125208	-0005104615
1960	8 89 95 00	7 529 636 000	44-2718672	12-5146495	-0005102041
1961	8 84 55 91	7 541 066 681	44-2831497	12-5167775	-0005099489
1962	8 84 54 24	7 553 609 198	44-2944692	12-5189047	-0005096840
1963	8 85 38 69	7 566 163 847	44-3057558	12-5210813	-0005094244
1964	8 85 37 06	7 575 730 844	44-3170396	12-5231571	-0005091650
1965	8 86 13 35	7 587 907 135	44-3283205	12-5252822	-0005089059
1966	8 86 01 56	7 598 696 696	44-3395985	12-5274065	-0005086470
1967	8 86 50 89	7 610 058 063	44-3508737	12-5295302	-0005083884
1968	8 87 30 24	7 623 111 293	44-3621460	12-5316531	-0005081301
1969	8 87 80 67	7 636 736 309	44-3734155	12-5337753	-0005078720
1970	8 88 09 00	7 646 378 000	44-3846820	12-5358968	-0005076142
1971	8 88 48 81	7 657 931 611	44-3959457	12-5380176	-0005073567
1972	8 88 87 84	7 668 693 048	44-4072066	12-5401377	-0005070991
1973	8 89 37 39	7 680 354 317	44-4184646	12-5422570	-0005068424
1974	8 89 66 76	7 693 038 424	44-4297198	12-5443757	-0005065856
1975	8 90 06 25	7 703 734 875	44-4409720	12-5464936	-0005063291
1976	8 90 45 76	7 715 443 176	44-4522215	12-5486107	-0005060729
1977	8 90 85 39	7 727 161 893	44-4634681	12-5507272	-0005058169
1978	8 91 24 84	7 738 893 353	44-4747119	12-5528430	-0005055612
1979	8 91 64 41	7 750 636 789	44-4859528	12-5549580	-0005053057
1980	8 92 04 00	7 763 393 000	44-4971909	12-5570723	-0005050505
1981	8 92 43 61	7 774 159 141	44-5084262	12-5591860	-0005047956
1982	8 92 83 24	7 785 938 168	44-5196586	12-5612969	-0005045409
1983	8 93 23 89	7 797 739 087	44-5308881	12-5634111	-0005042864
1984	8 93 63 56	7 809 531 904	44-5421149	12-5655226	-0005040323
1985	8 94 03 25	7 821 346 635	44-5533388	12-5676334	-0005037783
1986	8 94 43 96	7 833 178 268	44-5645599	12-5697435	-0005035247
1987	8 94 84 61	7 845 011 808	44-5757781	12-5718529	-0005032713
1988	8 95 25 44	7 856 863 373	44-5869986	12-5739615	-0005030181
1989	8 95 66 31	7 868 734 669	44-5982062	12-5760695	-0005027652
1990	8 96 07 01	7 880 599 000	44-6094164	12-5781767	-0005025126
1991	8 96 48 01	7 892 488 371	44-6206230	12-5802892	-0005022602
1992	8 96 89 04	7 904 388 468	44-6318272	12-5823891	-0005020080
1993	8 97 30 49	7 916 303 657	44-6430286	12-5844942	-0005017561
1994	8 97 71 36	7 928 215 764	44-6542271	12-5866097	-0005015045
1995	8 98 12 25	7 940 149 875	44-6654228	12-5887024	-0005012531
1996	8 98 53 16	7 952 095 986	44-6766158	12-5908054	-0005010020
1997	8 98 94 09	7 964 053 978	44-6878059	12-5929078	-0005007511
1998	8 99 35 04	7 976 023 995	44-6989953	12-5950093	-0005005005
1999	8 99 76 01	7 988 000 999	44-7101778	12-5971108	-0005002501
2000	4 00 00 00	8 000 000 000	44-7213596	12-5992105	-0005000000
2001	4 00 40 01	8 013 006 001	44-7325385	12-6013101	-0004997501
2002	4 00 80 04	8 026 034 008	44-7437146	12-6034089	-0004995005
2003	4 01 20 09	8 039 084 097	44-7548880	12-6055070	-0004992511
2004	4 01 60 16	8 052 096 084	44-7660586	12-6076044	-0004990020
2005	4 02 00 25	8 065 150 136	44-7772264	12-6097011	-0004987531

No.	Square	Cube	Square Root	Cube Root	Reciprocal
3006	4 02 40 36	8 078 216 316	44-7888913	12-6117971	-0004985045
3007	4 02 80 49	8 084 394 843	44-7995535	12-6138924	-0004982561
3008	4 03 20 64	8 090 384 519	44-8107190	12-6159870	-0004980080
3009	4 03 60 81	8 108 488 739	44-8218697	12-6180810	-0004977601
3010	4 04 01 00	8 120 601 000	44-8330235	12-6201743	-0004975124
3011	4 04 41 21	8 132 737 331	44-8441746	12-6222669	-0004972650
3012	4 04 81 44	8 144 865 739	44-8553280	12-6243587	-0004970179
3013	4 05 21 69	8 157 016 197	44-8664685	12-6264499	-0004967710
3014	4 05 61 96	8 169 178 744	44-8776118	12-6285404	-0004965248
3015	4 06 02 25	8 181 353 375	44-8887614	12-6306301	-0004962779
3016	4 06 42 56	8 193 540 886	44-8998866	12-6327192	-0004960317
3017	4 06 83 24	8 205 738 913	44-9110231	12-6348076	-0004957858
3018	4 07 23 89	8 217 949 893	44-9221549	12-6368953	-0004955401
3019	4 07 63 61	8 230 173 859	44-9334839	12-6389823	-0004952947
3020	4 08 04 00	8 242 408 000	44-9444101	12-6410687	-0004950495
3021	4 08 44 41	8 254 655 301	44-9553386	12-6431543	-0004948046
3022	4 08 84 84	8 266 914 648	44-9666543	12-6452398	-0004945598
3023	4 09 25 39	8 279 186 167	44-9777723	12-6473265	-0004943154
3024	4 09 65 76	8 291 469 334	44-9888875	12-6494071	-0004940711
3025	4 10 06 25	8 303 765 935	45-0000000	12-6514900	-0004938272
3026	4 10 46 76	8 316 078 876	45-0111097	12-6535722	-0004935834
3027	4 10 87 29	8 328 393 688	45-0222167	12-6556588	-0004933399
3028	4 11 27 84	8 340 726 953	45-0333210	12-6577846	-0004930966
3029	4 11 68 41	8 353 070 389	45-0444225	12-6598614	-0004928536
3030	4 12 09 00	8 365 424 000	45-0555213	12-6619398	-0004926108
3031	4 12 49 61	8 377 795 791	45-0666173	12-6639731	-0004923683
3032	4 13 30 24	8 390 176 768	45-0777107	12-6660512	-0004921260
3033	4 13 70 89	8 402 569 987	45-0888013	12-6681266	-0004918839
3034	4 14 11 56	8 414 975 304	45-0998891	12-6702053	-0004916421
3035	4 14 52 13	8 427 393 875	45-1109748	12-6722814	-0004914005
3036	4 15 32 69	8 439 823 656	45-1220567	12-6743567	-0004911591
3037	4 15 73 28	8 452 264 663	45-1331364	12-6764314	-0004909178
3038	4 16 13 93	8 464 718 873	45-1442134	12-6785054	-0004906771
3039	4 16 54 51	8 477 185 819	45-1552876	12-6805788	-0004904361
3040	4 17 35 31	8 489 664 000	45-1663592	12-6826514	-0004901961
3041	4 18 16 51	8 502 154 931	45-1774280	12-6847284	-0004899559
3042	4 18 57 64	8 514 658 088	45-1884941	12-6867947	-0004897160
3043	4 19 38 48	8 527 173 607	45-1995575	12-6888654	-0004894762
3044	4 19 79 36	8 539 701 135	45-2106182	12-6909354	-0004892361
3045	4 20 20 30	8 552 241 385	45-2216762	12-6930047	-0004889976
3046	4 21 01 16	8 564 793 838	45-2327815	12-6950733	-0004887586
3047	4 21 42 09	8 577 357 933	45-2437841	12-6971412	-0004885198
3048	4 22 23 04	8 589 934 699	45-2548340	12-6992084	-0004882813
3049	4 23 04 01	8 602 526 649	45-2658812	12-7012750	-0004880429
3050	4 23 85 00	8 615 133 000	45-2769257	12-7033409	-0004878049
3051	4 24 66 01	8 627 748 601	45-2879675	12-7054061	-0004875670
3052	4 25 47 04	8 640 364 608	45-2990066	12-7074707	-0004873294
3053	4 26 28 09	8 653 002 877	45-3100480	12-7095346	-0004870921
3054	4 27 09 16	8 665 653 464	45-3210768	12-7115978	-0004868549

TABLE XLV. (continued).

No.	Square	Cube	Square Root	Cube Root	Reciprocal
2055	4 33 30 35	8 678 316 875	45-3321078	12-7136603	-0004866180
2056	4 33 31 36	8 690 991 616	45-3431562	12-7157222	-0004869813
2057	4 33 32 37	8 703 179 118	45-3541619	12-7177835	-0004873449
2058	4 33 33 38	8 716 679 103	45-3651849	12-7198441	-0004877086
2059	4 33 34 39	8 729 991 879	45-3762052	12-7219040	-0004880723
2060	4 33 35 40	8 743 316 000	45-3872229	12-7239632	-0004884360
2061	4 33 36 41	8 757 632 916	45-3982378	12-7260218	-0004888000
2062	4 33 37 42	8 771 950 838	45-4092501	12-7280797	-0004891641
2063	4 33 38 43	8 786 269 765	45-4202598	12-7301370	-0004895284
2064	4 33 39 44	8 799 898 144	45-4312668	12-7321935	-0004898931
2065	4 33 40 45	8 813 436 486	45-4422717	12-7342494	-0004902581
2066	4 33 41 46	8 826 984 695	45-4532727	12-7363046	-0004906233
2067	4 33 42 47	8 840 532 763	45-4642717	12-7383592	-0004909887
2068	4 33 43 48	8 854 080 834	45-4752680	12-7404181	-0004913543
2069	4 33 44 49	8 867 628 900	45-4862616	12-7424764	-0004917201
2070	4 33 45 50	8 881 176 968	45-4972526	12-7445349	-0004920861
2071	4 33 46 51	8 894 724 000	45-5082410	12-7465932	-0004924523
2072	4 33 47 52	8 908 271 000	45-5192267	12-7486517	-0004928187
2073	4 33 48 53	8 921 818 000	45-5302097	12-7507102	-0004931853
2074	4 33 49 54	8 935 365 000	45-5411901	12-7527687	-0004935521
2075	4 33 50 55	8 948 912 000	45-5521679	12-7548272	-0004939191
2076	4 33 51 56	8 962 459 000	45-5631480	12-7568857	-0004942863
2077	4 33 52 57	8 976 006 000	45-5741155	12-7589442	-0004946537
2078	4 33 53 58	8 989 553 000	45-5850853	12-7609927	-0004950213
2079	4 33 54 59	8 999 999 000	45-5960525	12-7629927	-0004953891
2080	4 33 55 00	9 000 000 000	45-6070170	12-7649927	-0004957571
2081	4 33 56 01	9 011 807 441	45-6179780	12-7669927	-0004961253
2082	4 33 57 02	9 023 614 883	45-6289382	12-7689927	-0004964937
2083	4 33 58 03	9 035 422 325	45-6399034	12-7709927	-0004968623
2084	4 33 59 04	9 047 229 767	45-6508686	12-7729927	-0004972311
2085	4 34 00 05	9 059 037 209	45-6618338	12-7749927	-0004976001
2086	4 34 01 06	9 070 844 651	45-6727990	12-7769927	-0004979693
2087	4 34 02 07	9 082 652 093	45-6837642	12-7789927	-0004983387
2088	4 34 03 08	9 094 459 535	45-6947294	12-7809927	-0004987083
2089	4 34 04 09	9 106 266 977	45-7056946	12-7829927	-0004990781
2090	4 34 05 10	9 118 074 419	45-7166598	12-7849927	-0004994481
2091	4 34 06 11	9 129 881 861	45-7276250	12-7869927	-0004998183
2092	4 34 07 12	9 141 689 303	45-7385902	12-7889927	-0005001887
2093	4 34 08 13	9 153 496 745	45-7495554	12-7909927	-0005005593
2094	4 34 09 14	9 165 304 187	45-7605206	12-7929927	-0005009301
2095	4 34 10 15	9 177 111 629	45-7714858	12-7949927	-0005013011
2096	4 34 11 16	9 188 919 071	45-7824510	12-7969927	-0005016723
2097	4 34 12 17	9 200 726 513	45-7934162	12-7989927	-0005020437
2098	4 34 13 18	9 212 533 955	45-8043814	12-8009927	-0005024153
2099	4 34 14 19	9 224 341 397	45-8153466	12-8029927	-0005027871
2100	4 34 15 20	9 236 148 839	45-8263118	12-8049927	-0005031591
2101	4 34 16 21	9 247 956 281	45-8372770	12-8069927	-0005035313
2102	4 34 17 22	9 259 763 723	45-8482422	12-8089927	-0005039037
2103	4 34 18 23	9 271 571 165	45-8592074	12-8109927	-0005042763
2104	4 34 19 24	9 283 378 607	45-8701726	12-8129927	-0005046491
2105	4 34 20 25	9 295 186 049	45-8811378	12-8149927	-0005050221
2106	4 34 21 26	9 306 993 491	45-8921030	12-8169927	-0005053953
2107	4 34 22 27	9 318 800 933	45-9030682	12-8189927	-0005057687
2108	4 34 23 28	9 330 608 375	45-9140334	12-8209927	-0005061423
2109	4 34 24 29	9 342 415 817	45-9249986	12-8229927	-0005065161
2110	4 34 25 30	9 354 223 259	45-9359638	12-8249927	-0005068901
2111	4 34 26 31	9 366 030 701	45-9469290	12-8269927	-0005072643
2112	4 34 27 32	9 377 838 143	45-9578942	12-8289927	-0005076387
2113	4 34 28 33	9 389 645 585	45-9688594	12-8309927	-0005080133
2114	4 34 29 34	9 401 453 027	45-9798246	12-8329927	-0005083881
2115	4 34 30 35	9 413 260 469	45-9907898	12-8349927	-0005087631
2116	4 34 31 36	9 425 067 911	45-1007550	12-8369927	-0005091383
2117	4 34 32 37	9 436 875 353	45-1017202	12-8389927	-0005095137
2118	4 34 33 38	9 448 682 795	45-1026854	12-8409927	-0005098893
2119	4 34 34 39	9 460 490 237	45-1036506	12-8429927	-0005102651
2120	4 34 35 40	9 472 297 679	45-1046158	12-8449927	-0005106411

No.	Square	Cube	Square Root	Cube Root	Reciprocal
3104	4 42 68 16	9 814 020 964	45-9693798	12-8139170	-0004752852
3105	4 43 10 25	9 827 507 635	45-9802790	12-8159468	-0004756594
3106	4 43 12 36	9 840 994 016	45-9911786	12-8179759	-0004760338
3107	4 43 14 47	9 854 480 397	45-1002696	12-8200044	-0004764084
3108	4 43 16 58	9 867 966 778	45-1013691	12-8220320	-0004767833
3109	4 43 19 09	9 881 453 159	45-1024686	12-8240595	-0004771584
3110	4 43 21 20	9 894 939 540	45-1035681	12-8260861	-0004775336
3111	4 43 23 31	9 908 425 921	45-1046676	12-8281127	-0004779091
3112	4 43 25 42	9 921 912 302	45-1057671	12-8301393	-0004782848
3113	4 43 27 53	9 935 398 683	45-1068666	12-8321659	-0004786606
3114	4 43 30 04	9 948 885 064	45-1079661	12-8341925	-0004790365
3115	4 43 32 15	9 962 371 445	45-1090656	12-8362191	-0004794125
3116	4 43 34 26	9 975 857 826	45-1101651	12-8382457	-0004797886
3117	4 43 36 37	9 989 344 207	45-1112646	12-8402723	-0004801648
3118	4 43 38 48	10 002 830 588	45-1123641	12-8422989	-0004805411
3119	4 43 40 59	10 016 316 969	45-1134636	12-8443255	-0004809175
3120	4 43 43 10	10 029 803 350	45-1145631	12-8463521	-0004812940
3121	4 43 45 21	10 043 289 731	45-1156626	12-8483787	-0004816706
3122	4 43 47 32	10 056 776 112	45-1167621	12-8504053	-0004820473
3123	4 43 49 43	10 070 262 493	45-1178616	12-8524319	-0004824241
3124	4 43 51 54	10 083 748 874	45-1189611	12-8544585	-0004828010
3125	4 43 54 05	10 097 235 255	45-1200606	12-8564851	-0004831780
3126	4 43 56 16	10 110 721 636	45-1211601	12-8585117	-0004835551
3127	4 43 58 27	10 124 208 017	45-1222596	12-8605383	-0004839323
3128	4 43 60 38	10 137 694 398	45-1233591	12-8625649	-0004843096
3129	4 43 62 49	10 151 180 779	45-1244586	12-8645915	-0004846871
3130	4 43 64 60	10 164 667 160	45-1255581	12-8666181	-0004850647
3131	4 43 66 71	10 178 153 541	45-1266576	12-8686447	-0004854424
3132	4 43 68 82	10 191 639 922	45-1277571	12-8706713	-0004858202
3133	4 43 70 93	10 205 126 303	45-1288566	12-8726979	-0004861981
3134	4 43 73 04	10 218 612 684	45-1299561	12-8747245	-0004865762
3135	4 43 75 15	10 232 099 065	45-1310556	12-8767511	-0004869545
3136	4 43 77 26	10 245 585 446	45-1321551	12-8787777	-0004873331
3137	4 43 79 37	10 259 071 827	45-1332546	12-8808043	-0004877119
3138	4 43 81 48	10 272 558 208	45-1343541	12-8828309	-0004880910
3139	4 43 83 59	10 286 044 589	45-1354536	12-8848575	-0004884703
3140	4 43 86 10	10 300 530 970	45-1365531	12-8868841	-0004888498
3141	4 43 88 21	10 314 017 351	45-1376526	12-8889107	-0004892295
3142	4 43 90 32	10 327 503 732	45-1387521	12-8909373	-0004896094
3143	4 43 92 43	10 341 990 113	45-1398516	12-8929639	-0004900000
3144	4 43 94 54	10 356 476 493	45-1409511	12-8949905	-0004903908
3145	4 43 97 05	10 370 962 874	45-1420506	12-8970171	-0004907818
3146	4 44 00 16	10 385 449 255	45-1431501	12-8990437	-0004911730
3147	4 44 02 27	10 399 935 636	45-1442496	12-9010703	-0004915644
3148	4 44 04 38	10 414 422 017	45-1453491	12-9030969	-0004919561
3149	4 44 06 49	10 428 908 398	45-1464486	12-9051235	-0004923480
3150	4 44 09 00	10 443 394 779	45-1475481	12-9071501	-0004927401
3151	4 44 11 11	10 457 881 160	45-1486476	12-9091767	-0004931324
3152	4 44 13 22	10 472 367 541	45-1497471	12-9112033	-0004935250

TABLE XLV. (continued).

No.	Square	Cube	Square Root	Cube Root	Reciprocal
2153	4 63 54 09	9 980 085 577	46-4004310	12-9126291	-0004644682
2154	4 63 97 16	9 998 948 264	46-4112055	12-9146279	-0004642526
2155	4 64 40 25	10 007 878 875	46-4219775	12-9166262	-0004640371
2156	4 64 83 36	10 021 819 416	46-4327471	12-9186238	-0004638219
2157	4 65 26 40	10 035 768 898	46-4435141	12-9206208	-0004636069
2158	4 65 69 64	10 049 738 812	46-4542786	12-9226172	-0004633920
2159	4 66 12 81	10 063 705 679	46-4650406	12-9246129	-0004631774
2160	4 66 56 00	10 077 696 000	46-4758002	12-9266081	-0004629630
2161	4 66 99 21	10 091 699 281	46-4865572	12-9286027	-0004627487
2162	4 67 42 44	10 105 715 538	46-4973118	12-9305966	-0004625347
2163	4 67 85 69	10 119 744 747	46-5080638	12-9325899	-0004623209
2164	4 68 28 96	10 133 786 944	46-5188134	12-9345827	-0004621072
2165	4 68 72 25	10 147 842 125	46-5295605	12-9365747	-0004618938
2166	4 69 15 56	10 161 910 296	46-5403051	12-9385662	-0004616805
2167	4 69 58 80	10 175 991 468	46-5510472	12-9405570	-0004614675
2168	4 70 02 24	10 190 085 682	46-5617869	12-9425472	-0004612546
2169	4 70 45 61	10 204 192 809	46-5725241	12-9445369	-0004610420
2170	4 70 89 00	10 218 318 000	46-5832588	12-9465259	-0004608295
2171	4 71 32 41	10 232 446 211	46-5939910	12-9485143	-0004606172
2172	4 71 75 84	10 246 592 448	46-6047208	12-9505021	-0004604052
2173	4 72 19 29	10 260 751 717	46-6154481	12-9524898	-0004601988
2174	4 72 62 76	10 274 924 024	46-6261729	12-9544759	-0004599816
2175	4 73 06 25	10 289 109 875	46-6368953	12-9564618	-0004597701
2176	4 73 49 76	10 303 307 776	46-6476152	12-9584472	-0004595588
2177	4 73 93 29	10 317 519 288	46-6583826	12-9604319	-0004593477
2178	4 74 36 84	10 331 748 752	46-6690476	12-9624161	-0004591368
2179	4 74 80 41	10 345 981 889	46-6797601	12-9643996	-0004589261
2180	4 75 24 00	10 360 232 000	46-6904701	12-9663826	-0004587156
2181	4 75 67 61	10 374 495 741	46-7011777	12-9683649	-0004585058
2182	4 76 11 24	10 388 772 568	46-7118829	12-9703466	-0004582951
2183	4 76 54 89	10 403 062 487	46-7225855	12-9723277	-0004580852
2184	4 76 98 51	10 417 365 504	46-7332858	12-9743042	-0004578755
2185	4 77 42 25	10 431 681 625	46-7439886	12-9762881	-0004576659
2186	4 77 85 96	10 445 010 856	46-7546789	12-9782674	-0004574565
2187	4 78 29 69	10 460 358 908	46-7653718	12-9802461	-0004572474
2188	4 78 73 44	10 474 708 672	46-7760623	12-9822242	-0004570384
2189	4 79 17 21	10 489 077 269	46-7867503	12-9842017	-0004568296
2190	4 79 61 00	10 503 459 000	46-7974358	12-9861786	-0004566210
2191	4 80 04 81	10 517 853 871	46-8081189	12-9881549	-0004564126
2192	4 80 48 64	10 532 261 888	46-8187996	12-9901306	-0004562044
2193	4 80 92 49	10 546 683 087	46-8294779	12-9921057	-0004559964
2194	4 81 36 36	10 561 117 884	46-8401537	12-9940802	-0004557885
2195	4 81 80 25	10 575 564 875	46-8508271	12-9960540	-0004555809
2196	4 82 24 16	10 590 025 536	46-8614981	12-9980273	-0004553734
2197	4 82 68 09	10 604 499 873	46-8721666	13-0000000	-0004551661
2198	4 83 12 04	10 618 986 892	46-8828327	13-0019721	-0004549591
2199	4 83 56 01	10 633 486 599	46-8934963	13-0039436	-0004547522
2200	4 84 00 00	10 648 000 000	46-9041576	13-0059145	-0004545455
2201	4 84 44 01	10 663 526 601	46-9148164	13-0078848	-0004543389

(Reproduced by permission from "Mackrow's Naval Architects' Pocket-book.")

TABLE XLVI.

SQUARES, CUBES, AND FOURTH POWERS OF FRACTIONS.											
No.	Square.	Cube.	Fourth Power.	No.	Square.	Cube.	Fourth Power.	No.	Square.	Cube.	Fourth Power.
$\frac{1}{16}$	0.0002441	0.0000008815	0.000000005961	$\frac{1}{16}$	0.02659	0.01571	0.07069	$\frac{1}{16}$	1.031	1.048	1.064
$\frac{1}{8}$	0.0003766	0.00003052	0.0000009587	$\frac{1}{8}$	0.2822	0.01499	0.07965	$\frac{1}{8}$	1.063	1.097	1.131
$\frac{1}{4}$	0.002197	0.0001030	0.000001922	$\frac{1}{4}$	0.2991	0.01636	0.08944	$\frac{1}{4}$	1.096	1.147	1.201
$\frac{1}{2}$	0.003906	0.0002441	0.00001626	$\frac{1}{2}$	0.3164	0.01780	0.1001	$\frac{1}{2}$	1.129	1.199	1.274
$\frac{3}{4}$	0.006104	0.0004768	0.00008725	$\frac{3}{4}$	0.3342	0.01932	0.1117	$\frac{3}{4}$	1.162	1.253	1.351
$\frac{5}{8}$	0.008789	0.0008240	0.00007725	$\frac{5}{8}$	0.3526	0.02093	0.1248	$\frac{5}{8}$	1.196	1.316	1.431
$\frac{3}{2}$	0.01196	0.001308	0.0001431	$\frac{3}{2}$	0.3713	0.02263	0.1379	$\frac{3}{2}$	1.231	1.365	1.484
$\frac{7}{8}$	0.01563	0.001953	0.0002441	$\frac{7}{8}$	0.3906	0.02441	0.1526	$\frac{7}{8}$	1.266	1.424	1.563
$\frac{9}{8}$	0.01978	0.002781	0.0003911	$\frac{9}{8}$	0.4104	0.02629	0.1684	$\frac{9}{8}$	1.301	1.484	1.693
$\frac{5}{4}$	0.02441	0.003815	0.0005961	$\frac{5}{4}$	0.4307	0.02825	0.1855	$\frac{5}{4}$	1.337	1.546	1.787
$\frac{3}{2}$	0.02954	0.005077	0.0008727	$\frac{3}{2}$	0.4514	0.03033	0.2038	$\frac{3}{2}$	1.373	1.609	1.996
$\frac{7}{2}$	0.03516	0.006592	0.001236	$\frac{7}{2}$	0.4727	0.03250	0.2234	$\frac{7}{2}$	1.410	1.675	1.989
$\frac{9}{2}$	0.04126	0.008381	0.001702	$\frac{9}{2}$	0.4944	0.03476	0.2444	$\frac{9}{2}$	1.448	1.742	2.095
$\frac{5}{2}$	0.04785	0.01047	0.002290	$\frac{5}{2}$	0.5166	0.03713	0.2669	$\frac{5}{2}$	1.485	1.810	2.203
$\frac{3}{2}$	0.05493	0.01287	0.003018	$\frac{3}{2}$	0.5393	0.03961	0.2909	$\frac{3}{2}$	1.524	1.881	2.322
$\frac{7}{2}$	0.06250	0.01563	0.003906	$\frac{7}{2}$	0.5625	0.04219	0.3164	$\frac{7}{2}$	1.563	1.953	2.441
$\frac{9}{2}$	0.07056	0.01874	0.004978	$\frac{9}{2}$	0.5862	0.04488	0.3436	$\frac{9}{2}$	1.602	2.027	2.566
$\frac{5}{2}$	0.07910	0.02225	0.006257	$\frac{5}{2}$	0.6104	0.04768	0.3725	$\frac{5}{2}$	1.642	2.103	2.695
$\frac{3}{2}$	0.08813	0.02617	0.007768	$\frac{3}{2}$	0.6350	0.05060	0.4032	$\frac{3}{2}$	1.682	2.181	2.829
$\frac{7}{2}$	0.09766	0.03052	0.009537	$\frac{7}{2}$	0.6602	0.05364	0.4358	$\frac{7}{2}$	1.723	2.261	2.968
$\frac{9}{2}$	0.1077	0.03533	0.01159	$\frac{9}{2}$	0.6858	0.05679	0.4703	$\frac{9}{2}$	1.764	2.343	3.111
$\frac{5}{2}$	0.1182	0.04062	0.01396	$\frac{5}{2}$	0.7119	0.06007	0.5068	$\frac{5}{2}$	1.806	2.426	3.260
$\frac{3}{2}$	0.1292	0.04641	0.01668	$\frac{3}{2}$	0.7385	0.06347	0.5454	$\frac{3}{2}$	1.848	2.512	3.415
$\frac{7}{2}$	0.1406	0.05273	0.01978	$\frac{7}{2}$	0.7656	0.06699	0.5862	$\frac{7}{2}$	1.891	2.600	3.575
$\frac{9}{2}$	0.1526	0.05960	0.02328	$\frac{9}{2}$	0.7932	0.07065	0.6290	$\frac{9}{2}$	1.934	2.689	3.740
$\frac{5}{2}$	0.1650	0.06705	0.02724	$\frac{5}{2}$	0.8213	0.07448	0.6745	$\frac{5}{2}$	1.978	2.781	3.911
$\frac{3}{2}$	0.1780	0.07508	0.03168	$\frac{3}{2}$	0.8499	0.07835	0.7223	$\frac{3}{2}$	2.022	2.875	4.087
$\frac{7}{2}$	0.1914	0.08374	0.03664	$\frac{7}{2}$	0.8789	0.08240	0.7725	$\frac{7}{2}$	2.066	2.970	4.270
$\frac{9}{2}$	0.2053	0.09304	0.04216	$\frac{9}{2}$	0.9084	0.08659	0.8253	$\frac{9}{2}$	2.112	3.068	4.459
$\frac{5}{2}$	0.2197	0.1030	0.04828	$\frac{5}{2}$	0.9385	0.09091	0.8807	$\frac{5}{2}$	2.157	3.168	4.654
$\frac{3}{2}$	0.2346	0.1136	0.05505	$\frac{3}{2}$	0.9690	0.09539	0.9380	$\frac{3}{2}$	2.203	3.271	4.855
$\frac{7}{2}$	0.2500	0.1250	0.06250	$\frac{7}{2}$	1.000	1.000	1.000	$\frac{7}{2}$	2.250	3.375	5.063

SQUARES, CUBES, AND FOURTH POWERS OF FRACTIONS—(continued).											
No.	Square.	Cube.	Fourth Power.	No.	Square.	Cube.	Fourth Power.	No.	Square.	Cube.	Fourth Power.
$\frac{1}{16}$	0.0002441	0.0000008815	0.000000005961	$\frac{1}{16}$	0.02659	0.01571	0.07069	$\frac{1}{16}$	1.031	1.048	1.064
$\frac{1}{8}$	0.0003766	0.00003052	0.0000009587	$\frac{1}{8}$	0.2822	0.01499	0.07965	$\frac{1}{8}$	1.063	1.097	1.131
$\frac{1}{4}$	0.002197	0.0001030	0.000001922	$\frac{1}{4}$	0.2991	0.01636	0.08944	$\frac{1}{4}$	1.096	1.147	1.201
$\frac{1}{2}$	0.003906	0.0002441	0.00001626	$\frac{1}{2}$	0.3164	0.01780	0.1001	$\frac{1}{2}$	1.129	1.199	1.274
$\frac{3}{4}$	0.006104	0.0004768	0.00008725	$\frac{3}{4}$	0.3342	0.01932	0.1117	$\frac{3}{4}$	1.162	1.253	1.351
$\frac{5}{8}$	0.008789	0.0008240	0.00007725	$\frac{5}{8}$	0.3526	0.02093	0.1248	$\frac{5}{8}$	1.196	1.316	1.431
$\frac{3}{2}$	0.01196	0.001308	0.0001431	$\frac{3}{2}$	0.3713	0.02263	0.1379	$\frac{3}{2}$	1.231	1.365	1.484
$\frac{7}{8}$	0.01563	0.001953	0.0002441	$\frac{7}{8}$	0.3906	0.02441	0.1526	$\frac{7}{8}$	1.266	1.424	1.563
$\frac{9}{8}$	0.01978	0.002781	0.0003911	$\frac{9}{8}$	0.4104	0.02629	0.1684	$\frac{9}{8}$	1.301	1.484	1.693
$\frac{5}{4}$	0.02441	0.003815	0.0005961	$\frac{5}{4}$	0.4307	0.02825	0.1855	$\frac{5}{4}$	1.337	1.546	1.787
$\frac{3}{2}$	0.02954	0.005077	0.0008727	$\frac{3}{2}$	0.4514	0.03033	0.2038	$\frac{3}{2}$	1.373	1.609	1.996
$\frac{7}{2}$	0.03516	0.006592	0.001236	$\frac{7}{2}$	0.4727	0.03250	0.2234	$\frac{7}{2}$	1.410	1.675	1.989
$\frac{9}{2}$	0.04126	0.008381	0.001702	$\frac{9}{2}$	0.4944	0.03476	0.2444	$\frac{9}{2}$	1.448	1.742	2.095
$\frac{5}{2}$	0.04785	0.01047	0.002290	$\frac{5}{2}$	0.5166	0.03713	0.2669	$\frac{5}{2}$	1.485	1.810	2.203
$\frac{3}{2}$	0.05493	0.01287	0.003018	$\frac{3}{2}$	0.5393	0.03961	0.2909	$\frac{3}{2}$	1.524	1.881	2.322
$\frac{7}{2}$	0.06250	0.01563	0.003906	$\frac{7}{2}$	0.5625	0.04219	0.3164	$\frac{7}{2}$	1.563	1.953	2.441
$\frac{9}{2}$	0.07056	0.01874	0.004978	$\frac{9}{2}$	0.5862	0.04488	0.3436	$\frac{9}{2}$	1.602	2.027	2.566
$\frac{5}{2}$	0.07910	0.02225	0.006257	$\frac{5}{2}$	0.6104	0.04768	0.3725	$\frac{5}{2}$	1.642	2.103	2.695
$\frac{3}{2}$	0.08813	0.02617	0.007768	$\frac{3}{2}$	0.6350	0.05060	0.4032	$\frac{3}{2}$	1.682	2.181	2.829
$\frac{7}{2}$	0.09766	0.03052	0.009537	$\frac{7}{2}$	0.6602	0.05364	0.4358	$\frac{7}{2}$	1.723	2.261	2.968
$\frac{9}{2}$	0.1077	0.03533	0.01159	$\frac{9}{2}$	0.6858	0.05679	0.4703	$\frac{9}{2}$	1.764	2.343	3.111
$\frac{5}{2}$	0.1182	0.04062	0.01396	$\frac{5}{2}$	0.7119	0.06007	0.5068	$\frac{5}{2}$	1.806	2.426	3.260
$\frac{3}{2}$	0.1292	0.04641	0.01668	$\frac{3}{2}$	0.7385	0.06347	0.5454	$\frac{3}{2}$	1.848	2.512	3.415
$\frac{7}{2}$	0.1406	0.05273	0.01978	$\frac{7}{2}$	0.7656	0.06699	0.5862	$\frac{7}{2}$	1.891	2.600	3.575
$\frac{9}{2}$	0.1526	0.05960	0.02328	$\frac{9}{2}$	0.7932	0.07065	0.6290	$\frac{9}{2}$	1.934	2.689	3.740
$\frac{5}{2}$	0.1650	0.06705	0.02724	$\frac{5}{2}$	0.8213	0.07448	0.6745	$\frac{5}{2}$	1.978	2.781	3.911
$\frac{3}{2}$	0.1780	0.07508	0.03168	$\frac{3}{2}$	0.8499	0.07835	0.7223	$\frac{3}{2}$	2.022	2.875	4.087
$\frac{7}{2}$	0.1914	0.08374	0.03664	$\frac{7}{2}$	0.8789	0.08240	0.7725	$\frac{7}{2}$	2.066	2.970	4.270
$\frac{9}{2}$	0.2053	0.09304	0.04216	$\frac{9}{2}$	0.9084	0.08659	0.8253	$\frac{9}{2}$	2.112	3.068	4.459
$\frac{5}{2}$	0.2197	0.1030	0.04828	$\frac{5}{2}$	0.9385	0.09091	0.8807	$\frac{5}{2}$	2.157	3.168	4.654
$\frac{3}{2}$	0.2346	0.1136	0.05505	$\frac{3}{2}$	0.9690	0.09539	0.9380	$\frac{3}{2}$	2.203	3.271	4.855
$\frac{7}{2}$	0.2500	0.1250	0.06250	$\frac{7}{2}$	1.000	1.000	1.000	$\frac{7}{2}$	2.250	3.375	5.063

(Reproduced by permission from "The Mechanical World Pocket Diary.")

INDEX.

ACCCELERATION in a gas engine, 25, 26, 27, 29
Adjustable cap to small end of connecting rod, 161, 162
Arms of flywheel, 187, 195, 198, 199
Asbestos packing, 115

BALANCE weights, 79, 80, 81
Bearings, pressure on the, 87
Bearings, main, pressure on the, 56
— — pressure on the, flywheel side, 58
— — — — side shaft side, 57
— — pressure on the, 91, 92, 93, 97, 98
— — — — at greatest turning moment, 84, 85
— — — — with crank on dead point, 83
— of crank shaft, 70, 101
— overheating the, 95, 99
— strength of the, 97
Bending and twisting moments and Stresses, 86, 88
Bending moment, connecting rod, 160
— stress on flywheel arms, 196
— — on piston rings, 133, 134, 135
Blast furnace gas engines, 22
Bolts, breech end, 115
— on flywheel, 188, 197
— — pulley flywheels, 180, 181
— — the frame, 110
Bore of the cylinder, 131
Boss for the piston pin, 137
Box frame, 122
— pistons, 125
Brake horse power in a gas engine, 21
Brasses of connecting rod, 151, 153
— of main bearings, 101, 102
Breech end bolts, 115
— — of cylinder, 114, 115
Built up flywheels, 171, 174, 187
Bursting of flywheels, 197

CALCULATION, Enslein's method of, 96
— of a double-acting, four-cycle engine, 40
— of a double vis-à-vis four-cycle engine, 45

Calculation of a single-acting four-cycle engine, 40
— — tandem four-cycle engine, 44
— — twin double-acting four-cycle engine, 49
— — vis-à-vis four-cycle engine, 42, 43
— of mean temperature in a cylinder, 144
— of the crank shaft, 90, 91
— — flywheel, 166
— — parts of an engine, 68
Cap bolts of connecting rod, 152
— or keep of connecting rod, 151
— on the bearings, 104
Centrifugal force in flywheel rim, 186
— lubricator for crank pin, 78
— oil ring lubricator, 76, 77
Check screws and oil grooves, 102
Clamps for flywheel rims, 191
Classification of types, 16
Combined inertia and indicator diagram, 30, 31
Combustion chamber in a gas engine, 4
— — temperature diagrams for, 143, 144
Comparison of flywheel weights in steam and gas engines, 167
— of gas and steam engines, 178
Compression in a gas engine, 5, 6
Connecting rod, the, 150
— — brasses, 151, 153
— — cap bolts, 152
— — cap or keep of, 151
— — crank pin or big end of, 159
— — crank shaft bearings, etc., dimensions of, 162, 163
— — dimensions of, 154, 155, 156
— — marine type, 152, 153, 159, 161
— — nuts and bolts, 158
— — rules for constructing the, 150
— — shaft of, 157, 158, 159
— — small end, adjustable cap, 161, 162
— — small or piston pin end, 160
— — stresses, 157, 158, 159
— — thrust, 55
Construction of balance weights, 80
Consumption of fuel in gas engines, 213, 214
— — steam engines, 213, 214
— of cooling water, 148

Continuous energy diagrams, 41
 Cooling parts of cylinder with water, 145
 — exhaust valve — — 146
 — piston with water, 128, 148
 — water pipes, diameter of, 149
 — — thermal units transmitted to the, 147
 Cost of anthracite in suction gas plant, 215
 — superheated steam in a steam engine, 215
 Cotters for flywheel rims, 189, 190, 194, 195
 Crank circle, development of the, 88
 Crank pin, centrifugal lubrication for, 78
 — — end of connecting rod (or big end), 159
 Crank pin, forces acting on the, 59, 60, 61, 62
 — lubrication, 75
 — pressure on the, 98
 Crank pit of an engine, 110, 111
 Crank shaft bearings, 70, 101
 — — pressure on the, 54, 55
 — calculation of the, 90, 91
 — dimensions of the, 70, 72, 73, 74, 90, 91
 — dimensions of crank web, 75
 — limit of elasticity in, 96
 — oil guard for bearings of, 103, 108
 — of a gas engine, 69
 — strength of the, 82
 — stresses on the, 94
 — webs, pressure on the, 87, 88
 Crank splasher guard, 112
 Crosshead, forces acting on the, 53, 59
 — or piston pin, 132, 138
 Cycle of work in a gas engine, 8, 17
 Cylinder and frame, 109, 117, 118, 119, 120
 — bore, 131
 — breech end, 114
 — cooling the, with water, 145
 — jacket, 118
 — liner, 113
 — lubrication of the, 129
 — of the engine, 112
 — packing, 115
 — parts to be cooled, 145
 — pressure in the, 123
 — temperatures in the, 142, 143, 146
 — thickness of wall of, 123

DEGREE of irregularity at full load, 169
 — — light load, 167, 169
 — — in running gas engines, 164, 172, 216
 — — uniformity in engines driving dynamos, 175
 Depreciation in costs of gas and steam engines, 209
 Determination of the resultant thrust, 57, 58
 Deutz gas engine, 23, 71, 129
 Developed diagrams, 16
 — — double-acting four-cycle engine, 9

Developed diagrams, double vis-à-vis four-cycle engine, 13
 — — single - cylinder four-cycle engine, 8, 9
 — — tandem double-acting four-cycle engine, 15
 — — tandem four-cycle engine, 12
 — — twin — — 11
 — — twin double-acting four-cycle engine, 14
 — — vis-à-vis four-cycle engine, 10
 — — of work, 31
 Development of the crank circle, 38
 Diagram of cooling the piston, 148
 — crank movements, 87
 — dimensions of cylinder and bearings, 71
 — energy, 86
 — — continuous, 41
 — explosion in a gas engine, 4
 — fluctuations of power in a gas engine, 164
 — pressures, 32
 — tangential pressure, or turning moment, 84, 87, 39, 84, 165, 168
 — work in single-acting four-cycle engine, 35
 Diameter of cooling water pipes, 149
 — flywheels and pulleys, 179
 — piston rings, 134
 Dimensions of balance weights, 81
 Dimensions of connecting rod, 154, 155, 156
 — — crank shaft bearings, &c., 162, 163
 — — crank shaft, 70, 72, 73, 74, 90, 91
 — — crank web, 75
 — — cylinder and frame, 116-120
 — — flywheel, 182, 183, 184
 — — main bearings, 105, 106, 107
 — — Ramsbottom rings, 133
 Double-acting engines, 1
 — — four-cycle engines, 2, 3, 9
 — — — developed diagram, 9
 — — — calculation of a, 40
 — — — forces acting on the crank-pin of, 61
 — — two-cycle engines, 2, 3
 — — — forces acting on the crank-pin of, 62
 Double vis-à-vis four-cycle engine, calculation of a, 45
 — — — — developed diagram, 13
 — — — — turning moment diagram, 45
 Dowels for flywheel rims, 189, 190, 195
 Drip tray for lubricating oil, 111
 Dynamos, degree of uniformity in driving, 175

- E**LECTRIC light and power transmission, 174
 End of the piston, — convex, 131
 — — — flat, 131
 Energy absorbed by the flywheel, 39
 — diagram, 36, 46, 47, 48, 50
 — — continuous, 41
 — of the flywheel, 172
 Ensslin, method of calculation, 96
 — on multiple cranked shafts, 95
 Exhaust of gas engines, utilization of heat in, 216
 — steam in steam engines, 216
 — valve, cooling the, 145, 146
 Expansion curve in gas and steam engines, 6
 — of piston, 127, 128
 — in a gas engine, diagram of, 4
- F**ASTENINGS of flywheel rims, 194
 Fluctuations in the speed of gas engines, 170
 Flywheel arms, 187, 195, 198, 199
 — bending and tensile stress on, 196
 — bolts, 188
 — calculation of the, 166, 199
 — combined stress on the, 187
 — comparison of weight of, in steam and gas engines, 167
 — energy absorbed by the, 39, 172
 Flywheel keys, feather keys, 201, 202
 — hollow — 201, 202
 — round — 201, 202
 — sunk — 200, 201, 202
 — tangential keys, 200, 201, 202
 — kinetic energy stored up in the, 170, 171
 — moment of rotation of the, 173
 Flywheel naves, 197, 200
 — stresses on, 199
 — rim, clamps for, 191
 — cross section, 185, 186, 189
 — fastenings, 194
 — joints, 183
 — lugs on, 197
 — shoulder on, for shrunk rings, 192, 193
 — shrunk rings for, 192, 193, 200
 — stresses on, 186, 190, 199
 — weight of, 165, 198
 — width of, 184, 198
 — securing to shaft, 200
 — tensile strength of the, 185
 — weight of the, 55, 99, 174, 177
 — work done by the, 171
 Flywheels and pulleys, diameter of, 179
 — built up, 171, 174, 187
 — bursting of, 197
 — cotters for rims of, 189, 190, 194, 195
 — dowels for rims of, 189, 190, 194, 195
 — dimensions of, 182, 188, 184
 — pulley, 178
 — transmission of power in, 178
 — with grooved rims, 187
 — solid rims, 187
- Forces acting on the crosshead, crank pin, etc., 53, 59
 Four-cycle gas engines, indicator diagram, 7
 — — — working method, 7
 Frame and cylinder of a gas engine, 109, 116, 117, 118, 119, 120
 Frame, bolts to hold down the, 110
 — load on the, 122
 — strength of the, 121
 — stresses on the, 121, 122
- G**AS and steam engines, comparison of, 178
 Gas engine, brake horsepower, 20, 21
 — compression in a, 5, 6
 — connecting rod, 150
 — crank shaft, 69
 — cycle of work in a, 8, 17
 — cylinder, 112
 — double-acting four-cycle, 9
 — — two-cycle, 3
 — exhaust in a, 216
 — flywheel, 164
 — four-cycle, 1, 2, 3
 — — parts of a, 66, 67
 — frame, 109
 — governing, 19
 — indicated horse-power, 20, 21
 — indicator diagram, 5, 6
 — inertia of reciprocating parts, 25
 — instroke, 8, 25
 — load on the piston of a, 63, 64, 99
 — main bearings of a, 100
 — mechanical efficiency, 18
 — out-put of work, 18
 — outstroke, 8, 25
 — piston, 124
 — piston pin, 137
 — pressure on the piston, 18
 — quantity or quality governing, 170
 — rated horse-power, 22
 — ratio ϵ , 19
 — stresses in a, 210
 — subsidiary costs in a, 211
 — two-cycle, 1, 2, 3
 — types, 16, 24
 — water required to cool a, 147
 Gas engines, blast furnace, 22
 — calculation of the output, 20, 21
 — comparison of weight of flywheel, 167
 — consumption of fuel in, 213, 214
 — cost of fuel in, 211, 212
 — degree of irregularity in running, 164
 — depreciation, 209
 — Deutz, 13, 23
 — Koerting, 2, 3, 28
 — load in, comparison with steam engines, 176

Gas engines, main dimensions, 23, 203, 204, 205
 — Nuremberg, 23
 — Oechelhaeuser, 2, 3
 — Speed of, 203
 — suction gas, 22
 — Swiderski, 23
 — working costs, 209
 — working method, 1
 Governing of the engine, quantity or quality, 170
 — methods of, in a gas engine, 19

HIT-AND-MISS governing, 19, 170
 Horse-power, maximum, at normal load, 65
 Housing of bearings, 103

INDICATED horse-power in a gas engine, 20, 21
 Indicator diagram, four-cycle gas engine, 7
 — — of a gas engine, 5, 6, 142
 — — — steam engine, 5, 6
 Inertia and indicator combined diagrams, 30, 31
 — diagram, 26, 27, 32
 — of moving parts, 216
 — of reciprocating parts, 25
 Inlet water cooling pipes, 149
 Instroke of a gas engine, 8, 25

JACKET of the cylinder, 113
 Joint between breech end and liner, 114
 Journals, pressure on the, 87, 89

KEYS for securing the flywheel, 201, 203
 Kinetic energy stored up in the flywheel, 170, 171
 Koerting gas engine, 23, 71

LIDS over oil boxes, 104
 Limit of elasticity in crank shafts, 96
 Liner, cylinder, 113
 — joint ring and stuffing box, 114
 Load, comparison of the, in gas and steam engines, 176
 — degree of irregularity at full, 169
 — — — light, 167, 169
 — — — varying, 172
 — normal, maximum horse-power at, 65
 — on a gas engine, 99
 — — steam engine, 99
 — on the frame, 122
 — — piston, maximum, 162, 163
 — — piston of a gas engine, 63, 64
 — — — steam engine, 63, 64
 — — — pin, 138
 — — rods, changes of, 29
 — variations in the, in mills and workshops, 176
 Lubrication, centrifugal oiling ring, 76, 77
 — crank pin, 75

Lubrication drip tray in crank pit, 111
 — oil fender ring, dimensions of, 75
 — main bearings, 101
 — of piston, 123
 — — pin, 141
 Lugs on flywheel rims, 197

MAIN bearing brasses, 101, 102
 — bearings, 100
 Main bearings, cap on the, 104
 — — dimensions of, 105, 106, 107
 — — forces acting on the, 53
 — — lubrication of the, 101
 — — oiling ring on the, 104, 108
 — — dimensions of a gas engine, 23, 203, 204, 205
 — — — steam engine, 206, 207
 Marine type of connecting rods, 152, 153, 159, 161
 Mean pressure in a gas engine, 19
 Mechanical efficiency in a gas engine, 18
 Moments, bending and twisting, on journals, 86-89
 Moment of inertia in the frame, 122
 — rotation of the flywheel, 173
 Motor car engines, weights of, 23
 Movements of heat in the cylinder, 142

NAVES of flywheels, 197, 200
 Number of piston rings, 135
 Nuremberg gas engine, 23, 71
 Nuts and bolts for connecting rod, 153

OIL box lids, 104
 Oil fender ring, dimensions of, 75
 — grooves and check screws, 102
 — guard for crank shaft bearing, 103, 103
 — holes, 130
 — pump for lubricating piston and pin, 129, 130
 — splasher guard, 111, 112
 Oiling rings, 100
 Oiling ring in the bearings, 104, 103
 Open-ended pistons, 125
 Outlet water cooling pipes, 149
 Output of a gas engine, calculation of the, 18, 20, 21
 Outstroke in a gas engine, 8, 25
 Overheating the bearings, 95, 99

PACKING of the cylinder, 115
 — of liner joint, 114, 115
 Parts of a gas engine, 4, 66, 67, 68
 Piston and piston pin, standard types of, 139, 140
 Piston, body or trunk of, 131
 — boss on the, 137
 — cooling the, 123, 143
 — ends, 131
 — forces acting on the, 53
 — guide, pressure on the, 126, 127
 — lubrication of the, 123, 129
 — maximum load on the, 162, 163

Piston, mean pressure on the, 19
 — of a gas engine, 124
 — weight of the, 127
 Piston pin, 126, 127, 137
 — load on the, 138
 — lubrication of the, 129, 130, 141
 — or crosshead, calculation of the, 138
 — position of, 127
 — stiffening rib on the bosses for the, 137
 Piston rings, 132, 133
 — bending, stress on, 133, 134, 135
 — diameter of, 134
 — number of, 135
 — Ramsbottom, 132, 133
 — Reinhardt on, 135, 136
 — securing the, 136
 — self-adjusting, 132
 Pistons, box, 125
 — open-ended, 125
 — trunk, 124
 Pressure, bending and twisting, on bearings, 87
 — change of, in the rods, 59
 — diagram, 32
 — in a gas engine, 18, 19
 — on bearings, journals, etc., 97, 98
 — — at greatest turning moment, 84, 85
 — — calculation of the, 91, 92, 98
 — — crank on dead point, 83
 — — outer side, 55
 — — side shaft side, 57
 — on crank pin, 98
 — — shaft bearings, 54, 55
 — — shaft webs, 87, 88
 — on journals, 87, 89
 — — main bearings, 56, 58
 — — piston guide, 126
 Pressures and temperatures, table of, 68
 Pulley belts, thickness of, 180
 — flywheels, 178
 — — belts on, 180, 181
 — — width of, 180
 Pulleys, driving, and flywheels, diameter of, 179
 RADIAL acceleration in a gas engine, 30
 — component, 85
 — determination of the, 84
 Radinger, 37
 — on gas engines, 26
 Ramsbottom rings, 132, 133
 Rated horse-power of a gas engine, 22
 Ratio ϵ in a gas engine, 19
 Reciprocating and rotating parts, balancing of, 79
 — parts, weight of, 28
 Reinhardt on piston rings, 135, 136
 Resultant thrust, determination of the, 57, 58
 Retardation in a gas engine, 26, 27
 Rim joints of flywheels, 188
 — of the flywheel, cross section, 185, 186, 189
 Rods, change of pressure in the, 59

Rods, forces acting on the, 53
 Rolling mill engines, degree of irregularity in, 172, 173
 Rope driving, 273
 Rules for constructing the connecting rod, 150
 Running gas engines, driving dynamos in parallel for, 174

SECURING the piston rings, 136
 Shaft or body of connecting rod, 157, 158, 159
 Shoulder on flywheel rims for shrunk hoops, 192, 193
 Shrunk rings for flywheel rims, 192, 193, 200
 — tensile stress on, 192, 193
 Side frames, 121
 Single-acting four-cycle engine, 2, 3
 — — — calculation of a , 40
 — — — developed diagram, 8, 9
 — — — diagram of work, 35
 — — — forces acting on the crankpin of, 60
 Single-acting gas engines, 1
 Small end of connecting rod, solid forged eye, 160
 Speed of gas engines, 208
 — fluctuations in the, 170
 — steam engines, 208
 Solid forged eye, small end of connecting rod, 160
 Standard types of piston and piston pin, 139, 140
 Steam engines, comparative weight of flywheel of, 167
 — — consumption of coal in, 213, 214
 — — cost of coal in, 211, 212
 — — — superheated steam in, 215
 — — depreciation, 209
 — — indicator diagram, 5, 6
 — — exhaust steam in, 216
 — — load on, 99
 — — compared with gas engines, 176
 — — piston of, 63, 64
 — — main dimensions, 206, 207
 — — speed of, 208
 — — stresses in, 210
 — — subsidiary costs in, 211
 — — working costs, 209
 Stiffening the boss for the piston pin, 137
 Strength of the bearings, 97
 — crank shaft, 82
 — frame, 121
 Stresses, combined, on the flywheel, 187
 — in a gas engine, 210
 — — steam engine, 210
 — on the connecting rod, 157, 158, 159
 — — crank shaft, 94
 — — cylinder, 123
 — — flywheel naves, 199
 — on flywheel rims, 190
 — on the frame, 120, 121
 — on the piston pin, 138
 Stuffing box and liner joint ring, 114

Subsidiary costs in a gas engine, 211
 — — — steam engine, 211
 Suction gas engines, 22
 — — — plant, cost of anthracite in a, 215
 Swiderski gas engine, 71

TANDEM double-acting four-cycle engine, developed diagram, 15
 — — — four-cycle engine, calculation of a, 44
 — — — — — developed diagram, 12
 — — — — — turning moment diagram, 44

Tangential pressure or turning moment diagram, 84, 87, 168
 Temperature, calculation of the mean, 144
 — — — diagrams for combustion chamber, 143, 144
 Temperatures in the cylinder, 142, 143, 146
 Tensile strength of the flywheel, 185
 — — — stress on flywheel arms, 196
 — — — — — rim, 186, 199
 — — — on shrunk rings, 192, 198
 Theoretical pressures, 53
 Thermal units, number of, transmitted to water, 147
 Thickness of cylinder wall, 128
 — — — pulley belts, 180
 Thrust on the connecting rod, 55
 Transmission, system of, for electric light and power, 174
 — — — of power in flywheels, 178
 Trunk or body of piston, 181
 — — — pistons, 124
 Turning moment diagram, 38, 39, 84
 — — — — — double-acting four-cycle engine, 41
 — — — — — double vis-à-vis four-cycle engine, 45, 47

Turning moment diagram, twin double-acting four-cycle engine, 49, 50
 — — — — — vis-à-vis four-cycle engine, 43
 — — — — — maximum, 128
 — — — — — tandem four-cycle engine, 44
 Twin double-acting four-cycle engine, calculation of a, 48
 — — — — — — — developed diagram, 14
 — — — — — — — turning moment diagram, 49, 50
 Twin four-cycle engine, developed diagram, 11
 Types of gas engines, 2, 3, 24

VARIATIONS in the load, in mills and workshops, 176
 Vis-à-vis four-cycle engine, calculation of a, 42
 — — — — — developed diagram, 10
 — — — — — turning moment diagram, 43

WATER, consumption of cooling, 147, 148
 — — — cooling in cylinder, 145
 Weight of flywheel, 55, 99, 174, 177, 216
 — — — — — rim, 165, 198
 — — — — — piston, 127
 — — — — — reciprocating parts, 23
 Weights of motor car engines, 23
 Width of flywheel rim, 184, 198
 — — — pulley flywheels, 180
 Work done by the flywheel, 171
 Working cost of gas engines, 209
 — — — — — steam engines, 209
 Working method of gas engines, 1

THE END.

Important Books for Gas Engineers.

INTERNAL COMBUSTION ENGINES.

Their Theory, Construction, and Operation. By ROLLA C. CARPENTER, M.M.E., LL.D., and H. DIEDERICH, M.E., Professors of Experimental Engineering, Sibley College, Cornell University. 610 pages, with 373 Illustrations. Medium 8vo, cloth *Net 21s.*

"It is undoubtedly a valuable addition to the literature on this subject, and to those engineers who make a study of the internal combustion engine it is well worth acquisition."—*Cassier's Magazine*.

"The whole subject has been most exhaustively and thoroughly prepared, and we have no hesitation in classing the book among the leading text-books on the internal combustion engine."—*Practical Engineer*.

GAS-ENGINES AND PRODUCER-GAS PLANTS.

A Treatise setting forth the Principles of Gas Engines and Producer Design, the Selection and Installation of an Engine, the Care of Gas Engines and Producer-Gas Plants, with a Chapter on Volatile Hydrocarbon and Oil Engines. By R. E. MATHOT, M.E. Translated from the French. With a Preface by DUGALD CLERK, M.Inst.C.E., F.C.S. Medium 8vo, cloth, 310 pages, with about 150 Illustrations *Net 12s.*

"It may, indeed, be said that there is no other work in English giving so up-to-date an account of Producer-Gas Plants."—*Times (Eng. Supt.)*.

"It is the sort of book that every mechanical engineer should have, even if he be with a steam driven plant, because the use of producer-gas is becoming so extended that it is now necessary for all of us to be well acquainted with the details of such plant."—*Engineering Times*.

AMERICAN PRODUCER GAS PRACTICE AND INDUSTRIAL GAS ENGINEERING.

By NISBET LATTA, M.Amer.Soc.M.E., M.Amer. Gas Inst. 558 pp., with 247 Illustrations. Demy 4to, cloth *Net 25s.*

"All interested in gas producer practice will find Mr. Latta's volume invaluable, both for reading and reference."—*Mining Journal*.

GAS-ENGINE HANDBOOK.

A Manual of Useful Information for the Designer and the Engineer. By E. W. ROBERTS, M.E. With Forty Full-page Engravings. Small F'cap. 8vo, leather *Net 8s. 6d.*

LONDON: CROSBY LOCKWOOD AND SON
7 STATIONERS' HALL COURT, E.C., AND 121A VICTORIA STREET, S.W.

Important Books for Gas Engineers.

GAS ENGINEER'S POCKET-BOOK.

Comprising Tables, Notes and Memoranda relating to the Manufacture, Distribution, and Use of Coal Gas and the Construction of Gas Works. By H. O'CONNOR, A.M.Inst.C.E. Third Edition, Revised. Crown 8vo, leather *Net 10s. 6d.*

"The book contains a great quantity of specialised information compiled, we believe, from trustworthy sources, which should make the volume of considerable value to those for whom it is specially produced."—*Engineer.*

GAS AND OIL ENGINE MANAGEMENT.

A Practical Guide for Users and Attendants, being Notes on Selection, Construction and Management. By M. POWIS BALE, M.Inst.C.E., M.I.Mech.E., Author of "Woodworking Machinery," etc. Third Edition, enlarged, with an additional Chapter on Gas Producers. Crown 8vo, cloth. *Net 3s. 6d.*

"The book is written in a practical manner for practical men, and contains numerous notes on the construction of the different parts of gas and oil engines."—*Engineer.*

"Mr. Bale being both a user and builder of gas engines, is competent to give good advice on the subject dealt with, and we think it will not be sought in vain in the book under notice."—*Journal of Gas Lighting.*

GAS ENGINES.

With Appendix describing a Recent Engine with Tube Igniter. By T. M. GOODEVE, M.A. Crown 8vo, cloth *2s. 6d.*

CHEMISTRY OF GAS MANUFACTURE.

A Practical Manual for the Use of Gas Engineers, Gas Managers and Students. By HAROLD M. ROYLE, F.C.S., Chief Chemical Assistant at the Beckton Gas Works. Demy 8vo, cloth. 340 pages, with numerous Illustrations and Coloured Plate *Net 12s. 6d.*

"With its many excellent features, the book will deservedly make friends."—*Engineering.*

"Where no separate chemical staff is kept, the volume should prove of the greatest help and utility to the engineer and manager. At the same time students will find it a well-arranged and up-to-date work."—*Engineering Review.*

GAS WORKS.

Their Construction and Arrangement, and the Manufacture and Distribution of Coal Gas. By S. HUGHES, C.E. Ninth Edition. Revised, with Notices of Recent Improvements, by HENRY O'CONNOR, A.M.Inst.C.E. Crown 8vo, cloth *6s.*


LONDON: CROSBY LOCKWOOD AND SON

7 STATIONERS' HALL COURT, E.C., AND 121A VICTORIA STREET, S.W.

Am grüß
500 netx



This book may be kept



89089678353



b89089678353a